


HAND CRIMP TOOL M22520/2-01



This Hand Crimp Tool has been designed for use with the following Datamate crimp sockets (when used with Positioner T5747):

M80-0110001......Large bore crimp socket (22 AWG), Tin shell/Gold clip (used in M80-889XX01 and M80-899XX01)

M80-0110005...... Large bore crimp socket (22 AWG), Gold shell/Gold clip (used in M80-889XX05 and M80-899XX05)

M80-0130001....... Small bore crimp socket (24-28 AWG), Tin shell/Gold clip (used in M80-888XX01 and M80-898XX01)

M80-0130005...... Small bore crimp socket (24-28 AWG), Gold shell/Gold clip (used in M80-888XX05 and M80-898XX05)


The following Datamate Power Crimp Sockets can also be crimped (when used with Positioner Z80-058):

M80-0550001.......Power crimp socket (18-20 AWG), Tin shell/Gold clip (used in M80-716XX01 and M80-719XX01)

M80-0550005....... Power crimp socket (18-20 AWG), Gold shell/Gold clip (used in M80-716XX05 and M80-719XX05)

	HARWIN Inc	HARWIN plc	HARWIN pte
	U.S.A.	U.K.	Singapore
Tel:	812 285 0055	023 9231 4545	65 779 1304
Fax:	812 285 0056	023 9231 4590	65 779 3868
E-Mail:	mis@harwin.com	mis@harwin.co.uk	mis@harwin.com.sg

IS-01 Issue: 2 Date: 06.09.00 C/Note: 5393 Side 1



M22520/2-01

DATAMATE HAND CRIMP TOOL

Y2SEMBLY DRG:

CUSTOMER REF:

:NWA9C

CHECKED:

DRAWING NUMBER:

OE

THS

1. KEIR

UNLESS STATED

 $mm10.0 \pm XXX.X$

 $mm01.0\pm = XX.X$

mm2S.0± = X.X

mmt = .X

TOLERANCES

S/AREA:

HSINIAH:

:JAIA3TAM

VACES = ∓2.

OTHER PURPOSE WITHOUT THEIR WRITTEN PERMISSION.

TENDERING OR FOR ANY

ОВ ИЅЕВ БОВ МАИПЕАСТИВІИС

DISCLOSED, LOANED, COPIED

GROUP AND MUST NOT BE

CONFIDENTIAL AND COPYRIGHT PROPERTY OF THE HARWIN

INFORMATION OR DESCRIPTIVE MATTER SET OUT HEREON ARE

THIS INFORMATION AND ANY

K3607-T6

K3606-06

M80-0550005

1000530-08M

FAX: 65 7793868

TEL: 65 7794909

SINGAPORE

TA NIWAAH

06

The following Power Crimp Sockets can also be crimped (when used with Positioner ZK3609-00):

K3606-06......Power crimp pin (18 AWG), Tin plated K3607-T6.....Power crimp socket (18 AWG), Tin shell/ Tin clip

GENERAL INFORMATION

The Hand crimp tool M22520/2-01 consists of a basic hand tool, which should be used with a positioner.

The contact is correctly crimped when the tool is free to open at the fully closed position, i.e., when the ratchet releases. The tool cannot be opened without completing the cycle.

TOOL PREPARATION

- 1. Check that the tool is in the open position. Remove the safety clip from the positioner guide (do not discard).
- 2. Insert the Positioner into the positioner guide and turn it 90° in the direction shown on the tool, until the bayonet pins lock.
- 3. Install the safety clip back into the positioner guide (optional).
- 4. Check Table 1 for the correct crimp tool setting of the wire size you wish to crimp.
- 5. Remove the safety clip from the selector knob (do not discard).
- 6. Lift and turn the selector knob until the correct crimp tool setting is lined up with the "Sel. No." arrow. Lower the selector knob, ensuring the locating peg lines up with a notch.
- 7. Install the safety clip back into the selector knob.

Side 2

CRIMPING PROCEDURE

1. Ensure that the wire to be crimped is within the specified range of sizes for the contact and the crimp tool. Failure to use the specified wire size will result in poor quality crimps and possible tool damage.

Table 1

Contact	Crimp Type	Wire Gauge (AWG)	Stranding (mm)	Crimp Tool Setting	Minimum pull-off force
M80-01100XX	Large Bore	22	19/0.15	6	50N
		24	7/0.2	6	44N
M80-01300XX	Small Bore	26	19/0.1	6	25N
		28	7/0.125	6	12.5N
M80-05500XX	Power Crimp	20	19/0.2	8	85N
		18	19/0.26	8	140N
KF36XX	Power Crimp	18	Variable	8	142N

2. Cut the end of the cable to be terminated so that there is a clean cut end (Figure A). Strip the cable to the correct length (Figure B) using a PTFE Wire stripper, preferably with adjustable rotating cutter. This should result in all the strands laying together neatly. If the lay of the strands is disturbed, it may be re-imposed with a slight twist.




Figure A Figure B

- 3. Position the crimp socket fully into the positioner, with the crimp barrel uppermost.
- 4. Load the terminated end of the cable into the crimp barrel of the socket. Ensure the wire is fully home, with all strands in place (see Figure C).




Figure C

- 5. Squeeze the handles of the crimp tool fully together, until the ratchet releases. The handle will return to the open position. Remove the crimped socket and wire. Using the sight hole on the side wall of the socket, ensure that adequate insertion of strands into the crimp socket has been achieved.
- 6. Crimp joints should be checked for:
 - a) Correct combination of cable, tool setting and crimp termination.
 - b) Correctness of form and location of crimp.
 - c) Freedom of fracture, rough edges and flash.
 - d) Adequate insertion of all conductor strands in the crimp barrel.
 - e) Absence of damage to the conductor or the insulation.

ASSEMBLY PROCEDURE

M80-XXX piece parts are assembled using the Assembly Tool T5748-19. See Instruction Sheet IS-02 for details on assembly.

K36XX piece parts are assembled using the Assembly Tool ZK3610-00. See Instruction Sheet IS-22 for details on assembly.

CARE OF TOOL

There is virtually no maintenance required for the M22520/2-01 tool. However, it is good practice to keep the indenter tips free of residual colour band deposits and other debris. A small wire brush may be used for this purpose.

We strongly recommend that you:

- 1. **DO NOT** immerse tools in any cleaning solution.
- 2. **DO NOT** spray oil into tool to lubricate.
- 3. **DO NOT** attempt to disassemble tool or make repairs.

This is a precision crimp tool and should be handled as such.

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for harwin manufacturer:

Other Similar products are found below:

M20-1160046 G125-MC12005L4-0150M M80-4711005 M80-4801642 M80-5711005 M80-5T10405M1-02-331-00-000 M80-9403405

Z1023-00 G125-MH15005L7P M80-8412042 M80-8662622 M80-5400622 M22520-02-01 M20-9760742 Z80-292 Z30-021 DEV-001

M20-9752046 M80-4801605 Z50-020 G125-MS12605M2P G125-FV12005F1P G125-9641600 M80-4D10605F2-02-327-00-000 G125-FC11005F0-0450L G125-FC11005F1-0150F1 M80-4051605 M80-FC325F1-04-0300L M80-5T10622MC M80-5T10805M2-02-331-00-000

M80-FC23468FC-0150L M80C150968C M22-6013005 M50-3111042 M80-4122042 M80-4123442 M80-5000000M3-10-332-00-000 M80-9400605 M80-9424205 M80-MV311M2-06 H2039-01 M20-9970845 M80-4201442 Z80-300 Z1022-00 M83-LFT1F2N27-0000-000 M83-LFT1F2N36-0000-000 M80-8771722 M80-8871001 M22520/2-01