

### Model Number

NJ5-18GM-N

#### Features

- · Comfort series
- 5 mm flush
- Usable up to SIL 2 acc. to IEC 61508

### Accessories


BF 18 Mounting flange, 18 mm EXG-18 Quick mounting bracket with dead stop

Technical Data		
General specifications		
Switching element function		NAMUR, NC
Rated operating distance	s <sub>n</sub>	5 mm
Installation		flush
Output polarity		NAMUR
Assured operating distance	Sa	0 4.05 mm
Reduction factor r <sub>Al</sub>		0.21
Reduction factor r <sub>Cu</sub>		0.18
Reduction factor r <sub>304</sub>		0.63
Nominal ratings		
Nominal voltage	Uo	8.2 V (R <sub>i</sub> approx. 1 kΩ)
Operating voltage	UB	5 25 V
Switching frequency	f	0 500 Hz
Hysteresis	н	3 %
Current consumption		
Measuring plate not detected		≥ 3 mA
Measuring plate detected		≤ 1 mA
Functional safety related parameter	ers	
MTTF <sub>d</sub>		14110 a
Mission Time (T <sub>M</sub> )		20 a
Diagnostic Coverage (DC)		0 %
Ambient conditions		
Ambient temperature		-25 100 °C (-13 212 °F)
Mechanical specifications		
Connection type		cable PVC , 2 m
Core cross-section		0.75 mm <sup>2</sup>
Housing material		Stainless steel 1.4305 / AISI 303
Sensing face		PBT
Degree of protection		IP67
Cable		
Bending radius		> 10 x cable diameter
General information		
Use in the hazardous area		see instruction manuals
Category		1G; 2G; 1D
Compliance with standards and di	rectives	3
Standard conformity		
NAMUR		EN 60947-5-6:2000
		IEC 60947-5-6:1999
Standards		EN 60947-5-2:2007 IEC 60947-5-2:2007
Approvals and certificates		
FM approval		110.0105
Control drawing		116-0165

# CCC approval

UL approval

CSA approval



cULus Listed, General Purpose

cCSAus Listed, General Purpose

CCC approval / marking not required for products rated ≤36 V


Refer to "General Notes Relating to Pepperl+Fuchs Product Information".

Pepperl+Fuchs Group www.pepperl-fuchs.com USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



1

### **Electrical Connection**



Refer to "General Notes Relating to Pepperl+Fuchs Product Information".

Pepperl+Fuchs Group USA: +1 330 www.pepperl-fuchs.com fa-info@us.pepp

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Equipment protection level Ga	Manual electrical apparatus for hazardous areas
Device category 1G	for use in hazardous areas with gas, vapour and mist
EC-Type Examination Certificate	PTB 00 ATEX 2048 X
CE marking	€0102
ATEX marking	↔ II 1G Ex ia IIC T6T1 Ga The Ex-related marking can also be printed on the enclosed label.
Directive conformity	94/9/EG
Standards	EN 60079-0:2012+A11:2013 EN 60079-11:2012 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions
Appropriate type	NJ 5-18GM-N
Effective internal inductivity C <sub>i</sub>	$\leq$ 70 nF ; a cable length of 10 m is considered.
Effective internal inductance L <sub>i</sub>	$\leq$ 50 $\mu H$ ; a cable length of 10 m is considered.
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to! Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority. If the equipment is not used under atmospheric conditions, a reduction of the permis- sible minimum ignition energies may have to be taken into consideration.
Ambient temperature	Details of the correlation between the type of circuit connected, the maximum per- missible ambient temperature, the temperature class, and the effective internal reac- tance values can be found on the EC-type examination certificate. <u>Note</u> : Use the temperature table for category 1 !!! The 20 % reduction in accordance with EN 1127- 1 has already been applied to the temperature table for category 1.
Installation, commissioning	Laws and/or regulations and standards governing the use or intended usage goal
	must be observed. The intrinsic safety is only assured in connection with an appropriate related appara- tus and according to the proof of intrinsic safety. The associated apparatus must satisfy the requirements of category ia. Due to the possible danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation of the power supply and signal circuit is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met. If the Ex- related marking is printed only on the supplied label, then this must be attached in the immediate vicinity of the sensor. The sticking surface for the label must be clean and free from grease. The attached label must be legible and indelible, including in the event of possible chemical corrosion.
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.
Special conditions	The connecting parts of the sensor must be set up in such a way that degree of pro- tection IP20, in accordance with IEC 60529, is achieved as a minimum.
Protection from mechanical danger	When using the device in a temperature range of -60 °C to -20 °C, protect the sensor against the effects of impact by installing an additional enclosure. The information regarding the minimum ambient temperature for the sensor as provided in the datasheet must also be observed.
Electrostatic charge	Electrostatic charges on the metal housing components must be avoided. Danger- ous electrostatic charges on the metal housing components can be avoided by incor- porating these components in the equipotential bonding.

Refer to "General Notes Relating to Pepperl+Fuchs Product Information".

Pepperl+Fuchs Group www.pepperl-fuchs.com USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Equipment protection level Gb	
Instruction	Manual electrical apparatus for hazardous areas
Device category 2G	for use in hazardous areas with gas, vapour and mist
EC-Type Examination Certificate	PTB 00 ATEX 2048 X
CE marking	<b>C €</b> 0102
ATEX marking	II 1G Ex ia IIC T6T1 Ga The Ex-related marking can also be printed on the enclosed label.
Directive conformity	94/9/EG
Standards	EN 60079-0:2012+A11:2013 EN 60079-11:2012 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions
Appropriate type	NJ 5-18GM-N
Effective internal inductivity C <sub>i</sub>	$\leq$ 70 nF ; a cable length of 10 m is considered.
Effective internal inductance L <sub>i</sub>	$\leq$ 50 $\mu H$ ; a cable length of 10 m is considered.
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to! Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority. If the equipment is not used under atmospheric conditions, a reduction of the permis- sible minimum ignition energies may have to be taken into consideration.
Maximum permissible ambient temperature $T_{amb}$	Details of the correlation between the type of circuit connected, the maximum per- missible ambient temperature, the temperature class, and the effective internal reac- tance values can be found on the EC-type examination certificate.
Installation, commissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appro- priate related apparatus and according to the proof of intrinsic safety. If the Ex-related marking is printed only on the supplied label, then this must be attached in the immediate vicinity of the sensor. The sticking surface for the label must be clean and free from grease. The attached label must be legible and indeli- ble, including in the event of possible chemical corrosion.
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.
Special conditions	The connecting parts of the sensor must be set up in such a way that degree of pro- tection IP20, in accordance with IEC 60529, is achieved as a minimum.
Protection from mechanical danger	When using the device in a temperature range of -60 °C to -20 °C, protect the sensor against the effects of impact by installing an additional enclosure. The information regarding the minimum ambient temperature for the sensor as provided in the datasheet must also be observed.
Electrostatic charge	Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com



Equipment protection level Da		
Instruction		Manual electrical apparatus for hazardous areas
Device category 1D		for use in hazardous areas with combustible dust
EC-Type Examination Certificate		PTB 00 ATEX 2048 X
CE marking		<b>C €</b> 0102
ATEX marking		$\bigotimes$ II 1D Ex ia IIIC T135°C Da The Ex-related marking can also be printed on the enclosed label.
Directive conformity		94/9/EG
Standards		EN 60079-0:2012+A11:2013 EN 60079-11:2012 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions
Appropriate type		NJ 5-18GM-N
Effective internal inductivity	Ci	$\leq$ 70 nF ; a cable length of 10 m is considered.
Effective internal inductance	Li	$\leq$ 50 $\mu H$ ; a cable length of 10 m is considered.
General		The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority. If the equipment is not used under atmospheric conditions, a reduction of the permis- sible minimum ignition energies may have to be taken into consideration.
Maximum permissible ambient te	mperature T <sub>amb</sub>	Details of the correlation between the type of circuit connected, the maximum per- missible ambient temperature, the surface temperature, and the effective internal reactance values can be found on the EC-type-examination certificate. The maximum permissible ambient temperature of the data sheet must be noted, in addition, the lower of the two values must be maintained.
Installation, commissioning		Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety. If the Ex-related marking is printed only on the supplied label, then this must be attached in the immediate vicinity of the sensor. The sticking surface for the label must be clean and free from grease. The attached label must be legible and indelible, including in the event of possible chemical corrosion.
Maintenance		No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.
Special conditions		The connecting parts of the sensor must be set up in such a way that degree of pro- tection IP20, in accordance with IEC 60529, is achieved as a minimum.
Protection from mechanical day	nger	When using the device in a temperature range of -60 °C to -20 °C, protect the sensor against the effects of impact by installing an additional enclosure. The information regarding the minimum ambient temperature for the sensor as provided in the datasheet must also be observed.
Electrostatic charge		Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

Do not attach the nameplate provided in areas where electrostatic charge can build up.

Refer to "General Notes Relating to Pepperl+Fuchs Product Information".

Pepperl+Fuchs Group www.pepperl-fuchs.com Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



## **X-ON Electronics**

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Pepperl & Fuchs manufacturer:

Other Similar products are found below :

 RL31-54/73C/136
 3RG7122-0AA00
 NBB-12GM40-E1
 3RG4013-3KB00
 3RG7134-3AA00
 LD31/LV31/25/73C/76A/136

 NBB4-12GM50-A2-V1
 RL31-8-1200-RT/73C/136
 CBB8-18GS75-E2
 45018
 UC2000-30GM-E6R2-V15
 6GR6221-3AB00
 REF-MH50

 3RG4148-3CD00
 INX360D-F99-I2E2-V15
 MPS11HD
 UB2000-F42-U-V15
 50FY416
 NBN4-12GM50-E0
 UC2000-30GM-IUR2-V15

 41FR2
 3RG6233-3JS00
 NBN8-12GM50-E2-V1
 UC-30GM-R2
 M100/MV100-RT/35/76A/95/103
 3RG4013-0KB00
 UB400-F77-E2-V31

 3RG4023-3AG33
 MD17/73
 NBB5-18GM50-E2
 NBN4-12GM50-E2
 UB800-18GM40-U-V1
 UB800-18GM40-I-V1
 ML100-55/95/103

 KCD2-R
 NBB15-30GM50-E2-V1
 UB2000-F42-E5-V15
 REF-C110-2
 ML100-8-1000-RT/95/103
 3RG4200-1AB00
 NBB2-V3-E2

 3RG7120-3AA00
 OB-150-F6-E5
 REF-H50
 UB800-18GM40-E5-V1
 MV17/73/136
 NBB4-12GM50-E2-V1
 3RG6343-3AB00
 NJ2-PD-US-2.062-V93