LINEAR TECHNOLOGY

DEMO CIRCUIT 1672A QUICK START GUIDE

HIGH EFFICIENCY SINGLE PHASE BUCK CONVERTER FOR INTEL IMVP-6/IMVP-6.5 CPUs

DESCRIPTION

Demonstration circuit 1672A is a high efficiency, single phase, synchronous buck converter for Intel IMVP-6/IMVP-6.5 CPUs. It can supply 25A maximum load current at up to 1.5V output with 4.5V to 28V input range. The demo board features the LTC®3816EUHF controller. The LTC3816 is a single-phase synchronous buck controller in a constant-frequency voltage mode architecture. The controller's leading edge modulation topology allows extremely low output voltages and supports a phaselockable switching frequency up to 550kHz. The output voltage is programmed using a 7-bit VID code. The default VID jumpers (VID6 to VID0) are set to be 0110000 for 0.9V output. The LTC3816 features all of the IMVP-6/IMVP-6.5 requirements, including start-up to a preset boot voltage, differential remote output voltage sensing with programmable active voltage positioning, Imon output current reporting, power optimization during sleep state, and slow slew rate sleep state exit. Fault protection features include input undervoltage lockout, cycle-bycycle current limit, output overvoltage protection, and power-good (PWRGD) and overtemperature flags. The LTC3816 supports wide input range (4.5V to 36V) with optional line feedforward compensation, temperature compensated inductor DCR or sense resistor output current monitoring. The LTC3816 can provide high efficiency, high power density and

versatile power solutions for embedded computing, mobile computers, internet devices and navigation displays. The controller is available in 38-pin thermally enhanced eTSSOP and 5mm \times 7mm QFN packages.

The VRON pin (JP15) provides enable feature. To shut down the converter, one simple way is to force the VRON pin below 0.65V (JP15: OFF). Use JP19 jumper to select pulse-skipping or forced continuous mode operation. Switching frequency is pre-set at about 400KHz, and it can be easily modified from 150KHz to 550KHz. JP20~JP26 (VID0~VID7) are used to set the output voltage based on the IMVP-6/IMVP-6.5 VID code, as shown in table 2. JP1 and JP18 are used to select either IMVP6 or IMVP6.5 specification. For detailed information, please see LTC3816 data sheet and Intel IMVP-6/IMVP-6.5 specification.

Design files for this circuit board are available. Call the LTC factory.

PARAMETER	CONDITION	VALUE							
Input Voltage Range		4.5V to 28V							
Output Voltage, V _{OUT}	V _{IN} = 4.5-28V, I _{OUT} = 0A to 23A, VID6-0=0110000	0.9V ±1.5%							
Maximum Output Current, I _{OUT}	V _{IN} = 4.5-28V, V _{OUTMAX} = 1.5V	25A							
Typical Efficiency	V _{IN} = 12V, V _{OUT} = 1.5V, I _{OUT} = 23A	86.7%							
Typical Switching Frequency		400kHz							

Table 1.Performance Summary ($T_A = 25^{\circ}C$)



Table 2. IMVP-6/IMVP-6.5 VID Output Voltage Programming

VID6	VID5	VID4	VID3	VID2	VID1	VIDO	V _{CC(COBE)}	VID6	VID5	VID4	VID3	VID2	VID1	VIDO	V _{CC(CORE)}
0	0	0	0	0	0	0	1.5000	1	0	0	0	0	0	0	0.7000
0	0	0	0	0	0	1	1.4875	1	0	0	0	0	0	1	0.6875
0	0	0	0	0	1	0	1.4750	1	0	0	0	0	1	0	0.6750
0	0	0	0	0	1	1	1.4625	1	0	0	0	0	1	1	0.6625
0	0	0	0	1	0	0	1.4500	1	0	0	0	1	0	0	0.6500
0	0	0	0	1	0	1	1.4375		0	0	0	1	0	1	0.6375
0	0	0	0	1	1	0	1.4250	1	0	0	0	1	1	0	0.6250
0	0	0	0	1	1	1	1.4125		0	0	0	1	1	1	0.6125
0	0	0	1	0	0	0	1.4000		0	0	1	0	0	0	0.6000
0	0	0	1	0	0	1	1.38/5		0	0	1	0	0		0.58/5
		8		<u> </u>		1	1.3730		8	8		8	4	4	0.5750
- <u>ñ</u>	ň	ň	4	1	6	6	1 3500		ň	ň		1	6	6	0.5625
0	0	0	1	1	0	1	1 3375		ő	ő	1	1	0	1	0.5375
ő	ŏ	ő	1	1	1	Ó	1.3250	- 	ŏ	ŏ	1	1	1	ó	0.5250
ŏ	ŏ	ŏ	1	1	1	Ť	1.3125		ŏ	ŏ	1	1	1	ĭ	0.5125
ŏ	ŏ	Ť	Ó	Ó	Ó	Ó	1.3000		ŏ	Ĭ	Ó	Ó	Ó	Ó	0.5000
Õ	Õ	1	Ö	Ö	Ō	1	1.2875	1	Ö	1	Ö	Ö	Ö	1	0.4875
0	0	1	0	0	1	0	1.2750	1	0	1	0	0	1	0	0.4750
0	0	1	0	0	1	1	1.2625	1	0	1	0	0	1	1	0.4625
0	0	1	0	1	0	0	1.2500	1	0	1	0	1	0	0	0.4500
0	0	1	0	1	0	1	1.2375	1	0	1	0	1	0	1	0.4375
0	0	1	0	1	1	0	1.2250		0	1	0	1	1	0	0.4250
0	0	1	0	1	1	1	1.2125	1	0	1	0	1	1	1	0.4125
0	0	1	1	0	0	0	1.2000		0	1	1	0	0	0	0.4000
0	0	1	1	<u> </u>	0	1	1.18/5		0	1	1	0	<u> </u>	1	0.38/5
0	0	1	1	0	1	0	1.1/50		0	1	1	0	1	U 4	0.3750
0		4	4	4			1.1020	-	0	4		4			0.3020
0	0	4	4	4	0	1	1 1 2 7 5		0	4	4	4	0	1	0.3300
ŏ	ŏ	-	1		1	ó	1 1250		ŏ	-			Ť	- i	0.3250
ŏ	ŏ	1	i	- i	i	Ť	1.1125		ŏ	l i	l i	l i	1 i	Ť	0.3125
õ	1	Ö	Ö	Ó	Ö	Ó	1.1000	1	1	Ó	Ó	Ö	Ó	Ó	0.3000
ŏ	1	ŏ	ŏ	ŏ	Ŏ	Ĩ	1.0875	1	1	ŏ	ŏ	ŏ	ŏ	Ĩ	0.2875
Ō	1	Ō	Ō	Ō	1	Ó	1.0750	1	1	Ō	Ō	Ō	1	Ó	0.2750
0	1	0	0	0	1	1	1.0625	1	1	0	0	0	1	1	0.2625
0	1	0	0	1	0	0	1.0500	1	1	0	0	1	0	0	0.2500
0	1	0	0	1	0	1	1.0375	1	1	0	0	1	0	1	0.2375
0	1	0	0	1	1	0	1.0250		1	0	0	1	1	0	0.2250
0	1	0	0	1	1	1	1.0125		1	0	0	1	1	1	0.2125
0	1	0	1	0	0	0	1.0000		1	0	1	0	0	0	0.2000
0	1	0	1	0	0	1	0.98/5		1	0	1	0	0	1	0.18/5
- 6	-	0	-	- 6		1	0.9750		-	8		8	-	4	0.1730
- 6	-	ň	4	1	6	-	0.9025		4	Ň		1	6		0.1025
0	1	0	1	1	0	1	0.9375	1	1	ő	1	1	0	1	0.1375
ő	1	ő	1	1	1	Ó	0.9250	1	1	ő	1	1	1	Ó	0.1250
ŏ	1	ŏ	1	1	1	Ť	0.9125	1	1	ŏ	1	1	1	Ť	0.1125
Õ	1	1	Ó	Ó	Ó	Ó	0.9000	1	1	1	Ó	Ó	Ó	Ó	0.1000
Ó	1	1	Ő	Ő	Ő	1	0.8875	1	1	1	0	Ő	Ő	1	0.0875
0	1	1	0	0	1	0	0.8750	1	1	1	0	0	1	0	0.0750
0	1	1	0	0	1	1	0.8625	1	1	1	0	0	1	1	0.0625
0	1	1	0	1	0	0	0.8500	1	1	1	0	1	0	0	0.0500
0	1	1	0	1	0	1	0.8375	1	1	1	0	1	0	1	0.0375
0	1	1	0	1	1	0	0.8250		1	1	0	1	1	0	0.0250
0	1	1	U	1	1	1	0.8125	1	1	1	0	1	1	1	0.0125
0				0	0	0	0.8000					0	0	U	0.0000
0	4			0	0	1	0.78/0		4	1	4	0	0	1	0.0000
0	4	4	4	0	1	1	0.7625		1	1	1	0	1	1	0.0000
0	1	1	1	1	0	0	0.7520	1	1	1	1	1	0		0.0000
0	1	1	1	1	0	1	0.7375	1	1	1	1	1	0	1	0.0000
ŏ	1	1	1	1	Ť	ó	0.7250	1	1	1	1	1	Ť	ó	0.0000
Ő	1	1	1	1	1	1	0.7125	1	1	1	1	1	1	1	0.0000



QUICK START PROCEDURE

Demonstration circuit 1672A is easy to set up to evaluate the performance of the LTC3816EUHF. Refer to Figure 1 for the proper measurement equipment setup and jumpers' location, and follow the procedure below:

- **1.** With power off, connect the input power supply to Vin (4.5V-28V) and GND (input return).
- 2. Set VID jumpers VID6-0: 0110000 for 0.9V ouput.
- **3.** Connect the output load between Vout and GND (Initial load: no load).
- 4. Connect the DVMs to the input and outputs.
- **5.** Turn on the input power supply and check for the proper output voltages. Vout should be within 0.885 V to 0.915V.
- **6.** Once the proper output voltages are established, adjust the loads within the operating range and observe the output voltage regulation, ripple voltage and other parameters.

Note: When measuring the output or input voltage ripple, do not use the long ground lead on the oscilloscope probe. See Figure 2 for the proper scope probe technique. Short, stiff leads need to be soldered to the (+) and (-) terminals of an output capacitor. The probe's ground ring needs to touch the (-) lead and the probe tip needs to touch the (+) lead.





Figure 1. Proper Measurement Equipment Setup



Figure 2. Measuring Output Voltage Ripple





Figure 3. Efficiency vs load current

































X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Power Management IC Development Tools category:

Click to view products by Analog Devices manufacturer:

Other Similar products are found below :

EVAL-ADM1168LQEBZ EVB-EP5348UI MIC23451-AAAYFLEV MIC5281YMMEEV DA9063-EVAL ADP122-3.3-EVALZ ADP130-0.8-EVALZ ADP130-1.2-EVALZ ADP130-1.5-EVALZ ADP130-1.8-EVALZ ADP1714-3.3-EVALZ ADP1716-2.5-EVALZ ADP1740-1.5-EVALZ ADP1752-1.5-EVALZ ADP1828LC-EVALZ ADP1870-0.3-EVALZ ADP1871-0.6-EVALZ ADP1873-0.6-EVALZ ADP1874-0.3-EVALZ ADP1882-1.0-EVALZ ADP199CB-EVALZ ADP2102-1.25-EVALZ ADP2102-1.875EVALZ ADP2102-1.8-EVALZ ADP2102-2-EVALZ ADP1882-1.0-EVALZ ADP199CB-EVALZ ADP2102-1.25-EVALZ ADP2102-1.875EVALZ ADP2102-1.8-EVALZ ADP2102-2-EVALZ ADP2102-3-EVALZ ADP2102-4-EVALZ ADP2106-1.8-EVALZ ADP2147CB-110EVALZ AS3606-DB BQ24010EVM BQ24075TEVM BQ24155EVM BQ24157EVM-697 BQ24160EVM-742 BQ24296MEVM-655 BQ25010EVM BQ3055EVM NCV891330PD50GEVB ISLUSBI2CKIT1Z LM2744EVAL LM2854EVAL LM3658SD-AEV/NOPB LM3658SDEV/NOPB LM3691TL-1.8EV/NOPB LM4510SDEV/NOPB LM5033SD-EVAL LP38512TS-1.8EV EVAL-ADM1186-1MBZ EVAL-ADM1186-2MBZ