Daniels Manufacturing Corporation offers complete refurbishing and recalibration services.

DMC specially engineers and manufactures complete tool kits to satisfy individual customer requirements, such as total aircraft support, general shop maintenance or production, on board ship and vehicle service, etc.

LIMITATION OF LIABILITY

DANIELS MANUFACTURING CORPORATION IS NOT LIABLE FOR CONSEQUENTIAL OR SPECIAL DAMAGES OF ANY NATURE OR KIND RESULTING FROM THE USE, OR MISUSE, OF ANY OF ITS PRODUCTS. OWNERS AND USERS OF DMC PRODUCTS ASSUME FULL RESPONSIBILITY FOR INSTRUCTING THEIR EMPLOYEES IN THE PROPER AND SAFE USE OF SUCH PRODUCTS.

LIMITED WARRANTY

DMC (Daniels Manufacturing Corporation) warronts each new product sold by it to be free from defects in material and workmanship under normal DMC's obligation under this warranty is limited to the free correction or, at DMC's option, the refund of the purchase price of any such product which proves defective in normal service within ninety (90) days after delivery to the first user, provided that the product is returned to DMC with oil transportation charges prepaid and which shall oppeor to DMC's satisfaction, ofter DMC's inspection, to have been defective in material or workmanship, it being understood that DMC products ore not consumer products. This warranty shall not cover any damage to any product which, in the opinion of DMC, was caused by normal wear, misuse, improper operation, tampering, neglect or accident. This warranty is in lieu of all other warranties express or implied. No warranty, express or implied, is made or authorized to be made or assumed with respect to products of Daniels Manufacturing Corporation other than those herein set forth.

86-37 UNIVERSAL POSITIONER

DATASHEET

LIMITED WARRANTY, AND LIMITATION OF LIABILITY.

JAM NUT

POSITIONER BODY

BAYONET PIN

ADJUSTMENT

SCREW

SEE REVERSE SIDE FOR IMPORTANT INFORMATION CONCERNING

SPRING

LOCATOR

86-37 POSITIONER

SLOTS

SELECTOR KNOB



WIRE BARREL

CRIMP TOOL

INSULATION

INSPECTION

HOLF -

CONTACTS


The 86-37 Universal Positioner is used with the MH860 crimp tools to locate contacts horizontally and vertically between the indenters of the tools.

INSTRUCTIONS

CAUTION: Before installing or removing the positioner from the crimp tool, be sure the adjustment screw is at least one complete turn outward from the inner limit of adjustment (turn the adjustment screw counterclockwise for at least one full rotation).

- 1. Align the bayonet pins of the positioner with the slots in the crimp tool. Insert and push positioner against the spring, then rotate the positioner 90° so that the bayonet pins fall into the internal slots
- of the tool. The positioner is now secured to the tool frame.
- 2. Raise and rotate the selector knob to the desired setting,
- 3. Screw the jam nut away from the positioner body and turn the adjustment screw clockwise to its highest setting.
- 4. Insert the contact to be crimped, into the locator. The contact should now be sitting too high into the tool. Turn the adjustment screw counterclockwise to move the contact lower into the crimp tool, until the indenters of the tool are estimated to be centered between the inspection hole and the top of the wire barrel. If the contact is designed with an insulation cup, adjust the vertical location of the contact so that the indenters are centered between the inspection hole and the bottom of the insulation cup.
- 5. When the ideal positioner adjustment is achieved for the contact, tighten the jam nut against the positioner body in order to lock the adjustment screw in place. The tool and positioner assembly is now ready for crimping the designated

DANIELS MANUFACTURING CORP., 526 THORPE ROAD, ORLANDO, FL 32824, USA, PHONE 407/855-6161, FAX 407/855-6884 COPYRIGHT © 2002 DANIELS MANUFACTURING CORP., USA. WWW.DMCTOOLS.COM E-MAIL: DMC@DMCTOOLS.COM ALL RIGHTS RESERVED.



LIMITED WARRANTY, AND LIMITATION OF LIABILITY.

JAM NUT

POSITIONER BODY

ADJUSTMENT

SCREW

SEE REVERSE SIDE FOR IMPORTANT INFORMATION CONCERNING

SPRING

LOCATOR

86-37 POSITIONER

SLOTS

SELECTOR KNOB

INSULAT ION

CUP **INSPECTION**

HOLE

CONTACTS

TOP OF

WIRE BARREL

CRIMP TOOL

The 86-37 Universal Positioner is used with the MH860 crimp tools to locate contacts horizontally and vertically between the indenters of the tools.

INSTRUCTIONS

CAUTION: Before installing or removing the positioner from the crimp tool, be sure the adjustment screw is at least one complete turn outward from the inner limit of adjustment (turn the adjustment screw counterclockwise for at least one full rotation).

- 1. Align the bayonet pins of the positioner with the slots in the crimp tool. Insert and push positioner against the spring, then rotate the positioner 90° so that the bayonet pins fall into the internal slots
- of the tool. The positioner is now secured to the tool frame. 2. Raise and rotate the selector knob to the desired setting.
- 3. Screw the jam nut away from the positioner body and turn the adjustment screw clockwise to its highest setting.

BAYONET PIN

- 4. Insert the contact to be crimped, into the locator. The contact should now be sitting too high into the tool. Turn the adjustment screw counterclockwise to move the contact lower into the crimp tool, until the indenters of the tool are estimated to be centered between the inspection hole and the top of the wire barrel. If the contact is designed with an insulation cup, adjust the vertical location of the contact so that the indenters are centered between the inspection hole and the bottom of the insulation cup.
- 5. When the ideal positioner adjustment is achieved for the contact, tighten the jam nut against the positioner body in order to lock the adjustment screw in place. The tool and positioner assembly is now ready for crimping the designated

DANIELS MANUFACTURING CORP., \$26 THORPE ROAD, ORLANDO, FL 32824, USA, PHONE 407/855-6161, FAX 407/855-6884 ALL RIGHTS RESERVED.

COPYRIGHT © 2002 DANIELS MANUFACTURING CORP., USA. WWW.DMCTOOLS.COM E-MAIL: DMC@DMCTOOLS.COM

2/02

REV. B

86-37-DS

Daniels Manufacturing Corporation offers complete refurbishing and recalibration services.

DMC specially engineers and manufactures complete tool kits to satisfy individual customer requirements, such as total aircraft support, general shop maintenance or production, on board ship and vehicle service, etc.

LIMITATION OF LIABILITY

DANIELS MANUFACTURING CORPORATION IS NOT LIABLE FOR CONSEQUENTIAL OR SPECIAL DAMAGES OF ANY NATURE OR KIND RESULTING FROM THE USE, OR MISUSE, OF ANY OF ITS PRODUCTS. OWNERS AND USERS OF DMC PRODUCTS ASSUME FULL RESPONSIBILITY FOR INSTRUCTING THEIR EMPLOYEES IN THE PROPER AND SAFE USE OF SUCH PRODUCTS.

LIMITED WARRANTY

DMC (Daniels Manufacturing Corporation) warrants each new product sold by it to be free from defects in material and workmanship under normal use and service. DMC's obligation under this warranty is limited to the free correction or, at DMC's option, the refund of the purchase price of any such product which proves defective in normal service within ninety (90) days after delivery to the first user, provided that the product is returned to DMC with all transportation charges prepaid and which shall appear to DMC's satisfaction, ofter DMC's inspection, to have been defective in material or workmanship, it being understood that DMC products ore not consumer products. This warranty shall not cover any damage to any product which, in the opinion of DMC, was caused by normal wear, misuse, improper operation, tampering, neglect or accident. This warranty is in lieu of all other warranties express or implied. No warranty, express or implied, is made or authorized to be mode or assumed with respect to products of Daniels Manufacturing Corporation other than those herein set forth.

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Crimpers / Crimping Tools category:

Click to view products by DMC manufacturer:

Other Similar products are found below:

010-0096 M225201-06 M225202-37 6-1579015-5 CT150-6-RH07 622-6441LF M322 6-304052-1 63456-0054 63484-3701 63800-8355 63819-1875 63819-2875 63819-4475 63827-5375 64001-0975 64001-4175 64005-0175 662903-2 690602-6 7-1579001-9 7-23471-1 762637-1 808714-1 811242-5 999-50-020083 1-21002-3 1-21002-7 12085270 1-21002-6 1-21113-6 1-22548-4 125442-1 DCE.91.073.BVC DCE.91.090.3MVM DCE.91.130.5MVU DCE.91.202.BVCM 1338300-1 1-354003-0 1338301-1 DF62/RE-MD 142321 1456088-1 1490794-1 1-45804-6 1490357-2 1490357-3 AX100749 1-59619-7 1596970-1