


PART NO.	CODE NO.		MBER OF DIMENSION OF CONNECTOR, PCB MOUNTING PATTERN, STENCIL PATTERN AND FFC/FPC								DIMENSION OF DRAWING FOR PACKING						
		CONTACT	Α	B	C	D	E	F	G	<u> </u>	J	K	L	M	N	Р	Q
FH52K-6S-0.5SH(99)	CL580-4613-0-99	6	7.3	2.5	3.57	5.55	8.1	5.1	5.1	3.5	7.6	8.6	11.5	24.0		29.4	25
FH52K-8S-0.5SH(99)	CL580-4611-0-99	8	8.3	3.5	4.57	6.55	9.1	6.1	6.1	4.5	8.6	9.6	11.5	24.0		29.4	25
FH52K-10S-0.5SH(99)	CL580-4606-0-99	10	9.3	4.5	5.57	7.55	10.1	7.1	7.1	5.5	9.6	10.6	11.5	24.0		29.4	25
FH52K-12S-0.5SH(99)	CL580-4629-0-99	12	10.3	5.5	6.57	8.55	11.1	8.1	8.1	6.5	10.6	11.6	11.5	24.0		29.4	25.
FH52K-15S-0.5SH(99)	CL580-4617-0-99	15	11.8	7.0	8.07	10.05	12.6	9.6	9.6	8.0	12.1	13.1	11.5	24.0		29.4	25.
FH52K-18S-0.5SH(99)	CL580-4636-0-99	18	13.3	8.5	9.57	11.55	14.1	11.1	11.1	9.5	13.6	14.6	11.5	24.0		29.4	25.
FH52K-20S-0.5SH(99)	CL580-4604-0-99	20	14.3	9.5	10.57	12.55	15.1	12.1	12.1	10.5	14.6	15.6	11.5	24.0		29.4	25.
FH52K-22S-0.5SH(99)	CL580-4632-0-99	22	15.3	10.5	11.57	13.55	16.1	13.1	13.1	11.5	15.6	16.6	14.2	32.0	28.4	37.4	33.
FH52K-24S-0.5SH(99)	CL580-4633-0-99	24	6.3	11.5	12.57	14.55	17.1	14.1	14.1	12.5	16.6	17.6	14.2	32.0	28.4	37.4	33.
FH52K-25S-0.5SH(99)	CL580-4634-0-99	25	16.8	12.0	13.07	15.05	17.6	14.6	14.6	13.0	17.1	18.1	14.2	32.0	28.4	37.4	33.
FH52K-26S-0.5SH(99)	CL580-4635-0-99	26	17.3	12.5	13.57	15.55	18.1	15.1	15.1	13.5	17.6	18.6	14.2	32.0	28.4	37.4	33.
FH52K-30S-0.5SH(99)	CL580-4631-0-99	30	19.3	14,5	15.57	17.55	20.1	17.1	17.1	15.5	19.6	20.6	20.2	44.0	40.4	49.4	45.
FH52K-32S-0.5SH(99)	CL580-4600-9-99	32	20.3	15.5	16.57	18.55	21.1	18.1	18.1	16.5	20.6	21.6	20.2	44.0	40.4	49.4	45.
FH52K-34S-0.5SH(99)	CL580-4601-0-99	34	21.3	16.5	17.57	19.55	22.1	19.1	19.1	17.5	21.6	22.6	20.2	44.0	40.4	49.4	45.
FH52K-40S-0.5SH(99)	CL580-4620-0-99	40	24.3	19.5	20.57	22.55	25.1	22.1	22.1	20.5	24.6	25.6	20.2	44.0	40.4	49.4	45.
FH52K-45S-0.5SH(99)	CL580-4637-0-99	45	26.8	22.0	23.07	25.05	27.6	24.6	24.6	23.0	27.1	28.1	20.2	44.0	40.4	49.4	45.
FH52K-50S-0.5SH(99)	CL580-4609-0-99	50	29.3	24.5	25.57	27.55	30.1	27.1	27.1	25.5	29.6	30.6	20.2	44.0	40.4	49.4	45.
FH52K-60S-0.5SH(99)	CL580-4607-0-99	60	34.3	29.5	30.57	32.55	35.1	32.1	32.1	30.5	34.6	35.6	26.2	56.0	52.4	61.4	57.
FH52K-64S-0.5SH(99)		64	36.3	31.5	32.57	34.55	37.1	34.1	34.1	32.5	36.6	37.6	26.2	56.0	52.4	61.4	57.
FH52K-68S-0.5SH(99)	CL580-4614-0-99	68	38.3	33.5	34.57	36.55	39.1	36.1	36.1	34.5	38.6	39.6	26.2	56.0	52.4	61.4	57.
‰CONTACT POSI PLEASE CONTA	TIONS WITHOUT CT HIROSE FOR	CODE DETAI	NUMBE LED	ERS AR INFORM	E CUR IATION	RENTL' ABOU	Y UNDE T PROD	R PLA UCT V	NNING.	10N. VC							

PART NO.
CODE NO. EDC-365730-99-00 FH52K-**S-0.5SH(99) CL580

FORM HC0011-5-8 1



FORM HC0011-5-8

3. How to insert FPC/FFC 4. FPC/FFC insertion check This connector has contact point on the bottom, insert the FPC/FFC with the exposed conductors face down. Guide for positioning FPC/FFC guide the FPC/FFC tabs to the correct position. This connector has Guide for positioning FPC/FFC, insert the FPC/FFC at about 10 degree angle Make sure that the FPC/FFC tabs are located in correct position to the PCB mounting surface. (example 10) as shown in the figure below after FPC/FFC insertion (example 14) In case of using FPC/FFC without tabs, insert the FPC/FFC horizontally along the surface. [Caution] -Do not insert the FPC/FFC at an angle and/or stop it before insertion is completed (example 15.16) [Caution] -Do not insert the FPC/FFC with the conductor surface face up. -Insert the FPC/FFC properly to the very end. -Do not insert the FPC/FFC at an angle (example 11) Example 14 Example 15 Example 16 -Insert the FPC/FFC with the actuator opened (example 12) -Do not twist the FPC/FFC to up and down, right and left or an angle (example 13) Example 10 Guide for positioning FPC/FFC FPC/FFC (inserted with angle) FPC/FFC (insufficient inserted) FPC/FFC alignment tab Guide for positioning FPC/FFC Insert the FPC/FFC - Incorrect operation -- Correct operation -- Incorrect operation with the exposed conductors face down. - Correct operation -Example 11 [°] Pattern breakage - Incorrect operation Hook of guide for positioning FPC/FFC FPC/FFC TAB run on the guide FPC/FFC TAB run on the guide fits in FPC/FFC TAB. Example 12 Example 13 for positioning FPC/FFC. for positioning FPC/FFC. A<INSTRUCTION MANUAL(2)> FPC/FFC FPC/FFC EDC-365730-99-00 - Correct operation -- Incorrect operation -FH52K-**S-0.5SH(99) CL580

FORM HC0011-5-8

5. How to lock 7. How to unlock The actuator rotates on its axis as shown below. Slowly flip up the actuator to release the lock. (example 20) Apply load to rotate the actuator after inserting the FPC/FFC. (example 17) [Caution] -Open the actuator by carefully lifting it at the center (example 21) -Close the actuator by carefully operating it at the center. (example 18) -Do not lift the actuator at one end only. (example 22) -Do not operate the actuator at one end only. (example 19) -Do not apply excessive force to the actuator in the direction parallel to the actuator while unlocking the actuator. -The actuator must be operated by hand only. -The actuator must be operated by hand only. Do not insert any tools or fingernails into the connector. Do not insert any tools or fingernails into the connector. -Do not try to rotate the actuator further towards the opening direction while it is fully open. -The actuator rotates 116 degrees max. -Do not apply excessive force to the actuator other than force necessary for rotating the actuator. Do not try to rotate the actuator further towards the opening direction or apply any extra force to the actuator -Do not attempt to dislodge the actuator. while it is fully open (example 23) -After the actuator is closed, the actuator should be parallel to the PCB mounting surface. -Do not attempt to dislodge the actuator. (example 24) Example 20 Example 17 Rotational axis - Correct operation - Correct operation Example 22 Example 18 Example 19 Do not operate the actuator at one end only - Incorrect operation Do not operate the actuator at one end only Close the actuator at the center Example 23 Example 24 - Correct operation - Incorrect operation 6. Mating confirmation of the FPC/FFC After the actuator is closed, please check if the actuator is parallel to the PCB mounting surface. Please keep the actuator stress free while it is near its 0° position. Any extra stress on actuator may lead to contact deformation. - Incorrect operation -- Incorrect operation -A<INSTRUCTION MANUAL(3)> EDC-365730-99-00 FH52K-**S-0.5SH(99) CL580

8. How to remove FPC/FFC


This connector has a FPC/FFC positioning structure for guiding the FPC/FFC into the right position while insertion. After rotating the actuator to the fully open position, carefully withdraw the FPC/FFC

at about 10 degree angle to the PCB mounting surface (example 25)

In case of using FPC/FFC without tabs, pull out the FPC/FFC horizontally along the PCB mounting surface.


[Caution]

- -For FPC/FFC removal, do not pull out the FPC/FFC horizontally.
- -Do not withdraw the FPC/FFC at extreme(inclined towards vertical) angle (example 26)
- -Do not attempt to pull the FPC/FFC without unlocking the actuator (example 27)



Example 31

Stiffener film (angled)






Incorrect operation



Example 30



Stiffener film (angled)

Follow the instructions shown below when mounting on the PCB.

-Refer to recommended layouts on page 1 for PCB and stencil pattern.

Using either narrower land pattern or wider stencil pattern than recommendation

may end up with excessive amount of solder/flux climbing on contact.

Please inspect the size of solder fillet and flux climbing height of the mounted connector

while using different land/stencil pattern from our recommendation.

-Clearance between the mounting surface of the connector contact lead and the bottom of the housing is very small. Solder resist/silk screening applied underneath the connector may interfere with the connector. This may lead to soldering defect/insufficient fillet formation.

Please verify your solder resist/silk screening design carefully before implementing the design.

-Apply reflow temperature profile within the specified conditions.

For specific applications, the recommended temperature may vary depending on

type/ volume/thickness of solder paste and size/thickness of PCB.

Please consult with your solder paste and equipment manufacturer for specific recommendations.

-Please try to minimize the warpage of the PCB. Soldering failure could still occur due to the PCB warpage even if the coplanarity of the connecter is under 0.1mm.

-If the connector is mounting on FPC/FFC, please make sure to put a stiffener

on the backside of the FPC/FFC.

Recommended stiffner: Glass epoxy material with thickness of 0.3 mm MIN.

-Do not apply 1 N or greater external force on the connector when unreeling

or handling the connector before mounting

Excessive mechanical stress may damage the connector before mounting.

Example 26

Deformation of the terminal upper arm

IPrecautions for component layout I While the FPC/FFC is under tension due to the connecting configuration, extra stress may be applied to the connector.

As a result, conduction failure may occur due to the extra stress.

Incorrect operation

In order to prevent such kind of conduction failure, please read through the following parts before making circuits/mechanism design.

[Caution]

-Avoid applying forces to/pulling the FPC/FFC along/perpendicular to the direction of FPC/FFC insertion (example 28)
Avoid pushing/pulling the FPC/FFC upwards/downwards.

-If the FPC/FFC has to be curled/bended in your cabling design.

please keep enough degree of freedom in your design to keep the FPC/FFC tension free. In this regard, the stiffener should be parallel to the PCB (example 29)

-If the FPC/FFC has to be curled/bended in your cabling design, do not curl/bend the FPC/FFC area near the connector. This may lead to conduction failure or FPC/FFC breakage (example 30)

It is recommended to keep the FPC/FFC fixed to avoid applying stress through the FPC/FFC to the connector.

-Do not mount other components underneath the FPC/FFC stiffener which may interfere with the connection (example 31)

-Follow the recommended FPC/FFC design.

Please consult with the FPC/FFC manufacturer about FPC/FFC bending performance and wire breakage strength while making design.

-Keep sufficient operating space for FPC/FFC insertion during layout design in order to avoid incorrect FPC/FFC insertion.

Please keep enough FPC/FFC length and component layout space for assembly during design process.

FPC/FFC with too short length may make the assembly difficult.

–Keep enough space for the rotation of the actuator during PCB and component layout design.

-Please consult with our sales representative if you are using FPC/FFC with different configuration from our recommendation.

EDC-365730-99-00 FH52K-**S-0.5SH(99) CL580

FORM HC0011-5-8

FORM HC0011-5-8

Instructions for PCB handling after mounting the connector Instructions on manual soldering Follow the instructions shown below when mounting on the PCB. Follow the instructions shown below when soldering the connector manually during repair work, etc. [Caution] [Caution] - Splitting a large PCB into several pieces -Do not perform manual soldering with the FPC/FFC inserted into the connector. ·Installing mounting screw on PCB -Do not heat the connector excessively. Be very careful not to let the soldering iron touch During the assembly processes described above, care shall be taken any parts other than connector leads. Otherwise, the connector may be deformed or melted. so as not to give any stresses of deflection or twisting to the PCB. -Do not supply excessive solder (or flux). Stresses applied on PCB may damage the connector as well
-The warpage of a 100 mm wide PCB should remain within 0.5 mm .(example 32) If excessive solder (or flux) is supplied on the contact lead, solder or flux may adhere to the contact point or rotating parts of the actuator, resulting in conduction failure or a rotation failure of the actuator. The warpage of PCB may apply excessive stress on the connector and damage the connector.

—Please perform conduction check with caution. Conductivity probe may damage the connector contacts. Supplying excessive solder to the metal fittings may hinder actuator rotation. resulting in breakage of the connector. -Attachment of foreign particles with the connector contact may lead to conduction failure. In this particular case, the conduction failure may be fixed by re-inserting the FPC/FFC. [Recommended reflow temperature profile] Example 32 5 MAX The temperatures mentioned below refer to the PCB surface Connector temperature near the connector contact leads. For specific applications the recommended temperature may vary depending on solder paste type, volume/thickness and board size/thickness. Connector Please consult with your solder paste and equipment manufacturer for specific recommendations. -Reflow method: IR reflow - Number of reflow cycles: 2 cycles MAX. 5 MAX MAX 250 ℃ Example 33 230℃ 200°C Deformation of the Deformation of the contact upper arm contact EMPERATURE (°C Conductivity probe Conductivity probe 25 90~120 sec (60 sec.) MAX 60 sec. PRE-HEATING TIME SOIDFRING TIME TIME (sec.) △<Recommended reflow temperature profile> _F EDC-365730-99-00 FH52K-**S-0.5SH(99) CL580

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for FFC & FPC Connectors category:

Click to view products by Hirose manufacturer:

Other Similar products are found below:

FPH-1422G FPH-1602G K-FC20 FH29B-80S-0.2SHW(99) FPH-2022G AYF332735 52610-1075 52610-1275 52610-1934 501864-3091TR225 086222026001800 52610-0675 62684-36210E9ALF 52746-1671-TR250 10051922-2810EHLF 6-520415-9 SFV6R-1STE9HLF

XF3M-2915-1B-R100 1658549-1 AYF534065TA AYF351525 086212040340800+ AYF530365TA 67000-014LF 67000-004LF

006207341915000+ DS1020-19RT1D 67000-003LF 67000-011LF 67000-016LF HFW14R-2STE9LF SFV32R-2STBE9HLF SFW12R
5STE9LF SFW18R-1STAE9LF SFW4R-5STE9LF 52807-0430 046283021002868+ THD1015-8CL-SN 67000-006LF 502250-8027

104267-9617 66987-011LF AYF362535 F0501-T-50-20T-R F1003-ZV-12-25T-R HFW8S-2STAE1HLF 67000-008LF 67000-012LF

ECC576069EU F1002-B-20-20T-R