PSAN Series

Small size, 1/2,000 resolution connector type digital pressure sensor

▣Features

- Ideal for a wide range of applications of gas, liquid, and oil.
 (Inappropriate to corrosion environment for SUS316L)
- Enhanced environmental resistance with diaphragm
- 1/2,000 high resolution for indication
- Hold/Auto shift input function
 (Only for models with Hold/Auto shift input type)
 −Hold : Holding instantaneous outputs and display value
 −Auto shift : Enable to output regardless of initial pressure change
- Hold function for instantaneous outputs and holding display value
- 2 independent outputs and NO/NC output selectable
- Forced−output mode embodied for easy operation test and monitoring
- One−touch connector type for easy maintenance
- Analog output (1/2,000 resolution, voltage : 1−5V, current : 4−20mA)
- Zero−point adjustment function, peak monitoring function, and chattering prevention function


Pneumatic type

Line−up

Fluid type

⚠ **Please read "Caution for your safety" in operation manual before using.**

CE

▣Ordering information

PS | AN | − | | V | 01 | C | P | V | − | Rc1/8

Pressure port(★)	R1/8	Standard(Fluid type)
	Rc1/8	Standard(Pneumatic type)
	NPT1/8	Option
	7/16−20UNF	Option(Fluid type)
Option output(Function)	V	Analog voltage(1−5V) output
	A	Analog current(4−20mA) output
	H	Hold/Auto shift input
Output type	Blank	NPN open collector output
	P	PNP open collector output
Cable	C	Connector type
Pressure range	01	100kPa
	1	1MPa
Pressure type	Blank	Positive pressure type
	V	Vacuum pressure type
	C	Compound pressure type
Applicable fluid	Blank	Pneumatic type(Gas)
	L	Fluid type(Gas, Liquid, Oil)
Appearance	AN	Regular square New type(30mm×30mm)
	PS	Pressure Sensor

※(★)In case of using M5 port, use PSO−Z01 (M5 Gender) together.

▣Pressure and Max. pressure display range

Type	kPa	kgf/cm²	bar	psi	mmHg	inHg	mmH₂O
Vacuum pressure	0.0 to −101.3 (5.0 to −101.3)	0.000 to −1.034 (0.051 to −1.034)	0.000 to −1.013 (0.050 to −1.013)	0.00 to −14.70 (0.74 to −14.70)	0 to −760 (38.0 to −760.0)	0.0 to −29.9 (1.50 to −29.90)	0.0 to −103.4 (5.1 to −103.4)
Positive pressure	0.0 to 100.0 (−5.0 to 110.0)	0.000 to 1.020 (−0.051 to 1.122)	0.000 to 1.000 (−0.050 to 1.100)	0.00 to 14.50 (−0.72 to 15.96)	——	——	——
	0 to 1000 (−50 to 1100)	0.00 to 10.20 (−0.51 to 11.22)	0.00 to 10.00 (−0.50 to 11.00)	0.0 to 145.0 (−7.2 to 159.6)	——	——	——
Compound pressure	−101.3 to 100.0 (−101.3 to 110.0)	−1.034 to 1.020 (−1.034 to 1.122)	−1.013 to 1.000 (−1.013 to 1.100)	−14.70 to 14.50 (−14.70 to 15.96)	−760 to 750 (−760.0 to 824.0)	−29.9 to 29.5 (−29.88 to 32.58)	−103.4 to 102.0 (−103.4 to 112.2)

※( ) is Max. pressure display range.
※For using a unit mmH₂O, multiply display value by 100.

■Pressure conversion chart

from \ to	Pa	kPa	MPa	kgf/cm²	mmHg	mmH₂O	psi	bar	inHg
1kPa	1000.000	1	0.001000	0.010197	7.500616	101.9689	0.145038	0.010000	0.2953
1kgf/cm²	98066.54	98.066543	0.09806	1	735.5595	10000.20	14.22334	0.980665	28.95878
1mmHg	133.322368	0.133322	0.000133	0.001359	1	13.5954	0.019336	0.001333	0.039370
1mmH₂O	9.80665	0.00980	——	0.000099	0.0735578	1	0.00142	0.000098	0.002895
1psi	6894.757	6.89493	0.00689	0.070307	51.71630	703.07	1	0.068947	2.036074
1Pa	100000.0	100.0000	0.100000	1.019689	750.062	10196.89	14.50339	1	29.52998
1inHg	3386.417	3.386388	0.003386	0.034532	25.40022	345.31849	0.491158	0.033863	1

Ex) For calculating 760mmHg as kPa :
    According to above chart, 1mmHg is 0.133322kPa, therefore 760mmHg will be 760×0.133322kPa=101.32472kPa.

■Specifications

Pressure type		Gauge pressure			
		Vacuum pressure type	**Positive pressure type**		**Compound pressure type**
Model (★1)	Analog voltage output	**PSAN-(L)V01C(P)V-□**	**PSAN-(L)01C(P)V-□**	**PSAN-(L)1C(P)V-□**	**PSAN-(L)C01C(P)V-□**
	Analog current output	**PSAN-(L)V01C(P)A-□**	**PSAN-(L)01C(P)A-□**	**PSAN-(L)1C(P)A-□**	**PSAN-(L)C01C(P)A-□**
	Hold/Auto shift input	**PSAN-(L)V01C(P)H-□**	**PSAN-(L)01C(P)H-□**	**PSAN-(L)1C(P)H-□**	**PSAN-(L)C01C(P)H-□**
Rated pressure range		0.0 to −101.3kPa	0.0 to 100.0kPa	0 to 1,000kPa	−101.3kPa to 100.0kPa
Display pressure range		5.0 to −101.3kPa	−5.0 to 110.0kPa	−50 to 1,100kPa	−101.3kPa to 110.0kPa
Min.display unit(internal resolution)		0.1kPa(1/2,000)	0.1kPa(1/2,000)	1kPa(1/2,000)	0.1kPa(1/2,000)
Max. pressure range		2 times of rated pressure		1.5 times of rated pressure	2 times of rated pressure
Applicable fluid		\• **Pneumatic type** ☞ Air, Non−corrosive gas \• **Fluid type** ☞ Air, Non−corrosive gas and fluid that will not corrode SUS316L			
Power supply		12V−24VDC ±10%(Ripple P−P:Max. 10%)			
Current consumption		Max. 50mA(Analog Current Output type Max 75mA)			
Control output		• NPN open collector output ☞ Max. sink current:Max. 100mA, Applied voltage:Max. 30VDC, Residual voltage:Max. 1V • PNP open collector output ☞ Max. source current:Max. 100mA, Residual voltage:Max. 2V			
Hysteresis(★2)		Min. display range			
Repeat error		±0.2%F.S ± Min. display range			
Response time		Selectable 2.5ms, 5ms, 100ms, 500ms, 1000ms			
Short circuit protection		Built−in			
Analog output (★3)	Voltage output	• Output voltage:1−5VDC ±2% F.S • Linear:Within ±1% F.S • Output impedance: 1kΩ • Zero point:Within 1VDC ±2% F.S • Span:Within4VDC ±2% F.S • Resolution:1/2,000(equal to display resolution) • Response Time:50ms			
	Current output	• Output current:4−20mA ±2% F.S • Linear:Within ±1% F.S • Zero−point:Within 4mA ±2% F.S • Span:Within16mA ±2% F.S • Resolution:1/2,000(equal to display resolution) • Response Time:70ms			
Display method		4 digit LED 7segment			

Min. Display interval(★4)	resolution / pressure unit	1000	2000	1000	2000	1000	2000	1000	2000
	kPa	0.1	—	0.1	—	1	—	—	0.1
	kgf/cm²	0.001	—	0.001	—	0.01	—	—	0.001
	bar	0.001	—	0.001	—	0.01	—	—	0.001
	psi	—	0.01	—	0.01	—	0.1	—	0.02
	mmHg	—	0.4	—	—	—	—	—	0.8
	inHg	—	0.02	—	—	—	—	—	0.03
	mmH₂O	0.1	—	—	—	—	—	—	0.1

Characteristic of control output and display temp.	Max. ±0.5% F.S. of display pressure at 25℃ within 0℃ to 50℃ ※Max. ±1% F.S. of display pressure at 25℃ under −10℃
Analog output temp. characteristic	Max. ±2% F.S. of display pressure at 25℃ within 0℃ to 50℃
Dielectric strength	1000VAC 50/60Hz for 1 minute
Insulation resistance	Min. 50MΩ (at 500VDC megger)
Ambient temperature	−10℃ to +50℃ (at non−dew status)
Storage temperature	−20℃ to +60℃ (at non−freezing status)
Ambient humidity	30 to 80%RH
Storage humidity	30 to 80%RH
Vibration	1.5mm amplitude at frequency of 10 to 55Hz in each of X, Y, Z direction for 2 hours
Protection	IP40 (IEC specification)
Material	\• **Pneumatic type** ☞ Front case : PC, Rear case : PC, Pressure port : Nickel Plated Brass \• **Fluid type** ☞ Front case : PC, Rear case : PA6, Pressure port : SUS316L
Cable	Connector cable(φ4, 5P, Length: 2m, AWG 24, Insulator diameter: φ1)
Approval	CE
Unit weight	\• **Pneumatic type** ☞ Approx. 84g • **Fluid type** ☞ Approx. 57.5g

※F.S : Rated pressure.   ※(★1) (P) is PNP output type, □ of model name is as pressure port.
※(★2) In hysteresis output mode, detection difference is variable.   ※(★3) It is allowed to select one analog output type only.
※(★4) Resolution(1000/2000) of min. Display interval is automatically selected depend on pressure units.

(A) Photo electric sensor
(B) Fiber optic sensor
(C) Door/Area sensor
(D) Proximity sensor
(E) Pressure sensor
(F) Rotary encoder
(G) Connector/ Socket
(H) Temp. controller
(I) SSR/ Power controller
(J) Counter
(K) Timer
(L) Panel meter
(M) Tacho/ Speed/ Pulse meter
(N) Display unit
(O) Sensor controller
(P) Switching power supply
(Q) Stepping motor & Driver & Controller
(R) Graphic/ Logic panel
(S) Field network device
(T) Production stoppage models & replacement

PSAN Series

● Analog output voltage and current−Pressure characteristic

(Normal Example)

PSAN-01

Output voltage (V) / Output current (mA) vs Pressure (kPa)

● Analog output voltage and current−Linear characteristic

(Normal Example)

PSAN-01

Output voltage (V) / Output current (mA) vs Pressure (kPa)

±2% F.S.

Full scale

▣ Dimensions

◎ Pneumatic type

(Unit:mm)

30.7
30
22.8 7.9
20
2−M3 Tap
12
20
PT1/8"(Standard)

● **Panel mounting bracket**

34.2
40
42
6
Panel mounting bracket (PSO−B02)
Front protection cover (PSO−P01)
When front cover is mounted

● **Fixing bracket A for mounting**

45
20
30
6
2−M4 Bolt
15
35.8
1.6

● **Fixing bracket B for mounting**

35
25
2−M4 Bolt
6
22
45
44.8
1.6

Pressure Sensor

(A)
Photo electric sensor

(B)
Fiber optic sensor

(C)
Door/Area sensor

(D)
Proximity sensor

(E)
Pressure sensor

(F)
Rotary encoder

(G)
Connector/ Socket

(H)
Temp. controller

(I)
SSR/ Power controller

(J)
Counter

(K)
Timer

(L)
Panel meter

(M)
Tacho/ Speed/ Pulse meter

(N)
Display unit

(O)
Sensor controller

(P)
Switching power supply

(Q)
Stepping motor & Driver & Controller

(R)
Graphic/ Logic panel

(S)
Field network device

(T)
Production stoppage models & replacement

■Dimensions

◎Fluid type

(Unit:mm)

PT 1/8" (Standard)
〇17
2−M3 Tap
Inner part M5 Tap

※(A) PT1/8" model(Standard): 8, NPT1/8" model: 8,
7/16"−20 UNF model: 11
※(∗1) Only for PT1/8" model, NPT1/8" model

●Panel mounting bracket

Panel mounting bracket (PSO−B02)
Front protection cover (PSO−P01)
When front cover is mounted

※(B) PT1/8" model(Standard): 56.3, NPT1/8" model: 56.3,
7/16"−20 UNF model: 59.3

●Fixing bracket A for mounting

2−M4 Bolt

●Fixing bracket B for mounting

2−M4 Bolt

●Panel cut−out

$36^{+0.5}_{0}$
$36^{+0.5}_{0}$

(Panel thickness : 0.8mm to 3.5mm)

●Accessory(Sold separately)

• Panel mounting bracket
< PSO−B02 >

• Front protection cover
< PSO−P01 >

• M5 Gender
< PSO−Z01 >

●Accessory

• Pressure unit label

	±100kPa	-101.3kPa	2kPa	10kPa	100kPa	1MPa
	±1.020kgf/cm²	-1.034kgf/cm²	2.040kgf/cm²	10.20kgf/cm²	1.020kgf/cm²	10.20kgf/cm²
	±14.50psi	-14.70psi	29.00psi	145.0psi	14.50psi	145.0psi
	±1.000bar	-1.013bar	2.000bar	10.00bar	1.000bar	10.00bar
	±750mmHg	-760mmHg				
	±29.5inHg	-29.9inHg			/100	/100
	±102.0mmH₂O	-103.4mmH₂O	2.040mmH₂O	10.20mmH₂O	X100	X100

DISPLAY UNIT LABEL

• Bracket A

• Bracket B

• Connector cable(PSO−C01)

●Bracket A

3−φ3.2
2−M4 BOLT

●Bracket B

2−M4 Bolt
3−φ3.2

PSAN Series

▣Control output diagram

◎Analog output (Voltage output PSAN-□□□□V-□, Current output PSAN-□□□□A-□ type)

● NPN open collector output type ● PNP open collector output type

※ In case of analog voltage output type models short−circuit protection is not embodied. ([____] : For voltage output type only.)
   Do not connect with power source or load directly.
※ Be careful with input impedance of connecting devices when using analog voltage output type models.
※ Be careful with voltage drop due to cable resistance when extending sensor cable.

◎Hold/Auto shift input (PSAN-□□□□H-□ type)

● NPN open collector output type ● PNP open collector output type

▣Front panel identification and function

① **Range of rated pressure** : The unit label is changeable.
   Please use a desired measure unit label.
② **4 digit LED display(Red)** : Indicates measuring pressure value, setting value, and error message.
③ **Output1 indicator(Red)** : Output 1 is ON, LED will be ON.
④ **Output2 indicator(Green)** : Output 2 is ON, LED will be ON.
⑤ **M key** : Used to enter into Preset/Parameter setting mode and to save Setting mode.
⑥ **⌃ key** : Used to set parameter and preset, peak value check mode, function setting or output operation mode.
⑦ **⌃ + ⌄ keys** : Used for zero−point adjustment function by pressing ⌃+⌄ keys over 1 sec. simultaneously in RUN mode.

▣Setting

Press M key over 3sec.	Parameter setting	Pressure unit setting	▶ Output operation mode setting	▶ Output type setting	▶ Response time setting	▶ Analog output scale and Hold/Auto Shift input setting	▶ Key lock setting
Press M key	Preset value setting	Detection level 1 setting (out1)		▶ Detection level 2 setting (out2)			
Press ⌃ key over 3sec.	Peak hold	High peak value check	▶ Low peak value check	▶ Auto shift input setting (In case of Hold/Auto shift input type model)			
Press ⌃+⌄ keys over 1sec.	Zero−point adjustment	Zero−point adjustment					

(RUN mode)

▣Zero-point adjustment

Press over 1sec.

1. In state of atmospheric pressure during RUN mode,
   press ⌄ key and ⌃ key at the same time for over 1sec.
2. When the zero-point adjustment is completed, it will display
   ⎡0.0⎤ and return to RUN mode automatically.
   ※Please execute zero-point adjustment regularly.

If executing zero-point adjustment when external pressure has been applied, ⎡Err1⎤ will flash.
Please execute zero-point adjustment again in state of atmospheric pressure without external pressure.

▣Parameter setting

1. It is able to set pressure unit, display resolution, output operation mode, output type, response time, analog output scale, Hold/Auto shift and key lock setting in parameter setting mode.
2. If the key lock is set (lock1 or lock2), unlock the key lock before setting parameters. (Refer to Key Lock setting below.)

RUN mode

Press M key over 3sec. Press M key over 3sec.

⎡Unl t⎤ **Pressure unit setting**

Press M key

⎡Unl t⎤ and previously set unit will flash in turn every 0.5 sec.
Press ⌃ or ⌄ key to select the unit.
(Press M key for 1 sec to save selected unit and move to next mode.)

●Vacuum pressure, compound pressure:

⎡ⱩPA⎤ → ⎡ⱩGF⎤ → ⎡bAr⎤ → ⎡PSI⎤ → ⎡m̄m̄HG⎤ → ⎡I nHG⎤ → ⎡H2o⎤

(kPa)   (kgf/cm²)   (bar)   (psi)   (mmHg)   (inHg)   (mmH₂O)

※For using mmH2O unit, multiply display value by 100.

●Positive pressure:

⎡ⱩPA⎤ → ⎡ⱩGF⎤ → ⎡bAr⎤ → ⎡PSI⎤

(kPa)   (kgf/cm²)   (bar)   (psi)

⎡oUt.m̄⎤ **Output operation mode setting**

Press M key

⎡oUt.m̄⎤ and previously set output operation mode will flash in turn every 0.5 sec.
Press ⌃ or ⌄ key to select output operation mode.
(Press M key for 1 sec. to save selected output operation mode and move to next mode.)

⎡HYS.m̄⎤ → ⎡Yl n⎤ → ⎡HY-Y⎤ → ⎡AUto⎤ → ⎡F.oUt⎤

※Refer to E-10 page.

⎡no.nC⎤ **Output setting**

Press M key

⎡no.nC⎤ and previously set output operation mode will flash in turn every 0.5 sec.
Press ⌃ or ⌄ key to select output type.
(Press M key for 1 sec. to save selected output type and move to next mode.)

⎡Io2o⎤ → ⎡Io2C⎤ → ⎡IC2o⎤ → ⎡IC2C⎤

※Refer to E-11 page.

⎡SPd⎤ **Response time setting**

Press M key

⎡SPd⎤ and previously set output operation mode will flash in turn every 0.5 sec.
Press ⌃ or ⌄ key to select response time.
(Press M key for 1 sec. to save selected response time and move to next mode.)

⎡2.5⎤ → ⎡5.0⎤ → ⎡100⎤ → ⎡500⎤ → ⎡1000⎤

(Unit: ms)

(A) Photo electric sensor

(B) Fiber optic sensor

(C) Door/Area sensor

(D) Proximity sensor

(E) Pressure sensor

(F) Rotary encoder

(G) Connector/ Socket

(H) Temp. controller

(I) SSR/ Power controller

(J) Counter

(K) Timer

(L) Panel meter

(M) Tacho/ Speed/ Pulse meter

(N) Display unit

(O) Sensor controller

(P) Switching power supply

(Q) Stepping motor & Driver & Controller

(R) Graphic/ Logic panel

(S) Field network device

(T) Production stoppage models & replacement

PSAN Series

● **Analog output scale setting**   ● **Hold/Auto shift input setting**

Analog voltage output type	**Analog current output type**	**Hold/Auto shift input type**
★1 `A- 1u` Analog output scale setting 1V	★1 `A-04` Analog output scale setting 4mA	★3 `d-I n` Select control function
Press Ⓜ key	Press Ⓜ key	Press Ⓜ key
★2 `A-5u` Analog output scale setting 5V	★2 `A-20` Analog output scale setting 20mA	`SH.ot` Select Auto Shift Output
Press Ⓜ key	Press Ⓜ key	Press Ⓜ key

★**1.** `A- 1u` (voltage output)/ `A-04` (current output) and previously set pressure value will flash in turn every 0.5 sec.
Press ⊼ or ⊻ key to set analog output scale value for 1V and 4mA.
Setting range: Min.rated pressure ≤ `A- 1u`, `A-04` ≤ 90% of rated pressure
(Press Ⓜ key for 1 sec to save selected pressure value as a scale value for 1V and 4mA and move to next mode.)

★**2.** `A-5u` (voltage output)/ `A-20` (current output) and previously set pressure value will flash in turn every 0.5 sec.
Press ⊼ or ⊻ key to set analog output scale value for 5V and 20mA.
Setting range: `A- 1u`, `A-04` +10% of rated pressure ≤ `A-5u`, `A-20` ≤ Max. rated pressure
(Press Ⓜ key for 1 sec to save selected pressure value as a scale value for 5V and 20mA and move to next mode.)

★**3.** `d-I n` and previously set control function will flash in turn every 0.5 sec.
Press ⊼ or ⊻ key to select external function.
(Press Ⓜ key for 1 sec to save selected function and move to next mode.)

● Select external input function: ● Select the control output for Auto shift function in case of selecting Auto shift function:

`Ho.Ld` ⇄ `SHFt`   `oUt 1` ⇄ `oUt2` ⇄ `ALL`

`LoCk` **Key Lock**

Press Ⓜ key

`LoCk` will flash in turn with previous setting parameter.
Press ⊼ or ⊻ key to select key lock setting.
(Press Ⓜ key for 1 sec. to save selected lock setting. Then, it will be returned to pressure unit setting mode.)

`LoC 1` ⇄ `LoC2` ⇄ `oFF`

※When pressing Ⓜ key for 3 sec. in the middle of parameter setting, current setting value will be saved in EEPROM and it will be returned to RUN mode.
※All settings are saved in EEPROM regardless of power failure. Make sure that EEPROM has a limited write life cycle (100,000 times).

■ Preset setting

◎ Hysteresis mode (`HYS.m`)

Press Ⓜ key for 3 sec in RUN mode.

Press Ⓜ key → Press Ⓜ key → Press Ⓜ key → Press Ⓜ key → Press Ⓜ key → **RUN mode**

`St 1` and previously set value will flash in turn every 0.5 sec.

`HYS 1` and previously set value will flash in turn every 0.5 sec.

`St2` and previously set value will flash in turn every 0.5 sec.

`HYS2` and previously set value will flash in turn every 0.5 sec.

Press ⊼ or ⊻ key to select `St 1` setting value.

Press ⊼ or ⊻ key to select `HYS 1` setting value.

Press ⊼ or ⊻ key to select `St2` setting value.

Press ⊼ or ⊻ key to select `HYS2` setting value.

※`St 1` setting range : Min. display pressure < `St 1` ≤ Max. display pressure
※`HYS 1` setting range : Min. display pressure < `HYS 1` ≤ `St 1`
※`St2` setting range : Min. display pressure < `St2` ≤ Max. display pressure
※`HYS2` setting range : Min. display pressure < `HYS2` ≤ `St2`

Pressure Sensor

E
Pressure
sensor

◎Window comparison output mode(Ⱳı �n)

Press M key for 3 sec in RUN mode.

Press M key → Press M key → Press M key → Press M key → Press M key → **RUN mode**

Lo-1 and previously set value will flash in turn every 0.5 sec.

HI-1 previously set value will flash in turn every 0.5 sec.

Lo-2 and previously set value will flash in turn every 0.5 sec.

HI-2 and previously set value will flash in turn every 0.5 sec.

Press ⊼ or ⊻ key to select Lo-1 setting value.

Press ⊼ or ⊻ key to select HI-1 setting value.

Press ⊼ or ⊻ key to select Lo-2 setting value.

Press ⊼ or ⊻ key to select HI-2 setting value.

※Low value setting range : Min. display pressure < Lo-1, Lo-2 ≤ Max. display pressure−(3×Min. display range)
※High value setting range : Lo-1, Lo-2+(3×Min. display range) ≤ HI-1, HI-2 ≤ Max. display pressure
※The minimum display unit for hysteresis is fixed to 1.

◎Hysteresis−Window comparison output mode(HY-Ⱳ)

Press M key for 3 sec in RUN mode.

Press M key → Press M key → Press M key → Press M key → Press M key → **RUN mode**

5t1 and previously set value will flash in turn every 0.5 sec.

HY51 previously set value will flash in turn every 0.5 sec.

LoY and previously set value will flash in turn every 0.5 sec.

HI GH and previously set value will flash in turn every 0.5 sec.

Press ⊼ or ⊻ key to select 5t1 setting value.

Press ⊼ or ⊻ key to select HY51 setting value.

Press ⊼ or ⊻ key to select LoY setting value.

Press ⊼ or ⊻ key to select HI GH setting value.

※5t1 setting range : Min. display pressure < 5t1 ≤ Max. display pressure
※HY51 setting range : Min. display pressure <HY51 ≤ 5t1
※Low value setting range : Min. display pressure < LoY ≤ Max. display pressure−(3×Min. display range)
※High value setting range : Low value+(3×Min. display range) ≤ HI GH ≤ Max. display pressure
※In case HY51 and 5t1 have the same setting values, it will have the minimum display unit as a hysteresis.

◎Automatic sensitivity setting mode(AUto)

Press M key for 3 sec in RUN mode.

Press M key → Press M key → Press M key → **RUN mode**

5t1 and previously set value will flash in turn every 0.5 sec.

5t2 and previously set value will flash in turn every 0.5 sec.

5Et and previously set value will flash in turn every 0.5 sec.

Press ⊼ or ⊻ key to select 5t1 setting value.

Press ⊼ or ⊻ key to select 5t2 setting value.

Press ⊼ or ⊻ key to select 5Et setting value.

Sensitivity will be automatically set. Press ⊼ or ⊻ key to fine−adjust the setting value between 5t1 and 5t2.

$$SET = \frac{5t1 + 5t2}{2}$$

※5t1 setting range : Min. display pressure ≤ 5t1 ≤ Max. display pressure−1% of rated pressure
※5t2 setting range : 5t1+1% of rated pressure ≤ 5t2 ≤ Max. display pressure
※If certain detection level difference is not ensured, or setting conditions are not met, Err3 message will flash three times and returned to 5t2 setting mode. Check all setting conditions and set proper setting values.
※Press ⊼ key to change set values and last set value will be saved for level 1 and level 2.
※In case of PSAN−□□□H−□ models, it is possible to set 5t1 and 5t2 using option input (yellow) after applying pressure on pressure port.

(A) Photo electric sensor
(B) Fiber optic sensor
(C) Door/Area sensor
(D) Proximity sensor
(E) Pressure sensor
(F) Rotary encoder
(G) Connector/ Socket
(H) Temp. controller
(I) SSR/ Power controller
(J) Counter
(K) Timer
(L) Panel meter
(M) Tacho/ Speed/ Pulse meter
(N) Display unit
(O) Sensor controller
(P) Switching power supply
(Q) Stepping motor & Driver & Controller
(R) Graphic/ Logic panel
(S) Field network device
(T) Production stoppage models & replacement

Autonics   E−8

## ◎Forced output control mode(F.oUt)

Press M key

Press M key

If forced output control mode is selected, pressure value is displayed only. (No output will be provided.)

Present pressure value and " F.oUt " will flash in turn every 0.5 sec.

Control output 1 OFF ⬅⋯⋯ Control output 1 ON

Control output 2 OFF ⬅⋯⋯ Control output 2 ON

※If there is no additional key operation within 60 sec while setting, it is returned to Run mode (Except for force output mode). Previously set values are remained.

※In case of changing output operation mode, no preset values will be initialized. Instead, previous output operation settings will become the preset values.

※When changing pressure display unit, resolution, and Hold/Auto shift input function, preset values will be initialized as shown the next table. (When changing pressure display unit, preset value will be automatically switched to changed pressure unit.)

※When using the forced output function, Hold/Auto shift function is not available to use in Hold/Auto shift model.

●Factory default
(Unit:kPa)

Output mode	Vacuum pressure −101.3 to 0	Positive pressure 0 to 100.0	Positive pressure 0 to 1,000	Compound pressure −101.3 to 100.0
HYS.ñ	St 1:−50.0 HYS 1:0 St2:−50.0 HYS2:0	St 1:50.0 HYS 1:0 St2:50.0 HYS2:0	St 1:500 HYS 1:0 St2:500 HYS2:0	St 1:50.0 HYS 1:−50.0 St2:50.0 HYS2:−50.0
Y1 n	Lo- 1:−50.0 HI - 1:0 Lo-2:−50.0 HI -2:0	Lo- 1:0 HI - 1:50.0 Lo-2:0 HI -2:50.0	Lo- 1:0 HI - 1:500 Lo-2:0 HI -2:500	Lo- 1:−50.0 HI - 1:50.0 Lo-2:−50.0 HI -2:50.0
HY-Y	St 1:−50.0 HYS 1:0 LoY:0 HI GH:−50.0	St 1:50.0 HYS 1:0 LoY:0 HI GH:50.0	St 1:500 HYS 1:0 LoY:0 HI GH:500	St 1:50.0 HYS 1:−50.0 LoY:−50.0 HI GH:50.0
AUto	St 1:0 St2:−50.0 SEt:−25.0	St 1:0 St2:50.0 SEt:25.0	St 1:0 St2:500 SEt:250	St 1:−50.0 St2:50.0 SEt:0

■High peak/Low peak function and Auto shift reference pressure check/change

Press ⊼+⊻ keys over 1sec.

It will be returned to RUN mode after previously set Auto shift reference pressure is removed.

Press M key

Press M key

Press ⊼+⊻ keys over 1sec.

Remove the retained minimum pressure value.

Press M key

Press ⊼+⊻ keys over 1sec.

Remove the retained minimum pressure value.

Press M key

Press ⊼+⊻ keys over 1sec.

Remove the retained minimum pressure value.

★1

Press M key for 3 sec in RUN mode.

Retained maximum pressure value will flash every 0.5 sec.

Retained maximum pressure value will flash every 0.5 sec.

Auto shift reference pressure value will flash every 0.5 sec.

"HHHH" will flash if retained maximum pressure value is above the upper limit of rated pressure. (For vacuum pressure type, LLLL will flash)

"LLLL" will flash if retained minimum pressure value exceeds low−limit of rated pressure. (For vacuum pressure type, HHHH will flash)

Press ⊼ or ⊻ key to select set value.

★1. ※Displayed only when "d-i n" is set to "SHFt".(PSAN−□□□H−□ models only)
※If there is no Auto shift input, "0" will be displayed.(Refer to E−11 page for more details.)

■Output operation mode

1. Hysteresis mode(HYS.ñ)

It is able to set certain value for pressure detection level(St 1, St2) and hysteresis(HYS 1, HYS2).


2. Window comparison output mode(ษı n)

①It is able to set the range for high(HI - 1, HI -2), low(Lo- 1, Lo-2)limit of pressure detection level when it is required to detect pressure at a certain range.
②Detection hysteresis is fixed to min. display range.


3. Hysteresis-window comparison output mode(HY-ย)

①It is available to set hysteresis mode and window comparison output mode when both hysteresis mode(St 1, HYS 1) and window comparison output mode(LoY, HI ūH)are necessary.
②Detection hysteresis is fixed to min. display range.

4.Automatic sensitivity setting mode(AUto)

①This function is to set pressure detection level to the proper position automatically. It is set by applied pressure from two positions(St 1, St2).
②Detection hysteresis is fixed to min. display range.
③The pressure detection level is shown in the following calculation.

$$SET= \frac{(St 1 + St2)}{2}$$

5. Forced output control mode(F.oUt)

①Used to display pressure with forcibly holding comparing output OFF regardless of setting value.
②Output 1, 2 can be ON/OFF manually by pressing ⊼, ⊻ key while the forced output control mode is applied.

(A) Photo electric sensor

(B) Fiber optic sensor

(C) Door/Area sensor

(D) Proximity sensor

(E) Pressure sensor

(F) Rotary encoder

(G) Connector/ Socket

(H) Temp. controller

(I) SSR/ Power controller

(J) Counter

(K) Timer

(L) Panel meter

(M) Tacho/ Speed/ Pulse meter

(N) Display unit

(O) Sensor controller

(P) Switching power supply

(Q) Stepping motor & Driver & Controller

(R) Graphic/ Logic panel

(S) Field network device

(T) Production stoppage models & replacement

PSAN Series

▣Functions

◎Pressure unit change function

PSAN-V01C(P) and PSAN-C01C(P) has 7 kinds of pressure unit, PSAN-01C(P) and PSAN-1C(P) has 4 kinds of pressure unit. Please select the proper unit for application.
- PSAN-V01C(P), PSAN-C01C(P) : kPa, kgf/cm², bar, psi, ㎜Hg, inHg, mmH₂O
- PSAN-01C(P), PSAN-1C(P) : kPa, kgf/cm², bar, psi
※When using mmH₂O unit, multiply display value by 100.

◎Output mode change function

There are 5 kinds of control output mode in order to realize the various pressure detection.
- Hysteresis mode(HYS.m) : When needed to change hysteresis for detecting pressure.
- Window comparison output mode(Ꮍ! n) : When needed to detect pressure in certain area.
- Hysteresis - Window comparison output mode(HY-Ꮍ) : When both hysteresis mode and window comparison output mode are required.
- Automatic sensitivity setting mode(AUto) : When needed to set detection sensitivity automatically at proper position.
- Forced output control mode(F.oUt) : When needed to display pressure with remaining comparison output OFF regardless of setting value.

◎Control output change function

Type of control output for Out1 and Out2 is able to set Normal Open or Normal Close.
※Note that Normal Open and Normal Close provide opposite output.

OUT1 output	OUT2 output	Parameter setting value
Normal Open	Normal Open	[lo2o]
Normal Open	Normal Close	[lo2C]
Normal Close	Normal Open	[lC2o]
Normal Close	Normal Close	[lC2C]

◎Response time change function (Chattering prevention)

It can prevent chattering of control output by changing response time. It is able to set 5 kinds of response time(2.5ms, 5ms, 100ms, 500ms, 1000ms) and if the response time is getting longer, the detection will be more stable by increasing the number.

◎Analog output scale setting function

- Analog voltage output scale setting : The scale function for analog output voltage (1-5VDC) is not fixed to the rated pressure range. It can be changed for User's application. Analog output voltage range will be fixed to 1-5VDC within the pressure range from pressure point of 1VDC output(A- Iu) to pressure point of 5VDC output(A-5u).
- Analog current output scale setting : The scale for analog output Current (4-20mADC) is not fixed to the rated pressure range. It can be changed for User's application. Analog output voltage will be fixed to 4-20mA within the rated pressure range from pressure point of 4mA output(A-04) to pressure point of 20mA output(A-20).

◎Hold/Auto shift input setting function

- Hold function: A function to hold present pressure value and control output at the time of hold signal input.
※Present pressure value and Hold message will flash in turn every 0.5 sec. while Hold function is set. Make sure that Hold function is not able to execut while forced output mode is executed.

▶Control output timing chart
EX) When Hold signal is applied in Hysteresis mode, refer to Control output diagram for hold signal input.

※[Hold] and present pressure value will flash in turn every 0.5 sec. while Hold signal is applied.

Flashing in turn every 0.5 sec.

- Auto shift function: A function to use the measured pressure at the moment of auto shift input as a reference pressure in order to correct the set point values of control output when initial pressure changes.
※Reference pressure is fixed to atmospheric pressure (0.0kPa) when Auto shift function is not used.
※SHi n (Auto shift compensation value) will be reset to 0 when changing control output or preset values.
※Auto shift function will not be executed if "HHHH" or "LLLL" error occurs or if forced output mode is set.

[SH.ot] : Reference pressure change through setting.
[oUt I] : Changed reference will be applied to control output 1 only.
[oUt2] : Changed reference will be applied to control output 2 only.
[ALL] : Changed reference will be applied to both control output 1 and control output 2.

▶When Auto shift function is used

When Auto shift input signal remains at low level more than 1ms, the measured pressure at this point will be saved as a reference value to make correct judgment regardless of pressure changes. Corrected preset pressure value will be applied after 7.5ms. Measured reference pressure value will be saved in [5H.in].

Flashing twice when input Auto shift signal

Auto shift input

Min. 1ms

Switch output response

Min. 7.5ms
(Switch output response time when Auto shift signal is input)

Preset point value will be corrected by Auto shift input.

※When Auto shift function is used, the possible set pressure range will be wider than rated set pressure range.
※The possible set pressure range for Auto shift type models.

Pressure type	Set pressure range	Possible set pressure range for Auto shift type models
Vacuum pressure	−101.3kPa to 5.0kPa	−101.3kPa to 101.3kPa
Standard pressure	−5.0kPa to 110.0kPa	−110.0kPa to 110.0kPa
	−50.0kPa to 1100kPa	−1100kPa to 1100kPa
Compound pressure	−101.3kPa to 110.0kPa	−101.3kPa to 110.0kPa

※If the set point value corrected by auto shift input exceeds set pressure range, an error message will flash three times and corrected value is not saved.
→[-HH-] displayed when the set point value corrected by Auto shift input is above the upper limit of set pressure range.
→[-LL-] displayed when the set point value corrected by Auto shift input is below the lower limit of set pressure range.
※The correction value will be saved in EEPROM.

▶Example of Auto shift function
< When Auto shift is not used >

Pressure

Normal primary pressure
Drop of primary pressure
Increase of primary pressure

5t1
HYS1

Time

OUT ON OFF

Time

< When Auto shift is used >

Pressure

Normal primary pressure
Drop of primary pressure
Increase of primary pressure

5t1
HYS1

Time

OUT ON OFF

Time

Auto shift input   Auto shift input

Reference pressure = Atmospheric pressure (0.0kPa)

Reference pressure ≤ Atmospheric pressure (0.0kPa)

Reference pressure ≥ Atmospheric pressure (0.0kPa)

Correction set value: [5t1]' = [5t1] + [5H.in]
Correction set value: [HYS1]' = [HYS1] + [5H.in]
※[5H.in] is the reference pressure set by Auto shift input.

◎**Key lock function**
The key lock function prevents key operations so that conditions set in each mode.
• LoC1 : All keys are locked; therefore it is not available to change parameter settings, preset value, zero adjustment, High/Low peak check, and 5H.in data initialization. (Lock setting change is available)
• LoC2 : Partially locked status; therefore it is not available to change parameter settings only (Lock setting change is available). Other settings are still available.
• oFF : All of the setting is available, all keys are unlocked.

◎**Zero-point adjustment function**
The zero-point adjustment function forcibly sets the pressure value to "zero" when the pressure port is opened to atmospheric pressure. When the zero adjustment is applied, analog output [Voltage or Current] is changed by this function.
(Press ⊼ + ⊽ keys over 1 sec. in RUN mode.)

◎**High Peak / Low Peak Hold function**
This function is to diagnosis malfunction of the system caused by parasitic pressure or to check through memorizing the max./min. pressure occurred from the system.

◎**Error display function**

| Error display	Description	Troubleshooting
Err1	When external pressure is input while adjusting zero point	Try again after removing external pressure
Err2	When overload is applied on control output	Remove overload
Err3	When setting condition is not met in Auto sensitivity setting mode	Check setting conditions and set proper setting values
LLLL	When applied pressure exceeds Low−limit of display pressure range	Apply pressure within display pressure range
HHHH	When applied pressure exceeds High−limit of display pressure range	
-HH- -LL- -HL-	Auto shift correction error	Set the corrected setting value within setting pressure range.

PSAN Series

▣Installation

1. Pressure port is divided as basic and option specification. Therefore, be sure that to use commercially available one touch fitting. (Standard: R(PT)1/8", Option: NPT1/8", 7/16" − 20 UNF)
2. Please connect it by using spanner(12mm, 17mm) at the metal part in order not to overload on the body when connecting one touch fitting.
3. Two different fixing brackets are provided for PSAN model. Select proper one with considering your application environments.
4. At first, please unscrew hexagon wrench bolt and assemble the bracket on this unit by fixing hexagon the wrenchbolt.

In this case, tightening torque of hexagon wrench should be max. 3kgf · cm.
If not, it may cause mechanical problem.

⚠ Caution

The tightening torque of one touch fitting should be max. 100kgf · cm.
If not, it may cause mechanical problem.

12mm Spanner
⟨Pneumatic type⟩

17mm Spanner
⟨Fluid type⟩

Spring washer
Hexagon wrench bolt (M3x6)

5. Bracket(PSO−B02) and front protection cover (PSO− P01) are sold separately. Please see the pictures for installation.

Panel mounting bracket (**PSO-B02**)
Body (**PSAN**)
Protection cover (**PSO-P01**)
Bracket panel

▣Proper usage

⚠ Caution

PSAN Series is for sensing of non corrosive gas. Do not use this product at corrosive gas or flammable gas, etc.

- Please using this unit within the range of specification, if applying pressure is larger than specification, it may not be working properly due to damage.

- After supplying power, it takes 3 sec. to work.

- When using switching regulator as power supply, it must be grounded(F.G.).

Switching regulator
+
−
F.G.
Ground

- It may cause malfunction by noise, when wiring with power line or high voltage line.

- Do not insert any sharp or pointed object into pressure port.
  It may cause mechanical problem due to sensor damage.

- Do not use this unit with flammable gas, because this is not an explosion proof structure.

- Be sure that this unit should not be contacted directly with water, oil, thinner, etc.

- Wiring must be done with power off.

Autonics

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Autonics *manufacturer:*

Other Similar products are found below :

MT4W-DV-4N CR30-15AO E40S6-2500-6-L-5 LP-S070-T9D6-C5T PRFT30-10DO-V PRFWT12-2DO-IV PRFWT30-10DO-IV TC4W-24R TK4H-14CC TX4S-B4C TX4S-B4S CR30-15AC PRD12-8DN TMHA-42AE TMHE-82RE CX6M-1P2 PRFAT12-2DO-V PRFAWT12-2DO-IV PT4-S3DP5 PT8-S3DP5 SRH2-4440 SRH3-4430 SRHL1-4220 TF33-31H-R E50S8-360-3-T-24 BTF30-DDTL-P PR08-1.5DP2 PRL30-10DP AT8PSN-6 100/120VAC CT6S-2P4 BJ15M-TDT-P E40H12-1000-6-L-5 PRCM12-2DN PRDCM12-4DN PRDCM18-14DN PRDCM18-7DN PRDCM30-25DN PRDCML12-8DN PRDCML18-7DP PRDCML30-25DN SR1-4425 SR3-2450 TK4H-14SC TK4H-14SR TK4M-14RN TK4N-14RC TX4S-A4S PR08-1.5DP PR18-5AO SR3-1440R