



## Screw grommet 57121Z

Romix catalogue number: 57121Z

Quantity in package: 10

Dimensions: A 15,6 C 4,4 F 9,5 G 7,9 H 17

Brand	Model	Location	Description	OEM number
Audi	100 C4	interior pillars	sun visor - grommet, interior pillars trim,	4A0857610
Audi	80 B4	interior pillars	tailgate trim,	4A0857610
Audi	A4 B5	interior pillars	front fenders fixing,	4A0857610
Audi	A5	interior pillars	boot upholstery,	4A0857610
Audi	A6 C4	interior pillars	interior sills overrides	4A0857610
Audi	A6 C5	interior pillars		4A0857610
Seat	Altea	wheel guards		4A0857610
Seat	Ibiza '02-'08	trunk		4A0857610
Seat	Toledo '05-'09	wheel guards		4A0857610
Skoda	Superb '02-'08	sill mouldings		4A0857610
VW	Bora	trunk		4A0857610
VW	Passat B5	trunk		4A0857610

## X-ON Electronics

Largest Supplier of Electrical and Electronic Components

*Click to view similar products for [Screws & Fasteners](#) category:*

*Click to view products by [ROMIX](#) manufacturer:*

Other Similar products are found below :

[5721-1440-1/4-SS](#) [593503FX](#) [0098.0093](#) [0098.0094](#) [0098.9206](#) [0098.9219](#) [0098.9221](#) [0098.9262](#) [596-2114-013](#) [59781-1](#) [59781-4](#)  
[0098.0026](#) [0098.9210](#) [0098.9212](#) [60227-01](#) [60227-04](#) [60227-08](#) [60228-09](#) [618-00001](#) [62153-03](#) [62153-11](#) [M316-KSSTMCZ100](#) [M3440-SS](#)  
[M3442-SS](#) [M3448-SS](#) [6291A](#) [6292-1](#) [6-306105-9](#) [6-306131-4](#) [690432-1](#) [700989](#) [7-18023-1](#) [7-21002-8](#) [7230-3](#) [7235-3](#) [7248-1](#) [7248-2](#)  
[748174-2](#) [F03-02](#) [SUS316](#) [F1209](#) [80011](#) [809704-1](#) [864LW](#) [8700](#) [8860220](#) [9047](#) [95000002B](#) [9521](#) [9885-2](#) [992326-6](#)