10Gig Termination System



Gig Termination Kit...

meets 10-Gig performance standard.




P/N 12515C

- Specifically designed for RJ45 Cat6A/10-Gig shielded connectors (Not for standard RJ45 modular plugs)
- · Minimal hand force
- Straight action crimp
- · Compact & rugged
- · Terminates to industry specified crimp heights
- · Stays securely closed with gun-style lock
- Built-in cable stripper for round wire and flat satin
- · Easily control the blade depth when stripping
- · Built-in cable cutter

Applications:

· Cat6E, Cat6A, Cat7 & over-sized Cat5e/6 industrial Ethernet cables









CT-360 External Ground Crimp Tool

- P/N 12360C
- 360° crimp on the external ground tab of shielded RJ45 connectors
- Perform concentric termination with full control to prevent over or under crimping
- Dual cavity covers wide range of cable ODs ranging from 0.245" to 0.335" (6.2mm - 8.5mm)
- Spring-loaded, non-ratcheted design
- Steel frame, black oxide finish, molded handles





Instructions

1 Strip & remove 1" of your cable jacket with the Cyclops® 2 Cable Stripper (P/N 15010C). Remove cellophane and shield. Straighten the wires.


Use the chart above to determine whether you will be using the T568A or T568B configuration and organize wires accordingly.

T568A/T568B Wiring Chart


Wire	1	2	3	4	5	6	7	8
T568A	W/G	G	W/0	В	W/B	0	W/B	В
T568B	W/0	0	W/G	В	W/B	G	W/B	В



Line up your wires and make a clean cut across all 8 conductors and slide on the wire guide bar.




- (A) Slide bar down toward end of jacket and stop with 3/16" away from the end.
- (B) Flush cut across all 8 conductors at the front end of the bar.
- Reshape the end of the cable using the CT-360 (PN 12360), making it oval so it slides into the connector with ease.




Your cable is ready to be inserted.


4 Carefully insert into backend of connector (A) and push all the way forward (B) until all 8 conductors are seated flush against the front end.

NOTE: DO NOT use a standard RJ45 crimp tool. This connector is designed with NO primary strain relief. Using a standard RJ45 crimp tool will crush the connector.







Insert the prepped connector into the proper cavity of the Tele-TitanXg (P/N 12515C) crimper, Squeeze handle to terminate.




Roll up the drain wire and place in the base of the external ground. As you start to bring the external ground into place onto the cable, keep the mass of drain wire tucked in so it is totally covered.





Use the large or small tool cavity depending on the size of your cable.

NOTE: DO NOT over crimp the external ground.



9 You are finished



PLATINUM TOOLS

Phone: 800.749.5783 Fax: 800.749.5784

California, USA

www.platinumtools.com

We Make Connections EZ!

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for PLATINUM TOOLS manufacturer:

Other Similar products are found below:

15020C 12515 16801C 90170 10531C 106188J 105 004 706BL-1 28038J 17059C T130K3 12100C 11008 90173 600WH-25 18002

18039 18042 90160NW TCC200 T138 10711C 660-12C6 18012 28001J TAR104 TCC220 10503 106148J 100028C 202044J 13109C

15010C 725BL-50 T139 706BL-40 15005C 28006J TP500C 100 011C 13157C 100035C 100054SBL-10C 19002C 19101 10200C

10500C JH64AC-25 18312 TG210C