

## OEM Emergency Fuse Kits

Available for GM®, Ford® and Chrysler/Dodge/Jeep® models, these kits contain MINI®, Low Profile MINI®, JCASE® and/or Low Profile JCASE® fuses for that model. The Littelfuse Emergency Fuse Kits are ideal for the glove box or trunk offering instant protection in the garage or on the road.

Packaging designed to generate impulse sales. Contains the most popular amperages for that brand vehicle.



**General Motors Emergency Fuse Kit**  
Part No: 00940561ZPA

MINI	JCASE
(3) 10 amp	(1) 20 amp
(3) 15 amp	(1) 30 amp
(2) 20 amp	(1) 40 amp
(1) 7.5 amp	(1) 50 amp
(1) 25 amp	LPJCASE
(1) 30 amp	(1) 30 amp
LP MINI	(1) 40 amp
(1) 10 amp	
(1) 15 amp	



**Ford Emergency Fuse Kit**  
Part No: 00940562ZPA

MINI	JCASE
(3) 10 amp	(1) 20 amp
(3) 15 amp	(1) 30 amp
(2) 20 amp	(1) 40 amp
(1) 7.5 amp	(1) 50 amp
(1) 25 amp	LPJCASE
(1) 30 amp	(1) 30 amp
LP MINI	(1) 40 amp
(1) 10 amp	
(1) 15 amp	



**Chrysler/Dodge/Jeep Emergency Fuse Kit**  
Part No: 00940563ZPA

MINI	JCASE
(3) 10 amp	(1) 20 amp
(3) 15 amp	(1) 30 amp
(2) 20 amp	(1) 40 amp
(1) 7.5 amp	(1) 50 amp
(1) 25 amp	
(1) 30 amp	



## X-ON Electronics

Largest Supplier of Electrical and Electronic Components

*Click to view similar products for [Fuse Kits & Assortments](#) category:*

*Click to view products by [Littelfuse](#) manufacturer:*

Other Similar products are found below :

[12052472](#) [194-044-9-001](#) [FUSE-2A/600VBLSTR](#) [00950000XXN](#) [SF-LAB1](#) [203411](#) [00940551Z](#) [00940367ZP](#) [ERK-28J](#) [00940553Z](#)  
[00940419ZP](#) [CFBAR1-250BP](#) [32BS](#) [3004000](#) [521.800](#) [522.800](#) [632.830](#) [GSK-260](#) [ORBOX006Z](#) [12146815](#) [SF-SP-LAB1](#) [FUSE-](#)  
[11A/1000V](#) [B1](#) [0695020.L](#) [0AGC0001ZPGLO](#) [00940558ZPA](#) [632.800](#) [812404](#) [12160438](#) [12160541](#) [SF-KIT-AUTO-1](#) [SF-KIT-AUTO-2](#)  
[SF-KIT-HC-1](#) [SF-KIT-HV-1](#) [12004943](#) [12010105](#) [12160504](#) [BK/ATC-TAP](#) [BK/ATM-TAP](#) [BP/ATM-TAP-RP](#) [CDY10TRY-ATM-LP](#)  
[CDY10TRY-FLNK2](#) [CDY10TRY-MAX](#) [CDY5TRY-BMOUNT](#) [CDY5TRY-FMX](#) [CDY5TRY-SMOUNT](#) [FUSE-ACC-KIT](#) [FUSE-CADDY1](#)  
[FUSE-CADDY2](#) [NO270](#) [203403](#)