



### BU-P6383-02

(Red and Black Pair of Shrouded 4mm Banana Jack with Insulators)



- Used on stranded wire from 18 to 22 AWG with an insulator diameter from 0.06" to 0.15".
- Attach to wire with available crimp tools or by soldering.
- Provides safe and secure connections to 4mm shrouded banana jacks recessed for shrouded plugs.
- Compatible with most digital multimeters (Fluke, Wavetek, Agilent, Amprobe, Greenlee and others).
- Material:
  - Banana Jack – Nickel plated Brass
  - Insulation – Santoprene (Thermoplastic Elastomer)
- Ratings:
  - Hands free testing up to 1,500 V Max.
  - Operating Voltage: 300V Cat II (Handheld)
  - Current: 15 Amps
  - Operating Temperature: -20°F (-29°C) to 275°F (135°C)
- RoHS 3 Compliant, **CE** Certified

**Assembly Instructions:** (Wire Not Included)



1. Slide Insulator over wire
2. Crimp/Solder wire to Banana Plug
3. Pull wire and slide insulator over banana plug
4. Insulator will lock into place once you have pulled it far enough over the plug.

## X-ON Electronics

Largest Supplier of Electrical and Electronic Components

*Click to view similar products for [Test Plugs & Test Jacks](#) category:*

*Click to view products by [Mueller](#) manufacturer:*

Other Similar products are found below :

[01-2601-4-0210](#) [01-2601-4-0212](#) [01-2604-4-0212](#) [01-2350-1-02](#) [01-2368-1-02](#) [01-2606-4-0210](#) [01-2606-5-0212](#) [M39024/11-09G](#)  
[M39024/11-42](#) [M39024/11-43](#) [M39024/12-08](#) [707-5311](#) [707-5402-01-19](#) [707-5410](#) [R948161000](#) [1408-4](#) [1533-1](#) [1659559](#) [1659567](#)  
[1663921](#) [1663939](#) [1696-102](#) [174-R825B-EX](#) [1905509](#) [1905527](#) [1914916](#) [211-101](#) [RS100GBL](#) [RS250GBL](#) [251-102](#) [25-2251-2-03](#) [25-](#)  
[2259-2-03](#) [923743-28-I](#) [2854-BLU](#) [2970-BLK](#) [30-443G](#) [1909861](#) [1916120](#) [1916466](#) [1918007](#) [1919515](#) [1920271](#) [1929125](#) [1933440](#)  
[1938303](#) [1944375](#) [204-103](#) [2079](#) [2435108](#) [2803-102](#)