

Web Site: www.parallax.com
Forums: forums.parallax.com
Sales: sales@parallax.com
Technical: support@parallax.com

**Office:** (916) 624-8333 **Fax:** (916) 624-8003 **Sales:** (888) 512-1024 **Tech Support:** (888) 997-8267

# XBee Adapter Board (#32403)

This low cost XBee Adapter Board comes in a kit form and provides a cost-effective solution to interfacing to any XBee or XBee Pro module. By using this adapter board you can provide an easy interface to the XBee or XBee Pro modules by converting the 2mm pin spacing to breadboard friendly 0.100" spacing. The adapter boards also provide a means to connect pluggable wires or solder connections and also provide mounting holes.

#### **Features**

- Converts XBee 2mm pin spacing to 0.100" pin spacing
- Provides easy pluggable wire or solder connections
- Includes mounting holes
- Pin-out compatible with our other XBee Adapter boards
- Kit form for flexible configuration



#### **Key Specifications**

- Power requirements: 3.3V pass-through to XBee module
- Communication: Serial pass-through to XBee module
- Operating temperature: -40 to +185°F (-40 to +85°C)
- Dimensions: 1.16" L x 1.00" W x 0.58" H\* (29.4 mm x 25.6 mm x 14.8 mm\*)
  - \* when headers are attached

### **Application Ideas**

- Easy connection of XBee modules to breadboard or proto board
- Convenient way to mount the XBee module away from the microcontroller

## **Packing List**

- (1) XBee Adapter Board PCB
- (2) 10-pin 2mm sockets
- (1) 40-pin SIP header


## **Tools Required**

- Soldering Iron (always wear safety glasses when soldering)
- Solder (some soldering experience required)
- Flux (if not using rosin/flux-core solder)
- Diagonal cutters or Exacto knife (optional)

# **Assembly Instructions**


#### Step 1:

Check to ensure your kit contains the following parts as shown in the photo.




#### Step 2:

Install the 2mm sockets on top of the PCB as shown and solder them in place from the bottom side of the board.



#### Step 3:


Using an Exacto knife, hobby knife or a pair of diagonal cutters, cut two 11pin headers from the 40-pin header. Extra header material was included in case of a mistake or damaged header.




#### Step 4 (optional):

Insert the two 11-pin SIP headers into the bottom of the adapter board as shown and solder them in place from the top.

This step is optional in that you could leave the headers out and solder wires into the pads instead if you wish.




### **Adapter Board Dimensions**



### **Adapter Board Schematic**

The schematic below shows the relationship between the connections on the XBee module (outer sockets) and the headers from the Adapter Board. Please note that the lower-right pin (labeled VDD) is not used on this adapter but is shown for compatibility with our other XBee Adapter boards.



# **X-ON Electronics**

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Sockets & Adapters category:

Click to view products by Parallax manufacturer:

Other Similar products are found below:

6508-0-00-01-00-00-33-0 AC164348 1262 22827 AC164353 TDGL015 SA247 SM64TQ-ACTEL-1 70-0036 8.06.03 DS91230+ SMPA-ISP-ACTEL-3-KIT 16017 LFVDBGF KIT 70601-3 SM132CQ-ACTEL IPC0181 IPC0175 IPC0165 AC164397 conga-Thin MITX/eDP to DP Adapter SLG46621V-SKT SLG46722V-SKT ML-ADP-EVN ASA.01 ASA.09 ASA.12 ASA.14 TOOLSTICK990MPP MIKROE-425 C305000ACP2 110-83-320-41-605101 110-83-632-41-605101 110-83-640-41-605101 110-83-628-41-605101 116-83-306-41-001101 PA0003 PA0007 PA0009 PA0035 PA0085 PA0096 IPC0079 ATARD-DBGADPT 80-000286 ATSTK600-RC26 ATSTK600-RC46 ATSTK600-RC78