
MP05MA PowerBank Instruction Manual





Read the instruction manual thoroughly before use. Keep the manual for future reference.



Operating instructions

Recharging the PowerBank

 Connect the Micro-USB port of the PowerBank with a power source (computer or USB power adapter, output: 1A or above) through the provided USB charging cable (see figures below).



You can use the PowerBank to charge other devices (using USB-A port) while it is being recharged (see chapter "Charging other devices").

 Disconnect the USB charging cable when all LED indicators are lit.

Charging other devices

 Connect the fully-charged PowerBank with the device through the provided USB charging cable or the cable provided by the device's manufacturer. Select either one USB-A port, or use both ports for charging (see figures below).



 Disconnect the USB charging cable when charging is complete. The PowerBank will turn off automatically.

LED indicators

 Refer to the LED indicators for battery level during charging or recharging. The PowerBark has the best battery strength when all LED indicators are lit. Before use, the battery level can be checked by pressing the power button once. Depending on the battery level, the last applicable LED indicator flashes when the PowerBank is being recharged and all applicable LED indicators remain It when it is charging other devices. When the PowerBank is being charged and charging another device at the same time, the last applicable LED indicator flashes.

Usage tips

- If the PowerBank does not work, unplug the USB charging cable and reconnect it.
- It is normal that the PowerBank gets warm during use. It will gradually cool down to room temperature after fully discharged or recharged.

Specifications

- Input : DC 5V / 1A
- Output : USB-A x 2 DC 5V / 2.1A (Total 2.1A)
- Dimension : 135.5(L)×70(W)×10(H)mm
- Weight : 147g
- Operating temperature : 5 °C to 40 °C
- Battery : Lithium Polymer 3.7V 5000mAh
- Recharging time : 5.5 hours^
- Recharging time may vary under different operating conditions. Longer recharging time may be required when using for the first time.

Safety information

Please read below safety notes carefully before use to avoid any personal injury and property damage caused by improper use of the product. Any warrantly claims or returns caused by misuses will not be accepted.

- Keep the product away from children and infirm persons.
- Keep the product away from heat sources, combustible gas, humidity and liquids.
- Do not attempt to repair, disassemble or destroy the product in any way.
- Keep the product away from metallic or conductive objects to avoid short-circuit.
- Do not operate a wet or otherwise damaged product.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak

into the groundwater and get into the food chain, damaging your health and well-being.

X-ON Electronics

Authorized Distributor

Click to view similar products for Battery Packs category:

BP7217 CL18700HT48 VL PA0126P LP573450HV PA0127W PA0142B PA0142W **GPMP10MAO** ACCU280PIR AMID CGA1034504S 1P

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Battery Packs category:

Click to view products by

GP Batteries manufacturer:

Other Similar products are found below :

2280309-1

R101-B

220AAH-B AA

E92 MAX

E91 MAX

4114 210 501

4120 210 501

LR03/AAA/M N2400(K4) LR03 MAXELL S4 LR1130 MAXELL B10 LR14-MN1400-C K2 LR1/910A LR43 LR43 MAXELL B10 LR6 MAXELL S4 11012 E23A E90 625302 625304 637871 638006 6LF22/9V/MN 1604(K1)C&B 6LF22/9V/MN 1604 PLUS

6LR61 SR626SW MAXELL **SR920SW** MAXELL 7K67 J 55615303059 55615702012 GP14A S2 GP **15AU ULTRA** PLUS B4

GP15E GP1604GLF-2UE1 GP 1604 **ULTRA PLUS** GP 24AU ULTRA PLUS B4 23733 10 ET

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Battery Packs category:

Click to view products by GP Batteries manufacturer:

Other Similar products are found below :

2280309-1 R101-B 4114 210 501 4120 210 501 4600 726 406 4610 726 406 312G-U1 55615703012 3LR12 4103 210 392 4103 210 394 4106 210 392 4106 210 394 4223 210 501 4606 726 406 4607 726 406 ZA13 LR03/AAA/MN2400(K4) LR03 MAXELL S4 LR1130 MAXELL B10 LR14-MN1400-C K2 LR1/910A LR41 MAXELL B10 LR43 LR43 MAXELL B10 LR6 MAXELL S4 11012 E23A E90 625302 625304 637871 638006 6LF22/9V/MN1604(K1)C&B 6LF22/9V/MN1604 PLUS 6LR61 SR626SW MAXELL S8920SW MAXELL 7K67 J 55615303059 GP14A S2 GP15E GP1604GLF-2UE1 GP 1604 ULTRA PLUS 23733 10 ET 675 ET 11A B5 A544 A76-U10