

Thanks for purchasing the **PLPTS**, a professional DJ laptop stand great for mixing it up at gig. The plastic and steel construction is durable enough to get you through any gig, any time, anywhere.



Specifications:

- Portable Laptop/Notebook Desk/Workstation
- Easily Adjustable Height
- Stand For Musicians, DJs, Based Performances
- Plastic Material Counter Construction
- Black High Gloss Finish
- Steel Frame Construction

Your kit includes one (1) set of the following items:



- 1 x tripod base
- 1 x laptop surface
- 2 x support brackets
- 4 x washers (on support brackets)
- 4 x gold screws (on support brackets)
- 4 x wing nuts (on support brackets)

Note: your stand may include different parts. If so, please check *Version 1* of this manual on www.PyleAudio.com.

1. Familiarize yourself with the tripod.



Note that knob (a) is for raising and lowering the T-bar, knob (b) is for opening and closing the tripod legs, and bar (c) secures the t-bar in place.

2. Next, prepare the support brackets. Remove the screws, washers, and nuts. Unscrew the knob. Then snap the bracket onto the t-bar.





3. Repeat this process for the next support bracket. Snap it on to the other side of the tbar. When reinserting the knob, make sure not to tighten too much, as you'll need to adjust their position to line up with the laptop plate.



4. Line up the two support brackets with the screw holes on the laptop plate. Insert each of the four screws.



5. From underneath the tripod, add a washer and wing nut to each screw to hold in place. They should look like this once installed.



6. Tighten the screws from above using a screwdriver to secure everything into place.



7. You can raise the stand by loosening knob (a) and raising the stand. Make sure to use bar (c) to secure the t-bar.



8. Congratulations - your stand is now complete!



X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for pyle manufacturer:

Other Similar products are found below :

PDS442 PSPVC6 PDWM4300 PDWM4400 PDMW6 PDBT28 PDJSD2 PLRSTND10 PLG3.2 PSCRIM2B PSCRIM2W PDWM2115 PDWM1904 PSTND1 PPA15 PPA10 PDS341 PDS122 PDMW5 PLAM40 PFN41 PCT40 PPA6 PDMR6 PPA8 PDS221