DATA SHEET



# **Redundancy unit CP-C.1-A-RU**

# Accessory for CP range power supplies

ABB's redundancy units are used to establish true redundancy which increases the availability of electrical systems significantly.



2CDC 271 001 V0018


## **Characteristics**

- Decoupling of CP power supply units with 2 inputs, each up to 20 A per input / channel
- Output up to 40 A
- True redundancy by 100 % decoupling of two parallel connected power supplies
- 2 integrated diodes for the decoupling of 2 switch mode power supplies up to 20 A
- Device with coated PCBA for harsh environments and with extended temperature range
- Various certifications and approvals (see overview, document no. 2CDC114098D0201)

# Ordering details - CP-C.1-A-RU for decoupling of CP power supplies up to 20 A per input / channel

Input voltage range	Rated input current per channel	Rated output voltage /current		Туре	Order code	Weight (1 pc.) kg (lb)
10 - 58 V DC 20 A	20 A	12-48 V DC / 2 x 20 A	uncoated	CP-C.1-A-RU	1SVR360060R1001	1.04 (2.29)
	or 1 x 40 A	coated	CP-C.1-A-RU-C	1SVR360060R2001	1.04 (2.29)	
			uncoated	CP-C.1-A-RU-L	1SVR361060R1001	1.04 (2.29)

# **Function**



- 1 INPUT 1, 2: Terminals – input
- 2 Circuit diagram
- 3 OUTPUT ++/--Terminals – output

## **Application**

The redundancy unit CP-C.1-A-RU provides decoupling of two CP power supply units. It provides automatic redundant power supply operation for critical applications. It has 2 inputs, each up to 20 A, and 1 output up to 40 A.


# **Operating mode**

# True redundancy with decoupling provided by the CP-C.1-A-RU and CP-C.1-A-RU-C

Redundant circuits are used to increase the operational reliability and eliminate power supply outages. Events that can cause a power supply failure include: incorrect wiring, blown fuses, or failure of a single power supply. If a fault event occurs (called initial fault) in the first power supply circuit, power to all loads is then supplied by the second (redundant) power supply. For this reason, both power supplies must be sized to handle the total current requirement of all loads. The primary and the redundant power supplies are decoupled from one another by the CP-C.1-A-RU unit.

It automatically switches from the primary to the redundant supply after a fault. It decouples the output of the failed power supply from the redundant supply preventing the initial fault from shorting or compromising the redundant supplies' output. In this way, uninterrupted supply of power to all loads is guaranteed. When available, the two power supplies should be connected to different input voltage phases, to avoid loss of power caused by a blown fuse on the primary side of the power supplies.


### True redundancy, $I_{out} \le I_r$




## Parallel operation for increased power

Another operation mode of two power supplies in combination with a redundancy unit is to parallel and decouple them for increased power. The setup looks similar to the true redundant installation above but the field of application is different. Instead of redundancy the max. output current (limits see under the schematics) can be used to power up the loads. The redundancy module decouples both power supplies from each other to avoid that any electrical failure from one power supply circuit affects the other one. However, using the increased power also means there is no redundancy since if one supply fails the other one can not supply the load alone.


## Increased power, $I_{out} \geq I_r$






# **Mounting**

To mount the unit place the upper edge of the DIN rail adapter on the upper edge of the DIN rail holding the unit slightly tilted upwards as shown in the illustration. Then tilt the unit down until the latch snaps onto the DIN rail.




## **Mounting positions**




In order to ensure a sufficient convection in mounting position 1 and 7, the minimum distance to other modules must not be less than 25 mm in vertical direction and 25 mm in horizontal direction. For the derating of the output current, see the characteristic curve of temperature. Details for other mounting positions on request.

2CDC 273 008 F0015

## Mounting CP-C.1-A-RU in position 7






To mount the power supply in position 7 remove the DIN rail adapter that is fasten with 4 screws and attach it on the side of the power supply.

Screwdriver: Torx T10

Tightening torque: 0.7 ±0.1 Nm

# **Demounting**

To release the unit pull the latching lever downwards with a screwdriver and press the upper side of the the latching lever down. The device can be unhinged from the DIN rail and removed.



## **Electrical connection**


## Input side [INPUT 1 + - / INPUT 2 + -]

Connect the input terminals, stripping length of the cable – see technical data. For channel 1 left-hand input terminals + -, for channel 2 right-hand input terminals + -.

## Output side [OUTPUT ++ --]

Rate the lines for the maximum output current or provide a separate fuse protection. We recommend to choose the cable cross section as large as possible in order to minimize voltage drops. Observe the polarity.

## **Connection diagram**



INPUT 1 +, - Connection of the output of power supply unit 1
INPUT 2 +, - Connection of the output of power supply unit 2

OUTPUT ++, -- Output for load

## Safety instructions and warnings



### In operation pay attention to:

- Do not modify the installation (primary and secondary side)! High current!
   Risk of electric arcs and electric shock (danger to life)!
- · Risk of burns: Depending on the operation conditions the housing can become hot.
- The device contains no user serviceable parts. In any case of device malfunction please send the unit back to manufacturer.

The device must be installed by qualified persons only and in accordance with the specific national regulations (e. g. VDE, etc.).



The CP-C.1 redundancy units are chassis-mounted units. It is maintenance-free and does not contain any integral setting elements and should therefore not be opened.



### Before any installation, maintenance or modification work:

- Read the operating and installation instructions carefully and completely!
- Disconnect the system from the supply network and protect against switching on!



### CAUTION

Improper installation/operation may impair safety of personnel and cause operational difficulties or destruction of the unit.



### **WARNING**

### Before start of operation the following must be ensured:

- Connection to mains or DC supply according to the specific national regulations for class of protection I.
   Power supply cables and unit must be sufficiently fused. A disconnecting device has to be provided for the end product to disengage unit and supply cables from supply mains if required.
- Rate the output lines for the output current of the power supply and connect them with the correct polarity.
- · In order to ensure sufficient convection the distance to the other devices has to be considered.



## WARNING

### Danger to life!

Never carry out work when voltage is present. The power supply contains components with high stored energy and circuits with high voltage! Do not introduce any objects into the unit and do not open the unit. With some units of this range the output is capable of providing hazardous energy. Ensure that the service personnel is protected against inadvertent contact with parts carrying energy. If the internal fuse is blown most probably the device is defect. In this case an examination of the device by the manufacturer is necessary.

# **Technical data**

Data at  $T_a$  = 25 °C,  $U_{in}$  = 230 V AC and rated values, unless otherwise indicated

\_

## Input circuit - Supply circuit

Туре		CP-C.1-A-RU, CP-C.1-A-RU-L	CP-C.1-A-RU-C
Input circuit - Supply circuit		(+/+, -/-)	
Rated input voltage U <sub>in</sub>		12-48 V DC	
Input voltage range		10 - 58 V DC	
Rated input current lin per channel	-25 °C $\leq$ T $_a$ $\leq$ 60 °C	20 A	
Mariana da mariana da maria	-25 °C $\leq$ T $_a$ $\leq$ 40 °C	30 A	
Maximum input current per channel	$-40  ^{\circ}\text{C} \le \text{T}_{a} \le 40  ^{\circ}\text{C}$	-	30 A
Transient overvoltage protection		yes, varistor	,
Rated frequency		(++/)	
Rated output voltage U <sub>out</sub>		12-48 V DC	
Voltage drop input/output		typ. 0.6 V, max. 0.9 V	
Rated output current $I_r$ -25 °C $\leq$ $T_a \leq$ 60 °C		2 x 20 A or 1 x 40 A	
Many authorit august (naugust paganga)	-25 °C $\leq$ T $_a$ $\leq$ 40 °C	2 x 30 A or 1 x 60 A	
Max. output current (power reserve)	$-40  ^{\circ}\text{C} \le \text{T}_{a} \le 40  ^{\circ}\text{C}$	- 2 x 30 A or 1 x 60 A	
Derating of the output current $60  ^{\circ}\text{C} < T_a \le 70  ^{\circ}\text{C}$		2.5 % per Kelvin temperature increase	
Resistance to reverse feed		< 60 V	

\_

## General data

Powerloss	input 2 x 20 A	23.0 W
	input 2 x 10 A	9.4 W
	input 2 x 5 A	4.1 W
МТВБ	acc. to MIL 217 HDBK	on request
Dimensions		see "Dimensional drawings"
Material of housing	cover / housing shell / front	aluminium / zinc-coated sheet steel / plastic
Mounting		DIN rail (IEC/EN 60715), snap-on mounting
Mounting position		1 and 7
Minimum distance to other units	horizontal / vertical	25 mm (0.98 in) / 25 mm (0.98 in)
Degree of protection (IEC/EN 60529)	housing / terminals	IP20 / IP20
Protection class (IEC/EN 61140)		III

\_

## **Electrical connection**

Input circuit / Output circuit		CP-C.1-A-RU, CP-C.1-A-RU-L	CP-C.1-A-RU-C
Connecting capacity	rigid	d 2.5-16 mm² (12-6 AWG)	
	fine-strand with(out) wire end ferrule	2.5-10 mm² (12-8 AWG)	
Stripping length		10 mm (0.39 in)	
Tightening torque		1.2 Nm (10.5 lb.in)	
Recommended screw driver		PH1 / Ø 4.0 x 0.8 mm (0.16 x 0.03 in)	

## **Environmental data**

		CP-C.1-A-RU, CP-C.1-A-RU-L	CP-C.1-A-RU-C	
	operation	-25+70 °C (-13 +158 °F)	-40+70 °C (-40+158 °F)	
A malais and de among a made i ma a mag	rated load	-25+60 °C (-13 +140 °F)	-40+60 °C (-40+140 °F)	
Ambient temperature range	storage	-40+85 °C (-40+185 °F)		
	transportation	-40+85 °C (-40+185 °F)		
Climatic class (IEC/EN 60721-3-1)	storage	1K2		
Climatic class (IEC/EN 60721-3-2)	transportation	2K2		
Climatic class (IEC/EN 60721-3-3)	operation	3K3		
Damp heat, cyclic (IEC/EN 60068-2-30)		test Db: 55°C, 2 cycles		
Vibration (IEC/EN 60068-2-6)		test Fc: 10-58 Hz, amplitude ±0.15 mm, 58-150 Hz, 2 g, 10 sweep cycles each axis		
Shock, half-sine (IEC/EN 60068-2-27)		test Ea: 30 g, 6 ms, 3 pulses each axis; bump 20 g, 11 ms, 100 pulses each axis		
Coated PCBA		no	yes	
Gaseous corrosive environment withstand test (IEC/EN 60068-2-60)		-	testing method: 4 testing period: 21 days ambient conditions: 25 °C, 75 % r.h. air/volume change rate per hour: 3-6 sample not energized during exposure gas concentrations acc. ISA-S71.04.2013 Harsh Group A, G3 IEC 60721-3.3 acc. 3C2/3C3 $- H_2S \geq 100 \pm 10 \text{ ppb}$ $- SO_2/SO_3 \geq 300 \pm 20 \text{ ppb}$ $- Cl_2 \geq 100 \pm 10 \text{ ppb}$ $- NOX \geq 1250 \pm 20 \text{ ppb}$	

## Isolation data

		CP-C.1-A-RU, CP-C.1-A-RU-L	CP-C.1-A-RU-C
Rated impulse withstand	input circuit / output circuit	t 1.5 kV (1.2/50 µs)	
voltage U <sub>imp</sub> (EN 62477-1)	input circuit / PE	1.5 kV (1.2/50 µs)	
Pollution degree		2	


## Standards / Directives

	CP-C.1-A-RU, CP-C.1-A-RU-L	CP-C.1-A-RU-C	
Standards IEC/EN 61204		'	
EMC Directive 2014/30/EU			
ATEX Directive		2014/34/EU	
RoHS Directive 2011/65/EU			
Electrical safety	IEC/EN 61010-1, IEC/EN 61010	IEC/EN 61010-1, IEC/EN 61010-2-201, IEC 60950-1	
Process control equipment	UL 61010-1, UL 61010-2-201/C CAN/CSA-IEC 61010-2-201:18	UL 61010-1, UL 61010-2-201/CAN/CSA C22.2 no. 61010-1-12, CAN/CSA-IEC 61010-2-201:18	

## **Electromagnetic compatibility**

		CP-C.1-A-RU, CP-C.1-A-RU-L	CP-C.1-A-RU-C
nterference immunity to	,		
electrostatic discharge IEC/EN 61000-4-2		Level 4, contact discharge 8 kV, air discharge 15 kV (criterion B)	
electrical fast transient / burst	IEC/EN 61000-4-4	-4-4 Level 3, DC mains inputs and output ±2 kV (criterion B)	
surge IEC/EN 61000-4-5 Level 1, DC mains inputs and output ±0.5 kV, input vs. PE ±1 kV (criterion B)		put ±0.5 kV, input and output	

## **Dimensions**



## **Further documentation**

Document title	Document type	Document number
Electronic relays and controls	Catalog	2CDC 110 004 C02xx
Redundancy unit	Instruction manual	1SVC 360 561 M0000
Additional information and notes on safety (ATEX)	Instruction manual	1SVC 360 560 M9000

You can find the documentation on the internet at www.abb.com/lowvoltage

-> Automation, Control and Protection -> Power supplies.

# **CAD** system files

You can find the CAD files for CAD systems at

http://abb-control-products.partcommunity.com

-> Low Voltage Products & Systems -> Control Products -> Electronic Relays and Controls.



## **X-ON Electronics**

Largest Supplier of Electrical and Electronic Components

Click to view similar products for DIN Rail Power Supplies category:

Click to view products by ABB manufacturer:

Other Similar products are found below:

DVP01PU-S DVP06AD-S DVPPS02 PS9Z-5R1G PS-C24024 ADNB017-24-1PM-C ADNB040-24-1PM-C ADNB034-12-1PM-C SS14011524 PS-UPS40 S8T-BUS03 PS-S4024 NTPS-24-1.3 PS-10024 PS-S10024 PS-C12024 PSP-480S24 PS-C48024 PS-C480P24 PSC-2024 PSC-4012 PSC-4048 PSC-9615 PSC-15124 PSC-15148 PSC-24148 PSC-48148 TRIO-PS-2G/1AC/12DC/5/C2LP PSS18/24/0.75 PSS120/24/5 96PSD-A40W24-MM PSD-A120W12 NDR-7524 NDR-12024 SCP30D512-DN SCP30S24-DN SDN20-24-100C SDN40-24-480C AMED75-48SJZ 1SVR427043R1200 1110466 50995 50903 50997 EL50-D 18924-9989 50996 HDN-3024 LWR1601-6ER 1170952