



Model: **AK-SW-10**



Product code	AK-SW-10
Compatible with	Samsung
USB output voltage	5 V / 1 A
Power supply connector	USB
Cable length	1 m
Product size (L x W x H)	53 x 46 x 46 mm
Package size (L x W x H)	160 x 115 x 47 mm
Net weight	48 g
Gross weight	51 g
CE compatibility	Yes
RoHS compatibility	Yes
REACH compatibility	Yes
EAN code	5901720136596
Warranty	24 months



Description

The **Akyga® AK-SW-10 charging stand** has been created **for Samsung smartwatches**. It has a specially contoured shape that ensures a perfect fit of the smartwatch to the wireless charging surface. What's more, the vertical part of the charger is equipped **with magnets**, which are designed to keep the watch in the right position during charging. This prevents the smartwatch from slipping and is thus protected against accidental knocking it off the station.

An undoubted advantage of the charger is the high quality finish. At the bottom of the stand there is an **anti-slip rubber pad**. It increases the grip of the stand, while reducing the chances of unwanted sliding on the surface of the desk or table. The upper part has a nice to the touch coating, which protects your watch from scratches.

The stand has a **detachable micro USB - USB** cable with a length of **1 m**. This solution allows you to change the length of the connected cable, depending on your needs. In addition, the universal **USB connector** allows you to freely choose the power source. It can be both a desktop computer, notebook, AC adapter and a travel powerbank.

On the front of the stand, an LED has been placed. The built-in **tell-tale** changes colour to red, blue and green depending on the charging status.

Fits the Gear S2, Gear S3 Frontier, Gear S3 Classic, Galaxy Watch 42 mm and Galaxy Watch 46 mm, among other models.

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for [Akyga manufacturer](#):

Other Similar products are found below :

[AK-CA-36](#) [AK-AD-25](#) [AK-AD-32](#) [CPSUNOTAKY-07056](#) [CPSUNOTAKY-07340](#) [CPSUNOTAKY-07812](#) [AK-CH-10](#) [AK-U4-800](#) [AK-USB-33](#) [CPSUNOTAKY-07707](#) [CPSUNOTAKY-07714](#) [AK-CA-29](#) [AK-CA-66](#) [AK-CH-09](#) [AK-AD-46](#) [AK-AD-66](#) [AK-I2-150](#) [AK-T1-250](#) [AK-AV-16](#) [AK-USB-20](#) [AK-P3-650](#) [AK-CA-13](#) [AK-CA-40](#) [AK-SC-07](#) [AK-SC-14](#) [AK-AD-39](#) [AK-CH-08](#) [AK-S1-300](#) [AK-U4-600](#) [AK-B1-950](#) [AK-SW-11](#) [AK-SW-15](#) [CPSUNOTAKY-07169](#) [CPSUNOTAKY-07312](#) [CPSUNOTAKY-07289](#) [CPSUNOTAKY-07399](#) [CPSUNOTAKY-07540](#) [CPSUNOTAKY-07708](#) [AK-U4-400](#) [AK-CA-34](#) [AK-AV-03](#) [AK-AD-23](#) [AK-AD-40](#) [AK-AD-02](#) [AK-SW-12](#) [AK-AD-30](#) [AK-AD-57](#) [AK-SW-13](#) [AK-SW-02](#) [AK-SW-03](#)