



## TinkerKit Blue LED [10mm]



### Overview

The **LED** is possibly the simplest actuator available. It's a low power light source available in many colors. It lights up when powered from an Arduino pin.

**Input:** Arduino provides a maximum of 40 mA per pin; this is enough to light up the LED through the `digitalWrite()` and `analogWrite()` functions.

**Module description:** this module features a 10mm Blue Light Emitting Diode, the standard TinkerKit 3pin connector and a green LED that signals that the module is correctly powered and a tiny yellow LED that shows the current brightness of the blue LED. A resistor provides the optimal amount of current when connected to an Arduino.

This module is an **ACTUATOR** therefore the connector is an **INPUT** that need to be connected to one of the **OUTPUT** connectors on the **TinkerKit Shield**.

## Code Example

```
/*  
based on Blink, Arduino's "Hello World!"  
Turns on an LED on for one second, then off for one second, repeatedly.  
The Tinkerkit Led Modules (T010110-7) is hooked up on O0
```

```
This example code is in the public domain.  
*/
```

```
#define O0 11  
#define O1 10  
#define O2 9  
#define O3 6  
#define O4 5  

```

```
void setup() {  
  // initialize the digital pin as an output.  
  // Pin 13 has an LED connected on most Arduino boards:  
  pinMode(O0, OUTPUT);  
}
```

```
void loop() {  
  digitalWrite(O0, HIGH); // set the LED on  
  delay(1000); // wait for a second  
  digitalWrite(O0, LOW); // set the LED off  
  delay(1000); // wait for a second  
}
```

## X-ON Electronics

Largest Supplier of Electrical and Electronic Components

*Click to view similar products for [LED Lighting Development Tools](#) category:*

*Click to view products by [Arduino](#) manufacturer:*

Other Similar products are found below :

[MIC2870YFT EV](#) [ADP8860DBCP-EVALZ](#) [LM3404MREVAL](#) [ADM8843EB-EVALZ](#) [TDGL014](#) [ISL97682IRTZEVALZ](#) [LM3508TLEV](#)  
[EA6358NH](#) [MAX16826EVKIT](#) [MAX16839EVKIT+](#) [TPS92315EVM-516](#) [MAX6956EVKIT+](#) [OM13321,598](#) [DC986A](#) [DC909A](#) [DC824A](#)  
[STEVAL-LLL006V1](#) [IS31LT3948-GRLS4-EB](#) [PIM526](#) [PIM527](#) [MAX6946EVKIT+](#) [MAX20070EVKIT#](#) [MAX21610EVKIT#](#)  
[MAX6951EVKIT](#) [MAX20090BEVKIT#](#) [MAX20092EVSYS#](#) [PIM498](#) [AP8800EV1](#) [ZXLD1370/1EV4](#) [MAX6964EVKIT](#) [TLC59116EVM-](#)  
[390](#) [1216.1013](#) [TPS61176EVM-566](#) [TPS61197EVM](#) [TPS92001EVM-628](#) [1270](#) [1271.2004](#) [1272.1030](#) [1273.1010](#) [1278.1010](#) [1279.1002](#)  
[1279.1001](#) [1282.1000](#) [1293.1900](#) [1293.1800](#) [1293.1700](#) [1293.1500](#) [1293.1100](#) [1282.1400](#) [1282.1100](#)