




## PC SPACER SUPPORT




PARTNO	A	PACKAGE
MSP-3	3.2	1000
MSP-5	5.0	
MSP-6	6.3	
MSP-7	7.0	
MSP-8	8.0	
MSP-9	9.5	
MSP-10	10.5	
MSP-12	12.7	
MSP-14	14.0	
MSP-15	15.9	
MSP-19	19.0	
MSP-22	22.0	

## PC SPACER SUPPORT



PARTNO	PACKAGE
MSPM-24	1000

## PC SPACER SUPPORT



PARTNO	A	PACKAGE
MSPS-3	3.2	2000
MSPS-5	4.8	1000