

"If any part of the loop should open (become disconnected or have out of limit resistance), the circuit will go into the alarm state" [ref TR20.20], nonetheless, due to the redundancy inherent in the dual wire wrist strap design, the operator will continue to be grounded via the second intact wire.

Per ESD Handbook TR20.20 section 5.3.9.2.2 Dual Conductor Resistance Continuous Monitors, "This type of monitor is used with a two wire (dual conductor) wrist strap. The wrist strap assembly consists of a two-wire ground cord and a wristband that has two isolated halves. When a person is wearing the wrist strap properly, the monitor measures the loop resistance consisting of one wire of the ground cord, one-half of the wristband, the person's skin, the second half of the wristband, and a second wire in the ground cord. If any part of the loop should open (become disconnected or have out of limit resistance), the circuit will go into the alarm state.

ESD Handbook TR 20.20 paragraph 5.3.2.4.4 Test Frequency "Because wrist straps have a finite life, it is important to develop a test frequency that will guarantee integrity of the system. Typical test programs recommend that wrist straps that are used daily should be tested daily. However, if the products that are being produced are of such value that knowledge of a continuous, reliable ground is needed, and then continuous monitoring should be considered or even required"

Continuous Monitors pay for themselves improving quality, productivity, eliminating wrist strap daily testing and test result logging. Per ESD-S1.1 paragraph 6.1.3 Frequency of Functional Testing "Daily [Wrist Strap] testing may be omitted if constant monitoring is used."

Improve wrist strap contact with Reztore™ ESD Hand Lotion

*U.S. Patents 6,052,053 and 6,205,408



Made in America

Unless otherwise noted, tolerance ±10%

Dual Wire Wrist Strap provides redundancy; even if one dual wire wrist strap conductor is severed, operator has reliable path-to-ground with other wire.



- · Used with resistive loop technology continuous monitor, continuously verifies the proper resistance to ground of the operator
- Comfortable adjustable wrist band made of silver suffused monofilament conductive interior
- 304 stainless steel back plate
- Woven Silveron[™] fabric infused with silver monofilament conductive fiber is comfortable and hypo-allergenic
- Patented* dual wire technology
- Superior warranty See details of 1 year Limited Warranty http://www.Desco.com/LimitedJewelWarrantv.aspx
- Superior quality product Made in America at our Chino CA facility
- UL listed

Cleaning

For proper operation, the wrist strap, especially the wrist band, must be kept clean. All wrist band should be cleaned with a mild detergent on a periodic basis.

Use patented* Dual Wire Wrist Strap with Desco's Dual Wire Continuous Monitor. 3M monitors, or other brands which use 3.5 mm mono plug.

Item	Description	Minimum Circumference	Maximum Circumference
<u>19691</u>	ADJ. Wristband only, 4mm male snaps	4.5 in	12 in
<u>09163</u>	ADJ. Wrist Strap, 4mm male snaps, w/ 6' coil cord	4.5 in	12 in
<u>09164</u>	ADJ. Wrist Strap, 4mm male snaps, w/ 12' coil cord	4.5 in	12 in

See drawing 09160 for details on the Jewel® coil cords.

Thermoplastic elastomer strain relief molded on. Flex life average >11,700,000 cycles (per ESD S1.1 Bending Life Test, greatly exceeding the 16,000 average cycle requirement). Break load average 30 pounds.

Meets ESD S1.1 breakaway force requirement >1 pound <five pound

JEWEL® ADJUSTABLE ELASTIC. WRIST STRAP. DUAL WIRE

DESCO WEST: 3651 WALNUT AVE., CHINO, CA 91710 WEB SITE: Desco.com PHONE (909) 627-8178 FAX (909) 627-7449

DESCO EAST: ONE COLGATE WAY, CANTON, MA 02021-1407 PHONE (781) 821-8370 FAX (781) 575-0172

DRAWING NUMBER 09163

DATE: February 2011

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Antistatic Control Products category:

Click to view products by Desco manufacturer:

Other Similar products are found below:

13020 13490 13870 13879 13881 13883 13882 14404 2202SP 3039 37061 42470 09060 09857 42516 37059 04563 17252 19691 19695 09037 09826 09813 66070 100816 68101 68103 98132 73741 13868 13485 13457 13245 13468 13420 13332 13205 13135 91070 8031 8523 66085 40931 37081 13080 13215 13806 73749 010-0225 17260