







Hand tools

Crimping tools

Crimping tools

| Terminals and parts model number in alphabetical order | Hand tools | | | | Hand tools | | Extraction and Insertion tools | | |
|--|---|---|---|---|---------------------------|-------------------------------------|---|--|---|
| | for chain terminals | for loose piece terminals | | | for loose piece terminals | | Extraction tool | Insertion tool | |
| | YRS series | YC series | YRM series | YRF series | | | | | |
| |  |  |  |  | | |  |  | |
| | Dimensions: (W x L) 59X224mm (2.3" x 8.8") | Dimensions: (W x L) 70X296mm (2.8" x 11.7") | Dimensions: (W x L) 59X224mm (2.3" x 8.8") | Dimensions: (W x L) 70X295mm (2.8" x 11.6") 80X305mm (3.1" x 12.0") | | | Extraction tool is used to extract contacts improperly inserted in the housing. | Insertion tool allows contacts be inserted in the housing. This tool greatly increases efficiency especially when thin wires are used. | |
| | <p>Note: (1) These tools are for prototype tooling or repair. (2) YC tool has two crimping sections (A and B). YRS tool has also two crimping sections by inverting upper dies. Be sure to check applicable wires before use. Since the dies are fixed, the crimping height cannot be adjusted. Therefore, some of the applicable wires described in this catalog may not be crimped properly. Before use, check for proper crimping (such as tensile strength, terminal/contact deformation). (3) These tools are not applicable to 2-wire crimping. (4) When hand crimping board-in terminals (SAN, SCN, SDN, SGN, SIN, SJN, SZN), care should be taken not to contaminate the solder tails of the terminals, as with greasy or oily fingers. If a solder problem arises, some cleaning of the lips of the terminal is advisable. (5) WC and JUC hand tools are provided by J.S.T.(U.K.) LTD. and contact them about the details of these hand tools.</p> | | | | | | | | |
| | YRS series | YC series | YRM series | YRF series | | WC & JUC series JUK's Hand Tools | Terminal in loose form model No. | | |
| CN-SAP/S1 | YRS-870 | - | - | - | | - | - | - | - |
| JK-SP2*** | YRS-370 | - | - | - | | - | - | KEJ-0.7 | - |
| JK-SS2*** | YRS-370 | - | - | - | | - | - | KEJ-0.4 | - |
| J-SP1*** | YRS-440 | YC-440 | - | - | | - | J-BP1*** | DEJ-0.3 | - |
| J-SS1*** | YRS-440 | YC-440 | - | - | | - | J-BP1*** | DEJ-0.3 | - |
| J-SP2*** | YRS-330 | - | - | - | | - | - | DEJ-0.3 | - |
| J-SS2*** | YRS-330 | - | - | - | | - | - | DEJ-0.3 | - |
| LFO-1.0-250N | - | - | - | - | | JUCS-FO | - | - | - |
| LFO-2.5-250N | - | - | - | - | | JUCS-FO | - | - | - |
| MD-SP12** | YRS-470 | - | - | - | | - | - | MEJ-06 | - |
| MD-SP22** | YRS-460 | - | - | - | | - | - | MEJ-06 | - |
| RA-SC1290 | YRS-231 | - | YRM-232 (for AWG #26, #24) YRM-233 (for AWG #24, #22) | - | | - | RA-BC12** | EJ-RA | - |
| RF-SC22** | - | - | YRM-230 | - | | - | RF-BC22** | - | - |
| RPJ-SP/SS2331 | YRS-331 | - | - | - | | - | - | - | - |
| UBB-SP1110 | YRS-951 | - | - | - | | - | - | - | - |
| UBB-SP2110 | YRS-950 | - | - | - | | - | - | - | - |
| SAA-21(T)-** | - | YC-141 | - | - | | - | LAA-21(T)-** | - | - |
| SAA-50(T)-** | - | YC-182 | - | - | | - | LAA-50(T)-** | - | - |
| SAA-51(T)-** | - | YC-142 | - | - | | - | LAA-51(T)-** | - | - |
| SAB-51(T)-** | - | YC-142 | - | - | | - | LAB-51(T)-** | - | - |
| SAGH-002GU-P0.3 | YRS-858 | - | - | - | | - | - | - | - |
| SAN-002T-0.8A | YRS-220 | - | - | - | | - | - | EJ-PH | - |
| SAN-002T-0.8K | YRS-220 | - | - | - | | - | - | EJ-PH | - |
| SBH-001T-P0.5 | - | YC-670R | - | - | | WC-670 | BBH-001T-P0.5 | - | - |
| SBHL-002T-P0.5 | YRS-857 | - | - | - | | - | - | - | - |
| SBHM-001T-P0.5 | - | YC-670R | - | - | | - | BBHM-001T-P0.5 | - | - |
| SBHS-002T-P0.5A | YRS-852 | - | - | - | | - | - | - | - |
| SBHSM-002T-P0.5 | YRS-854 | - | - | - | | - | - | - | - |

Crimping tools

Crimping tools

| Terminals and parts model number in alphabetical order | Hand tools | | | | | Hand tools | | Extraction and Insertion tools | |
|--|---|---|------------|------------|-------------------------------------|----------------------------------|-----------------|--------------------------------|--------|
| | for chain terminals | for loose piece terminals | | | for loose piece terminals | | Extraction tool | Insertion tool | |
| | YRS series | YC series | YRM series | YRF series | WC & JUC series JUC's Hand Tools | Terminal in loose form model No. | | | |
| SBHT-002T-P0.5 | YRS-856 (UL3443 AWG #28, UL3239 AWG #24) YRS-857 (UL3443 AWG #26, UL10267 AWG #26) | - | - | - | - | - | - | EJ-BHT | IT-BHT |
| SCN-001T-1.0K | YRS-191 | YC-191R | - | - | - | WC-191 | BCN-001T-1.0K | - | - |
| SCN-001T-P1.0 | YRS-191 | YC-191R | - | - | - | WC-191 | BCN-001T-P1.0 | - | - |
| SCS-41T-2.3 | - | - | - | - | - | - | - | CSJ-23 | - |
| SCZH-002T-P0.5 | YRS-492 | - | - | - | - | - | - | - | - |
| SDF-01T-1.0A | - | YC-045 | - | - | - | - | LDF-01T-1.0A | - | - |
| SDF-01T-1.3AS | - | YC-045 | - | - | - | - | LDF-01T-1.3AS | - | - |
| SDN-21T-P1.5 | - | YC-600R | - | - | - | - | BDN-21T-P1.5 | - | - |
| SDY-01T-P1.6ASV | - | YC-525R | - | - | - | - | - | SLJ-1.4 | - |
| SEH-001T-P0.6 | YRS-260 | YC-260R | - | - | - | WC-260 | BEH-001T-P0.6 | - | - |
| SF3F-002GF-P2.0 | - | - | - | YRF-882 | - | - | BF3F-002GF-P2.0 | EJ-JFAJ3 | - |
| SF3F-01GF-P2.0 | - | - | - | YRF-881 | - | - | BF3F-01GF-P2.0 | EJ-JFAJ3 | - |
| SF3M-01GF-M2.0N | - | - | - | YRF-881 | - | - | BF3M-01GF-M2.0N | EJ-JFAJ3 | - |
| SF3F-41GF-P2.0 | - | - | - | YRF-880 | - | - | LF3F-41GF-P2.0 | EJ-JFAJ3 | - |
| SF3M-41GF-M2.0N | - | - | - | YRF-880 | - | - | LF3M-41GF-M2.0N | EJ-JFAJ3 | - |
| SF3F-71GF-P2.0 | - | - | - | YRF-1070 | - | - | BF3F-71GF-P2.0 | - | - |
| SF3M-71GF-M2.0N | - | - | - | YRF-1071 | - | - | BF3M-71GF-M2.0N | - | - |
| SFO-41(T)-187N | - | YC-271 | - | - | - | - | LFO-41(T)-187N | - | - |
| SFO-61(T)-250A | - | YC-270 | - | - | - | - | LFO-61(T)-250A | - | - |
| SFPS-61(T)-250 | - | YC-272 | - | - | - | - | LFPS-61(T)-250 | - | - |
| SFT-61T-250N | - | YC-510 | - | - | - | - | LFT-61T-250N | - | - |
| SGF-41(T)-4 | - | YC-055 | - | - | - | - | LGF-41(T)-4 | - | - |
| SGF-51(T)-5 | - | YC-065 | - | - | - | - | LGF-51(T)-5 | - | - |
| SGF-51(T)-5A | - | YC-065 | - | - | - | - | LGF-51(T)-5A | - | - |
| SGM-51(T)-4 | - | YC-056 | - | - | - | - | LGM-51(T)-4 | - | - |
| SGM-51(T)-5 | - | YC-056 | - | - | - | - | LGM-51(T)-5 | - | - |
| SHCM-A03T-P025 | YRS-960 | - | - | - | - | WC-SHCM-A03 | - | - | - |
| SHF-001T-0.8BS | YRS-122 | YC-122R | - | - | - | WC-122 | BHF-001T-0.8BS | - | - |
| SHF-002T-0.8BS | YRS-300 | - | - | - | - | - | - | - | - |
| SHR-001T-P0.6 | YRS-580 | YC-580R | - | - | - | - | BHR-001T-P0.6 | - | - |
| SIM-01(T)-110A | - | YC-054 | - | - | - | - | LIM-01(T)-110A | - | - |
| SIM-1.0-250D/N | - | - | - | - | - | JUCS-IM | - | - | - |
| SIM-2.5-250D/N | - | - | - | - | - | JUCS-IM | - | - | - |
| SIM-41(T)-110B | - | YC-067 | - | - | - | - | LIM-41(T)-110B | - | - |
| SIM-51(T)-250N | - | YC-321 | - | - | - | - | LIM-51(T)-250N | - | - |
| SIN-001T-1.2 | YRS-034 | - | - | - | - | - | - | - | - |
| SIN-002T-1.0S | YRS-035 | - | - | - | - | - | - | - | - |
| SIN-01T-1.2 | - | YC-340R | - | - | - | - | LIN-01T-1.2 | - | - |
| SIN-01T-1.8 | - | YC-032 | - | - | - | - | LIN-01T-1.8 | - | - |
| SIN-21T-1.8 | - | YC-350 | - | - | - | - | LIN-21T-1.8 | - | - |
| SIN-21T-1.8S | - | YC-570 (for UL1015 AWG #22, #20) YC-571 (for UL1015 AWG #18) | - | - | - | - | LIN-21T-1.8S | - | - |
| SIN-61T-2.6S | - | YC-560 (for UL1015 AWG #14) | - | - | - | - | LIN-61T-2.6S | - | - |

Crimping tools

Crimping tools

| Terminals and parts model number in alphabetical order | Hand tools | | | | | Hand tools | | Extraction and Insertion tools | |
|--|---------------------|--|------------|------------|-------------------------------------|-------------------------------------|-----------------|--------------------------------|--|
| | for chain terminals | for loose piece terminals | | | for loose piece terminals | | Extraction tool | Insertion tool | |
| | YRS series | YC series | YRM series | YRF series | WC & JUC series JUC's Hand Tools | Terminal in loose form model No. | | | |
| SIN-81T-3.6S | - | YC-940 | - | - | - | LIN-81T-3.6S | - | - | |
| SJ2F-002GF-P1.0 | YRS-8851 | - | - | - | - | - | - | - | |
| SJ2M-002GF-M1.0 | YRS-8851 | - | - | - | - | - | - | - | |
| SJ2F-01GF-P1.0 | YRS-8861 | - | - | - | - | - | - | - | |
| SJ2M-01GF-M1.0N | YRS-8861 | - | - | - | - | - | - | - | |
| SJ2M-01GF-M1.0S | YRS-8861 | - | - | - | - | - | - | - | |
| SJ2F-21GF-P1.0 | - | - | - | YRF-1120 | - | LJ2F-21GF-P1.0 | - | - | |
| SJ2M-21GF-M1.0N | - | - | - | YRF-1120 | - | LJ2M-21GF-M1.0N | - | - | |
| SJ5F-71GF-P6.5 | - | - | - | YRF-888 | - | LJ5F-71GF-P6.5 | - | - | |
| SJ5M-71GF-M6.5 | - | - | - | YRF-888 | - | LJ5M-71GF-M6.5 | - | - | |
| SJ5F-81GF-P6.5 | - | - | - | YRF-889 | - | LJ5F-81GF-P6.5 | - | - | |
| SJ5M-81GF-M6.5 | - | - | - | YRF-889 | - | LJ5M-81GF-M6.5 | - | - | |
| SJN-002PT-0.9 | YRS-036 | - | - | - | - | - | - | - | |
| SLC-21T-2.0 | - | YC-310 | - | - | WC-310 | LLC-21T-2.0 | - | - | |
| SLF/M-01T-P1.3E | - | YC-202 | - | - | WC-202 | LLF/M-01T-P1.3E | LEJ-13 | LIT-2013 | |
| SLF/M-41T-P1.3E | - | YC-203 | - | - | WC-203 | LLF/M-41T-P1.3E | LEJ-13 | - | |
| SMF-01T-1.0 | - | YC-081 | - | - | - | LMF-01T-1.0 | - | - | |
| SMF-01T-1.3 | - | YC-082 | - | - | - | LMF-01T-1.3 | - | - | |
| SMM-003T-0.5 | YRS-800 | - | - | - | WC-800 | - | - | - | |
| SMR-001T-0.6 | YRS-580 | YC-580R | - | - | - | BMR-001T-0.6 | HRWJ | - | |
| SOM-21(T)-187 | - | YC-680 | - | - | - | LOM-21(T)-187 | - | - | |
| SOM-51(T)-250 | - | YC-066 | - | - | WC-066 | LOM-51(T)-250 | - | - | |
| SPA-001T-P0.5 | - | YC-610R (for AWG #26, #24) YC-611R (for UL1007 AWG #24, UL1061 AWG #22) | - | - | - | BPA-001T-P0.5 | - | - | |
| SPAL-001T-P0.5 | - | YC-610R (for AWG #26, #24) YC-611R (for UL1007 AWG #24, UL1061 AWG #22) | - | - | - | BPAL-001T-P0.5 | - | - | |
| SPB-1.0-250N-S | - | - | - | - | JUCS-PB | - | - | - | |
| SPB-2.5-250N-S | - | - | - | - | JUCS-PB | - | - | - | |
| SPF-01T-2.5C | - | YC-043R | - | - | - | LPF-01T-2.5C | - | - | |
| SPH-001T-P0.5L | YRS-245 | - | - | - | - | - | - | - | |
| SPH-002T-P0.5L | YRS-241 | - | - | - | - | - | EJ-PH | - | |
| SPH-002T-P0.5S | YRS-240 | - | YRM-240 | - | WC-240 | BPH-002T-P0.5S | EJ-PH | - | |
| SPH-004T-P0.5S | YRS-243 | - | - | - | - | - | EJ-PH | - | |
| SPHD-001T-P0.5 | - | YC-610R (for AWG #26, #24) YC-611R (for UL1007 AWG #24, UL1061 AWG #22) | - | - | WC-610 | BPHD-001T-P0.5 | EJ-PHD | - | |
| SPHD-002T-P0.5 | YRS-620 | - | YRM-620 | - | WC-620 | BPHD-002T-P0.5 | EJ-PHD | - | |
| SPND-001T-C0.5 | YRS-1091 | - | - | - | - | - | - | - | |
| SPND-002T-C0.5 | YRS-1090 | - | - | - | - | - | - | - | |
| SPS-01T-110 | - | YC-740 | - | - | WC-740 | LPS-01T-110 | - | - | |
| SPS-01T-187(-8) | - | YC-730 (for AWG #26, #22) YC-731 (for AWG #24, #20) | - | - | WC-730 | LPS-01T-187(-8) | EJ-PS187 | - | |
| SPS-21T-250(-5) | - | YC-760 | - | - | - | LPS-21T-205(-5) | - | - | |
| SPS-21T-250 | - | YC-780 | - | - | WC-780 | LPS-21T-250 | EJ-PS250 | - | |

Crimping tools

Crimping tools

| Terminals and parts model number in alphabetical order | Hand tools | | | | | Hand tools | | Extraction and Insertion tools | |
|--|---------------------|--|------------|------------|----------------------------------|----------------------------------|-----------------|--------------------------------|--|
| | for chain terminals | for loose piece terminals | | | for loose piece terminals | | Extraction tool | Insertion tool | |
| | YRS series | YC series | YRM series | YRF series | WC & JUC series JUC's Hand Tools | Terminal in loose form model No. | | | |
| SPS-21T-250S | - | YC-780 | - | - | WC-780 | LPS-21T-250S | EJ-PS250 | - | |
| SPS-41T-110 | - | YC-750 (for AWG #20, #18) YC-751 (for AWG #16) | - | - | WC-750 | LPS-41T-110 | - | - | |
| SPS-51T-187(-8) | - | YC-710 (for AWG #20, #16) YC-711 (for AWG #18, #14) | - | - | WC-710 | LPS-51T-187(-8) | EJ-PS187 | - | |
| SPS-51T-205 | - | YC-770 (for UL1015 AWG #20, #16) YC-771 (for UL1015 AWG #18, #14) | - | - | - | LPS-51T-205 | - | - | |
| SPS-61T-250 | - | YC-720 | - | - | WC-720 | LPS-61T-250 | EJ-PS250 | - | |
| SPS-61T-250S | - | YC-721 | - | - | - | LPS-61T-250S | EJ-PS250 | - | |
| SPS-91T-250 | - | - | - | YRF-790 | - | BPS-91T-250 | EJ-PS250 | - | |
| SPS-91T-250S | - | - | - | YRF-791 | - | BPS-91T-250S | EJ-PS250 | - | |
| SRA-20(T)-** | - | YC-181 | - | - | - | LRA-20(T)-** | - | - | |
| SRA-21(T)-** | - | YC-141 | - | - | - | LRA-21(T)-** | - | - | |
| SRA-50(T)-** | - | YC-182 | - | - | - | LRA-50(T)-** | - | - | |
| SRA-51(T)-** | - | YC-142 | - | - | - | LRA-51(T)-** | - | - | |
| SRB-1.0(-) | - | - | - | - | JUCS-RB/RT | - | - | - | |
| SRB-2.5(-) | - | - | - | - | JUCS-RB/RT | - | - | - | |
| SRB-51(T)-** | - | YC-142 | - | - | - | LRB-51(T)-** | - | - | |
| SRC-01(T)-** | - | YC-033 | - | - | - | LRC-01(T)-** | - | - | |
| SRC-50(T)-** | - | YC-183 | - | - | - | LRC-50(T)-** | - | - | |
| SRC-51(T)-** | - | YC-142 | - | - | - | LRC-51(T)-** | - | - | |
| SRF-51(T)-** | - | YC-142 | - | - | - | LRF-51(T)-** | - | - | |
| SRT-1.0(-) | - | - | - | - | JUCS-RB/RT | - | - | - | |
| SRT-2.5(-) | - | - | - | - | JUCS-RB/RT | - | - | - | |
| SRT-51T-** | - | YC-143R | - | - | - | LRT-51T-** | - | - | |
| SRWF-01GG-M0.6 | - | YC-830R | - | - | - | BRWF-01GG-M0.6 | - | - | |
| SRWM-01GG-S0.6 | - | YC-830R | - | - | - | BRWM-01GG-S0.6 | - | - | |
| SRWF-61GG-M0.6 | - | YC-840R | - | - | - | BRWF-61GG-M0.6 | - | - | |
| SRWM-61GG-S0.6 | - | YC-840R | - | - | - | BRWM-61GG-S0.6 | - | - | |
| SSHL-002(-)-P0.2 | - | - | - | - | WC-GH2630 | - | - | - | |
| SSH-003T-P0.2-H | YRS-859 | - | - | - | WC-SH2832 | - | - | - | |
| SSH-003GA-P0.2 | YRS-859 | - | - | - | WC-SH2832 | - | - | - | |
| SSHL-003T-P0.2 | YRS-859 | - | - | - | WC-SH2832 | - | - | - | |
| SSHL-003GA1-P0.2 | YRS-859 | - | - | - | WC-SH2832 | - | - | - | |
| SSF-01T-P1.4 | - | YC-500 | - | - | - | BSF-01T-P1.4 | SLJ-1.4 | ITBL-08V | |
| SSM-01T-P1.4 | - | YC-500 | - | - | - | BSM-01T-P1.4 | SLJ-1.4 | ITBL-08V | |
| SSF/M-21T-P1.4 | - | YC-550 | - | - | WC-550 | BSF/M-21T-P1.4 | SLJ-1.4 | - | |
| STI-01(T)-110N | - | YC-041 | - | - | - | LTI-01(T)-110N | - | - | |
| STI-1.0-250D/N | - | - | - | - | JUCS-TI | - | - | - | |
| STI-2.5-250D/N | - | - | - | - | JUCS-TI | - | - | - | |
| STI-41(T)-110N | - | YC-063 | - | - | - | LTI-41(T)-110N | - | - | |
| STI-51(T)-250N | - | YC-322 | - | - | - | LTI-51(T)-250N | - | - | |
| STO-01(T)-110N(-8) | - | YC-041 | - | - | - | LTO-01(T)-110N(-8) | - | - | |
| STO-01(T)-187N(-8) | - | YC-042 | - | - | - | LTO-01(T)-187N(-8) | - | - | |
| STO-0.25-110N | - | YC-810 | - | - | - | - | - | - | |

Crimping tools

Crimping tools

| Terminals and parts model number in alphabetical order | Hand tools | | | | Hand tools | | | Extraction and Insertion tools | |
|--|---------------------|--|------------------------|------------|-------------------------------------|----------------------------------|----------------|--------------------------------|----------------|
| | for chain terminals | for loose piece terminals | | | for loose piece terminals | | | Extraction tool | Insertion tool |
| | YRS series | YC series | YRM series | YRF series | WC & JUC series JUK's Hand Tools | Terminal in loose form model No. | | | |
| STO-0.5-110N | - | YC-820 | - | - | JUCS-05110 | - | - | - | |
| STO-1.0-110N | - | - | - | - | JUCS-2.8/4.8 | - | - | - | |
| STO-1.0-187N | - | - | - | - | JUCS-2.8/4.8 | - | - | - | |
| STO-1.0-250N | - | - | - | - | JUCS-6.3 | - | - | - | |
| STO-2.5-250N | - | - | - | - | JUCS-6.3 | - | - | - | |
| STO-21T-205 | - | YC-052 | - | - | - | - | - | - | |
| STO-21(T)-205N | - | YC-053 | - | - | - | LTO-21(T)-205N | - | - | |
| STO-21(T)-250N | - | YC-102 | - | - | - | LTO-21(T)-250N | - | - | |
| STO-41(T)-110N(-8) | - | YC-062 | - | - | - | LTO-41(T)-110N(-8) | - | - | |
| STO-41(T)-187N(-8) | - | YC-051 | - | - | - | LTO-41(T)-187N(-8) | - | - | |
| STO-41T-187S | - | YC-064 | - | - | - | LTO-41T-187S | - | - | |
| STO-61(T)-250N | - | YC-047 | - | - | - | LTO-61(T)-250N | - | - | |
| STO-81(T)-250N | - | YC-280 | - | YRF-280 | - | LTO-81(T)-250N | - | - | |
| SVA-41T-P1.1 | - | YC-450 | - | - | - | BVA-41T-P1.1 | EJ-SMP | - | |
| SVF-01T-1.5A | - | YC-044 | - | - | - | LVF-01T-1.5A | - | - | |
| SVF-01T-1.5N | - | YC-151 | - | - | - | LVF-01T-1.5N | - | - | |
| SVF-01T-2.36LN | - | - | - | - | - | - | EJ-LV | - | |
| SVF-01T-2.36N | - | YC-152 | - | - | - | LVF-01T-2.36N | EJ-LV | - | |
| SVF-42T-P2.0 | - | YC-592 | - | - | WC-592 | BVF-42T-P2.0 | VLJ-20 | - | |
| SVM-42T-P2.0 | - | YC-593 | - | - | WC-592 | BVM-42T-P2.0 | VLJ-20 | - | |
| SVF/M-61T-P2.0 | - | YC-590 | - | YRF-590 | WC-590 | BVF/M-61T-P2.0 | VLJ-20 | - | |
| SVF/M-81T-P2.0 | - | - | - | YRF-591 | WC-591 | BVF/M-81T-P2.0 | VLJ-20 | - | |
| SVH-21T-P1.1 | - | YC-160R (for AWG #22, #20) YC-161R (for AWG #20, #18) YC-164R (for UL1015 AWG #22, #20) | YRM-160 YRM-164 | - | WC-160 | BVH-21T-(P)1.1 | EJ-NV | - | |
| SVH-41T-P1.1 | - | YC-930R (for AWG #20, #16) YC-931R (for UL1015 AWG #20, #18) | - | - | WC-930 | BVH-41T-P1.1 | - | - | |
| SVT-41T-P1.1 | - | YC-630 | - | - | - | BVT-41T-P1.1 | EJ-VT | - | |
| SVU-21T-P0.6 | - | YC-990R | - | - | - | BVU-21T-P0.6 | - | - | |
| SWPKR-21T-0.6 | - | - | - | YRF-1050 | - | - | - | - | |
| SWPKP-21T-0.6 | - | - | - | YRF-1051 | - | - | - | - | |
| SWPR-001T-P025 | YRS-980 | - | - | - | WC-JWPF | - | - | - | |
| SWPT-001T-P025 | YRS-980 | - | - | - | WC-JWPF | - | - | - | |
| SXA-01T-P0.6 | - | YC-701R | - | - | WC-700M | BXA-01T-P0.6 | EJ-XMP | - | |
| SXM-01T-P0.6 | - | YC-701R | - | - | - | BXM-01T-P0.6 | EJ-XMP | - | |
| SXA-001T-P0.6 | YRS-692 | YC-692R | - | - | - | BXA-001T-P0.6 | EJ-XMP, EJ-XMR | IT-XA | |
| SXM-001T-P0.6 | YRS-692 | YC-692R | - | - | - | BXM-001T-P0.6 | EJ-XMP, EJ-XMR | IT-XA | |
| SXA-001T-P0.6L | YRS-691 | - | - | - | WC-691 | - | - | - | |
| SXAM-01T-P0.6 | - | YC-701R | - | - | WC-700M | BXAM-01T-P0.6 | - | - | |
| SXAM-001T-P0.6 | YRS-692 | YC-692R | - | - | - | BXAM-001T-P0.6 | - | - | |
| SXF-01T-P0.7 | - | YC-251 | - | - | - | BXF-01T-(P)0.7 | LEJ-7 | - | |
| SXF-41T-P0.7 | - | YC-252 | - | - | - | BXF-41T-(P)0.7 | LEJ-7 | - | |

Crimping tools

Crimping tools

| Terminals and parts model number in alphabetical order | Hand tools | | | | | Hand tools | | Extraction and Insertion tools | |
|--|---------------------|--|------------|------------|-------------------------------------|----------------------------------|------------------|--------------------------------|----------------|
| | for chain terminals | for loose piece terminals | | | | for loose piece terminals | | Extraction tool | Insertion tool |
| | YRS series | YC series | YRM series | YRF series | WC & JUC series JUK's Hand Tools | Terminal in loose form model No. | | | |
| SXH-001T-P0.6 | YRS-110 | YC-110R (for AWG #26, #24) YC-111R (for AWG #24, #22) | - | - | | WC-110 | BXH-001T-P0.6 | XJ-06 | - |
| SXH-001T-P0.6N | - | - | - | - | | - | - | XJ-06 | - |
| SXH-002T-P0.6 | YRS-480 | - | - | - | | - | - | XJ-06 | - |
| SYF-001T-P0.6 | YRS-125 | - | - | - | | - | - | - | - |
| SYF/M-01T-P0.5A | - | YC-520 | - | - | | WC-520 | BYF/M-01T-P0.5A | YLJ-0.5 | - |
| SYF/M-41T-P0.5A | - | YC-530 | - | - | | WC-530 | BYF/M-41T-P0.5A | YLJ-0.5 | - |
| SYM-001T-P0.6 | YRS-121 | YC-121R | - | - | | WC-121 | BYM-001T-P0.6 | SMJ-06 | - |
| SYM-01T-P0.7 | - | YC-251 | - | - | | - | BYM-01T-(P)0.7 | LEJ-7 | - |
| SYM-41T-P0.7 | - | YC-252 | - | - | | - | BYM-41T-(P)0.7 | LEJ-7 | - |
| SZF/M-01T-P0.7 | - | YC-390R | - | - | | - | BZF/M-01T-(P)0.7 | ZLJ-07S | - |
| SZF/M-41T-P0.7 | - | YC-380R | - | - | | - | BZF/M-41T-(P)0.7 | ZLJ-07S | - |
| SZH-002T-P0.5 | YRS-491 | - | - | - | | WC-491 | - | - | - |
| SZH-003T-P0.5 | YRS-490 | - | - | - | | WC-490 | - | - | - |
| SZN-002T-P0.7K | YRS-541 | - | - | - | | - | - | - | - |
| SZN-003T-P0.7K | YRS-540 | - | - | - | | - | - | - | - |

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for [Crimpers / Crimping Tools](#) category:

Click to view products by [JST](#) manufacturer:

Other Similar products are found below :

[010-0096](#) [M225201-06](#) [M225202-37](#) [6-1579015-5](#) [CT150-2-D02](#) [CT150-6-RH07](#) [622-6441LF](#) [M322](#) [6-304052-1](#) [63456-0054](#) [63484-3701](#)
[63800-8355](#) [63819-1875](#) [63819-2875](#) [63819-4475](#) [63823-3475](#) [63827-5375](#) [64001-0975](#) [64001-4175](#) [64005-0175](#) [662903-2](#) [690602-6](#) [7-](#)
[1579001-9](#) [7-23471-1](#) [762637-1](#) [808714-1](#) [811242-5](#) [91362-1](#) [999-50-020083](#) [1-21002-3](#) [1-21002-7](#) [12085270](#) [1-21002-6](#) [1-21113-6](#) [1-](#)
[22548-4](#) [125442-1](#) [DCE.91.073.BVC](#) [DCE.91.090.3MVM](#) [DCE.91.130.5MVU](#) [DCE.91.202.BVCM](#) [1338300-1](#) [1-354003-0](#) [1338301-1](#)
[142321](#) [AP105-DF11-2428S\(64\)](#) [1456088-1](#) [1490794-1](#) [1-45804-6](#) [1490357-2](#) [1490357-3](#)