

NCVT-5A NON-CONTACT VOLTAGE TESTER

With Laser Pointer



70 – 1000V AC

DUAL-RANGE

12 – 1000V AC



3 m

**CAT IV
1000V**



NON-CONTACT VOLTAGE TESTER WITH LASER POINTER

The Klein Tools NCVT-5A is a dual-range non-contact voltage tester (NCVT) with a laser pointer. It can be set to detect voltage from 70 to 1000V AC (in Mode 1) or from 12-1000V AC (in Mode 2). The laser pointer can function independent of, or simultaneously with the NCVT.

70 – 1000V AC

DUAL-RANGE

12 – 1000V AC



**CAT IV
1000V**


NCVT-5A can detect voltage in two distinct modes*:

Mode 1: 70 to 1000V AC


Mode 2: 12 to 1000V AC

*defined by the voltage ranges to which the tester is sensitive

- Power On/Mode LEDs
- Voltage Detection LEDs (inside tip)
- Auto Power Off (APO) conserves and extends battery life
- Lightweight, compact tester with pocket clip for easy storage and quick access



Patent #D750985



**2x AAA
INCLUDED**

THE POWER-ON INDICATOR LEDs WILL INDICATE THE CURRENTLY ACTIVE MODE.

DETECTS AC VOLTAGE WITH AUDIBLE & VISUAL INDICATORS



Cat. No.	UPC 0-92644+	Description	Overall Length
NCVT-5A	69294-9	Non-Contact Voltage Tester w/ Laser Pointer	6" (152 mm)
NCVT-6	69225-3	Non-Contact Voltage Tester w/ Laser Distance Meter	6.45" (16.4 cm)
NCVT-4IR	69061-7	Non-Contact Voltage Tester w/ Infrared Thermometer	6.25" (159 mm)
NCVT-3	69008-2	Non-Contact Voltage Tester w/ Flashlight	6" (152 mm)
NCVT-2	69002-0	Non-Contact Voltage Tester (Dual Range)	5.5" (140 mm)
NCVT-1	69000-6	Non-Contact Voltage Tester	5.5" (140 mm)

See our complete line of **Test & Measurement Products**

www.kleintools.com



© 2018 Klein Tools, Inc.
Lincolnshire, IL 60069
94819 Rev. 01/20 B



X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for [Component Testers](#) category:

Click to view products by [Klein Tools](#) manufacturer:

Other Similar products are found below :

[410-413](#) [FLUKE 9062](#) [2840](#) [2841](#) [570A](#) [35135](#) [815](#) [FLUKE-9040EUR](#) [881](#) [891](#) [895](#) [AK57X](#) [770734](#) [LCR200](#) [PRT200](#) [UM200](#) [T5-H5-1AC-KIT/US](#) [69127](#) [ET40](#) [ET45](#) [ET45VP](#) [ET60](#) [HVNCVT-1](#) [NCVT2P](#) [NCVT2PKIT](#) [NCVT3P](#) [NCVT-6](#) [RT110](#) [RT210](#) [RT250](#) [RT310](#) [35100](#) [35130](#) [VS-AVT-C02-L03](#) [1212598](#) [T3LCR1002](#) [T3LCR1300](#) [T3LCR1100](#) [VS-AVT-RKBB2](#) [VS-AVT-RKBB3](#) [VS-AVT-RKBB4](#) [NCVT-4IR](#) [LCR55A](#) [ET30B](#) [ET40B](#) [VS-AVT-C08-L10](#) [ET26B](#) [ET23B](#) [ET60](#) [ET28B](#)