

## PowerTool MAXPOWERTOOL002# Quick Start Guide



The MAXPOWERTOOL002# is a USB-to-PMBus™ interface dongle for exclusive use with Maxim Integrated's digital power products. The dongle can be used to communicate with PMBus devices using the installed PowerTool software.

1. Download and install the PowerTool software available at:  
[https://www.maximintegrated.com/en/design/software-description.html/swpart=SFW0005150H](https://www.maximintegrated.com/en/design/software-description.html?swpart=SFW0005150H)
2. Remove the MAXPOWERTOOL002# from the package.
3. Connect the provided USB cable and ribbon cable as shown in Figure 1. The STATUS LED on the MAXPOWERTOOL002# illuminates. The color of the LED indicates the device's status as follows:
  - **Steady GREEN color:** No I<sup>2</sup>C communication is in progress.
  - **Blinking ORANGE color:** The device is communicating I<sup>2</sup>C data.
  - **Steady RED color:** I<sup>2</sup>C communication has been interrupted.



Figure 1. MAXPOWERTOOL002# Installation

### **Features:**

- Supports 100kHz and 400kHz I<sup>2</sup>C communication speeds
- USB-to-SMBus conversion for Maxim digital power evaluation kits
- Uses USB only for power

For additional information, visit: [www.maximintegrated.com](http://www.maximintegrated.com).

*PMBus is a trademark of SMIF, Inc.*

**Revised 10/14**

## X-ON Electronics

Largest Supplier of Electrical and Electronic Components

*Click to view similar products for [Interface Development Tools](#) category:*

*Click to view products by [Maxim](#) manufacturer:*

Other Similar products are found below :

[ADP5585CP-EVALZ](#) [CHA2066-99F](#) [AS8650-DB](#) [MLX80104 TESTINTERFACE](#) [416100120-3](#) [XR18910ILEVB](#) [XR21B1421IL28-0A-EVB](#) [TW-DONGLE-USB](#) [EVAL-ADM2491EEBZ](#) [MAXREFDES23DB#](#) [MAX13235EEVKIT](#) [DFR0257](#) [XR22404CG28EVB](#) [ZLR964122L](#) [ZLR88822L](#) [EVK-U23-01S](#) [EVK-W262U-00](#) [DC327A](#) [PIM511](#) [PIM536](#) [PIM517](#) [DEV-17512](#) [STR-FUSB3307MPX-PPS-GEVK](#) [MAXREFDES177#](#) [EVAL-ADM2567EEBZ](#) [ZSSC3240KIT](#) [MAX9121EVKIT](#) [PIM532](#) [ZSC31010KITV2P1](#) [UMFT4233HPEV](#) [LVDS-18B-EVK](#) [XR20M1170G16-0A-EB](#) [XR20M1170G16-0B-EB](#) [XR20M1170G24-0B-EB](#) [XR20M1172G28-0A-EB](#) [XR20M1172G28-0B-EB](#) [SI871XSOIC8-KIT](#) [1764](#) [1833](#) [1862](#) [EVB-USB82514](#) [ATA6628-EK](#) [ATA6631-EK](#) [EVAL-CN0313-SDPZ](#) [2264](#) [MCP23X17EV](#) [PS081-EVA-HR MODULE](#) [237](#) [SMA2RJ45EVK/NOPB](#) [FR12-0002](#)