

IrThermo 2 click



1. Introduction

IrThermo 2 click carries the **TMP007** infrared thermopile sensor with an integrated math engine. The measurement range of the sensor is between -40°C to 125°C (with a 14-bit resolution). IrThermo 2 click communicates with the target board MCU through mikroBUS[™] I²C pins (SCL, SDA); there's also an Alert pin in place of the default mikroBUS[™] INT. The board is designed to use either a 3.3V or a 5V power supply.

2. Soldering the headers

2

Before using your click board[™], make sure to solder 1x8 male headers to both left and right side of the board. Two 1x8 male headers are included with the board in the package.





Turn the board upward again. Make sure to align the headers so that they are perpendicular to the board, then solder the pins carefully.



4. Essential features

IrThermo 2 click is a non-contact temperature measurement solution, ideal for monitoring hard to reach objects (too far, inconveniently placed, hazardous, fluid etc.). The sensor absorbs the infrared radiation emitted by the target object (within the sensor's field of view) and the integrated math engine calculates its temperature by comparing it with the temperature of the silicon die. The sensor is factory calibrated, but the user can adjust the calibration coefficients for specific applications (to correct for range, field of view, object shape and environmental factors).

click

BOARD

www.mikroe.com

IrThermo 2 click manual

010000079140



Turn the board upside down so that

the bottom side is facing you upwards.

Place shorter pins of the header into the

appropriate soldering pads.

3. Plugging the board in

Once you have soldered the headers your board is ready to be placed into the desired mikroBUS[™] socket. Make sure to align the cut in the lower-right part of the board with the markings on the silkscreen at the mikroBUS[™] socket. If all the pins are aligned correctly, push the board all the way into the socket.

5. Schematic

6. Dimensions



8. Code examples

Once you have done all the necessary preparations, it's time to get your click board[™] up and running. We have provided examples for mikroC[™], mikroBasic[™] and mikroPascal[™] compilers on our **Libstock** website. Just download them and you are ready to start.



9. Support

MikroElektronika offers **free tech support** (www.mikroe.com/support) until the end of the product's lifetime, so if something goes wrong, we're ready and willing to help!





	mm	mils
LENGTH	28.6	1125
WIDTH	25.4	1000
HEIGHT*	3.6	142

* without headers

7. SMD jumpers



IrThermo 2 click has two sets of jumpers. ADDR. SEL. for specifying the I²C address, and a jumper for switching between 3.3V and 5V power supplies.

10. Disclaimer

MikroElektronika assumes no responsibility or liability for any errors or inaccuracies that may appear in the present document. Specification and information contained in the present schematic are subject to change at any time without notice.

Copyright © 2015 MikroElektronika. All rights reserved.

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Temperature Sensor Development Tools category:

Click to view products by MikroElektronika manufacturer:

Other Similar products are found below :

 EVAL-ADT75EBZ
 T20321SS2B
 T2016P2CRRXC4S2
 DC2507A
 MAX1617AEVKIT
 BB-WSK-REF-2
 MCP9800DM-TS1
 TMPSNSRD

 RTD2
 MIKROE-2273
 MIKROE-2539
 MIKROE-2554
 DPP201Z000
 DPP901Z000
 1899
 EV-BUNCH-WSN-2Z
 DPP904R000
 KIT0021

 SEN0206
 SEN0227
 MIKROE-2769
 SEN-13314
 SEN0137
 3328
 DC1785B
 MHUM-01
 3538
 DPP201G000
 DFR0066
 WPP100B009
 393

 SDT310LTC100A3850
 SI7005EVB-UDP-M3L1
 2857
 1782
 2652
 269
 3245
 3622
 3648
 3721
 4089
 4101
 4369
 4566
 4636
 4808
 4821

 AS6200C-WL_EK_AB
 AS6200-WL_DK_ST
 AS6200-WL_EK_AB
 AS6200-WL_EK_AB
 AS6200-WL_EK_AB
 AS6200-WL_EK_AB