

Built-in Amplifier Photoelectric Sensor

E3V3

Easy-to-use, Low-cost Photoelectric Sensor

- Incorporating indicators that can be clearly seen from a distance
- Conforms to EN and IEC standards
- Incorporating polarizing function, thus accurately detecting lustrous objects
- Resin-filled construction resists vibration and ensures IP67 water-resistance
- Replaces E3V sensor





Ordering Information

Connection	Appearance	Sensing Method	Detection	Operating Mode	Output	
Method			Distance		NPN	PNP
Cord connection	Cord length: 2 m	Through-beam	7 m (23 ft)	Light-ON	E3V3-T61	E3V3-T81
		Retroreflective (polarized)	2 m (6.6 ft)	Dark-ON (selectable by wiring)	E3V3-R61	E3V3-R81
		Diffuse reflective	0.5 to 8 cm (0.20 to 3.15 in)		E3V3-D61	E3V3-D81
			70 cm (2.3 ft)		E3V3-D62	E3V3-D82

Note: Mounting brackets are not provided with the E3V3. Order them separately.

ACCESSORIES (ORDER SEPARATELY)

Attachments

Name	Remarks	Part Number
Retroreflector	Corner cube reflector	E39-R3
Retroreflector (tape type)	Glass bead adhesive back	E39-RSA, E39-RSB
Slit for Through-beam Sensor	0.5, 1, 2 dia. slits	E39-S7

Mounting Brackets

Part Number	Remarks
E39-L104	Standard vertical-mounting bracket
E39-L44	Rear-mounting bracket
E39-L43	Side-mounting bracket
E39-L98	Metal cover
E39-L93	Sensor adjustor

E39-L104

E39-L44



E39-L98









Detection of Labels



Application Examples

E3V3

Detection of Cardboard Boxes



Detection of Automobiles at Indoor Parking Lots



Sensing Method		Through-beam	Retroreflective (with MSR function)	Diffuse Reflective		
NPN output		E3V3-T61	E3V3-R61	E3V3-D61	E3V3-D62	
PNP output		E3V3-T81	E3V3-R81	E3V3-D81	E3V3-D82	
LED light source	e	Infrared LED	Red LED	Infrared LED		
Sensitivity adju	stment	Adjustor				
Connection me	thod	Drawing cord-Standard length: 2 m (6.6 ft)				
Weight		Approx. 160 g (with 2-m cord)	Approx. 80 g (with 2-m cord)			
Control output	selection	Cord wiring method (Light-ON or Dark-ON)				
Circuit protection		Overload protection, reversed connection protection, and mutual interference prevention function (except for through-beam models)				
Indicators		Operation indicator (orange), stability indicator (green), emission indicator for through-beam models only (orange)				
Materials	Case	Heat-resistive ABS				
	Lens	Methacrylic resin				
Attachments		Instruction sheet and reflector (E39-R1 retroreflective model only) (see note)				

Note: The mounting brackets are sold separately.

RATINGS/CHARACTERISTICS

Sensing Method		Through-beam	Retroreflective (with MSR function)	Diffuse Reflective			
Part number		E3V3-T61/-T81	E3V3-R61/-R81	E3V3-D61/-D81	E3V3-D62/-D82		
Power supply voltage		12 to 24 VDC ±10%, rip	12 to 24 VDC ±10%, ripple (p-p): 10% max.				
Current consur	mption	50 mA max.	40 mA max.				
Detection dista	ince	7 m	0.1 to 2 m (with E39-R1)	0.5 to 8 cm	70 cm		
Standard detectable object		Opaque object: 7 mm min. (0.28 in)	Opaque object: 30 mm min. (1.18 in)	10 x 10 cm white paper	20 x 20 cm white paper		
Directional angle		3° to 15°	Receiver/Emitter: 2° to 10° Reflector: 30° min.				
Differential trav	/el		·	20% max. of detection	distance		
Response time		1 ms max. for both operation and release					
Control output		100 mA max. at 30 VD	C, open collector output (re	sidual voltage: 1 V max.))		
Ambient illumination	Incandescent lamp	Illumination on optical spot: 3,000 <i>l</i> x max.					
	Sunlight	Illumination on optical s	spot: 10,000 ℓx max.				
Ambient	Operating	-25°C to 55°C (-13°F to 131°F) with no icing					
temperature	Storage	-40°C to 70°C (-40°F t	-40°C to 70°C (-40°F to 158°F)				
Ambient	Operating	35% to 85%					
humidity	Storage	35% to 95%					
Insulation resis	stance	20 MΩ min. (at 500 VDC)					
Dielectric stren	igth	1,000 VAC, 50/60 Hz for 1 min					
Vibration Destruction 10 to resistance		10 to 55 Hz, 1.5-mm do	10 to 55 Hz, 1.5-mm double amplitude for 2 hrs each in X, Y, and Z directions				
Shock resistance	Destruction	500 m/s ² (approx. 50G)	500 m/s ² (approx. 50G) 3 times each in X, Y, and Z directions				
Enclosure rating	IEC	IP67					

Retroreflector Specifications

Item		E39-R3	E39-RSA	E39-RSB	
Detection distance (with E3V3)		5 to 100 cm	20 to 50 cm	20 to 80 cm	
Directional angle		30° min.			
Ambient temperature	Operating	-25°C to 55°C (-13°F to 131°F)			
	Storage	-40°C to 70°C (-40°F to 158°F)			
Ambient humidity Operating		35% to 85%			
Storage		35% to 95%			
Enclosure rating IEC		IP67 (see note 2)			

Note: 1. The E39-R3, E39-RSA, and E39-RSB are polarizing reflectors.

2. Do not cut or scratch E39-R3, E39-RSA, or E39-RSB Reflectors, otherwise they will not be water resistant.

Engineering Data

PARALLEL OPERATING RANGE (TYPICAL)

E3V3-T 1



Detection distance X (m)

DETECTION DISTANCE VS. **OBJECT SIZE (TYPICAL)**







OPERATING RANGE (TYPICAL) E3V3-D 2



Detection distance X (m)

50 40 (mm) 20 10 Operating position Y 0 10 20 30 40

DETECTION DISTANCE VS. **OBJECT SIZE (TYPICAL)**

Detection distance X (cm)

80 90 100

COLOR OF OBJECT VS. **OPERATING RANGE** (TYPICAL)

E3V3-D 1

Parallel operating range Y(mm)



E3V3-D 1

50

0 10 20 30 40 50 60 70



Detection distance X (mm)

Size of object d (mm)

EXCESS GAIN VS. SET DISTANCE (TYPICAL)



E3V3-D 1



Operation _

OUTPUT CIRCUITS

Output Configuration	Mode Switch	Connection Method	Output Circuits
NPN (E3V3-⊡6⊡)	Light-ON	Connect the pink cord to the brown cord. (see note)	Operation Stability Brown 12 to 24 VDC Connector Pin Indicator Indicator Indicator Indicator Indicator Indicator Main Zo Blue 0 V 0 V Imax Ima
	Dark-ON	Connect the pink cord to the blue cord or disconnect the pink cord from the blue cord. (see note)	Operation Operation Orange) Main circuit Black Black Blue Pink Operating selection Connector Pin Arrangement Ov Operation Ov Operation Operation Ov Operation Ov Operation Ov Operation Ov Operation Ov Operation Ov Operation Ov Operation Ov Operation Ov Operation Ov Operation Ov Operation Ov Operation Ov Operation Operation Ov Operation Operation Ov Operation Operation Ov Operation Opera



Note: The E3V3 Model with a junction connector has a white cord instead of a pink cord.

Emitter (NPN/PNP)



TIMING CHARTS

Output Configuration	Mode Switch	Connection Method	Timing Chart
NPN (E3V3-⊡6⊡)	Light-ON	Connect the pink cord to the brown cord. (see note)	Light received Light not received Uight indicator (Orange) OUtput transistor Load (relay) Release (Between brown and black)
	Dark-ON	Connect the pink cord to the blue cord or disconnect the pink cord from the blue cord. (see note)	Light received Light not received Light indicator OR (Orange) OFF Output ON transistor OFF Load Operate (relay) Release (Between brown and black)
PNP (E3V3-⊡8⊡)	Light-ON	Connect the pink cord to the brown cord. (see note)	Light received Light not received Light indicator (Orange) Output transistor OFF Load (relay) Release (Between blue and black)
	Dark-ON	Connect the pink cord to the blue cord or disconnect the pink cord from the blue cord. (see note)	Light received Light not received Light indicator (Orange) Output transistor Load (relay) Release (Between blue and black)

Note: The E3V3 Model with a junction connector has a white cord instead of a pink cord.

_

■ SENSITIVITY ADJUSTMENT (REFLECTIVE SENSORS)

(Diffuse reflective model in light-ON mode)

Item	Position A	Position B	Setting	
Sensing condition	Photoelectric Sensor	Photoelectric Sensor		
Sensitivity adjustor		CCCB		
Indicators	OFF STABILITY OPERATION (orange)	OFF OFF OFF OPERATION (green) OFF (orange)	OFF STABILITY (green) ON OPERATION (orange)	
Procedure	Locate the sensing object at the detection distance of the E3V3 and turn the sensitivity adjustor clockwise to increase the sensitivity of the E3V3 until the orange operation indicator is lit. The moment the orange operation indicator is lit, stop turning the sensitivity adjustor, the position of which is point A.	Remove the sensing object and turn the sensitivity adjustor clockwise until the E3V3 detects the background object and the orange operation indicator is lit. The moment the orange operation indicator is lit, stop turning the sensitivity adjustor, the position of which is point B. Turn the sensitivity adjustor counterclockwise to decrease the sensitivity of the E3V3 until the orange operation indicator is off. The moment the orange operation indicator is off, stop turning the sensitivity adjustor, the position of which is point C. If there is no background object, point C is where the sensitivity adjustor is set to maximum.	Set the sensitivity adjustor midway between points A and C, where the best sensitivity of the E3V3 for the sensing object is ensured, and make sure that the green stability indicator is lit with and without the sensing object at that position of the sensitivity adjustor. If the green stability is not lit, try another sensing method.	

Note: The rotation range of the sensitivity adjustor is 240°. Do not try to turn the sensitivity adjustor clockwise or counterclockwise excessively, otherwise the sensitivity adjustor will break.

Dimensions

Unit: mm (inch)







Bracket



With Mounting Bracket (E3V3-D62)

E39-L44







18 ...(0.71)..

₹¢

E39-L43



With Mounting Bracket (E3V3-D62)





E39-L98





E39-S7 Slits for E3V3-T



Note: 1. A: 0.5, 1, or 2 dia.

2. Attach an E39-S7 Slit to both the emission panel of the emitter and the receiver's sensing panel of the E3V3-T□□.

Detection Distance (Rating)

Item	Diameter	0.5 dia.	1 dia.	2 dia.
Slit attached	Emitter and receiver	25 mm (0.98)	100 mm (3.94)	400 mm (15.75)
	Receiver	400 mm (15.75)	800 mm (31.50)	1,500 mm (59.06)

Precautions

POWER SUPPLY

The permissible voltage imposed on the E3V3 must be 24 VDC + 10% maximum (i.e., 26.4 V). Make sure that the voltage imposed on the E3V3 is correct before turning the E3V3 on.

If a standard switching regulator is used as a power supply, the frame ground (FG) terminal and the ground (G) terminal must be grounded, or otherwise the E3V3 may malfunction due to the switching noise of the power supply.

OPERATION OF THE E3V3 WITH POWER TURNED ON

The E3V3 is ready to detect objects within 100 ms after the E3V3 is turned on. If the E3V3 and the load connected to the E3V3 each use an independent power supply, be sure to turn on the E3V3 first and then the load.

If the input/output lines of the photoelectric sensor are placed in the same conduit or duct as power lines or high-voltage lines, the photoelectric sensor could be induced to malfunction, or even be damaged, by electrical noise. Either separate the wiring, or use shielded lines as input/output lines to the photoelectric sensor.

The cord connected to the E3V3 can be extended up to 100 m provided that the diameter of each wire of the cord is 0.3 mm^2 minimum.

WATER RESISTANCE

Do not use the E3V3 in water, in the rain, or outdoors.

MOUNTING

When mounting the E3V3, do not hit the E3V3 with a hammer, or the E3V3 will loose watertightness.

Use M3 screws to mount the E3V3.

Move the E3V3 up, down, left, and right to find the range where the operating indicator is lit or unlit. Then locate the E3V3 in the center of the range, at which time make sure that the stability indicator is lit.

PRECAUTIONS WHEN USING THE E39-R3, E39-RSA, OR E39-RSB REFLECTOR

Before applying adhesive tape to the reflector, make sure that the reflector is free from oil or dust, or otherwise the adhesive tape will not stick to the reflector properly.

Do not cut or scratch the reflector or the reflector will loose watertightness.

Do not press the reflector with a metal object or a nail, otherwise the reflector will not function properly.



The E3V3 is not a safety component for ensuring the safety of people as defined in EC directive 91/368/EEC, or as covered by separate European standards or by any other regulations or standards.

NOTE: DIMENSIONS SHOWN ARE IN MILLIMETERS. To convert millimeters to inches divide by 25.4.

Omron Europe B.V. EMA-ISD, tel:+31 23 5681390, fax:+31 23 5681397, http://www.eu.omron.com/ema

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Sensor Fixings & Accessories category:

Click to view products by Omron manufacturer:

Other Similar products are found below :

 F03-01 SUS304 BINIL
 8000-5130
 FH-AP1
 PH-1-10M
 PH-1-20M
 PH-2-30M
 AC201
 R4
 ADI-LC3S
 EC18-WELL
 PC-15015
 K35-4
 A

 1923
 SS-12143
 STA12
 AP4-T
 PH-1-50M
 R6
 D01051301
 43912557-020
 MF-1
 D=3.2
 BGN-035
 E39-L7
 ZX-SB11
 D01070602
 606072

 606075
 Y92ES12PVC4A10ML
 Y92ES12PVC4S5ML
 SA9Z-F11
 Z49-SF1
 ZFV-XMF2
 E4R-R12A-CS3M010
 28810-2
 ZX-SW11E V3

 CCS-PL-LDR2-70
 E4R-R12A-CS3M020
 BS-1T CHITAN
 F03-01 CHITAN
 CCS-PD2-1012
 ZX-SFW11E V3
 PH-2-90M
 PH-2-5M

 XMLZL008
 AC244
 28810-1
 PH-1-40M
 SS-12225
 32043-500
 81532111