

Panasonic



ORDERING INFORMATION



Notes: 1. Please consult us about other coil voltages. 2. LED indication color is green.

TYPES 1. Standard type

Contact arrangement		Naminal acil valtaga	Without LED indication	With LED indication Part No.	
		Nominal coil voltage	Part No.		
		12 V DC	SFS2-DC12V	SFS2-L-DC12V	
	2 Form A 2 Form B	24 V DC	SFS2-DC24V	SFS2-L-DC24V	
1 00100	Γ	48 V DC	SFS2-DC48V	SFS2-L-DC48V	
4 poles		12 V DC	SFS3-DC12V	SFS3-L-DC12V	
	3 Form A 1 Form B	24 V DC	SFS3-DC24V	SFS3-L-DC24V	
		48 V DC	SFS3-DC48V	SFS3-L-DC48V	
	4 Form A 2 Form B	12 V DC	SFS4-DC12V	SFS4-L-DC12V	
		24 V DC	SFS4-DC24V	SFS4-L-DC24V	
		48 V DC	SFS4-DC48V	SFS4-L-DC48V	
	5 Form A 1 Form B	12 V DC	SFS5-DC12V	SFS5-L-DC12V	
6 poles		24 V DC	SFS5-DC24V	SFS5-L-DC24V	
		48 V DC	SFS5-DC48V	SFS5-L-DC48V	
	3 Form A 3 Form B	12 V DC	SFS6-DC12V	SFS6-L-DC12V	
		24 V DC	SFS6-DC24V	SFS6-L-DC24V	
		48 V DC	SFS6-DC48V	SFS6-L-DC48V	

Standard packing: Carton: 50 pcs.; Case: 200 pcs.

* Sockets and terminal sockets available.

2. With diode and LED indication type

Contact arrangement		Nominal coil voltage	Part No.		
		12 V DC	SFS2-L-DC12V-D		
	2 Form A 2 Form B	24 V DC	SFS2-L-DC24V-D		
1 noloo		48 V DC	SFS2-L-DC48V-D		
4 poles		12 V DC	SFS3-L-DC12V-D		
	3 Form A 1 Form B	24 V DC	SFS3-L-DC24V-D		
		48 V DC	SFS3-L-DC48V-D		
	4 Form A 2 Form B	12 V DC	SFS4-L-DC12V-D		
		24 V DC	SFS4-L-DC24V-D		
		48 V DC	SFS4-L-DC48V-D		
	5 Form A 1 Form B	12 V DC	SFS5-L-DC12V-D		
6 poles		24 V DC	SFS5-L-DC24V-D		
		48 V DC	SFS5-L-DC48V-D		
		12 V DC	SFS6-L-DC12V-D		
	3 Form A 3 Form B	24 V DC	SFS6-L-DC24V-D		
		48 V DC	SFS6-L-DC48V-D		

Standard packing: Carton: 50 pcs.; Case: 200 pcs.

* Sockets and terminal sockets available.

RATING

1. Coil data

Contact arrangement		Nominal coil voltage	Pick-up voltage (at 20°C 68°F)	Drop-out voltage (at 20°C 68°F)	Nominal operating current [±10%] (at 20°C 68°F)	Coil resistance [±10%] (at 20°C 68°F)	Nominal operating power (at 20°C 68°F)	Max. applied voltage (at 20°C 68°F)
		12V DC		10%V or more of nominal voltage (Initial)	30 mA	400Ω	- Approx. 360mW	110%V of nominal voltage
	2 Form A 2 Form B	24V DC			15 mA	1,600Ω		
1 -		48V DC			7.5mA	6,400Ω		
4 poles		12V DC			30 mA	400Ω		
	3 Form A 1 Form B	24V DC	-		15 mA	1,600Ω		
		48V DC			7.5mA	6,400Ω		
	4 Form A 2 Form B	12V DC	75%V or less of nominal voltage (Initial)		41.7mA	288Ω	Approx. 500mW	
		24V DC			20.8mA	1,152Ω		
		48V DC			10.4mA	4,608Ω		
		12V DC			41.7mA	288Ω		
6 poles	5 Form A 1 Form B	24V DC			20.8mA	1,152Ω		
-		48V DC			10.4mA	4,608Ω		
	3 Form A 3 Form B	12V DC			41.7mA	288Ω		
		24V DC			20.8mA	1,152Ω		
		48V DC	1		10.4mA	4,608Ω		

Note: The nominal operating current will increase by approximately 2mA due to the LED on the LED indication type.

	Item		Specifications				
Characteristics			4 poles	6 poles			
	Contact arrangement		2 Form A 2 Form B 3 Form A 1 Form B	4 Form A 2 Form B 5 Form A 1 Form B 3 Form A 3 Form B			
Contact	Contact resistance (Initial)		Max. 100 mΩ (By voltage drop 6 V DC 1A)				
	Contact mater	rial	Au flashed AgSnO ₂ type				
	Nominal switching capacity (resistive load)		6A 250V AC, 6A 30V DC				
	Max. switching power (resistive load)		1,500VA, 180W				
Detier	Max. switching voltage		250V AC, 125V DC				
Rating	Max. switching	g current	6 A (Reduce by 0.1 A/°C for temperature	es 70 to 85°C 158 to 185°F)			
	Min. switching	capacity (Reference value)*1	1mA 5V DC				
	Nominal opera	ating power	Approx. 360mW	Approx. 500mW			
	Insulation resi	istance (Initial)	Min. 1,000MΩ (at 500V DC) Measureme	ent at same location as "Breakdown voltage" section.			
		Between open contacts	1,500 Vrms for 1 min. (Detection current	: 10mA)			
	Breakdown voltage (Initial)	Between contact sets	2,500 Vrms for 1 min. (Detection current: 10mA); 7-8/9-10 between open contacts	2,500 Vrms for 1 min. (Detection current: 10mA); 7-8/11-12 between open contacts 9-10/13-14 between open contacts 11-12/13-14 between open contacts			
Electrical characteristics			4,000 Vrms for 1 min. (Detection current: 10mA); 3-4/5-6 between open contacts 3-4/7-8 between open contacts 5-6/9-10 between open contacts	4,000 Vrms for 1 min. (Detection current: 10mA); 3-4/5-6 between open contacts 3-4/7-8 between open contacts 5-6/9-10 between open contacts 7-8/9-10 between open contacts			
		Between contact and coil	4,000 Vrms for 1min (Detection current:	10mA)			
	Operate time (at 20°C 68°F)		Max. 20ms (Nominal coil voltage applied to the coil, excluding contact bounce time)				
	Response time (at 20°C 68°F)*2		Max. 8ms (Nominal coil voltage applied to the coil, excluding contact bounce time and without diode)*4				
	Release time (at 20°C 68°F)		Max. 20ms (Nominal coil voltage applied to the coil, excluding contact bounce time)				
	Shock	Functional	200 m/s ² (Half-wave pulse of sine wave: 11 ms; detection time: 10µs)				
Mechanical	resistance Destructive		1,000 m/s ² (Half-wave pulse of sine wave: 6 ms)				
characteristics	Vibration	Functional	10 to 55 Hz at double amplitude of 1.5 mm (Detection time: 10µs)				
	resistance	Destructive	10 to 55 Hz at double amplitude of 1.5 mm				
	Mechanical		Min. 10 ⁷ (at 180 times/min.)				
			250 V AC 6 A resistive load: Min. 10 ⁵ (at 20 times/min.)				
			30 V DC 6 A resistive load: Min. 105 (at 2	20 times/min.)			
Expected life	Ele etrice el		250 V AC 1 A resistive load: Min. 5×10 ⁵ (at 30 times/min.)				
	Electrical		30 V DC 1 A resistive load: Min. 5×10 ⁵ (at 30 times/min.)				
			[AC 15] 240 V AC 2 A inductive load: Min. 10^5 (at 20 times/min., $\cos\varphi = 0.3$)				
			[DC 13] 24 V DC 1 A inductive load: Min. 10 ⁵ (at 20 times/min., L/R = 48 ms)				
Conditions	Conditions for storage*3	r operation, transport and	Ambient temperature: -40°C to +85°C - Humidity: 5 to 85% R.H. (Not freezing ar				
	Max. operating	g speed	20 times/min. (at max. rating)				
Unit weight			Approx. 20 g .71 oz	Approx. 23 g .81 oz			

Notes: *1. This value can change due to the switching frequency, environmental conditions, and desired reliability level, therefore it is recommended to check this with the actual load.


*2. Response time is the time after the coil voltage turns off until the time when "a" contact turns off.

*3. The upper limit of the ambient temperature is the maximum temperature that can satisfy the coil temperature rise value. Refer to Usage, transport and storage conditions in NOTES.
*4. Response time of built-in diode type is 12 ms or less (excluding contact bounce time when nominal coil voltage is applied to the coil).

-3-


REFERENCE DATA

1. Operate/response/release time Tested sample: SFS4-DC24V (4 Form A 2 Form B), 20pcs. (a contacts: 80, b contacts: 40)




2. Coil temperature rise Tested sample: SFS4-DC24V (4 Form A 2 Form B),

3pcs. Measured portion: Inside the coil Ambient temperature: Room temperature (27°C 80.6°F), 70°C 158°F, 85°C 185°F




3. Malfunctional shock

Tested sample: SFS4-DC24V (4 Form A 2 Form B), 3pcs.



4. Max, switching capacity



Other contact gaps when contacts are welded

Sample: SFS4-DC24V (4 Form A 2 Form B)

The table below shows the state of the other contacts.

In case of form "NO" contact weld the coil applied voltage is 0 V.

In case of form "NC" contact weld the coil applied voltage is nominal.

		State of other contacts					
		3-4 (NC)	5-6 (NC)	7-8 (NO)	9-10 (NO)	11-12 (NO)	13-14 (NO)
	3-4 (NC)			>0.5	>0.5	>0.5	>0.5
	5-6 (NC)			>0.5	>0.5	>0.5	>0.5
Welded contact No.	7-8 (NO)	>0.5	>0.5				
Welded contact No.	9-10 (NO)	>0.5	>0.5				
	11-12 (NO)	>0.5	>0.5				
	13-14 (NO)	>0.5	>0.5				

>0.5: contact gap is kept at min. 0.5 mm .020inch Empty cells: either ON or OFF


Note: Contact gaps are shown at the initial state.

If the contact transfer is caused by load switching, it is necessary to check the actual loading.

-4-

DIMENSIONS (mm inch) The CAD data of the products with a CAD Data mark can be downloaded from: http://industrial.panasonic.com/ac/e/ 1.4 poles (2 Form A 2 Form B, 3 Form A 1 Form B)

External dimensions PC board pattern (Bottom view) CAD Data Max. 40 10.16 10-1.4 .055 dia. Max. 13 0 .512 13.97 (1.83)5.08 5.08 .200 11.43 .450 Max. 24 .945 Tolerance: ±0.1 ±.004 1.83 0.5 13.97 5.08 10 10.16 5.08 .200 11.43 .450 General tolerance: $\pm 0.3 \pm .012$ Schematic (Bottom view) + With diode and Standard LED indication type (3 Form A 1 Form B) (2 Form A 2 Form B) (2 Form A 2 Form B) (3 Form A 1 Form B) With LED indication (2 Form A 2 Form B) (3 Form A 1 Form B) 2. 6 poles (4 Form A 2 Form B, 5 Form A 1 Form B, 3 Form A 3 Form B) External dimensions PC board pattern (Bottom view) CAD Data Max. 50 Max. 1.969 10.16 14-1.4 .055 dia.



SAFETY STANDARDS

Certification authority	File No.	
UL/C-UL	E43149*	6A 277V AC, 6A 30V DC
TÜV	B 15 05 13461 346	6A 250V AC (cosφ=1.0), 6A 30V DC (0ms), AC15: 2A 240V AC (cosφ=0.3), DC13: 1A 24V DC (L/R 48ms)
* CSA standard: Certified b	v C-UL	

-5-

5.08

Tolerance: ±0.1 ±.004

5.08

NOTES

1. For cautions for use, please read "GENERAL APPLICATION GUIDELINES".

2. Coil operating power

Pure DC current should be applied to the coil. If it includes ripple, the ripple factor should be less than 5%. However, check it with the actual circuit since the characteristics may be slightly different.

The wave form should be rectangular.

3. Coil connection

When connecting coils, refer to the wiring diagram to prevent mis-operation or malfunction.

4. Cleaning

This relay is not sealed, therefore, immersion may cause failure. Be careful that flux does not overflow onto the PC board or penetrate inside the relay.

5. Soldering

When using automatic soldering, the following conditions are recommended

1) Preheating: 120°C 248°F, within 120 Sec (PC board solder surface)

2) Soldering: 260°C±5°C 500°F±41°F, within 6 Sec 6. Other

b. Other

1) If the relay has been dropped, the appearance and characteristics should always be checked before use.

characteristics should always be checked before use

2) The switching lifetime is defined under the standard test condition specified in the JIS* C 5442-1996 standard (temperature 15 to 35° C 59 to 95° F, humidity 25 to 75°). Check this with the actual product as it is affected by the coil driving circuit, load type, activation frequency, activation phase, ambient conditions and other factors.

Also, be especially careful with loads such as those listed below. (1) When used for AC load-operation and the operating phase is synchronous. Rocking and fusing can easily occur due to contact shifting.

(2) During high frequency on/off operation with certain loads, arcing may occur at the contacts. This can cause fusion to Oxygen and Nitrogen gas in the air creating Nitric Acid (HNO₃) which can cause corrosion to the contacts.

Please see the following countermeasure examples:

- 1. Incorporate an arc-extinguishing circuit.
- 2. Lower the operating frequency
- 3. Lower the ambient humidity

3) For secure operations, nominal coil voltage should be applied. In addition, please note that pick-up and drop-out voltage will vary according to the ambient temperature and operating conditions.

4) Heat, smoke, and/or fire may occur if the relay is used outside the allowable ranges for the coil ratings, contact ratings, operating cycle lifetime, and other specifications. Therefore, do not use the relay if these ratings are exceeded. Also, make sure that the relay is wired correctly.

5) Incorrect wiring may cause false operation or generate heat or flames.

6) Check the ambient conditions when storing or transporting the relays and devices containing the relays. Freezing or condensation may occur in the relay causing damage. Avoid exposing the relays to heavy loads, or strong shock and vibration.

7. Usage, transport and storage conditions

1) Ambient temperature, humidity, and atmospheric pressure during usage, transport, and storage of the relay:


(1) Temperature: -40 to +85°C -40 to +185°F

(When the temperature is 70 to 85° C 158 to 185° F, reduce the 6 A max. switching current by 0.1 A/°C.)

(2) Humidity: 5 to 85% RH (Avoid freezing and condensation.) The humidity range varies with the temperature. Use within the range indicated in the graph below.

(3) Atmospheric pressure: 86 to 106 kPa

Temperature and humidity range for usage, transport, and storage



2) Condensation

Condensation forms when there is a sudden change in temperature under high temperature and high humidity conditions. Condensation will cause deterioration of the relay insulation.

3) Freezing

Condensation or other moisture may freeze on the relay when the temperatures is lower than 0°C 32°F. This causes problems such as sticking of movable parts or operational time lags. 4) Low temperature and low humidity

At low temperature, low humidity environments, the plastic becomes brittle.

Please note corrections.

8. Please connect DC coil types with LED and built-in diode correctly by verifying the coil polarity ("+" and "-"). Connecting with reverse polarity will cause the LED not to light and damage the built-in diode due to its specification.

Panasonic

ACCESSORIES



TYPES

1. Sockets

Туре	No. of poles	Part No.		
PC board sockets	4 poles	SFS4-PS		
PC board sockets	6 poles	SFS6-PS		

Standard packing: Carton: 10 pcs.; Case: 100 pcs.

2. DIN rail terminal socket

	Туре	No. of poles	Part No.
New	Terminal sockets	4 poles	SFS4-SFD-R
for spade and ring tongue terminals		6 poles	SFS6-SFD-R

Standard packing: Carton: 10 pcs.; Case: 100 pcs.

Note: For previous products (spade tongue terminal dedicated terminal sockets), please order SFS4-SFD for 4 poles and SFS6-SFD for 6 poles.

External dimensions

RATING

Specifications


Item	Specifications		
Breakdown voltage (Initial)	Between each terminal: 2,500 Vrms for 1 min. (Detection current: 10mA)		
Insulation resistance (Initial)	Min. 1,000M Ω (at 500V DC) Measurement at same location as "Breakdown voltage" section.		
Max. carrying current	6 A (Reduce by 0.1 A/°C for temperatures 70 to 85°C 158 to 185°F)		

The CAD data of the products with a CAD Data mark can be downloaded from: http://industrial.panasonic.com/ac/e/

DIMENSIONS (mm inch)

1. PC board sockets (4 poles) (SFS4-PS)






<u>6</u>

(When 3 Form A 1 Form B mounted)

(When 3 Form A 1 Form B mounted)

PC board pattern (Bottom view)



General tolerance: $\pm 0.3 \pm .012$

Schematic (Bottom view)

Standard

With LED indication

$$+ \underbrace{1}_{2} \underbrace{1}_{2} \underbrace{1}_{5} \underbrace{1}_{6} \underbrace{1}_{9} \underbrace{1}_{10} \underbrace{1}_{1$$


0.8

10.16

34 78

(When 2 Form A 2 Form B mounted)


(When 2 Form A 2 Form B mounted)




(When 2 Form A 2 Form B mounted) (When 3 Form A 1 Form B mounted)

2014.08 industrial.panasonic.com/ac/e/

SFS ACCESSORIES



3. Terminal socket for spade and ring tongue terminals (For 4 poles finger protect type)




Note: Ring tongue terminals cannot be used with conventional DIN rail terminal socket (SFS4-SFD). In use of a ring tongue terminals, please use SFS4-SFD-R.

-2-

4. Terminal socket for spade and ring tongue terminals (For 6 poles finger protect type)









2-4


6.5

Mounting hole dimensions





Schematic (Top view)



* Reference value (when using DIN rail ATA48011)

Note: Ring tongue terminals cannot be used with conventional DIN rail terminal socket (SFS6-SFD). In use of a ring tongue terminals, please use SFS6-SFD-R.


NOTES

Installation

- 1) Attach directly to the chassis or use a DIN rail.
- (1) When attaching directly to chassis
- Use a M3.5 screw, spring washer, and hex nut.
- For the mounting pitch, refer to the dimensions.
- (2) When installing on a DIN rail
- Use a 35 mm 1.378 inch wide DIN rail (DIN46277).
- Install and remove as shown in the figures below.

<When installing> When removing> Pull Screwdriver DIN rail

2) Refer to the figure below for applicable wire-pressed terminals.



-3-

For cautions for use, please read "GUIDELINES FOR RELAY USAGE". https://industrial.panasonic.com/ac/e/control/relay/cautions_use/index.jsp

Precautions for Coil Input

Long term current carrying

A circuit that will be carrying a current continuously for long periods without relay switching operation. (circuits for emergency lamps, alarm devices and error inspection that, for example, revert only during malfunction and output warnings with form B contacts) Continuous, long-term current to the coil will facilitate deterioration of coil insulation and characteristics due to heating of the coil itself.

For circuits such as these, please use a magnetic-hold type latching relay. If you need to use a single stable relay, use a sealed type relay that is not easily affected by ambient conditions and make a failsafe circuit design that considers the possibility of contact failure or disconnection.

DC Coil operating power

Steady state DC current should be applied to the coil. The wave form should be rectangular. If it includes ripple, the ripple factor should be less than 5%.

However, please check with the actual circuit since the electrical characteristics may vary. The rated coil voltage should be applied to the coil and the set/reset pulse time of latching type relay differs for each relays, please refer to the relay's individual specifications.

Coil connection

When connecting coils of polarized relays, please check coil polarity (+,-) at the internal connection diagram (Schematic). If any wrong connection is made, it may cause unexpected malfunction, like abnormal heat, fire and so on, and circuit do not work. Avoid impressing voltages to the set coil and reset coil at the same time.

Ambient Environment

•Usage, Transport, and Storage Conditions

During usage, storage, or transportation, avoid locations subjected to direct sunlight and maintain normal temperature, humidity and pressure conditions.

Temperature/Humidity/Pressure


When transporting or storing relays while they are tube packaged, there are cases the temperature may differ from the allowable range. In this case be sure to check the individual specifications. Also allowable humidity level is influenced by temperature, please check charts shown below and use relays within mentioned conditions. (Allowable temperature values differ for each relays, please refer to the relay's individual specifications.)

1) Temperature:

The tolerance temperature range differs for each relays, please refer to the relay's individual specifications

- 2) Humidity: 5 to 85 % RH
- 3) Pressure: 86 to 106 kPa

Humidity(%RH)



Maximum allowable voltage and temperature rise

Proper usage requires that the rated coil voltage be impressed on the coil. Note, however, that if a voltage greater than or equal to the maximum continuous voltage is impressed on the coil, the coil may burn or its layers short due to the temperature rise. Furthermore, do not exceed the usable ambient temperature range listed in the catalog.

Operate voltage change due to coil temperature rise (Hot start)

In DC relays, after continuous passage of current in the coil, if the current is turned OFF, then immediately turned ON again, due to the temperature rise in the coil, the pick-up voltage will become somewhat higher. Also, it will be the same as using it in a higher temperature atmosphere. The resistance/temperature relationship for copper wire is about 0.4% for 1°C, and with this ratio the coil resistance increases. That is, in order to operate of the relay, it is necessary that the voltage be higher than the pick-up voltage and the pick-up voltage rises in accordance with the increase in the resistance value. However, for some polarized relays, this rate of change is considerably smaller.

Dew condensation

Condensation occurs when the ambient temperature drops suddenly from a high temperature and humidity, or the relay is suddenly transferred from a low ambient temperature to a high temperature and humidity. Condensation causes the failures like insulation deterioration, wire disconnection and rust etc.

Panasonic Corporation does not guarantee the failures caused by condensation.

The heat conduction by the equipment may accelerate the cooling of device itself, and the condensation may occur.

Please conduct product evaluations in the worst condition of the actual usage. (Special attention should be paid when high temperature heating parts are close to the device. Also please consider the condensation may occur inside of the device.)

Icing

Condensation or other moisture may freeze on relays when the temperature become lower than 0°C. This icing causes the sticking of movable portion, the operation delay and the contact conduction failure etc. Panasonic Corporation does not guarantee the failures caused by the icing.

The heat conduction by the equipment may accelerate the cooling of relay itself and the icing may occur. Please conduct product evaluations in the worst condition of the actual usage.

•Low temperature and low humidity

The plastic becomes brittle if the switch is exposed to a low temperature, low humidity environment for long periods of time.

•High temperature and high humidity

Storage for extended periods of time (including transportation periods) at high temperature or high humidity levels or in atmospheres with organic gases or sulfide gases may cause a sulfide film or oxide film to form on the surfaces of the contacts and/or it may interfere with the functions. Check out the atmosphere in which the units are to be stored and transported.

Package

In terms of the packing format used, make every effort to keep the effects of moisture, organic gases and sulfide gases to the absolute minimum.

Silicon

When a source of silicone substances (silicone rubber, silicone oil, silicone coating materials and silicone filling materials etc.) is used around the relay, the silicone gas (low molecular siloxane etc.) may be produced.

This silicone gas may penetrate into the inside of the relay. When the relay is kept and used in this condition, silicone compound may adhere to the relay contacts which may cause the contact failure. Do not use any sources of silicone gas around the relay (Including plastic seal types).

Others

Cleaning

ultrasonic energy.

- Although the environmentally sealed type relay (plastic sealed type, etc.) can be cleaned, avoid immersing the relay into cold liquid (such as cleaning solvent) immediately after soldering. Doing so may deteriorate the sealing performance.
- 2) Cleaning with the boiling method is recommended(The temperature of cleaning liquid should be 40°C or lower).
 Avoid ultrasonic cleaning on relays. Use of ultrasonic cleaning may cause breaks in the coil or slight sticking of the contacts due to

NOx Generation

When relay is used in an atmosphere high in humidity to switch a load which easily produces an arc, the NOx created by the arc and the water absorbed from outside the relay combine to produce nitric acid. This corrodes the internal metal parts and adversely affects operation. Avoid use at an ambient humidity of 85%RH or higher (at 20°C). If use at high humidity is unavoidable, please contact our sales representative.

Please refer to **"the latest product specifications"** when designing your product.

•Requests to customers:

https://industrial.panasonic.com/ac/e/salespolicies/

Please contact

Panasonic Corporation

Electromechanical Control Business Division 1006, Oaza Kadoma, Kadoma-shi, Osaka 571-8506, Japan industral.panasonic.com/ac/e/



©Panasonic Corporation 2019

Specifications are subject to change without notice.

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for General Purpose Relays category:

Click to view products by Panasonic manufacturer:

Other Similar products are found below :

 APF30318
 JVN1AF-4.5V-F
 PCN-105D3MHZ
 5JO-10000S-SIL
 5JO-1000CD-SIL
 5JO-400CD-SIL
 LY2S-AC220/240
 LYQ20DC12

 6031007G
 6131406HQ
 6-1393099-8
 6-1393122-4
 6-1393123-2
 6-1393767-1
 6-1393843-7
 6-1415012-1
 6-1419102-2
 6-1423698-4
 6

 1608051-6
 6-1616170-6
 6-1616248-2
 6-1616348-2
 6-1616350-1
 6-1616350-8
 6-1616358-7
 6-1616359-9
 6-1616360-9
 6

 1617039-1
 6-1617090-2
 6-1617347-5
 6-1617353-3
 6-1617801-8
 6-1618248-4
 M83536/1-027M
 M83725/1-005
 CX-4014

 MAHC-5494
 MAVCD-5419-6
 703XCX-120A
 7-1393100-5
 7-1393111-7
 7-1393767-8
 7-1419130-3
 7-1608047-2
 7-1608065

 1
 7-1617090-0
 7-1617090-4
 4
 4
 4
 4
 4
 4
 4
 4
 4
 4
 4
 4
 4
 4
 4
 4
 4
 4
 4
 4
 4
 4
 4
 4
 4
 4
 4
 4
 4
 4
 4
 4
 4
 4
 4
 4