

Vacuum Base Repair Kit

Repair your torn or damaged vacuum base pad!

For use with PanaVise 380 and 381 vacuum bases.

- To determine if your Vacuum Base needs replacing, clean the pad with a clean towel and make sure that is free of debris. Then attach it to a clean, non-porous surface (such as a window). If it still loses suction, the pad needs to be replaced.
- Includes rubber pad, handle and lock washer
- For 380 Vacuum Base or 381 Vacuum Base PanaVise



In Use Example for the Vacuum Base Repair Kit



Before you consider a Vacuum Base Repair Kit, clean the pad and then test on a known flat, smooth and non-porous surface like a piece of glass or window.



Before you consider a Vacuum Base Repair Kit, clean the bottom of you current pad with water or a simple glass cleaner and then check to see if it holds.

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for [PCB Holders & Visers](#) category:

Click to view products by [Panavise](#) manufacturer:

Other Similar products are found below :

[510-R](#) [318-30](#) [511-A](#) [513-B](#) [513-C](#) [318-18](#) [400](#) [510](#) [856-03](#) [204](#) [MC24588](#) [513-A](#) [510-A](#) [301](#) [303](#) [304](#) [305](#) [308](#) [311](#) [312](#) [797-14](#) [845-](#)
[246](#) [327-12](#) [324](#) [727-04](#) [333](#) [727-12](#) [335](#) [592-12](#) [337](#) [670-A](#) [343](#) [344](#) [346](#) [352](#) [353](#) [354](#) [358](#) [366](#) [371](#) [376](#) [380](#) [385](#) [MC23796](#) [502](#) [506](#)
[507](#) [510](#) [511](#) [570](#)