


# TA018 AC/DC mA CURRENT CLAMP USER'S GUIDE



## INTRODUCTION

The AC/DC mA Current Clamp is a transducer which will allow your multimeter to measure low electrical or/and electronic current up to 60 amperes AC/DC, with a frequency response up to 20kHz. When measuring current with this clamp, there is no need to break a circuit or to disturb the insulation

The extended measurement jaws allow performing measurements in a narrow space. When measuring DC current, a simple operating push button is designed for zero adjustment. The clamp adaptor is applicable to leakage detection or monitoring.

## APPLICATION PROCEDURES

- 1. Connect the BNC plug to the input of any oscilloscope or other measuring instrument with an input impedance of at least 10 k $\Omega$ .
- Set the power switch from "OFF" to the desired range, 1mV/10mA or 1mV/100mA position. The green LED will light to indicate that the clamp is switched on.
- 3. For current measurement below 2A, set the unit to 1mV/ 10mA range and set the oscilloscope to 200mV AC range for AC current measurements, or 200mV DC range for DC current measurements. If the measured current exceeds 2A, set the unit to 1mV/100mA range.
- When perform DC current measurement, always push the zero adjustment button on the clamp until the oscilloscope reads zero.
- Clamp the jaws around the current-carrying conductor and interpret the reading according to Step 3 above.
- 6. When 1mV/10mA range of clamp unit is selected, multiply the reading displayed on the oscilloscope by "10" to interpret the measured current value in mA. For example, if the oscilloscope reads 10mV, the measured current is 10x10=100mA.
  - When 1mV/100mA range is selected, multiply the reading displayed on the oscilloscope by "100" to interpret the measured current value in mA. For example, if the oscilloscope reads 5mV, the measured current is 5x100=500mA.

## **APPLICATION NOTES**

- In the case of DC current, the output is positive when the current flows from the upside to the underside of the clamp.
- 2.In the case of DC current measurement, a hysteresis effect can occur so that it is impossible to zero the clamp properly. To eliminate this effect, open and close the jaws several times and push zero adjustment button.

## **OPERATOR SAFETY**

- 1.Do not clamp around conductors with voltages equal to or exceeding 300VDC or 240V rms AC.
- To avoid physical injury, measurements on bare conductors or conductors with cracked or frayed insulator are forbidden.

## **SPECIFICATIONS**

#### **GENERAL**

Captured Conductor Size: 9 mm maximum. Low Battery Indicator: Red LED lighting. Operating Temperature: 0°C to 40°C, 70% R.H. Storage Temperature: -20°C +70°C, 80% R.H.

Battery Type: 9V DC, NEDA 1604, 6F22, 006P.

Weight: 250 gm typical Dimensions: 195mm (H) x 70mm (W) x 33mm (D).

Output: Cable with BNC plug.

## ELECTRICAL (At 23±5°C, 70% R.H. maximum)

Effective Measurement Range

1mV/10mA: 10mA to 20A DC or rms AC for 200mV range

of the oscilloscope.

1mV/100mA: 10mA to 20A DC or rms AC for 200mV range

of the oscilloscope.

20A to 60A DC or rms AC for 2V range of the

oscilloscope.

Accuracy

System accuracy: Current clamp accuracy + DMM accuracy.

For example, if the measured conductor carries a 100mA current, set the current clamp to 1mV/10mA range to get an output signal of 10mV. Suppose the accuracy of the units is 2.0%, the tolerance limit should be between 10.20mV maximum and 9.80mV minimum.

When the unit is connected to a DSO whose accuracy is supposed to be 0.5% in 200mV range,the reading displayed on the DSO will be 10.25mV max. (10.20mV x (1+0.5%)=10.25mV) and 9.75mV min. (9.80mV x (1-0.5%)=9.75mV)

## **Current Clamp Accuracy**

DCA range: 1mV/10mA

± (2.0%±5mA) 10mA~20A

DCA range: 1mV/100mA

± (2.0%±20mA) 100mA~40A ± (4.0%±0.3A) 40A~60A

ACA range: 1mV/10mA

±(2.0%±5mA) 10mA~10A (40Hz~2kHz) ±(4.0%±30mA) 10mA~10A (2kHz~10kHz) ±(6.0%±30mA) 10mA~10A (10kHz~20kHz) ±(8.0%±30mA) 10A~15A (40Hz~20kHz)

ACA range: 1mV/100mA

±(2.0%±30mA) 100mA~40A (40Hz~1kHz) ±(4.0%±30mA) 100mA~40A (1kHz~2kHz) ±(6.0%±30mA) 100mA~40A (3kHz~5kHz) ±(8.0%±0.3A) 40A~60A (40Hz~5kHz)

Load Resistance: 10 kΩ typical

Temperature Coefficient: 0.1x(specified accuracy) per

degree C. (0°C to 18°C, 28°C to 40°C)

## SAFETY INFORMATION

## Cleaning

Wipe the case with a damp cloth and mild detergent. Do not use abrasives or solvents. Dirt or moisture in the terminals can affect readings.

Safety: Conforms to EN 61010-1, EN 61010-2-032, CAT II 300V, Class II, Pollution degree 2 Indoor use.

**CAT II:** Is for measurements performed on low-voltage circuits directly connected to the mains.

EMC: Conforms to EN 61326-1.

#### The symbols used on this instrument are:

Dangerous voltage.

▲ Caution, refer to accompanying documents

Equipment protected throughout by Double insulation (Class II)

→ Alternating current 
→ Direct current 
7000-1698A2

# **X-ON Electronics**

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Pico manufacturer:

Other Similar products are found below:

PICOSCOPE 3204D PICOSCOPE 3406D MSO PICOSCOPE 2405A PICOSCOPE 3203D PICOSCOPE 3403D PICOSCOPE 3404D MSO PICOSCOPE 4224 400BHD PICOSCOPE 4262 PICOSCOPE 4224 KIT PICOLOG 1216 PICOSCOPE 3403D MSO TA044 USB PT-104 MI136 ADC-24 PICOSCOPE 3406D PICOLOG CM3 USB DRDAQ KIT USB DRDAQ PH MI031 PA149 PICOSCOPE 4444 1000V CAT III KIT SE029 SE050 SE055 SE056 SE057 SE058 MI029 MI030 DRDAQ KIT PICOCONNECT 910 KIT DD103 PICOSCOPE 5243D PICOSCOPE 5443D AS108 69320 81170 PICOSCOPE 4424 PICOLOG 1012 USB TC-08 SE028 TA167 PICOSCOPE 3205D PICO CONNECT 441 PP624 TC-08 TERMINAL BOARD SE049 SE051 SE052