

## STANDARD SERIES ADAPTERS





22 / 2 flats

Interface

2B4 Female - BNC Male

27 / flats

Interface

7/16 Male - HN Female

-24/2 flats

40 nominal

Part number


R191 454 000


Part number

R191 907 000


Ø31,9 knur

M29×1.5





Part number	Interface
R191 908 000	7/16 Female - HN Male




	35 nominal
Part number	Interface
R191 723 000	7/16 Female - N Female


To download data sheets and assembly instructions, visit **www.radiall.com** & enter the part number in the Search box. **Bold** part numbers represent products typically in stock & available for immediate shipment. See page 8 and 9 for packaging information.










Part number	Interface
R191 720 000	7/16 Female - N Male



Part number	Interface
R191 353 711	BMA Female - SMA Female







Interface


BMA Male - SMA Male


Part number

R191 354 001


IDARD	SERIES ADAPTE
Ø 32 knut	Hex 27/flats Hex 18/flats Hex 18/flats
umber	Interface








Part number	Interface	Panel drilling
R191 355 001	BMA Male - SMA Female	P03



Part number	Interface	
R191 351 701	BMA Female - SMA Male	



	/	
Part number	Interface	
R191 350 001	BMA Male - SMA Male	18-17


To download data sheets and assembly instructions, visit **wwwradialLcom** & enter the part number in the Search box. **Bold** part numbers represent products typically in stock & available for immediate shipment. See page 8 and 9 for packaging information.

Panel drilling


P03



## **STANDARD SERIES ADAPTERS**









Ø23 knurl 38 nominal


Part number	Interface
R191 449 000	BNC Female - HN Male









Part number Interface Panel drilling R191 422 000 BNC Female - N Female P11 Flat Gasket Ø19,5 O-Ring Gasket 13.42 / 2 Flats 12






Part number	Interface	Panel drilling
R191 424 000	BNC Female - N Female	P01




To download data sheets and assembly instructions, visit www.radiall.com & enter the part number in the Search box. Bold part numbers represent products typically in stock & available for immediate shipment. See page 8 and 9 for packaging information.


RADIALL




Part number	Interface
R191 421 000	BNC Female - N Male





Part number	Interface
R191 305 000	BNC Male - SMA Female














Part number	Interface
R191 417 000	BNC Male - N Male



Part number	Interface
R191 303 000	BNC Female - SMA Male



Part number	Interface	Panel drilling
5512-7501-000	BNC Female - SMB Male	P17



18-19


To download data sheets and assembly instructions, visit www.radiall.com & enter the part number in the Search box. Bold part numbers represent products typically in stock & available for immediate shipment. See page 8 and 9 for packaging information.




P14

**ADAPTERS 50Ω** 

## **STANDARD SERIES ADAPTERS**





9,6

Ø12.2 knurl

Interface

Panel drilling

P02

Part number

R191 209 000

Part number

R191 123 000

Part number

Part number

R191 403 000

Ø11 diamond knurl

17,7 27,5


15,4

R191 120 000 BNC Female - SMC Male


Ø14,3 diamond knurl

Interface


32 nominal



Interface	
BNC Male - SMB Male	
Hex 6/flats	Hex 17.5/flats Hex 6/ flats
Interface BNC Female - SMC Female	Part number Interface Panel drilling   R191 124 000 BNC Female - SMC Female P06




Part number	Interface
R191 117 000	BNC Male - SMC Male



BNC Male - TNC Female To download data sheets and assembly instructions, visit www.radiall.com & enter the part number in the Search box. Bold part numbers represent products typically in stock & available for immediate shipment.

See page 8 and 9 for packaging information.


RADIALL The next conneXion





See page 8 and 9 for packaging information.

RADIALL


## **STANDARD SERIES ADAPTERS**









Part number	Interface
R191 386 000	MCX Female - SMA Male



Part number	Interface
R191 389 200	MMBX Male - SMA Female





Part number	Interface
R191 398 020	MMCX Male - SMA Female






To download data sheets and assembly instructions, visit www.radiall.com & enter the part number in the Search box. Bold part numbers represent products typically in stock & available for immediate shipment. See page 8 and 9 for packaging information.








Part number	Interface	Panel drilling
R191 399 100	MMCX Female - SMA Female	P07
















Part number	Interface
R191 327 000	N Female - SMA Male







Part number	Interface	Panel drilling	
R191 236 000	N Female - SMB Male	P01	18-23

To download data sheets and assembly instructions, visit www.radiall.com & enter the part number in the Search box. Bold part numbers represent products typically in stock & available for immediate shipment. See page 8 and 9 for packaging information.


RADIALL

ADAPTERS 50Ω







Part number	Interface
R191 513 000	N Male - TNC Female



'art number	Interface
2191 511 000	N Female - TNC Male




R191 733 000 N Female - UHF Male



To download data sheets and assembly instructions, visit www.radiall.com & enter the part number in the Search box. Bold part numbers represent products typically in stock & available for immediate shipment. See page 8 and 9 for packaging information.

RADIALL The next conneXion





To download data sheets and assembly instructions, visit www.radiall.com & enter the part number in the Search box. Bold part numbers represent products typically in stock & available for immediate shipment. See page 8 and 9 for packaging information.

RADIALL


ADAPTERS 50Ω

### **STANDARD SERIES ADAPTERS**






Part number	Interface
R191 311 000	SMA Male - TNC Female






Hex 8 / flats 5.5 / 2 flats


Part number	Interface
R191 347 000	SMA Male - SSMA Female



Part number 5938-1503-000 SM/



Interface



To download data sheets and assembly instructions, visit www.radiall.com & enter the part number in the Search box. Bold part numbers represent products typically in stock & available for immediate shipment. See page 8 and 9 for packaging information.

18-26

RADIALL The next conneXion

### **X-ON Electronics**

Largest Supplier of Electrical and Electronic Components

Click to view similar products for RF Adapters - Between Series category:

Click to view products by Radiall manufacturer:

Other Similar products are found below :

5945-9503-000 MCX/F-SMA/M R192417010 ADBJ20-E1-BJ379 ADM2 ADPL75-A1-PL75 242191 9317505 29-3835P AD130 ADBJ20-E1-PL74 ADBJ20-E2-BJ79 ADBJ77-A1-PL375 ADBJ77-E1-UPL20 ADRMF370 242215 242228 R125680000W R192430000 UAD95 1057367-1 8311505 R114704000 R451034500 R451030500 R451543000 HDVDPN ADBJ20-K1-PL20 R451570000 R451034000 J9 J3WE-5 R451032500 242201RP 17K132-K0085 AD-RSMAF-RTNC 53K156-K00N5 02K119-K00E3 29S132-K01N5 53S156-K00N5 02S119-S00E3 28K132-K00N5 02S109-K00S3 27-8200TP 242235 ADBJ20-E1-BJ89 000-2900 321-102-003 (SMA-50/2-H155/W1.03 AU) 1057377-1 321-350-001 (SMA-50-R/2-RG316/N2.01)