

Dimensions


Control and signalling units Ø 22

Harmony® style 4
Pushbuttons, switches and pilot lights, with chromium plated metal bezel
Completed units with contacts


1

Pushbuttons, spring return


ZB4-BA● + ZB4-BZ●●● + ZBE-●●●




ZB4-BL● + ZB4-BZ●●●



Common face view





ZB4-BP● + ZB4-BZ●●●





Mushroom head pushbuttons, spring return

ZB4-BC2 + ZB4-BZ●●●



Double-headed pushbuttons, spring return

ZB4-BL●●●● + ZB4-BZ●●●




e: panel thickness 1 to 6 mm.


(1) Additional row of contacts or double contact.

Emergency stop and mushroom head pushbuttons


ZB4-BT4 + ZB4-BZ●●●,
ZB4-BT84 + ZB4-BZ●●●




ZB4-BS54 + ZB4-BZ●●●,
ZB4-BS844 + ZB4-BZ●●●



ZB4-BS514 + ZB4-BZ●●●,
ZB4-BS944 + ZB4-BZ●●●





Common face view





e: panel thickness 1 to 6 mm.

Selector switches

Standard handle operator
ZB4-BD●● + ZB4-BZ●●●





Long handle operator
ZB4-BJ●● + ZB4-BZ●●●





Key switches

ZB4-BG●● + ZB4-BZ●●●



Heads for toggle switches

ZB4-BD●●



e: panel thickness 1 to 6 mm.

General:
pages 1/2 to 1/7

Characteristics:
pages 1/8 to 1/11

References:
pages 1/12 to 1/47

Control and signalling units Ø 22


Harmony® style 4

Pushbuttons, switches and pilot lights, with chromium plated metal bezel


Completed units with light functions with and without contacts




Pilot lights
Integral LED
ZB4-BVB●/BVG●/BVM● + ZB4-BV0●●




Direct supply
ZB4-BV6 + ZB4-BV0●●



Via integral transformer
ZB4-BV3, 4 + ZB4-BV0●●




Common face view




e: panel thickness 1 to 6 mm.


Illuminated pushbuttons
Integral LED
ZB4-BW0●●● + ZB4-BW3●●●
+ ZBE-●●●




Direct supply
ZB4-BW0●● + ZB4-BW3●●





Via integral transformer
ZB4-BW0●● + ZB4-BW3●●





Common face view



Double-headed pushbuttons with pilot light
Integral LED
ZB4-BW0●●● + ZB4-BW8●●●●●




Illuminated selector switches
Integral LED
ZB4-BK1●●● + ZB4-BW0●●●



e: panel thickness 1 to 6 mm.

(1) Additional row of contacts or double contact.

Support panel cut-out for pushbuttons, switches and pilot lights (1)



(1) Fixing centres for pushbuttons, switches and pilot lights fitted with Faston connector terminals: 32 x 45 mm.

General:
pages 1/2 to 1/7

Characteristics:
pages 1/8 to 1/11


References:
pages 1/12 to 1/47

Control and signalling units Ø 22


Harmony® style 4
 Pushbuttons, switches and pilot lights, with chromium plated metal bezel
 Sub-assemblies, ZB4-B: contact functions

1


Heads for pushbuttons, spring return
 ZB4-BA●, BA●●●, ZB4-BA●8
 ZB4-BL●, BL●●●



Common face view




ZB4-BP●●
 ZB4-BP●S




ZB4-	a
BP●●	36,5
BP●S	33

Heads for double-headed pushbuttons, spring return


ZB4-BA81●●,
 ZB4-BA82●●




ZB4-BL83●●,
 ZB4-BL84●●




Common face view




ZB4-BA91●●,
 ZB4-BA92●●




ZB4-BL93●●,
 ZB4-BL94●●




Common face view





Heads for pushbuttons
 "Push-push to release"
 ZB4-BH0●, ZB4-BH●





Common face view



Mushroom head
 ZB4-BC●4





ZB4-BC●, BR●





ZB4-	Ø
BC●	40
BR●	60



Mushroom heads for pushbuttons, latching
 Push-pull
 ZB4-BT●, BT●4





ZB4-BX2, BX4





ZB4-BR●16



Turn to release
 ZB4-BS4●, BS834



ZB4-BS5●, BS844, BS6●



ZB4-	Ø
BS5●, BS844	40
BS6●	60

General:
 pages 1/2 to 1/7

Characteristics:
 pages 1/8 to 1/11


References:
 pages 1/12 to 1/47

Control and signalling units Ø 22


Harmony® style 4
 Pushbuttons, switches and pilot lights, with chromium plated metal bezel
 Sub-assemblies, ZB4-B: contact functions

1

Mushroom heads for pushbuttons, latching (continued)
 Key release
 ZB4-BS7●, BS934



ZB4-BS1●, BS2●, BS944, BS964




ZB4-	Ø
BS1●, BS944	40
BS2●, BS964	60

Heads for selector switches
 Standard handle
 ZB4-BD●, BD0●M




Long handle
 ZB4-BJ●, BD0●M




Knurled knob
 ZB4-BD●9




Key switches
 ZB4-BG●, BG0●, BG0●M



Bodies for pushbuttons and switches
 Screw clamp terminal connections
 ZB4-BZ10●, BZ141



Plug-in connector
 ZB4-BZ10●4, BZ1414




Control and signalling units Ø 22

Harmony® style 4
 Pushbuttons, switches and pilot lights, with chromium plated metal bezel
 Sub-assemblies, ZB4-B: light functions with and without contacts


1

Heads for pilot lights, with light source


Integral LED
 ZB4-BV0●3, BV0●3S



Incandescent, neon or LED
 ZB4-BV0●, BV0●S




Common
 face view




Bodies for pilot lights, screw clamp terminal connections


Integral LED
 ZB4-BV●●



Direct supply, for BA 9s bulb
 ZB4-BV6




Via integral transformer, for BA 9s bulb
 ZB4-BV●, BV●D●



Bodies for pilot lights, plug-in connector

Integral LED
 ZB4-BV●●4



X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for [Switch Actuators](#) category:

Click to view products by [Schneider](#) manufacturer:

Other Similar products are found below :

[LW1B-M0](#) [61-1330.0](#) [61-2607.0/D](#) [680-4000-00](#) [704.411.018I](#) [704.412.0](#) [704.633.1](#) [704.730.1](#) [704.733.0](#) [79452124](#) [84-1221.7](#) [G6083](#)
[9PA24](#) [120-1867-000](#) [ADC-418G](#) [12MA7](#) [HW1M-L2222](#) [200-.704-00](#) [JS-10008](#) [JS-10083](#) [JS-10118](#) [JS-10133](#) [JS-116](#) [JS-150](#) [JS-555](#) [JS-](#)
[68](#) [JS-6-B](#) [JS-91](#) [JS-94](#) [22-211.011](#) [9001KXSDC](#) [KRR22NW3XX03](#) [SAPT654133](#) [2PA3](#) [STKLBU](#) [STKLWH](#) [SW53AA2](#) [302561](#) [3E-](#)
[10.4](#) [3E-12.0](#) [468-10243-001](#) [51-030.002](#) [51-030.005](#) [JM-13](#) [JS-10120](#) [JS-138-B](#) [JS-143-B](#) [JS-49](#) [JS-551](#) [JS-5-C](#)