



Home
Embedded Software

Development Tools
J-Link ARM

Adapters
5V adapter
 JTAG 14 pin adapter
DFPUs
Flash breakpoints

Flash download
Flash SDK
GDB Server
IDE integration
Interface description

J-Flash ARM
J-Link software
J-Mem
JTAG Isolator
Model comparison

Non-commercial-use
Performance comparison
RDI
SDK
J-Link ARM Pro

J-Link ARM Lite
J-Link Coldfire
J-Trace ARM
J-Trace for Cortex-M3

Production Tools

Evaluate our software!
Downloads

Distributors
Customers

Partners
Sales

Forum
About us

Head office Germany

Phone: +49-2103-2876-0
Fax: +49-2103-2876-288
E-mail: info@segger.com
www.segger.com

US office

Phone: +1-978-874-0299
Fax: +1-978-874-0599
E-mail: info@segger-us.com
www.segger-us.com



[Development Tools](#) [J-Link ARM](#) [Adapters](#) [JTAG 14 pin adapter](#)

JTAG 14 pin adapter

An adapter is available to use J-Link ARM with targets using this 14 pin 0.1" mating JTAG connector.

Pin Signal Pin no. on 20 pin JTAG

1	VTrref	1
2	GND	GND
3	nTRST	3
4	GND	GND
5	TDI	5
6	GND	GND
7	TMS	7
8	GND	GND
9	TCK	9
10	GND	GND
11	TDO	13
12	RESET	15
13	VTrref	1
14	GND	GND



Mapping between the JTAG 14 pin adapter and 20 pin JTAG interface

[Pricing](#)

[Imprint](#) [Disclaimer](#) [Sitemap](#)

[back to top](#)

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for [segger microcontroller manufacturer](#):

Other Similar products are found below :

[SD Card Adapter](#) [5.05.10](#) [8.06.03](#) [5.16.01](#) [FLASHER PORTABLE](#) [5.50.01.US](#) [US POWER ADAPTER FOR FLASHER 5/ST7](#) [5.17.01](#)
[8.20.00](#) [6.68.18](#) [8.06.17](#) [J-Link ARM-14 Adapter](#) [8.06.13](#) [6.32.32](#) [6.30.00](#) [6.68.20](#) [8.06.21](#) [8.07.10](#) [8.14.28](#) [8.06.14](#) [J-LINK SUPPLY](#)
[ADAPTER](#) [6.68.19](#) [8.06.24](#) [8.06.13](#) [J-LINK MEASUREMENT+PATCH ADAPTER](#) [8.06.23](#) [5.09.01](#) [FLASHER STM8](#) [6.37.04](#) [6.37.01](#)
[JTAG Isolator](#) [J-Link RX Adapter](#) [J-Link TI-CTI-20 Adapter](#) [8.06.18](#) [5.17.01](#) [FLASHER PRO](#) [8.07.00](#) [JTAG ISOLATOR](#) [6.90.00](#) [8.06.09](#) [J-](#)
[LINK MICROCHIP ADAPTER](#) [8.06.05](#) [10-PIN NEEDLE ADAPTER](#) [8.06.22](#) [8.06.25](#) [Flasher STM8](#) [8.06.26](#) [8.18.00](#) [8.06.05](#) [8.06.03](#) [J-](#)
[LINK 14PIN TIADAPTER](#) [8.06.06](#) [J-LINK TI CTI20ADAPTER](#) [5.16.02](#) [8.06.19](#) [5.07.01](#) [FLASHER ARM](#) [J-Link PRO](#) [8.06.28](#) [Flasher](#)
[ARM](#) [J-Link ULTRA+](#) [8.16.28](#) [J-LINK ULTRA+](#)