

Extraction Tool 843473-1




Figure 1

TOOLING ASSISTANCE CENTER 1-800-722-1111

PRODUCT INFORMATION 1-800-522-6752

1. INTRODUCTION

This instruction sheet covers the use of Extraction Tool 843473-1 which is recommended for removing crimp, snap-in contacts from AMPMODU MOD I and MOD IV Receptacle Connectors listed in Catalog 1307819. Read these instructions before attempting to extract the contacts.



All dimensions are in millimeters [with inches in brackets]. Figures are for reference only and are not drawn to scale.

Reasons for reissue are given in SECTION 5, **REVISION SUMMARY.**

2. DESCRIPTION

The extraction tip is designed to enter the lance recess in the front of the housing and depress the locking lance of the contact.



The connector includes both the housing and the contacts while the housing is the material which forms the encapsulation for the contacts.

The lance recess is the cavity located between the contact and the connector housing. A solid rib (locking ledge) at the rear of the lance recess cavity provides a stop for the extraction tool. The housings are designed to prevent improper insertion of the contacts which are inserted into the rear of the housing.

A lug is located on the side of the MOD I housing which contains the contact locking ledge.

3. EXTRACTION PROCEDURE (Figure 1)

Determine which connector contains the contact to be removed and proceed as follows:

- 1. Insert the tool straight into the lance recess until it bottoms on the locking ledge.
- 2. Holding the tool and connector in one hand, grip the wire of the contact with the other hand and pull the contact out of the back of the connector.

^{©2008} Tyco Electronics Corporation, Harrisburg, PA All International Rights Reserved

TE logo and Tyco Electronics are trademarks.

^{*}Trademark. Other products, logos, and company names used are the property of their respective owners.

Extraction Tool 843473-1 408-9451




Figure 2

4. TOOL INSPECTION/MAINTENANCE

Extraction Tool 843473–1 should conform to the dimensions listed in Figure 2. Each tool should be inspected upon arrival to be sure it has not been damaged in transit, and at regularly scheduled intervals to be sure it remains functional.

If the tool requires repair, send it with a written description of the problem, to:

CUSTOMER REPAIR (38–35) TYCO ELECTRONICS CORPORATION P.O. BOX 3608 HARRISBURG, PA 17105–3608

5. REVISION SUMMARY

Since the previous release of this sheet, the following revisions were made:

• Updated logo and format.

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Extraction, Removal & Insertion Tools category:

Click to view products by TE Connectivity manufacturer:

Other Similar products are found below:

M8196914-08 768211-2 809-131 844751-2 8-59558-2 91018-1 12014013 12093647 1-21048-0 R282867020 12093078 1-21048-6

12121897 DCF.91.405.5LT 1322 15314260 15313892 15350698 15350707 15430130 1579018-4 1643916-1 1-679532-0 1976593-3

OUTEXT-0321 2-1579008-3 2-1579008-4 229694-7 231106-1 241469 91040-3 91040-7 965004-000 965069-000 1738219-1 ET-JL05-16

FG 0300 146 3000 FIT-6 210S048 2-1579007-9 231879-1 312138-3 RJ11FODE 356-162 M8196914-10 4-1579018-0 430395-001 483249-1 5-1579007-2 5-1579007-9