(2)



A-MP* EXTRACTION TOOL CATALOG NO. 91017-3 FOR AMP-TAB* MALE (TAB) TERMINALS

IS 7233	
RELEASED	8-6-65
REVISED	

1. This Tool (see Figure 1) is used to extract AMP-TAB Male (Tab)Terminals from AMP-TAB Quad (4-Tab) Connectors. Read these instructions carefully before using the Tool.

2. EXTRACTION PROCEDURE

- (a) Insert Releasing Tip into back (wire-entry side) of Connector as shown in Figure 2. Make sure that Releasing Tip and Guide Tip straddle Receptacle Contact and that Releasing Tip is closest to the Tab Terminal to be extracted.
- (b) Push Tool into Cavity so Releasing Tip is parallel with Tab Terminal. See Figure 3. When Tool is bottomed in Cavity, align Tool Handle so it is parallel with Tab Terminal. See Figure 3.
- (c) With Tool still aligned as in Para. (b), pull back on Tool and Wire at the same time to remove Tab Terminal. NOTE: To remove Terminals crimped to small or slippery Wire, press Wire against embossments on Handle before removing Terminal.





FIG. 1








FIG. 3

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Extraction, Removal & Insertion Tools category:

Click to view products by TE Connectivity manufacturer:

Other Similar products are found below:

M8196914-08 768211-2 809-131 844751-2 8-59558-2 91018-1 12014013 12093647 1-21048-0 R282867020 12093078 1-21048-6

12121897 DCF.91.405.5LT 1322 15314260 15313892 15350698 15350707 15430130 1579018-4 1643916-1 1-679532-0 1976593-3

OUTEXT-0321 2-1579008-3 2-1579008-4 229694-7 231106-1 241469 91040-3 91040-7 965004-000 965069-000 1738219-1 ET-JL05-16

FG 0300 146 3000 FIT-6 210S048 2-1579007-9 231879-1 312138-3 RJ11FODE 356-162 M8196914-10 4-1579018-0 430395-001 483249-1 5-1579007-2 5-1579007-9