
User's Guide



200A Current Probe Set

Model PQ34-2



Introduction

Congratulations on your purchase of this Extech Current Probe Set. A set of three 200A current probes designed to be used with the Extech PQ3450 or PQ3470 Power Analyzers. These probes are shipped fully tested and calibrated and, with proper use, will provide years of reliable service.

Safety



This symbol, adjacent to another symbol or terminal, indicates the user must refer to the manual for further information.



This symbol, adjacent to a terminal, indicates that, under normal use, hazardous voltages may be present



Double insulation

Cautions

- Read and understand this user manual before operating the meter.
- Improper use of this meter can cause damage, shock, injury or death.
- Inspect the condition of the leads and the meter itself for any damage before operating the meter.
- Use great care when making measurements if the voltages are greater than 25VAC rms or 35VDC. These voltages are considered a shock hazard.
- . Do not attempt to measure Current that exceeds specified limits
- Do not operate this instrument in wet or dusty environments.
- . Do not operate this instrument in the presence of combustible or explosive gas
- Do not touch exposed metal parts or unused terminals.
- Use protective gloves near high current or voltage circuits.
- If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

Probe Description

- Current Sensing Jaws
- 2. Jaw Trigger
- 3. 1200A-200A-20A range switch
- 4. Signal output plug (+, red)
- 5. Signal output plug (-, black)
- 6. DCV power plug




Operation

- 1. Connect the "A1" signal output cables to the matching input sockets on the top of the analyzer.
- 2. Connect the "A1" power cable to the matching power socket on the top of the analyzer.
- 3. Set the "200A-20A" range switch to the range appropriate for the application.

Note: Make sure the range set on the clamp matches the range set in the analyzer.

- 4. Connect the "A2" and "A3" clamps as above, if needed.
- Press the "Trigger" to open the jaws and clamp around a single conductor.
- 6. Power on the power analyzer



Specifications

Measurement ranges 20A and 200A, switch selectable

Output sensitivity 10mV/A (20A range)

1mV/A (200A range)

Output coupling AC coupled.

Accuracy (50/60Hz) ± 1% F.S. @ 23 ± 5°C (50/60Hz)

Frequency range 45 to 400 Hz. Phase error (50/60Hz) < ± 1° (50/60Hz)

Minimum load 100 K ohm for specified accuracy

Enclosure material UL 94-V0 rated

Safety IEC 1010, Category III 600V Power Supply 8V± 1V (supplied from meter)

Max. Jaw Open Size 19 mm (0.75 inch) Dia.

Operating Temperature 0°C to 50°C (32°F to 122°F)

Operating Humidity Less than 80% RH

Dimension 179.9 x 66.9 x 40.1mm. (7.0 X 2.6 X 1.57"inch)

Cable length: 4 meters (13.1 feet)
DC plug size: 5.5 mm x 2.5 mm DIA.

Weight 330 g (0.73lb)

www.extech.com

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Test Probes category:

Click to view products by Teledyne FLIR / Extech manufacturer:

Other Similar products are found below:

6214 6474 815003 873455 P-KIT-1 R941850000 1288218 1541636 1906693 925250-R 1913459 973368101 972318101 972318100

TAS90 973368100 972327100 973995101 CT3982B-120 MO50-PINS 20009209-03 2294865-1 20009209-02 CT4386 PP023-1 PP026-1

PK-ZS-013 RT-ZP05S SET ISOPROBE II - 10:1 - 2,5 21070 68.9481-22 66.9516-23 6011 24.243.3 24.245.2 24.243.5 24.243.1 24.243.2

24.245.1 20.157.1 6014 66.9515-23 CT4203 6019 UT-P06 CT2676ARA UT-H03 P01102053Z 66.9515-22 102190