
TOSHIBA

32 Bit RISC Microcontroller TX03 Series

TMPM332FWUG

TOBHIBA CORPORATION



ARM, ARM Powered, AMBA, ADK, ARM9TDMI, TDMI, PrimeCell, RealView, Thumb, Cortex, Coresight, ARM9, ARM926EJ-S, Embedded Trace Macrocell, ETM, AHB, APB, and KEIL are registered trademarks or trademarks of ARM Limited in the EU and other countries.



<u>Introduction: Notes on the description of SFR (Special Function Register) under this specification</u>

An SFR (Special Function Register) is a control register for periperal circuits (IP).

The SFR addressses of IPs are described in the chapter on memory map, and the details of SFR are given in the chapter of each IP.

Definition of SFR used in this specification is in accordance with the following rules.

- a. SFR table of each IP as an example
 - · SFR tables in each chapter of IP provides register names, addresses and brief descriptions.
 - All registers have a 32-bit unique address and the addresses of the registers are defined as follows, with some exceptions: "Base address + (Unique) address"

Base Address = 0x0000_0000

Register name	Address(Base+)	
Control register	SAMCR	0x0004
		0x000C

Note: SAMCR register address is 32 bits wide from the address 0x0000_0004 (Base Address(0x00000000) + unique address (0x0004)).

Note: The register shown above is an example for explanation purpose and not for demonstration purpose. This register does not exist in this microcontroller.

- b. SFR(register)
 - Each register basically consists of a 32-bit register (some exceptions).
 - The description of each register provides bits, bit symbols, types, initial values after reset and functions.

1.2.2 SAMCR(Control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	МС	DDE
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	MODE				TDATA			
After reset	0	0	0	1	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-10	_	R	"0" can be read.
9-7	MODE[2:0]	R/W	Operation mode settings 000 : Sample mode 0 001 : Sample mode 1 010 : Sample mode 2 011 : Sample mode 3 The settings other than those above: Reserved
6-0	TDATA[6:0]	W	Transmitted data

Note: The Type is divided into three as shown below.

R / W READ WRITE
R READ
W WRITE

c. Data descriptopn

Meanings of symbols used in the SFR description are as shown below.

- x:channel numbers/ports
- · n,m:bit numbers

d. Register descriptoption

Registers are described as shown below.

• Register name <Bit Symbol>

Exmaple: SAMCR<MODE>="000" or SAMCR<MODE[2:0]>="000"

<MODE[2:0]> indicates bit 2 to bit 0 in bit symbol mode (3bit width).

· Register name [Bit]

Example: SAMCR[9:7]="000"

It indicates bit 9 to bit 7 of the register SAMCR (32 bit width).

TMPM332FWUG

Revision History

Date	Revision	Comment	
2010/6/11	1	First Release	
2010/10/6	2	Contents Revised	

Table of Contents

Introduction: Notes on the description of SFR (Special Function Register) under this specification

TM	IPM332FWUG	
1	.1 Features	1
1	.2 Block Diagram	3
1	.3 Pin Layout (Top view)	4
1	.4 Pin names and Functions	5
	1.4.1 Sorted by Pin	
1	1.5 Pin Numbers and Power Supply Pins	
2. P	Processor Core	
2	2.1 Information on the processor core	15
2	2.2 Configurable Options	
2	2.3 Exceptions/ Interruptions	15
	2.3.1 Number of Interrupt Inputs	
	2.3.2 Number of Priority Level Interrupt Bits	
	2.3.4 SYSRESETREQ.	
	2.3.5 LOCKUP	
2	2.3.6 Auxiliary Fault Status register	
	2.5 Power Management.	
	2.6 Exclusive access	
	ACCESSION DATES	
3. <u>C</u>	Debug Interface	
3	3.1 Specification Overview	19
3	3.2 SW-DP	19
3	3.3 ETM	19
3	3.4 Pin Functions	20
3	3.5 Peripheral Functions in Halt Mode	20
3	3.6 Reset Vector Break	21
3	3.7 Connection with a Debug Tool	21
	3.7.1 About connection with debug tool	
	3.7.2 Important points of using debug interface pins used as general-purpose ports	21
	Jamary Man	

	4.1 Memory map	
	4.2 SFR area detail.	
5.	Reset	
	5.1 Cold reset	27
	5.2 Warm reset	28
	5.2.1 Reset period	
	5.2.2 After reset	28
6.	Clock/Mode control	
	6.1 Features	20
	6.2 Registers	
	6.2.1 Register List	
	6.2.3 CGOSCCR (Oscillation control register)	
	6.2.4 CGSTBYCR (Standby control register)	
	6.2.5 CGPLLSEL (PLL Selection Register)	
	6.2.6 CGCKSEL (System clock selection register)	
	6.3 Clock control.	
	6.3.1 Clock System Block Diagram.	
	6.3.2 Initial Values after Reset	
	6.3.4 Clock Multiplication Circuit (PLL)	
	6.3.5 Warm-up function	
	6.3.6 System Clock	40
	6.3.6.1 High speed clock 6.3.6.2 Low speed clock	
	6.3.7 Prescaler Clock Control	40
	6.3.8 System Clock Pin Output Function	
	6.4 Modes and Mode Transitions	42
	6.4.1 Mode Transitions	42
	6.5 Operation mode	43
	6.5.1 NORMAL mode	
	6.5.2 SLOW mode	
	6.6 Low Power Consumption Modes	
	6.6.1 IDLE mode	
	6.6.2 SLEEP mode	
	6.6.4 Low power Consumption Mode Setting	
	6.6.5 Operational Status in Each Mode	
	6.6.6 Releasing the Low Power Consumption Mode	
	6.6.7 Warm-up	
	6.6.8 Clock Operations in Mode Transition	49
	6.6.8.2 Transition of operation modes: NORMAL → SLEEP → NORMAL	
	6.6.8.3 Transition of operation modes: $SLOW \rightarrow STOP \rightarrow SLOW$	
	6.6.8.4 Transition of operation modes: SLOW \rightarrow SLEEP \rightarrow SLOW	
7.	Exceptions	
	7.1 Overview	51
	7.1.1 Exception Types	
	7.1.2 Handling Flowchart.	
	7.1.2.1 Exception Request and Detection	
	7.1.2.2 Exception Handling and Branch to the Interrupt Service Routine (Pre-emption)	

	7.1.2.3 Executing an ISR 7.1.2.4 Exception exit	
7.2	Reset Exceptions.	57
7.3	Non-Maskable Interrupts (NMI)	
	1 ()	
7.4	SysTick	
7.5	Interrupts	
7.:	5.1 Interrupt Sources	59
	7.5.1.1 Interrupt Route 7.5.1.2 Generation	
	7.5.1.3 Transmission	
	7.5.1.4 Precautions when using external interrupt pins	
	7.5.1.5 List of Interrupt Sources 7.5.1.6 Active level	
7	5.2 Interrupt Handling	63
,	7.5.2.1 Flowchart	
	7.5.2.2 Preparation	
	7.5.2.3 Detection by Clock Generator 7.5.2.4 Detection by CPU	
	7.5.2.5 CPU processing	
	7.5.2.6 Interrupt Service Routine (ISR)	
7.6	Exception/Interrupt-Related Registers	68
7.	6.1 Register List	68
7.	6.2 NVIC Registers	69
	7.6.2.1 SysTick Control and Status Register	
	7.6.2.2 SysTick Reload Value Register 7.6.2.3 SysTick Current Value Register	
	7.6.2.4 SysTick Calibration Value Register	
	7.6.2.5 Interrupt Set-Enable Register 1	
	7.6.2.6 Interrupt Set-Enable Register 2 7.6.2.7 Interrupt Clear-Enable Register 1	
	7.6.2.8 Interrupt Clear-Enable Register 2	
	7.6.2.9 Interrupt Set-Pending Register 1	
	7.6.2.10 Interrupt Set-Pending Register 2 7.6.2.11 Interrupt Clear-Pending Register 1	
	7.6.2.11 Interrupt Clear-Pending Register 1 7.6.2.12 Interrupt Clear-Pending Register 2	
	7.6.2.13 Interrupt Priority Register	
	7.6.2.14 Vector Table Offset Register	
	7.6.2.15 Application Interrupt and Reset Control Register 7.6.2.16 System Handler Priority Register	
	7.6.2.17 System Handler Photity Register 7.6.2.17 System Handler Control and State Register	
7.	6.3 Clock generator registers	88
	7.6.3.1 CGIMCGA(CG Interrupt Mode Control Register A)	
	7.6.3.2 CGIMCGB(CG Interrupt Mode Control Register B)	
	7.6.3.3 CGIMCGC(CG Interrupt Mode Control Register C) 7.6.3.4 CGIMCGD(CG Interrupt Mode Control Register D)	
	7.6.3.5 CGICRCG(CG Interrupt Request Clear Register)	
	7.6.3.6 CGNMIFLG(NMI Flag Register)	
	7.6.3.7 CGRSTFLG (Reset Flag Register)	
Inp	out/Output Ports	
P		
8.1	Port Functions	97
	1.1 Function Lists	
	1.2 Port Registers Outline	
	1.3 Port States in STOP Mode	
8.	1.4 Precautions for Mode Transition between STOP and SLEEP	100
8.2	Port functions.	101
8	2.1 Port A (PA0 to PA3)	
	8.2.1.1 Port A Circuit Type	
	8.2.1.2 Port A register	
	8.2.1.3 PADATA (Port A data register) 8.2.1.4 PACR (Port A output control register)	
	8.2.1.5 PAFR1 (Port A function register 1)	
	8.2.1.6 PAPUP (Port A pull-up control register)	
	8.2.1.7 PAPDN (Port A pull-down control register)	
0	8.2.1.8 PAIE (Port A input control register) 2.2 Port B (PB0)	106
٥	8.2.2.1 Port B Circuit Type	100
	8.2.2.2 Port B Register	

	rt Turas	143
	k Diagrams of Ports	145
8.2.10.8	PKIE (Port K input control register)	
8.2.10.7	PKPUP (Port K pull-up control register)	
8.2.10.6	PKFR2(Port K function register 2)	
8.2.10.5	PKFR1(Port K function register 1)	
8.2.10.4	PKCR (Port K output control register)	
8.2.10.2	PKDATA (Port K data register)	
8.2.10.1 8.2.10.2	Port K Circuit Type Port K Register	
	ort K (PK0 to PK1)	140
8.2.9.7 8.2.10 B		1.40
8.2.9.6	PJPUP (Port J pull-up control register) PJIE (Port J input control register)	
8.2.9.5	PJFR1(Port J function register 1)	
8.2.9.4	PJCR (Port J output control register)	
8.2.9.3	PJDATA (Port J data register)	
8.2.9.2	Port J Register	
8.2.9.1	Port J Circuit Type	
8.2.9 Po	rt J (PJ0 to PJ4)	136
8.2.8.7	PIIE (Port I input control register)	
8.2.8.6	PIPUP (Port I pull-up control register)	
8.2.8.5	PIFR1(Port I function register 1)	
8.2.8.4	PICR (Port I output control register)	
8.2.8.3	PIDATA (Port I data register)	
8.2.8.2	Port I Register	
8.2.8.1	Port I Circuit Type	
	rt I (PI0 to PI5)	132
8.2.7.7	PHIE (Port H input control register)	
8.2.7.6	PHPUP (Port H pull-up control register)	
8.2.7.4 8.2.7.5	PHFR1(Port H function register 1)	
8.2.7.3 8.2.7.4	PHDATA (Port H data register) PHCR (Port H output control register)	
8.2.7.2	Port H Register	
8.2.7.1	Port H Circuit Type	
	rt H (PH0 to PH3)	128
8.2.6.8	PGIE (Port G input control register)	
8.2.6.7	PGPUP (Port G pull-up control register)	
8.2.6.6	PGOD (Port G open drain control register)	
8.2.6.5	PGFR1(Port G function register 1)	
8.2.6.4	PGCR (Port G output control register)	
8.2.6.3	PGDATA (Port G data register)	
8.2.6.1 8.2.6.2	Port G Circuit Type Port G Register	
8.2.6 Po 8.2.6.1	Prof G Circuit Type	123
	rt G (PG0 to PG3)	123
8.2.5.7 8.2.5.8	PFIC (Port F input control register) PFIE (Port F input control register)	
8.2.5.6 8.2.5.7	PFOD (Port F open drain control register) PFPUP (Port F pull-up control register)	
	PFFR1(Port F function register 1) PFOD (Port F open drain control register)	
8.2.5.4 8.2.5.5	PFCR (Port F output control register) PFER (Port F function register 1)	
8.2.5.3	PFDATA (Port F data register)	
8.2.5.2	Port F Register	
8.2.5.1	Port F Circuit Type	
	rt F (PF4 to PF6)	118
8.2.4.9	PEIE (Port E input control register)	
8.2.4.8	PEPUP (Port E pull-up control register)	
8.2.4.7	PEOD (Port E open drain control register)	
8.2.4.6	PEFR2(Port E function register 2)	
8.2.4.5	PEFR1(Port E function register 1)	
8.2.4.4	PECR (Port E output control register)	
8.2.4.3	PEDATA (Port E data register)	
8.2.4.1 8.2.4.2	Port E Circuit Type Port E Register	
8.2.4 Po 8.2.4.1	rt E (PE0 to PE6)	113
8.2.3.6 8.2.4 Pa	PDIE (Port D input control register)	112
8.2.3.5	PDPUP (Port D pull-up control register)	
8.2.3.4	PDFR1 (Port D function register 1)	
8.2.3.3	PDDATA (Port D data register)	
8.2.3.2	Port D Register	
8.2.3.1	Port D Circuit Type	
	rt D (PD0 to PD7)	110
8.2.2.7	PBIE (Port B input control register)	
8.2.2.6	PBPUP (Port B pull-up control register)	
8.2.2.4 8.2.2.5	PBCR (Port B output control register) PBFR1 (Port B function register 1)	
8.2.2.3	PBDATA (Port B data register)	
0 2 2 2	DDD (T) (D (D) (D) (C)	

8.3.3		
	Type T4	
8.3.4	Type5 T5	
8.3.5	Type T6	
8.3.6	Type T7	
8.3.7	Type T8	
8.3.8	Type T9	
8.3.9	Type T10	
8.3.10 8.3.11	51	
8.3.11	71	
8.3.12	71	
8.3.14	71	
8.3.15	31	
8.3.16	51	
8.3.17	J1 -	
	71	
	Appendix (Port setting List)	
8.4.1	Port A Setting	
8.4.2	Port B Setting	
8.4.3	Port D Setting	
8.4.4	Port E Setting	
8.4.5	Port F Setting	
8.4.6	Port G Setting	
8.4.7	Port I Setting	
8.4.8	Port I Setting	
8.4.9 8.4.10	Port J Setting	
0.4.10	FOILK Setting	107
9.1	Timer/Event Counters(TMRB) Outline	
9.1 C 9.2 D	Outline	170
9.1 C 9.2 D 9.3 C	Outline	170 171
9.1 C 9.2 D 9.3 C 9.4 R	Outline	
9.1 C 9.2 D 9.3 C 9.4 R 9.4.1	Outline	
9.1 C 9.2 D 9.3 C 9.4 R 9.4.1 9.4.2	Outline. Differences in the Specifications Configuration Registers Register list according to channel. TBxEN (Enable register).	
9.1 C 9.2 D 9.3 C 9.4 R 9.4.1 9.4.2 9.4.3	Outline. Differences in the Specifications Configuration. Registers Register list according to channel. TBxEN (Enable register). TBxRUN(RUN register).	
9.1 C 9.2 D 9.3 C 9.4 R 9.4.1 9.4.2 9.4.3 9.4.4	Outline. Differences in the Specifications Configuration. Registers. Register list according to channel. TBxEN (Enable register). TBxRUN(RUN register). TBxCR(Control register).	
9.1 C 9.2 D 9.3 C 9.4 R 9.4.1 9.4.2 9.4.3 9.4.4 9.4.5	Outline Differences in the Specifications Configuration Registers Register list according to channel TBxEN (Enable register) TBxRUN(RUN register) TBxCR(Control register) TBxMOD(Mode register)	
9.1 C 9.2 D 9.3 C 9.4 R 9.4.1 9.4.2 9.4.3 9.4.4 9.4.5 9.4.6	Outline Differences in the Specifications Configuration Registers Register list according to channel TBxEN (Enable register) TBxRUN(RUN register) TBxCR(Control register) TBxMOD(Mode register) TBxFFCR(Flip-flop control register)	
9.1 C 9.2 D 9.3 C 9.4 R 9.4.1 9.4.2 9.4.3 9.4.4 9.4.5 9.4.6 9.4.7	Outline Differences in the Specifications Configuration Registers Register list according to channel. TBxEN (Enable register). TBxRUN(RUN register). TBxCR(Control register). TBxMOD(Mode register). TBxFFCR(Flip-flop control register). TBxST(Status register).	
9.1 C 9.2 D 9.3 C 9.4 R 9.4.1 9.4.2 9.4.3 9.4.4 9.4.5 9.4.6 9.4.7 9.4.8	Outline Differences in the Specifications Configuration Registers Register list according to channel. TBxEN (Enable register). TBxRUN(RUN register). TBxCR(Control register). TBxMOD(Mode register). TBxFFCR(Flip-flop control register). TBxST(Status register). TBxST(Status register). TBxIM(Interrupt mask register).	
9.1 C 9.2 D 9.3 C 9.4 R 9.4.1 9.4.2 9.4.3 9.4.4 9.4.5 9.4.6 9.4.7 9.4.8 9.4.9	Outline Differences in the Specifications Configuration Registers Register list according to channel. TBxEN (Enable register). TBxRUN(RUN register). TBxCR(Control register). TBxMOD(Mode register). TBxFFCR(Flip-flop control register). TBxST(Status register). TBxIM(Interrupt mask register). TBxIM(Interrupt mask register). TBxUC(Up counter capture register).	
9.1 C 9.2 D 9.3 C 9.4 R 9.4.1 9.4.2 9.4.3 9.4.4 9.4.5 9.4.6 9.4.7 9.4.8 9.4.9 9.4.10	Outline Differences in the Specifications Configuration Registers Register list according to channel. TBxEN (Enable register). TBxRUN(RUN register) TBxCR(Control register). TBxMOD(Mode register). TBxFFCR(Flip-flop control register). TBxST(Status register). TBxST(Status register). TBxIM(Interrupt mask register). TBxUC(Up counter capture register). TBxRG0(Timer register 0).	
9.1 C 9.2 D 9.3 C 9.4 R 9.4.1 9.4.2 9.4.3 9.4.4 9.4.5 9.4.6 9.4.7 9.4.8 9.4.9	Outline Differences in the Specifications Configuration Registers Register list according to channel. TBxEN (Enable register). TBxRUN(RUN register). TBxCR(Control register). TBxMOD(Mode register). TBxFFCR(Flip-flop control register). TBxST(Status register). TBxIM(Interrupt mask register). TBxUC(Up counter capture register). TBxRG0(Timer register 0). TBxRG1(Timer register 1).	
9.1 C 9.2 D 9.3 C 9.4 R 9.4.1 9.4.2 9.4.3 9.4.4 9.4.5 9.4.6 9.4.7 9.4.8 9.4.9 9.4.10 9.4.11	Outline Differences in the Specifications Configuration Registers Register list according to channel. TBxEN (Enable register). TBxRUN(RUN register). TBxCR(Control register). TBxMOD(Mode register). TBxFFCR(Flip-flop control register). TBxST(Status register). TBxIM(Interrupt mask register). TBxUC(Up counter capture register). TBxRG0(Timer register 0). TBxRG1(Timer register 1). TBxCP0(Capture register 0).	
9.1 C 9.2 D 9.3 C 9.4 R 9.4.1 9.4.2 9.4.3 9.4.4 9.4.5 9.4.6 9.4.7 9.4.8 9.4.9 9.4.10 9.4.11 9.4.12 9.4.13	Outline Differences in the Specifications Configuration Registers Register list according to channel. TBxEN (Enable register). TBxRUN(RUN register) TBxCR(Control register). TBxMOD(Mode register). TBxFFCR(Flip-flop control register). TBxST(Status register). TBxIM(Interrupt mask register). TBxUC(Up counter capture register). TBxRG0(Timer register 0). TBxRG1(Timer register 1). TBxCP0(Capture register 0). TBxCP1(Capture register 1).	
9.1 C 9.2 D 9.3 C 9.4 R 9.4.1 9.4.2 9.4.3 9.4.4 9.4.5 9.4.6 9.4.7 9.4.8 9.4.9 9.4.10 9.4.11 9.4.12 9.4.13	Outline Differences in the Specifications Configuration Registers Register list according to channel. TBxEN (Enable register). TBxRUN(RUN register) TBxROD(Mode register). TBxFFCR(Flip-flop control register). TBxST(Status register). TBxIM(Interrupt mask register). TBxUC(Up counter capture register). TBxRGO(Timer register 0). TBxRG1(Timer register 1). TBxCP0(Capture register 1). TBxCP1(Capture register 1). Description of Operations for Each Circuit.	
9.1 C 9.2 D 9.3 C 9.4 R 9.4.1 9.4.2 9.4.3 9.4.4 9.4.5 9.4.6 9.4.7 9.4.8 9.4.9 9.4.10 9.4.11 9.4.12 9.4.13 9.5 D 9.5.1	Outline Differences in the Specifications Configuration Registers Register list according to channel. TBxEN (Enable register). TBxRUN(RUN register) TBxCR(Control register). TBxMOD(Mode register). TBxFFCR(Flip-flop control register). TBxST(Status register). TBxST(Status register). TBxUC(Up counter capture register). TBxUC(Up counter capture register). TBxRG0(Timer register 0). TBxRG1(Timer register 1). TBxCP0(Capture register 1). Description of Operations for Each Circuit. Prescaler	
9.1 C 9.2 D 9.3 C 9.4 R 9.4.1 9.4.2 9.4.3 9.4.4 9.4.5 9.4.6 9.4.7 9.4.8 9.4.9 9.4.10 9.4.11 9.4.12 9.4.13 9.5.1 9.5.1 9.5.2	Outline Differences in the Specifications Configuration Registers Register list according to channel. TBxEN (Enable register). TBxRUN(RUN register) TBxCR(Control register). TBxMOD(Mode register). TBxFFCR(Flip-flop control register). TBxST(Status register). TBxST(Status register). TBxUC(Up counter capture register). TBxRG0(Timer register 0). TBxRG1(Timer register 1). TBxCP0(Capture register 1). Description of Operations for Each Circuit. Prescaler. Up-counter (UC).	
9.1 C 9.2 D 9.3 C 9.4 R 9.4.1 9.4.2 9.4.3 9.4.4 9.4.5 9.4.6 9.4.7 9.4.8 9.4.9 9.4.10 9.4.11 9.4.12 9.4.13 9.5.1 9.5.1 9.5.2 9.5.3	Outline. Differences in the Specifications Configuration. Registers. Register list according to channel. TBxEN (Enable register). TBxRUN(RUN register). TBxCR(Control register). TBxMOD(Mode register). TBxFFCR(Flip-flop control register) TBxST(Status register). TBxIM(Interrupt mask register). TBxUC(Up counter capture register). TBxRG0(Timer register 0). TBxRG1(Timer register 1). TBxCP0(Capture register 0). TBxCP1(Capture register 1). Description of Operations for Each Circuit. Prescaler. Up-counter (UC). Timer registers (TBxRG0, TBxRG1).	
9.1 C 9.2 D 9.3 C 9.4 R 9.4.1 9.4.2 9.4.3 9.4.4 9.4.5 9.4.6 9.4.7 9.4.8 9.4.10 9.4.11 9.4.12 9.4.13 9.5.1 9.5.2 9.5.3 9.5.4	Outline. Differences in the Specifications. Configuration. Registers. Register list according to channel. TBxEN (Enable register). TBxRUN(RUN register). TBxCR(Control register). TBxFFCR(Flip-flop control register). TBxST(Status register). TBxST(Status register). TBxIM(Interrupt mask register). TBxRG0(Timer register 0). TBxRG1(Timer register 1). TBxCP0(Capture register 1). Description of Operations for Each Circuit. Prescaler. Up-counter (UC). Timer registers (TBxRG0, TBxRG1). Capture.	
9.1 C 9.2 D 9.3 C 9.4 R 9.4.1 9.4.2 9.4.3 9.4.4 9.4.5 9.4.6 9.4.7 9.4.8 9.4.9 9.4.10 9.4.11 9.4.12 9.4.13 9.5 D 9.5.1 9.5.2 9.5.3 9.5.4 9.5.5	Outline. Differences in the Specifications Configuration Registers. Register list according to channel. TBxEN (Enable register). TBxRUN(RUN register). TBxCR(Control register). TBxMOD(Mode register). TBxFFCR(Flip-flop control register). TBxST(Status register). TBxIM(Interrupt mask register). TBxUC(Up counter capture register). TBxRG0(Timer register 0). TBxRG1(Timer register 1). TBxCP0(Capture register 1). Description of Operations for Each Circuit. Prescaler. Up-counter (UC). Timer registers (TBxRG0, TBxRG1). Capture registers (TBxCP0, TBxCP1).	
9.1 C 9.2 D 9.3 C 9.4 R 9.4.1 9.4.2 9.4.3 9.4.4 9.4.5 9.4.6 9.4.7 9.4.8 9.4.9 9.4.10 9.4.11 9.4.12 9.4.13 9.5 D 9.5.1 9.5.2 9.5.3 9.5.4 9.5.5 9.5.6	Outline. Differences in the Specifications. Configuration. Registers. Register list according to channel. TBxEN (Enable register). TBxRUN(RUN register). TBxCR(Control register). TBxMOD(Mode register). TBxFFCR(Flip-flop control register). TBxST(Status register). TBxIM(Interrupt mask register). TBxUC(Up counter capture register). TBxRG0(Timer register 0). TBxRG1(Timer register 1). TBxCP0(Capture register 0) TBxCP1(Capture register 1). Description of Operations for Each Circuit. Prescaler. Up-counter (UC). Timer registers (TBxRG0, TBxRG1). Capture. Capture registers (TBxCP0, TBxCP1). Up-counter capture register (TBxUC).	
9.1 C 9.2 D 9.3 C 9.4 R 9.4.1 9.4.2 9.4.3 9.4.4 9.4.5 9.4.6 9.4.7 9.4.8 9.4.9 9.4.10 9.4.11 9.4.12 9.4.13 9.5.1 9.5.2 9.5.3 9.5.4 9.5.5 9.5.6 9.5.7	Outline. Differences in the Specifications. Configuration. Registers. Register list according to channel. TBxEN (Enable register). TBxRUN(RUN register). TBxCR(Control register). TBxFFCR(Flip-flop control register). TBxST(Status register) TBxIM(Interrupt mask register). TBxUC(Up counter capture register). TBxRG0(Timer register 0). TBxRG1(Timer register 1). TBxCP0(Capture register 0). TBxCP1(Capture register 1). Description of Operations for Each Circuit. Prescaler. Up-counter (UC). Timer registers (TBxRG0, TBxRG1). Capture. Capture registers (TBxCP0, TBxCP1). Up-counter capture register (TBxUC). Comparators (CP0, CP1).	
9.1 C 9.2 D 9.3 C 9.4 R 9.4.1 9.4.2 9.4.3 9.4.4 9.4.5 9.4.6 9.4.7 9.4.8 9.4.9 9.4.10 9.4.11 9.4.12 9.4.13 9.5.1 9.5.1 9.5.2 9.5.3 9.5.4 9.5.5 9.5.6 9.5.7 9.5.8	Outline. Differences in the Specifications. Configuration. Registers. Register list according to channel. TBxEN (Enable register). TBxRUN(RUN register). TBxROD(Mode register). TBxFFCR(Flip-flop control register). TBxST(Status register) TBxUC(Up counter capture register). TBxUC(Up counter capture register). TBxRG0(Timer register 0). TBxRG1(Timer register 1). TBxCP0(Capture register 0). TBxCP1(Capture register 1). Description of Operations for Each Circuit. Prescaler. Up-counter (UC). Timer registers (TBxRG0, TBxRG1). Capture. Capture registers (TBxCP0, TBxCP1). Up-counter capture register (TBxUC). Comparators (CP0, CP1). Timer Flip-flop (TBxFF0).	
9.1 C 9.2 D 9.3 C 9.4 R 9.4.1 9.4.2 9.4.3 9.4.4 9.4.5 9.4.6 9.4.7 9.4.8 9.4.9 9.4.10 9.4.11 9.4.12 9.4.13 9.5.1 9.5.2 9.5.3 9.5.4 9.5.5 9.5.6 9.5.7 9.5.8 9.5.9	Outline. Differences in the Specifications. Configuration. Registers. Register list according to channel. TBxEN (Enable register). TBxRUN(RUN register). TBxCR(Control register). TBxMOD(Mode register). TBxST(Status register). TBxST(Status register). TBxIM(Interrupt mask register). TBxIM(Interrupt mask register). TBxRG0(Timer register 0). TBxRG1(Timer register 0). TBxCP(Capture register 1). Description of Operations for Each Circuit. Prescaler. Up-counter (UC). Timer registers (TBxRG0, TBxRG1). Capture. Capture register (TBxUC). Comparators (CP0, CP1). Timer Flip-flop (TBxFF0). Capture interrupt (INTCAPx0, INTCAPx1).	
9.1 C 9.2 D 9.3 C 9.4 R 9.4.1 9.4.2 9.4.3 9.4.4 9.4.5 9.4.6 9.4.7 9.4.8 9.4.9 9.4.10 9.4.11 9.4.12 9.4.13 9.5 D 9.5.1 9.5.2 9.5.3 9.5.4 9.5.5 9.5.6 9.5.7 9.5.8 9.5.9	Outline. Differences in the Specifications. Configuration. Registers. Register list according to channel. TBxEN (Enable register). TBxRUN(RUN register). TBxROD(Mode register). TBxFCR(Flip-flop control register). TBxST(Status register). TBxIM(Interrupt mask register). TBxIM(Interrupt mask register). TBxRG0(Timer register 0). TBxRG1(Timer register 1). TBxCP0(Capture register 0). TBxCP1(Capture register 1) Description of Operations for Each Circuit. Prescaler. Up-counter (UC). Timer registers (TBxRG0, TBxRG1). Capture. Capture registers (TBxCP0, TBxCP1). Up-counter capture register (TBxUC). Comparators (CP0, CP1). Timer Flip-flop (TBxFF0). Capture interrupt (INTCAPx0, INTCAPx1). Description of Operations for Each Mode.	
9.1 C 9.2 D 9.3 C 9.4 R 9.4.1 9.4.2 9.4.3 9.4.4 9.4.5 9.4.6 9.4.7 9.4.8 9.4.9 9.4.10 9.4.11 9.4.12 9.4.13 9.5 D 9.5.1 9.5.2 9.5.3 9.5.4 9.5.5 9.5.6 9.5.7 9.5.8 9.5.9	Outline Differences in the Specifications. Configuration. Registers. Register list according to channel TBxEN (Enable register) TBxEN(Control register) TBxCR(Control register) TBxFFCR(Flip-flop control register) TBxFFCR(Flip-flop control register) TBxST(Status register) TBxIM(Interrupt mask register). TBxCQ(Up counter capture register) TBxRG0(Timer register 0) TBxRG1(Timer register 1) TBxCP0(Capture register 0) TBxCP1(Capture register 1) Description of Operations for Each Circuit. Prescaler Up-counter (UC) Timer registers (TBxRG0, TBxRG1) Capture. Capture registers (TBxCP0, TBxCP1) Up-counter capture register (TBxUC) Comparators (CP0, CP1) Timer Flip-flop (TBxFF0) Capture interrupt (INTCAPx0, INTCAPx1) Description of Operations for Each Mode 16-bit Interval Timer Mode	
9.1 C 9.2 D 9.3 C 9.4 R 9.4.1 9.4.2 9.4.3 9.4.4 9.4.5 9.4.6 9.4.7 9.4.8 9.4.9 9.4.10 9.4.11 9.4.12 9.4.13 9.5 D 9.5.1 9.5.2 9.5.3 9.5.4 9.5.5 9.5.6 9.5.7 9.5.8 9.5.9	Outline. Differences in the Specifications. Configuration. Registers. Register list according to channel. TBxEN (Enable register). TBxRUN(RUN register). TBxROD(Mode register). TBxFCR(Flip-flop control register). TBxST(Status register). TBxIM(Interrupt mask register). TBxIM(Interrupt mask register). TBxRG0(Timer register 0). TBxRG1(Timer register 1). TBxCP0(Capture register 0). TBxCP1(Capture register 1) Description of Operations for Each Circuit. Prescaler. Up-counter (UC). Timer registers (TBxRG0, TBxRG1). Capture. Capture registers (TBxCP0, TBxCP1). Up-counter capture register (TBxUC). Comparators (CP0, CP1). Timer Flip-flop (TBxFF0). Capture interrupt (INTCAPx0, INTCAPx1). Description of Operations for Each Mode.	

9.7 A	Applications using the Capture Function	192
9.7.1	One-shot pulse output triggered by an external pulse	
9.7.2	Frequency measurement	
9.7.3 9.7.4	Pulse width measurement Time Difference Measurement	
Seria	l Channel (SIO/UART)	
10.1	Overview	
10.2	Difference in the Specifications of SIO Modules	197
10.3	Configuration	198
10.4	Registers Description	199
10.4.1	•	
10.4.2	SCxEN (Enable Register)	200
10.4.3		
10.4.4	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	
10.4.5	()	
10.4.6 10.4.7	` '	
10.4.7		
10.4.9		
10.4.1		
10.4.1		
10.4.1	(6)	
10.4.1	ξ ,	
	Operation in Each Mode	
10.6	Data Format	215
10.6.1	Data Format List	215
10.6.2	Parity Control	216
	5.2.2 Receiving Data	
10.6.3	STOP Bit Length	216
10.7	Clock Control	217
10.7.1	Prescaler	217
10.7.2		221
	7.2.1 Baud Rate Generator 7.2.2 Clock Selection Circuit	
		225
	Transmit/Receive Buffer and FIFO	
10.8.1 10.8.2		
10.8.2		
	Status Flag	226
10.10	Error Flag	
10.10. 10.10.		
10.10.		
10.11	Receive	
10.11. 10.11.		
	2 Receive Control Offic	220
	11.2.2 UART Mode	
10.11.	I	228
	11.3.1 Receive Buffer	
	11.3.2 Receive FIFO Operation 11.3.3 I/O interface mode with SCLK output	
	11.3.4 Read Received Data	
10.	11.3.5 Wake-up Function	
	11.3.6 Overrun Error	
10.12	Transmission	
10.12.		
10.12.		232
10.	12.2.1 I/O Interface Mode	

10.12.3 Transmit Operation	222
	232
10.12.3.2 Transmit FIFO Operation	
10.12.3.3 I/O interface Mode/Transmission by SCLK Output	
10.12.3.4 Under-run error	
10.13 Handshake function	236
10.14 Interrupt/Error Generation Timing	237
10.14.1 RX Interrupts	
10.14.1.1 Single Buffer / Double Buffer	
10.14.1.2 FIFO	220
10.14.2 TX interrupts	238
10.14.2.1 Single Buffer / Double Buffer 10.14.2.2 FIFO	
10.14.3 Error Generation	239
10.14.3.1 UART Mode	
10.14.3.2 IO Interface Mode	
10.15 Software Reset.	239
10.16 Operation in Each Mode	240
10.16.1 Mode 0 (I/O interface mode)	
10.16.1.1 Transmitting Data	
10.16.1.2 Receive	
10.16.1.3 Transmit and Receive (Full-duplex)	251
10.16.2 Mode 1 (7-bit UART mode)	
10.16.4 Mode 3 (9-bit UART mode)	
10.16.4.1 Wakeup function	232
10.16.4.2 Protocol	
1. Serial Bus Interface (I2C/SIO) 11.1 Configuration	256
11.2 Register	257
11.2.1 Registers for each channel	
11.3 I2C Bus Mode Data Format.	258
11.4 Control Registers in the I2C Bus Mode	
11.4.1 SBIxCR0(Control register 0)	
11.4.1 SBIxCR(Control register 0)	
11.4.3 SBIxCR2(Control register 2)	
11.4.4 SBIxSR (Status Register)	
11.4.5 SBIxBR0(Serial bus interface baud rate register 0)	
11.4.6 SBIxDBR (Serial bus interface data buffer register)	264
	264
11.4.7 SBIxI2CAR (I2Cbus address register)	
11.4.7 SBIxI2CAR (I2Cbus address register)	265
ξ ,	265 266
11.5 Control in the I2C Bus Mode. 11.5.1 Serial Clock	265 266
11.5 Control in the I2C Bus Mode. 11.5.1 Serial Clock	
11.5 Control in the I2C Bus Mode. 11.5.1 Serial Clock	
11.5 Control in the I2C Bus Mode. 11.5.1 Serial Clock	
11.5 Control in the I2C Bus Mode. 11.5.1 Serial Clock	265 266 267 267 267
11.5 Control in the I2C Bus Mode. 11.5.1 Serial Clock	
11.5 Control in the I2C Bus Mode. 11.5.1 Serial Clock. 11.5.1.1 Clock source 11.5.1.2 Clock Synchronization 11.5.2 Setting the Acknowledgement Mode 11.5.3 Setting the Number of Bits per Transfer. 11.5.4 Slave Addressing and Address Recognition Mode 11.5.5 Operating mode	
11.5 Control in the I2C Bus Mode. 11.5.1 Serial Clock	
11.5 Control in the I2C Bus Mode. 11.5.1 Serial Clock. 11.5.1.1 Clock source 11.5.1.2 Clock Synchronization 11.5.2 Setting the Acknowledgement Mode. 11.5.3 Setting the Number of Bits per Transfer. 11.5.4 Slave Addressing and Address Recognition Mode. 11.5.5 Operating mode	
11.5 Control in the I2C Bus Mode. 11.5.1 Serial Clock. 11.5.1.1 Clock source 11.5.1.2 Clock Synchronization 11.5.2 Setting the Acknowledgement Mode. 11.5.3 Setting the Number of Bits per Transfer. 11.5.4 Slave Addressing and Address Recognition Mode. 11.5.5 Operating mode	
11.5 Control in the I2C Bus Mode. 11.5.1 Serial Clock. 11.5.1.1 Clock source 11.5.1.2 Clock Synchronization 11.5.2 Setting the Acknowledgement Mode. 11.5.3 Setting the Number of Bits per Transfer. 11.5.4 Slave Addressing and Address Recognition Mode. 11.5.5 Operating mode	
11.5 Control in the I2C Bus Mode. 11.5.1 Serial Clock. 11.5.1.1 Clock source 11.5.1.2 Clock Synchronization 11.5.2 Setting the Acknowledgement Mode. 11.5.3 Setting the Number of Bits per Transfer. 11.5.4 Slave Addressing and Address Recognition Mode. 11.5.5 Operating mode 11.5.6 Configuring the SBI as a Transmitter or a Receiver. 11.5.7 Configuring the SBI as a Master or a Slave. 11.5.8 Generating Start and Stop Conditions. 11.5.9 Interrupt Service Request and Release. 11.5.10 Arbitration Lost Detection Monitor. 11.5.11 Slave Address Match Detection Monitor. 11.5.12 General-call Detection Monitor.	
11.5 Control in the I2C Bus Mode. 11.5.1 Serial Clock. 11.5.1.1 Clock source 11.5.1.2 Clock Synchronization 11.5.2 Setting the Acknowledgement Mode. 11.5.3 Setting the Number of Bits per Transfer. 11.5.4 Slave Addressing and Address Recognition Mode. 11.5.5 Operating mode. 11.5.6 Configuring the SBI as a Transmitter or a Receiver. 11.5.7 Configuring the SBI as a Master or a Slave. 11.5.8 Generating Start and Stop Conditions. 11.5.9 Interrupt Service Request and Release. 11.5.10 Arbitration Lost Detection Monitor. 11.5.11 Slave Address Match Detection Monitor. 11.5.12 General-call Detection Monitor. 11.5.13 Last Received Bit Monitor.	
11.5 Control in the I2C Bus Mode. 11.5.1 Serial Clock. 11.5.1.1 Clock source 11.5.1.2 Clock Synchronization 11.5.2 Setting the Acknowledgement Mode 11.5.3 Setting the Number of Bits per Transfer. 11.5.4 Slave Addressing and Address Recognition Mode. 11.5.5 Operating mode 11.5.6 Configuring the SBI as a Transmitter or a Receiver. 11.5.7 Configuring the SBI as a Master or a Slave 11.5.8 Generating Start and Stop Conditions 11.5.9 Interrupt Service Request and Release 11.5.10 Arbitration Lost Detection Monitor 11.5.11 Slave Address Match Detection Monitor 11.5.12 General-call Detection Monitor 11.5.13 Last Received Bit Monitor 11.5.14 Data Buffer Register (SBIxDBR)	
11.5 Control in the I2C Bus Mode. 11.5.1 Serial Clock. 11.5.1.1 Clock source 11.5.1.2 Clock Synchronization 11.5.2 Setting the Acknowledgement Mode 11.5.3 Setting the Number of Bits per Transfer. 11.5.4 Slave Addressing and Address Recognition Mode. 11.5.5 Operating mode. 11.5.6 Configuring the SBI as a Transmitter or a Receiver. 11.5.7 Configuring the SBI as a Master or a Slave. 11.5.8 Generating Start and Stop Conditions. 11.5.9 Interrupt Service Request and Release. 11.5.10 Arbitration Lost Detection Monitor. 11.5.11 Slave Address Match Detection Monitor. 11.5.12 General-call Detection Monitor. 11.5.13 Last Received Bit Monitor. 11.5.14 Data Buffer Register (SBIxDBR). 11.5.15 Baud Rate Register (SBIxDBR).	
11.5 Control in the I2C Bus Mode. 11.5.1 Serial Clock. 11.5.1.1 Clock source 11.5.1.2 Clock Synchronization 11.5.2 Setting the Acknowledgement Mode 11.5.3 Setting the Number of Bits per Transfer. 11.5.4 Slave Addressing and Address Recognition Mode. 11.5.5 Operating mode 11.5.6 Configuring the SBI as a Transmitter or a Receiver. 11.5.7 Configuring the SBI as a Master or a Slave 11.5.8 Generating Start and Stop Conditions 11.5.9 Interrupt Service Request and Release 11.5.10 Arbitration Lost Detection Monitor 11.5.11 Slave Address Match Detection Monitor 11.5.12 General-call Detection Monitor 11.5.13 Last Received Bit Monitor 11.5.14 Data Buffer Register (SBIxDBR)	

11.6.2	2 Generating the Start Condition and a Slave Address	272
	6.2.2 Slave mode	
11.6.3		274
	6.3.1 Master mode (<mst> = "1") 6.3.2 Slave mode (<mst> = "0")</mst></mst>	
11.6.4		279
11.6.5		
11.7	Control register of SIO mode	281
11.7.1	8	
11.7.2		
11.7.3	(: : :)	
11.7.4	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	
11.7.5	(6)	
11.7.6		
	Control in SIO mode	
11.8.1	Serial Clock	287
	8.1.2 Shift Edge	
11.8.2		289
	8.2.1 8-bit transmit mode	
	8.2.2 8-bit receive mode 8.2.3 8-bit transmit/receive mode	
	8.2.4 Data retention time of the last bit at the end of transmission	
12. Cons	sumer Electronics Control (CEC)	
12. Cons	sumer Electronics Control (CEC)	
12.1	Outline	295
12.1.1		
12.1.2	1	
12.1.3	3 Precautions	295
12.2	Block Diagram	296
	Registers	
12.3.1	•	
12.3.2	· ·	
12.3.3	GECADD (Logical Address Register)	299
12.3.4	4 CECRESET (Software Reset Register)	300
12.3.5		
12.3.6	`	
12.3.7 12.3.8	\	
12.3.9	· · · · · · · · · · · · · · · · · · ·	
12.3.1		
12.3.1		
12.3.1	` ,	
12.3.1		
12.3.1	(1 2)	
	Operations	
12.4.1	~	
12.4.2	2 Reception	315
	4.2.2 Preconfiguration	
	4.2.3 Enabling Reception	
	4.2.4 Detecting Error Interrupt 4.2.5 Details of reception error	
	4.2.6 Stopping Reception	
12.4.3		324
	4.3.1 Basic Operation	
	4.3.2 Preconfiguration 4.3.3 Detecting Transmission Error	
	4.3.3 Detecting Transmission Error 4.3.4 Details of Transmission Error	
	4.3.5 Stopping Transmission	
	4.3.6 Retransmission	
12.4.4	Software Reset	329

Remot		
13.1 B	asic operation	
13.1.1	Reception of Remote Control Signal	
13.2 B	lock Diagram	
	e	
	egisters	
13.3.1	Register List	
13.3.2	RMCEN (Enable Register)	
13.3.3	RMCREN (Receive Enable Register)	
13.3.4 13.3.5	RMCRBUF1(Receive Data Buffer Register 1)	
13.3.5	RMCRBUF3(Receive Data Buffer Register 3)	
13.3.7	RMCRCR1(Receive Data Burlet Register 3)	
13.3.8	RMCRCR2(Receive Control Register 2)	
13.3.9	RMCRCR3(Receive Control Register 3)	
13.3.10	RMCRCR4(Receive Control Register 4)	
13.3.11	RMCRSTAT (Receive Status Register)	
	peration Description	
13.4.1	Reception of Remote Control Signal.	
13.4.1	1 &	34.
13.4.1		
13.4.1	1	
13.4.1		
13.4.1	11 6 1	
13.4.1 13.4.1	č č	
13.4.1	· · · · · · · · · · · · · · · · · · ·	
	g/Digital Converter (ADC)	
14.1 C	Outline	
14.1 C	, ,	
14.1 C	Outlineonfiguration	
14.1 C	Outline	
14.1 C 14.2 C 14.3 R	Outline	
14.1 C 14.2 C 14.3 R	Outline	
14.1 C 14.2 C 14.3 R 14.3.1 14.3.2	Outline	35 35 35 35
14.1 C 14.2 C 14.3 R 14.3.1 14.3.2 14.3.3	Outline	35. 35. 35. 35.
14.1 C 14.2 C 14.3 R 14.3.1 14.3.2 14.3.3 14.3.4	Outline Onfiguration egisters Register list ADCBAS (Conversion Accuracy Setting Register) ADCLK (Conversion Clock Setting Register) ADMOD0 (Mode Control Register 0) ADMOD1 (Mode Control Register 1) ADMOD2 (Mode Control Register 2)	35. 35. 35. 35. 35. 35. 35. 35. 35. 35.
14.1 C 14.2 C 14.3 R 14.3.1 14.3.2 14.3.3 14.3.4 14.3.5	Outline Onfiguration egisters Register list ADCBAS (Conversion Accuracy Setting Register) ADCLK (Conversion Clock Setting Register) ADMOD0 (Mode Control Register 0) ADMOD1 (Mode Control Register 1) ADMOD2 (Mode Control Register 2) ADMOD4 (Mode Control Register 4)	35. 35. 35. 35. 35. 35. 35. 35. 35. 35.
14.1 C 14.2 C 14.3 R 14.3.1 14.3.2 14.3.3 14.3.4 14.3.5 14.3.6	Outline Onfiguration egisters Register list ADCBAS (Conversion Accuracy Setting Register) ADCLK (Conversion Clock Setting Register) ADMOD0 (Mode Control Register 0) ADMOD1 (Mode Control Register 1) ADMOD2 (Mode Control Register 2) ADMOD4 (Mode Control Register 4) ADMOD3 (Mode Control Register 3)	35. 35. 35. 35. 35. 35. 35. 36. 36.
14.1 C 14.2 C 14.3 R 14.3.1 14.3.2 14.3.3 14.3.4 14.3.5 14.3.6 14.3.7	Outline. Configuration. Legisters. Register list. ADCBAS (Conversion Accuracy Setting Register). ADCLK (Conversion Clock Setting Register). ADMOD0 (Mode Control Register 0) ADMOD1 (Mode Control Register 1). ADMOD2 (Mode Control Register 2) ADMOD4 (Mode Control Register 4) ADMOD3 (Mode Control Register 3). ADMOD5 (Mode Control Register 5).	35: 35: 35: 35: 35: 35: 36: 36: 36: 36:
14.1 C 14.2 C 14.3 R 14.3.1 14.3.2 14.3.3 14.3.4 14.3.5 14.3.6 14.3.7 14.3.8 14.3.9 14.3.10	Outline. Configuration. Legisters. Register list. ADCBAS (Conversion Accuracy Setting Register). ADCLK (Conversion Clock Setting Register). ADMOD0 (Mode Control Register 0) ADMOD1 (Mode Control Register 1). ADMOD2 (Mode Control Register 2) ADMOD4 (Mode Control Register 4) ADMOD3 (Mode Control Register 3). ADMOD5 (Mode Control Register 5). ADREG08 (Conversion Result Register 08).	35: 35: 35: 35: 35: 36: 36: 36: 36: 36:
14.1 C 14.2 C 14.3 R 14.3.1 14.3.2 14.3.3 14.3.4 14.3.5 14.3.6 14.3.7 14.3.8 14.3.9 14.3.10 14.3.11	Outline. Configuration. Legisters. Register list. ADCBAS (Conversion Accuracy Setting Register). ADCLK (Conversion Clock Setting Register). ADMOD0 (Mode Control Register 0). ADMOD1 (Mode Control Register 1). ADMOD2 (Mode Control Register 2). ADMOD4 (Mode Control Register 4). ADMOD3 (Mode Control Register 3). ADMOD5 (Mode Control Register 3). ADMOD5 (Mode Control Register 5). ADREG08 (Conversion Result Register 08). ADREG19 (AD Conversion Result Register 19).	35: 35: 35: 35: 35: 36: 36: 36: 36: 36: 36:
14.1 C 14.2 C 14.3 R 14.3.1 14.3.2 14.3.3 14.3.4 14.3.5 14.3.6 14.3.7 14.3.8 14.3.9 14.3.10 14.3.11	Outline. Configuration. Legisters. Register list. ADCBAS (Conversion Accuracy Setting Register). ADCLK (Conversion Clock Setting Register). ADMOD0 (Mode Control Register 0). ADMOD1 (Mode Control Register 1). ADMOD2 (Mode Control Register 2). ADMOD4 (Mode Control Register 3). ADMOD5 (Mode Control Register 3). ADMOD5 (Mode Control Register 3). ADMOD5 (Mode Control Register 5). ADREG08 (Conversion Result Register 08). ADREG19 (AD Conversion Result Register 19). ADREG2A (AD Conversion Result Register 2A).	35 35 35 35 35 35 36 36 36 36
14.1 C 14.2 C 14.3 R 14.3.1 14.3.2 14.3.3 14.3.4 14.3.5 14.3.6 14.3.7 14.3.8 14.3.9 14.3.10 14.3.11 14.3.12 14.3.13	Outline. Configuration. Legisters. Register list. ADCBAS (Conversion Accuracy Setting Register). ADCLK (Conversion Clock Setting Register). ADMOD0 (Mode Control Register 0). ADMOD1 (Mode Control Register 1). ADMOD2 (Mode Control Register 2). ADMOD4 (Mode Control Register 3). ADMOD3 (Mode Control Register 4). ADMOD3 (Mode Control Register 3). ADMOD5 (Mode Control Register 5). ADREG08 (Conversion Result Register 08). ADREG19 (AD Conversion Result Register 19). ADREG2A (AD Conversion Result Register 2A). ADREG3B (AD Conversion Result Register 3B).	35. 35. 35. 35. 35. 35. 35. 36. 36. 36. 36. 36. 36.
14.1 C 14.2 C 14.3 R 14.3.1 14.3.2 14.3.3 14.3.4 14.3.5 14.3.6 14.3.7 14.3.8 14.3.9 14.3.10 14.3.11 14.3.12 14.3.13 14.3.14	Outline Configuration Legisters. Register list. ADCBAS (Conversion Accuracy Setting Register) ADCLK (Conversion Clock Setting Register) ADMOD0 (Mode Control Register 0) ADMOD1 (Mode Control Register 1) ADMOD2 (Mode Control Register 2) ADMOD4 (Mode Control Register 4) ADMOD3 (Mode Control Register 3) ADMOD4 (Mode Control Register 3) ADMOD5 (Mode Control Register 3) ADMOD5 (Mode Control Register 5) ADREG08 (Conversion Result Register 08) ADREG19 (AD Conversion Result Register 19) ADREG2A (AD Conversion Result Register 2A) ADREG3B (AD Conversion Result Register 3B) ADREG3B (AD Conversion Result Register 4C)	35. 35. 35. 35. 35. 35. 35. 36. 36. 36. 36. 36. 36. 36. 36.
14.1 C 14.2 C 14.3 R 14.3.1 14.3.2 14.3.3 14.3.4 14.3.5 14.3.6 14.3.7 14.3.8 14.3.9 14.3.10 14.3.11 14.3.12 14.3.13 14.3.14	Outline. Configuration. Legisters. Register list. ADCBAS (Conversion Accuracy Setting Register). ADCLK (Conversion Clock Setting Register). ADMOD0 (Mode Control Register 0). ADMOD1 (Mode Control Register 1). ADMOD2 (Mode Control Register 2). ADMOD4 (Mode Control Register 4). ADMOD3 (Mode Control Register 3). ADMOD5 (Mode Control Register 3). ADMOD5 (Mode Control Register 5). ADREG08 (Conversion Result Register 08). ADREG19 (AD Conversion Result Register 19). ADREG2A (AD Conversion Result Register 2A). ADREG3B (AD Conversion Result Register 3B). ADREG3B (AD Conversion Result Register 3B). ADREG4C (AD Conversion Result Register 4C). ADREG5D (AD Conversion Result Register 5D).	35. 35. 35. 35. 35. 35. 36. 36. 36. 36. 36. 36. 36. 36. 36. 36
14.1 C 14.2 C 14.3 R 14.3.1 14.3.2 14.3.3 14.3.4 14.3.5 14.3.6 14.3.7 14.3.8 14.3.9 14.3.10 14.3.11 14.3.12 14.3.13 14.3.14 14.3.15 14.3.16	Outline. Configuration. Legisters. Register list. ADCBAS (Conversion Accuracy Setting Register). ADCLK (Conversion Clock Setting Register). ADMOD0 (Mode Control Register 0). ADMOD1 (Mode Control Register 1). ADMOD2 (Mode Control Register 2). ADMOD4 (Mode Control Register 4). ADMOD4 (Mode Control Register 3). ADMOD5 (Mode Control Register 3). ADMOD5 (Mode Control Register 5). ADREG08 (Conversion Result Register 08). ADREG19 (AD Conversion Result Register 19). ADREG2A (AD Conversion Result Register 2A). ADREG3B (AD Conversion Result Register 3B). ADREG4C (AD Conversion Result Register 4C). ADREG5D (AD Conversion Result Register 5D). ADREG6E (AD Conversion Result Register 5D).	355 355 355 356 357 367 368 368 369 369 369 369 369 369 369 369
14.1 C 14.2 C 14.3 R 14.3.1 14.3.2 14.3.3 14.3.4 14.3.5 14.3.6 14.3.7 14.3.10 14.3.11 14.3.12 14.3.13 14.3.14 14.3.15 14.3.16 14.3.17	Outline. Configuration. Legisters. Register list. ADCBAS (Conversion Accuracy Setting Register). ADCLK (Conversion Clock Setting Register). ADMOD0 (Mode Control Register 0). ADMOD1 (Mode Control Register 1). ADMOD2 (Mode Control Register 2). ADMOD4 (Mode Control Register 2). ADMOD5 (Mode Control Register 3). ADMOD5 (Mode Control Register 3). ADMOD5 (Mode Control Register 5). ADREG08 (Conversion Result Register 08). ADREG19 (AD Conversion Result Register 19). ADREG2A (AD Conversion Result Register 2A). ADREG3B (AD Conversion Result Register 3B). ADREG3B (AD Conversion Result Register 4C). ADREG5D (AD Conversion Result Register 5D). ADREG6E (AD Conversion Result Register 5D). ADREG6E (AD Conversion Result Register 6E). ADREG7F (AD Conversion Result Register 7F).	355 356 356 357 358 358 359 369 360 360 360 360 360 360 360 360 370
14.1 C 14.2 C 14.3 R 14.3.1 14.3.2 14.3.3 14.3.4 14.3.5 14.3.6 14.3.7 14.3.10 14.3.11 14.3.12 14.3.13 14.3.14 14.3.15 14.3.16 14.3.17 14.3.18	Outline. Configuration. Legisters. Register list. ADCBAS (Conversion Accuracy Setting Register). ADCLK (Conversion Clock Setting Register). ADMOD0 (Mode Control Register 0). ADMOD1 (Mode Control Register 1). ADMOD2 (Mode Control Register 2). ADMOD4 (Mode Control Register 2). ADMOD5 (Mode Control Register 3). ADMOD5 (Mode Control Register 3). ADMOD5 (Mode Control Register 3). ADMOD5 (Mode Control Register 5). ADREG08 (Conversion Result Register 08). ADREG19 (AD Conversion Result Register 19). ADREG2A (AD Conversion Result Register 2A). ADREG3B (AD Conversion Result Register 3B). ADREG3B (AD Conversion Result Register 3B). ADREG4C (AD Conversion Result Register 5D). ADREG5D (AD Conversion Result Register 5D). ADREG6E (AD Conversion Result Register 6E). ADREG7F (AD Conversion Result Register 7F). ADREGSP (AD Conversion Result Register SP).	352 3553 3563 3573 3673 3673 3673 3773 3753 3
14.1 C 14.2 C 14.3 R 14.3.1 14.3.2 14.3.3 14.3.4 14.3.5 14.3.6 14.3.7 14.3.10 14.3.11 14.3.12 14.3.13 14.3.14 14.3.15 14.3.16 14.3.17 14.3.18 14.3.19	Outline. Configuration. Legisters. Register list. ADCBAS (Conversion Accuracy Setting Register). ADCLK (Conversion Clock Setting Register). ADMOD0 (Mode Control Register 0). ADMOD1 (Mode Control Register 1). ADMOD2 (Mode Control Register 2). ADMOD4 (Mode Control Register 2). ADMOD5 (Mode Control Register 4). ADMOD5 (Mode Control Register 3). ADMOD5 (Mode Control Register 5). ADREG08 (Conversion Result Register 08). ADREG19 (AD Conversion Result Register 19). ADREG2A (AD Conversion Result Register 2A). ADREG3B (AD Conversion Result Register 3B). ADREG3B (AD Conversion Result Register 3B). ADREG4C (AD Conversion Result Register 5D). ADREG5D (AD Conversion Result Register 5D). ADREG6E (AD Conversion Result Register 6E). ADREG7F (AD Conversion Result Register 7F). ADREGSP (AD Conversion Result Register SP). ADCMP0 (AD Conversion Result Comparison Register 0).	352 355 355 356 355 356 366 366 366 366 366
14.1 C 14.2 C 14.3 R 14.3.1 14.3.2 14.3.3 14.3.4 14.3.5 14.3.6 14.3.7 14.3.10 14.3.11 14.3.12 14.3.13 14.3.14 14.3.15 14.3.16 14.3.17 14.3.18 14.3.19 14.3.20	Outline. Configuration. Register S. Register list. ADCBAS (Conversion Accuracy Setting Register). ADCLK (Conversion Clock Setting Register). ADMOD0 (Mode Control Register 0). ADMOD1 (Mode Control Register 1). ADMOD2 (Mode Control Register 2). ADMOD4 (Mode Control Register 2). ADMOD5 (Mode Control Register 3). ADMOD5 (Mode Control Register 3). ADMOD5 (Mode Control Register 3). ADMOD5 (Mode Control Register 5). ADREG08 (Conversion Result Register 08). ADREG19 (AD Conversion Result Register 19). ADREG2A (AD Conversion Result Register 2A). ADREG3B (AD Conversion Result Register 3B). ADREG4C (AD Conversion Result Register 3B). ADREG6E (AD Conversion Result Register 5D). ADREG6E (AD Conversion Result Register 5D). ADREG6F (AD Conversion Result Register 7F). ADREGSP (AD Conversion Result Register 7F). ADREGSP (AD Conversion Result Register SP). ADCMP0 (AD Conversion Result Comparison Register 0). ADCMP1 (AD Conversion Result Comparison Register 1).	355 356 355 356 356 366 366 366 366 366
14.1 C 14.2 C 14.3 R 14.3.1 14.3.2 14.3.3 14.3.4 14.3.5 14.3.6 14.3.7 14.3.10 14.3.11 14.3.12 14.3.13 14.3.14 14.3.15 14.3.16 14.3.17 14.3.18 14.3.19 14.3.20	Outline Configuration Register S Register list ADCBAS (Conversion Accuracy Setting Register) ADCLK (Conversion Clock Setting Register) ADMOD0 (Mode Control Register 0) ADMOD1 (Mode Control Register 1) ADMOD2 (Mode Control Register 2) ADMOD4 (Mode Control Register 3) ADMOD3 (Mode Control Register 3) ADMOD5 (Mode Control Register 3) ADMOD5 (Mode Control Register 5) ADREG08 (Conversion Result Register 08) ADREG09 (Conversion Result Register 19) ADREG19 (AD Conversion Result Register 19) ADREG2A (AD Conversion Result Register 3B) ADREG3B (AD Conversion Result Register 3B) ADREG4C (AD Conversion Result Register 4C) ADREG5D (AD Conversion Result Register 5D) ADREG6E (AD Conversion Result Register 6E) ADREG7F (AD Conversion Result Register 7F) ADREG8P (AD Conversion Result Register SP) ADREGSP (AD Conversion Result Comparison Register 0) ADCMP1 (AD Conversion Result Comparison Register 1) PESCRIPTION OF OPERATIONS.	355 355 355 356 356 356 366 366 366 366
14.1 C 14.2 C 14.3 R 14.3.1 14.3.2 14.3.3 14.3.4 14.3.5 14.3.6 14.3.7 14.3.8 14.3.9 14.3.10 14.3.11 14.3.12 14.3.13 14.3.14 14.3.15 14.3.16 14.3.17 14.3.18 14.3.19 14.3.20 14.4 D 14.4.1	Outline Configuration Register S Register list ADCBAS (Conversion Accuracy Setting Register) ADCLK (Conversion Clock Setting Register) ADMOD0 (Mode Control Register 0) ADMOD1 (Mode Control Register 1) ADMOD2 (Mode Control Register 2) ADMOD4 (Mode Control Register 4) ADMOD3 (Mode Control Register 3) ADMOD5 (Mode Control Register 5) ADREG08 (Conversion Result Register 08) ADREG19 (AD Conversion Result Register 19) ADREG19 (AD Conversion Result Register 2A) ADREG3B (AD Conversion Result Register 3B) ADREG3B (AD Conversion Result Register 4C) ADREG5D (AD Conversion Result Register 5D) ADREG6E (AD Conversion Result Register 5D) ADREG6E (AD Conversion Result Register 6E) ADREG7F (AD Conversion Result Register 7F) ADREGSP (AD Conversion Result Register SP). ADREGSP (AD Conversion Result Comparison Register 0) ADCMP0 (AD Conversion Result Comparison Register 1) PESCRIPTION OF OPERATIONS Analog Reference Voltage	355 355 355 356 356 356 366 366 366 366
14.1 C 14.2 C 14.3 R 14.3.1 14.3.2 14.3.3 14.3.4 14.3.5 14.3.6 14.3.7 14.3.10 14.3.11 14.3.12 14.3.13 14.3.14 14.3.15 14.3.16 14.3.17 14.3.18 14.3.19 14.3.20	Outline Configuration Cegisters. Register list ADCBAS (Conversion Accuracy Setting Register) ADCLK (Conversion Clock Setting Register) ADMOD0 (Mode Control Register 0) ADMOD1 (Mode Control Register 1) ADMOD2 (Mode Control Register 2) ADMOD4 (Mode Control Register 2) ADMOD5 (Mode Control Register 3) ADMOD5 (Mode Control Register 3) ADMOD5 (Mode Control Register 5) ADREG08 (Conversion Result Register 19) ADREG19 (AD Conversion Result Register 19) ADREG2A (AD Conversion Result Register 2A) ADREG3B (AD Conversion Result Register 3B) ADREG3B (AD Conversion Result Register 4C) ADREG5D (AD Conversion Result Register 5D) ADREG6E (AD Conversion Result Register 5D) ADREG6E (AD Conversion Result Register 6E) ADREG7F (AD Conversion Result Register 7F) ADREGSP (AD Conversion Result Register SP) ADCMP0 (AD Conversion Result Comparison Register 1) DESCRIPTION OF OPERATIONS Analog Reference Voltage AD Conversion Mode	355 355 355 356 355 356 356 366 366 366
14.1 C 14.2 C 14.3 R 14.3.1 14.3.2 14.3.3 14.3.4 14.3.5 14.3.6 14.3.7 14.3.8 14.3.10 14.3.11 14.3.12 14.3.13 14.3.14 14.3.15 14.3.16 14.3.17 14.3.18 14.3.19 14.3.20 14.4 D 14.4.1 14.4.2	Outline Configuration Cegisters. Register list ADCBAS (Conversion Accuracy Setting Register). ADCLK (Conversion Clock Setting Register). ADMOD0 (Mode Control Register 0) ADMOD1 (Mode Control Register 1). ADMOD2 (Mode Control Register 2) ADMOD4 (Mode Control Register 4) ADMOD3 (Mode Control Register 3). ADMOD5 (Mode Control Register 3). ADMOD5 (Mode Control Register 5). ADREG08 (Conversion Result Register 19). ADREG19 (AD Conversion Result Register 19). ADREG2A (AD Conversion Result Register 2A). ADREG3B (AD Conversion Result Register 3B). ADREG3B (AD Conversion Result Register 4C). ADREG5D (AD Conversion Result Register 5D). ADREG6E (AD Conversion Result Register 6E). ADREG6F (AD Conversion Result Register 7F). ADREG7F (AD Conversion Result Register 5P). ADREG8P (AD Conversion Result Register 5P). ADCMP0 (AD Conversion Result Comparison Register 0). ADCMP1 (AD Conversion Result Comparison Register 1). Description of Operations. Analog Reference Voltage. AD Conversion Mode. 1 Normal AD conversion Mode.	355 355 355 356 355 356 356 366 366 366
14.1 C 14.2 C 14.3 R 14.3.1 14.3.2 14.3.3 14.3.4 14.3.5 14.3.6 14.3.7 14.3.8 14.3.10 14.3.11 14.3.12 14.3.13 14.3.14 14.3.15 14.3.16 14.3.17 14.3.18 14.3.19 14.3.20 14.4 D 14.4.1 14.4.2 14.4.2	Outline. Configuration. Legisters. Register list. ADCBAS (Conversion Accuracy Setting Register). ADCLK (Conversion Clock Setting Register). ADMOD0 (Mode Control Register 0). ADMOD1 (Mode Control Register 1). ADMOD2 (Mode Control Register 2). ADMOD4 (Mode Control Register 2). ADMOD5 (Mode Control Register 3). ADMOD5 (Mode Control Register 3). ADMOD5 (Mode Control Register 5). ADREG08 (Conversion Result Register 08). ADREG19 (AD Conversion Result Register 19). ADREG3B (AD Conversion Result Register 2A). ADREG3B (AD Conversion Result Register 3B). ADREG3B (AD Conversion Result Register 3B). ADREG6B (AD Conversion Result Register 5D). ADREG6C (AD Conversion Result Register 5D). ADREG6F (AD Conversion Result Register 5D). ADREG6F (AD Conversion Result Register 5P). ADREG5P (AD Conversion Result Register 5P). ADREGSP (AD Conversion Result Register 5P). ADREGSP (AD Conversion Result Comparison Register 0). ADCMP1 (AD Conversion Result Comparison Register 1). Pescription of Operations. Analog Reference Voltage. AD Conversion Mode. 1. Normal AD conversion 2. Top-priority AD conversion AD Monitor Function.	353 354 355 355 356 357 357 367 367 367 377 377 377 377 377 377 37
14.1 C 14.2 C 14.3 R 14.3.1 14.3.2 14.3.3 14.3.4 14.3.5 14.3.6 14.3.7 14.3.8 14.3.9 14.3.10 14.3.11 14.3.12 14.3.13 14.3.14 14.3.15 14.3.16 14.3.17 14.3.18 14.3.19 14.3.20 14.4.1 14.4.2 14.4.2 14.4.2	Putline Configuration Registers Register list ADCBAS (Conversion Accuracy Setting Register) ADCLK (Conversion Clock Setting Register) ADMOD0 (Mode Control Register 0) ADMOD1 (Mode Control Register 1) ADMOD2 (Mode Control Register 2) ADMOD4 (Mode Control Register 3) ADMOD5 (Mode Control Register 3) ADMOD5 (Mode Control Register 5) ADREG08 (Conversion Result Register 08) ADREG19 (AD Conversion Result Register 19) ADREG2A (AD Conversion Result Register 2A) ADREG3B (AD Conversion Result Register 3B) ADREG4C (AD Conversion Result Register 4C) ADREG5D (AD Conversion Result Register 5D) ADREG6E (AD Conversion Result Register 6E) ADREG7F (AD Conversion Result Register 7F) ADREG8F (AD Conversion Result Register SP) ADREG9F (AD Conversion Result Register SP) ADREG9F (AD Conversion Result Register SP) ADREGSP (AD Conversion Result Comparison Register 0) ADCMP1 (AD Conversion Result Comparison Register 1) Pescription of Operations Analog Reference Voltage AD Conversion Mode 1 Normal AD conversion 2 Top-priority AD conversion	355 356 356 357 357 357 357 357

	14.4.5 AD Conversion Details	
	14.4.5.1 Starting AD Conversion 14.4.5.2 AD Conversion	
	14.4.5.3 Top-priority AD conversion during normal AD conversion	
	14.4.5.4 Stopping Repeat Conversion Mode	
	14.4.5.5 Reactivating normal AD conversion	
	14.4.5.6 Conversion completion	
	14.4.5.7 Interrupt generation timings and AD conversion result storage register	
15.	Watchdog Timer(WDT)	
		292
	15.1 Configuration	
	15.2 Register	
	15.2.1 WDMOD(Watchdog Timer Mode Register)	
	15.2.2 WDCR (Watchdog Timer Control Register)	
	15.3 Operations.	
	15.3.1 Basic Operation	
	15.3.2 Operation Mode and Status.	
	15.4 Operation when malfunction (runaway) is detected	
	15.4.1 INTWDT interrupt generation	
	15.4.2 Internal reset generation	
	15.5 Control register	
	15.5.1 Watchdog Timer Mode Register (WDMOD)	
	15.5.2 Watchdog Timer Control Register(WDCR)	
	15.5.3.1 Disabling control	
	15.5.3.2 Enabling control	
	15.5.3.3 Watchdog timer clearing control	
	15.5.3.4 Detection time of watchdog timer	
16.	15.5.3.4 Detection time of watchdog timer Real Time Clock (RTC)	301
16.	15.5.3.4 Detection time of watchdog timer Real Time Clock (RTC) 16.1 Function	
16.	Real Time Clock (RTC) 16.1 Function	391
16.	Real Time Clock (RTC) 16.1 Function	391 392
16.	Real Time Clock (RTC) 16.1 Function 16.2 Block Diagram 16.3 Detailed Description Register 16.3.1 Register List	391 392
16.	Real Time Clock (RTC) 16.1 Function 16.2 Block Diagram 16.3 Detailed Description Register 16.3.1 Register List 16.3.2 Control Register	391 392 392 392
16.	Real Time Clock (RTC) 16.1 Function 16.2 Block Diagram 16.3 Detailed Description Register 16.3.1 Register List 16.3.2 Control Register 16.3.3 Detailed Description of Control Register	391 392 392 392
16.	Real Time Clock (RTC) 16.1 Function 16.2 Block Diagram 16.3 Detailed Description Register 16.3.1 Register List 16.3.2 Control Register	391 392 392 392
16.	Real Time Clock (RTC) 16.1 Function 16.2 Block Diagram 16.3 Detailed Description Register 16.3.1 Register List 16.3.2 Control Register 16.3.3 Detailed Description of Control Register 16.3.1 RTCSECR (Second column register (for PAGE0 only)) 16.3.3.2 RTCMINR (Minute column register (PAGE0/1)) 16.3.3.3 RTCHOURR (Hour column register(PAGE0/1))	391 392 392 392
16.	Real Time Clock (RTC) 16.1 Function 16.2 Block Diagram 16.3 Detailed Description Register 16.3.1 Register List 16.3.2 Control Register 16.3.3 Detailed Description of Control Register 16.3.1 REGISTER (Second column register (for PAGE0 only)) 16.3.3.1 RTCSECR (Second column register (PAGE0/1)) 16.3.3.3 RTCHOURR (Hour column register (PAGE0/1)) 16.3.3.4 RTCDAYR (Day of the week column register(PAGE0/1))	391 392 392 392
16.	Real Time Clock (RTC) 16.1 Function 16.2 Block Diagram 16.3 Detailed Description Register 16.3.1 Register List 16.3.2 Control Register 16.3.3 Detailed Description of Control Register 16.3.1 RTCSECR (Second column register (for PAGE0 only)) 16.3.3.2 RTCMINR (Minute column register (PAGE0/1)) 16.3.3.3 RTCHOURR (Hour column register(PAGE0/1))	391 392 392 392
16.	Real Time Clock (RTC) 16.1 Function 16.2 Block Diagram 16.3 Detailed Description Register 16.3.1 Register List	391 392 392 392
16.	Real Time Clock (RTC) 16.1 Function 16.2 Block Diagram 16.3 Detailed Description Register 16.3.1 Register List	391 392 392 392
16.	Real Time Clock (RTC) 16.1 Function 16.2 Block Diagram 16.3 Detailed Description Register 16.3.1 Register List 16.3.2 Control Register 16.3.3 Detailed Description of Control Register 16.3.3 Detailed Description of Control Register 16.3.3.1 RTCSECR (Second column register (for PAGE0 only)) 16.3.3.2 RTCMINR (Minute column register (PAGE0/1)) 16.3.3.3 RTCDAYR (Day of the week column register(PAGE0/1)) 16.3.3.4 RTCDAYR (Day column register (for PAGE0 only)) 16.3.3.5 RTCDATER (Day column register (for PAGE0 only)) 16.3.3.6 RTCMONTHR (Month column register (for PAGE0 only)) 16.3.3.8 RTCYEARR (Year column register (for PAGE0 only)) 16.3.3.9 RTCYEARR (Vear column register (for PAGE0 only))	391 392 392 392
16.	Real Time Clock (RTC) 16.1 Function 16.2 Block Diagram 16.3 Detailed Description Register 16.3.1 Register List	391 392 392 392
116.	Real Time Clock (RTC) 16.1 Function. 16.2 Block Diagram. 16.3 Detailed Description Register. 16.3.1 Register List. 16.3.2 Control Register. 16.3.3 Detailed Description of Control Register. 16.3.3 Detailed Description of Control Register. 16.3.3.1 RTCSECR (Second column register (for PAGE0 only)) 16.3.3.2 RTCMINR (Minute column register (PAGE0/1)) 16.3.3.3 RTCHOURR (Hour column register(PAGE0/1)) 16.3.3.4 RTCDAYR (Day of the week column register(PAGE0/1)) 16.3.3.5 RTCDATER (Day column register (for PAGE0 only)) 16.3.3.6 RTCMONTHR (Month column register (for PAGE0 only)) 16.3.3.7 RTCMONTHR (Selection of 24-hour clock or 12-hour clock24(for PAGE1 only)) 16.3.3.8 RTCYEARR (Year column register (for PAGE0 only)) 16.3.3.9 RTCYEARR (Leap year register (for PAGE1 only)) 16.3.3.10 RTCPAGER(PAGE register(PAGE0/1)) 16.3.3.11 RTCRESTR (Reset register (for PAGE0/1))	
16.	Real Time Clock (RTC) 16.1 Function 16.2 Block Diagram 16.3 Detailed Description Register 16.3.1 Register List 16.3.2 Control Register 16.3.3 Detailed Description of Control Register 16.3.3.1 RTCSECR (Second column register (for PAGE0 only)) 16.3.2.2 RTCMINR (Minute column register (PAGE0/1)) 16.3.3.3 RTCHOURR (Hour column register (PAGE0/1)) 16.3.3.4 RTCDAYR (Day of the week column register(PAGE0/1)) 16.3.3.5 RTCDATER (Day column register (for PAGE0 only)) 16.3.6 RTCMONTHR (Month column register (for PAGE0 only)) 16.3.7 RTCMONTHR (Selection of 24-hour clock or 12-hour clock24(for PAGE1 only)) 16.3.8 RTCYEARR (Year column register (for PAGE0 only)) 16.3.9 RTCYEARR (Leap year register (for PAGE1 only)) 16.3.10 RTCPAGER(PAGE register(PAGE0/1)) 16.3.11 RTCRESTR (Reset register (for PAGE0/1)) 16.4.1 Reading clock data	391 392 392 394 401
16.	Real Time Clock (RTC) 16.1 Function 16.2 Block Diagram 16.3 Detailed Description Register 16.3.1 Register List	391 392 392 394 401 401
16.	Real Time Clock (RTC) 16.1 Function. 16.2 Block Diagram. 16.3 Detailed Description Register. 16.3.1 Register List. 16.3.2 Control Register. 16.3.3 Detailed Description of Control Register. 16.3.3 Detailed Description of Control Register. 16.3.3.1 RTCSECR (Second column register (for PAGE0 only)) 16.3.3.2 RTCMINR (Minute column register (PAGE0/1)) 16.3.3.3 RTCHOURR (Hour column register(PAGE0/1)) 16.3.3.4 RTCDAYR (Day of the week column register(PAGE0/1)) 16.3.5 RTCMONTHR (Month column register (for PAGE0 only)) 16.3.3.6 RTCMONTHR (Selection of 24-hour clock or 12-hour clock24(for PAGE1 only)) 16.3.3.9 RTCYEARR (Year column register (for PAGE0 only)) 16.3.3.11 RTCRESTR (Reset register (for PAGE0 only)) 16.3.3.11 RTCRESTR (Reset register (FOR PAGE0 Only)) 16.4.1 Reading clock data. 16.4.2 Writing clock data. 16.4.3 Entering the Low Power Consumption Mode.	391 392 392 394 401 401 401 403
16.	Real Time Clock (RTC) 16.1 Function. 16.2 Block Diagram. 16.3 Detailed Description Register. 16.3.1 Register List. 16.3.2 Control Register. 16.3.3 Detailed Description of Control Register. 16.3.3.1 RTCSECR (Second column register (For PAGE0 only)) 16.3.3.2 RTCMINR (Minute column register (PAGE0/1)) 16.3.3.3 RTCHOURR (Hour column register (PAGE0/1)) 16.3.3.4 RTCDAYR (Day of the week column register(PAGE0/1)) 16.3.3.5 RTCDATER (Day column register (for PAGE0 only)) 16.3.3.6 RTCMONTHR (Month column register (for PAGE0 only)) 16.3.3.7 RTCMONTHR (Selection of 24-hour clock or 12-hour clock24(for PAGE1 only)) 16.3.3.9 RTCYEARR (Year column register (for PAGE0 only)) 16.3.3.10 RTCPAGRR (Year column register (for PAGE1 only)) 16.3.3.11 RTCRESTR (Reset register (for PAGE1 only)) 16.4.1 Reading clock data. 16.4.2 Writing clock data. 16.4.3 Entering the Low Power Consumption Mode. 16.5 Alarm function	
16.	Real Time Clock (RTC) 16.1 Function 16.2 Block Diagram 16.3 Detailed Description Register 16.3.1 Register List 16.3.2 Control Register 16.3.3 Detailed Description of Control Register 16.3.3 Detailed Description of Control Register 16.3.3 RTCSECR (Second column register (for PAGE0 only)) 16.3.3.2 RTCMINR (Minute column register (PAGE0/1)) 16.3.3.3 RTCDAYTR (Hour column register (PAGE0/1)) 16.3.3.4 RTCDAYR (Day of the week column register(PAGE0/1)) 16.3.3.5 RTCDATER (Day column register (for PAGE0 only)) 16.3.3.6 RTCMONTHR (Month column register (for PAGE0 only)) 16.3.3.7 RTCMONTHR (Selection of 24-hour clock or 12-hour clock24(for PAGE1 only)) 16.3.3.9 RTCYEARR (Year column register (for PAGE0 only)) 16.3.3.10 RTCPGAGER(PAGE register(PAGE0/1)) 16.3.3.11 RTCRESTR (Reset register (for PAGE0 only)) 16.3.3.11 RTCRESTR (Reset register (for PAGE0/1)) 16.4.4 Operational Description 16.4.1 Reading clock data 16.4.2 Writing clock data 16.4.3 Entering the Low Power Consumption Mode. 16.5 Alarm function	
16.	Real Time Clock (RTC) 16.1 Function. 16.2 Block Diagram. 16.3 Detailed Description Register. 16.3.1 Register List. 16.3.2 Control Register. 16.3.3 Detailed Description of Control Register. 16.3.3 Patailed Description of Control Register. 16.3.3 RTCSECR (Second column register (for PAGE0 only)) 16.3.3.2 RTCMINR (Minute column register (PAGE0/1)) 16.3.3.3 RTCHOURR (Hour column register (PAGE0/1)) 16.3.3.4 RTCDAYR (Day of the week column register (PAGE0/1)) 16.3.3.5 RTCDATER (Day column register (for PAGE0 only)) 16.3.3.6 RTCMONTHR (Month column register (for PAGE0 only)) 16.3.3.7 RTCMONTHR (Selection of 24-bour clock or 12-bour clock 24(for PAGE1 only)) 16.3.3.8 RTCYEARR (Year column register (for PAGE0 only)) 16.3.3.10 RTCPAGER(PAGE register (FAGE0/1)) 16.3.3.11 RTCRESTR (Reset register (For PAGE0)) 16.3.3.11 RTCRESTR (Reset register (For PAGE0/1)) 16.4.4 Operational Description. 16.4.5 Alarm function. 16.5.1 "Low" pulse (when the alarm register corresponds with the clock). 16.5.2 IHz cycle "Low" pulse I Hz.	
16.	Real Time Clock (RTC) 16.1 Function 16.2 Block Diagram 16.3 Detailed Description Register 16.3.1 Register List 16.3.2 Control Register 16.3.3 Detailed Description of Control Register 16.3.3 Detailed Description of Control Register 16.3.3 RTCSECR (Second column register (for PAGE0 only)) 16.3.3.2 RTCMINR (Minute column register (PAGE0/1)) 16.3.3.3 RTCDAYTR (Hour column register (PAGE0/1)) 16.3.3.4 RTCDAYR (Day of the week column register(PAGE0/1)) 16.3.3.5 RTCDATER (Day column register (for PAGE0 only)) 16.3.3.6 RTCMONTHR (Month column register (for PAGE0 only)) 16.3.3.7 RTCMONTHR (Selection of 24-hour clock or 12-hour clock24(for PAGE1 only)) 16.3.3.9 RTCYEARR (Year column register (for PAGE0 only)) 16.3.3.10 RTCPGAGER(PAGE register(PAGE0/1)) 16.3.3.11 RTCRESTR (Reset register (for PAGE0 only)) 16.3.3.11 RTCRESTR (Reset register (for PAGE0/1)) 16.4.4 Operational Description 16.4.1 Reading clock data 16.4.2 Writing clock data 16.4.3 Entering the Low Power Consumption Mode. 16.5 Alarm function	
16.	Real Time Clock (RTC) 16.1 Function. 16.2 Block Diagram. 16.3 Detailed Description Register. 16.3.1 Register List. 16.3.2 Control Register. 16.3.3 Detailed Description of Control Register. 16.3.3 Patailed Description of Control Register. 16.3.3 RTCSECR (Second column register (for PAGE0 only)) 16.3.3.2 RTCMINR (Minute column register (PAGE0/1)) 16.3.3.3 RTCHOURR (Hour column register (PAGE0/1)) 16.3.3.4 RTCDAYR (Day of the week column register (PAGE0/1)) 16.3.3.5 RTCDATER (Day column register (for PAGE0 only)) 16.3.3.6 RTCMONTHR (Month column register (for PAGE0 only)) 16.3.3.7 RTCMONTHR (Selection of 24-bour clock or 12-bour clock 24(for PAGE1 only)) 16.3.3.8 RTCYEARR (Year column register (for PAGE0 only)) 16.3.3.10 RTCPAGER(PAGE register (FAGE0/1)) 16.3.3.11 RTCRESTR (Reset register (For PAGE0)) 16.3.3.11 RTCRESTR (Reset register (For PAGE0/1)) 16.4.4 Operational Description. 16.4.5 Alarm function. 16.5.1 "Low" pulse (when the alarm register corresponds with the clock). 16.5.2 IHz cycle "Low" pulse I Hz.	

17. Flash Memory Operation

17.1 Flash Memory	407
17.1.1 Features.	407
17.1.2 Block Diagram of the Flash Memory Section	
17.2 Operation Mode	
17.2.1 Reset Operation	
17.2.2 User Boot Mode (Single chip mode)	412
17.2.2.2 (1-B) Method 2: Transferring a Programming Routine from an External Host	
17.2.3 Single Boot Mode	420
17.2.3.1 (2-A) Using the Program in the On-Chip Boot ROM 17.2.4 Configuration for Single Boot Mode	423
17.2.5 Memory Map	
17.2.6 Interface specification	425
17.2.7 Data Transfer Format	
17.2.8 Restrictions on internal memories	
17.2.9 Transfer Format for Single Boot Mode commands	420
17.2.9.2 Show Flash Memory SUM	
17.2.9.3 Transfer Format for the Show Product Information	
17.2.9.4 Chip Erase and Protect Bit Erase 17.2.10 Operation of Boot Program	433
17.2.10.1 RAM Transfer Command	
17.2.10.2 Show Flash Memory SUM Command	
17.2.10.3 Show Product Information Command 17.2.10.4 Chip and Protection Bit Erase Command	
17.2.10.4 Clinp and Protection Bit Erase Command 17.2.10.5 Acknowledge Responses	
17.2.10.6 Determination of a Serial Operation Mode	
17.2.10.7 Password 17.2.10.8 Calculation of the Show Flash Memory Sum Command	
17.2.10.9 Checksum Calculation	
17.2.11 General Boot Program Flowchart	
17.3 On-board Programming of Flash Memory (Rewrite/Erase)	
17.3.1 Flash Memory	446
17.3.1.1 Block Configuration	
17.3.1.1 Block Configuration 17.3.1.2 Basic operation 17.3.1.3 Reset(Hardware reset)	
17.3.1.2 Basic operation 17.3.1.3 Reset(Hardware reset) 17.3.1.4 Commands	
17.3.1.2 Basic operation 17.3.1.3 Reset(Hardware reset) 17.3.1.4 Commands 17.3.1.5 Flash control/ status register	
17.3.1.2 Basic operation 17.3.1.3 Reset(Hardware reset) 17.3.1.4 Commands 17.3.1.5 Flash control/ status register 17.3.1.6 List of Command Sequences 17.3.1.7 Address bit configuration for bus write cycles	
17.3.1.2 Basic operation 17.3.1.3 Reset(Hardware reset) 17.3.1.4 Commands 17.3.1.5 Flash control/ status register 17.3.1.6 List of Command Sequences	
17.3.1.2 Basic operation 17.3.1.3 Reset(Hardware reset) 17.3.1.4 Commands 17.3.1.5 Flash control/ status register 17.3.1.6 List of Command Sequences 17.3.1.7 Address bit configuration for bus write cycles	
17.3.1.2 Basic operation 17.3.1.3 Reset(Hardware reset) 17.3.1.4 Commands 17.3.1.5 Flash control/ status register 17.3.1.6 List of Command Sequences 17.3.1.7 Address bit configuration for bus write cycles	
17.3.1.2 Basic operation 17.3.1.3 Reset(Hardware reset) 17.3.1.4 Commands 17.3.1.5 Flash control/ status register 17.3.1.6 List of Command Sequences 17.3.1.7 Address bit configuration for bus write cycles 17.3.1.8 Flowchart	461
17.3.1.2 Basic operation 17.3.1.3 Reset(Hardware reset) 17.3.1.4 Commands 17.3.1.5 Flash control/ status register 17.3.1.6 List of Command Sequences 17.3.1.7 Address bit configuration for bus write cycles 17.3.1.8 Flowchart ROM protection	
17.3.1.2 Basic operation 17.3.1.3 Reset(Hardware reset) 17.3.1.4 Commands 17.3.1.5 Flash control/ status register 17.3.1.6 List of Command Sequences 17.3.1.7 Address bit configuration for bus write cycles 17.3.1.8 Flowchart ROM protection 18.1 Outline.	461
17.3.1.2 Basic operation 17.3.1.3 Reset(Hardware reset) 17.3.1.4 Commands 17.3.1.5 Flash control/ status register 17.3.1.6 List of Command Sequences 17.3.1.7 Address bit configuration for bus write cycles 17.3.1.8 Flowchart ROM protection 18.1 Outline 18.2 Future 18.2.1 Write/ erase-protection function 18.2.2 Security function	461 461
17.3.1.2 Basic operation 17.3.1.3 Reset(Hardware reset) 17.3.1.4 Commands 17.3.1.5 Flash control/ status register 17.3.1.6 List of Command Sequences 17.3.1.7 Address bit configuration for bus write cycles 17.3.1.8 Flowchart ROM protection 18.1 Outline 18.2 Future 18.2.1 Write/ erase-protection function	461 461
17.3.1.2 Basic operation 17.3.1.3 Reset(Hardware reset) 17.3.1.4 Commands 17.3.1.5 Flash control/ status register 17.3.1.6 List of Command Sequences 17.3.1.7 Address bit configuration for bus write cycles 17.3.1.8 Flowchart ROM protection 18.1 Outline 18.2 Future 18.2.1 Write/ erase-protection function 18.2.2 Security function	461 461 462
17.3.1.2 Basic operation 17.3.1.3 Reset(Hardware reset) 17.3.1.4 Commands 17.3.1.5 Flash control/ status register 17.3.1.6 List of Command Sequences 17.3.1.7 Address bit configuration for bus write cycles 17.3.1.8 Flowchart ROM protection 18.1 Outline	
17.3.1.2 Basic operation 17.3.1.3 Reset(Hardware reset) 17.3.1.4 Commands 17.3.1.5 Flash control/ status register 17.3.1.6 List of Command Sequences 17.3.1.7 Address bit configuration for bus write cycles 17.3.1.8 Flowchart ROM protection 18.1 Outline 18.2 Future 18.2.1 Write/ erase-protection function 18.2.2 Security function 18.3 Register 18.3.1 FCFLCS (Flash control register)	
17.3.1.2 Basic operation 17.3.1.3 Reset(Hardware reset) 17.3.1.4 Commands 17.3.1.5 Flash control/ status register 17.3.1.6 List of Command Sequences 17.3.1.7 Address bit configuration for bus write cycles 17.3.1.8 Flowchart ROM protection 18.1 Outline	
17.3.1.2 Basic operation 17.3.1.3 Reset(Hardware reset) 17.3.1.4 Commands 17.3.1.5 Flash control/ status register 17.3.1.6 List of Command Sequences 17.3.1.7 Address bit configuration for bus write cycles 17.3.1.8 Flowchart ROM protection 18.1 Outline 18.2 Future 18.2.1 Write/ erase-protection function 18.2.2 Security function 18.3 Register 18.3.1 FCFLCS (Flash control register) 18.3.2 FCSECBIT(Security bit register) 18.4 Writing and erasing	
17.3.1.2 Basic operation 17.3.1.3 Reset(Hardware reset) 17.3.1.4 Commands 17.3.1.5 Flash control/ status register 17.3.1.6 List of Command Sequences 17.3.1.7 Address bit configuration for bus write cycles 17.3.1.8 Flowchart ROM protection 18.1 Outline	
17.3.1.2 Basic operation 17.3.1.3 Reset(Hardware reset) 17.3.1.4 Commands 17.3.1.5 Flash control/ status register 17.3.1.6 List of Command Sequences 17.3.1.7 Address bit configuration for bus write cycles 17.3.1.8 Flowchart ROM protection 18.1 Outline	
17.3.1.2 Basic operation 17.3.1.3 Reset(Hardware reset) 17.3.1.4 Commands 17.3.1.5 Flash control/ status register 17.3.1.6 List of Command Sequences 17.3.1.7 Address bit configuration for bus write cycles 17.3.1.8 Flowchart ROM protection 18.1 Outline	
17.3.1.2 Basic operation 17.3.1.3 Reset(Hardware reset) 17.3.1.4 Commands 17.3.1.5 Flash control/ status register 17.3.1.6 List of Command Sequences 17.3.1.7 Address bit configuration for bus write cycles 17.3.1.8 Flowchart ROM protection 18.1 Outline 18.2 Future 18.2.1 Write/ erase-protection function 18.2.2 Security function 18.3 Register 18.3.1 FCFLCS (Flash control register) 18.3.2 FCSECBIT(Security bit register) 18.4 Writing and erasing 18.4.1 Protection bits 18.4.2 Security bit Electrical Characteristics 19.1 Absolute Maximum Ratings 19.2 DC Electrical Characteristics (1/3)	
17.3.1.2 Basic operation 17.3.1.3 Reset(Hardware reset) 17.3.1.4 Commands 17.3.1.5 Flash control/ status register 17.3.1.6 List of Command Sequences 17.3.1.7 Address bit configuration for bus write cycles 17.3.1.8 Flowchart ROM protection 18.1 Outline	
17.3.1.2 Basic operation 17.3.1.3 Reset(Hardware reset) 17.3.1.4 Commands 17.3.1.5 Flash control/ status register 17.3.1.6 List of Command Sequences 17.3.1.7 Address bit configuration for bus write cycles 17.3.1.8 Flowchart ROM protection 18.1 Outline 18.2 Future 18.2.1 Write/ erase-protection function 18.2.2 Security function 18.3 Register 18.3.1 FCFLCS (Flash control register) 18.3.2 FCSECBIT(Security bit register) 18.4 Writing and erasing 18.4.1 Protection bits 18.4.2 Security bit Electrical Characteristics 19.1 Absolute Maximum Ratings 19.2 DC Electrical Characteristics (1/3)	
17.3.1.2 Basic operation 17.3.1.3 Reset(Hardware reset) 17.3.1.4 Commands 17.3.1.5 Flash control/ status register 17.3.1.6 List of Command Sequences 17.3.1.7 Address bit configuration for bus write cycles 17.3.1.8 Flowchart ROM protection 18.1 Outline	

19.6	AC Electrical Characteristics	471
19.6.1		
19.6.2		
	6.2.1 I/O Interface mode	
19.6.3	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	473
	6.3.1 I2C Mode 6.3.2 Clock-Synchronous 8-Bit SIO mode	
19.6.4	y .	475
19.6.5	Capture	475
19.6.6	•	475
19.6.7		
19.6.8 19.6.9		
19.6.5		
	Flash Characteristics	
19.7.1		
	Recommended Oscillation Circuit	
19. 0 19.8.1		
19.8.1		
	Handling Precaution	
19.9.1		
19.9.1		
	Section Equivalent Circuit Schematic	404
	PA0, PE1 to 3, PE5 to 6, PF4 to 6, PG0 to 3, PH0 to 3, PJ0 to 3	
20.2	PA1	481
20.3	PA2 to 3, PB0, PE0, PE4, PI0 to 5, PJ4, PK1	482
	PD4 to 7	
	PD0 to 3	
	PK0	
	NMI, MODE.	
	RESET	
	X1, X2	
20.10	XT1, XT2	484
20.11	VREFH, AVSS	484
Pack	age Dimensions	

TMPM332FWUG

The TMPM332FWUG is a 32-bit RISC microprocessor series with an ARM Cortex[™]-M3 microprocessor core.

Product Name	ROM (FLASH)	RAM	Package
TMPM332FWUG	128 Kbyte	8 Kbyte	LQFP64-P-1010-0.50E

Features of the TMPM332FWUG are as follows:

1.1 Features

- 1. ARM Cortex-M3 microprocessor core
 - a. Improved code efficiency has been realized through the use of Thumb® -2 instruction.
 - · New 16-bit Thumb instructions for improved program flow
 - · New 32-bit Thumb instructions for improved performance
 - New Thumb mixed 16-/32-bit instruction set can produce faster, more efficient code.
 - b. Both high performance and low power consumption have been achieved.

[High performance]

- A 32-bit multiplication ($32 \times 32 = 32$ bit) can be executed with one clock.
- · Division takes between 2 and 12 cycles depending on dividend and devisor

[Low power consumption]

- · Optimized design using a low power consumption library
- · Standby function that stops the operation of the micro controller core
- c. High-speed interrupt response suitable for real-time control
 - · An interruptible long instruction.
 - Stack push automatically handled by hardware.
- 2. On Chip program memory and data memory

Product name	On chip Flash ROM	On chip RAM
TMPM332FWUG	128 Kbyte	8 Kbyte

- 3. 16-bit timer (TMRB): 10 channels
 - · 16-bit interval timer mode
 - 16-bit event counter mode
 - · 16-bit PPG output
 - · Input capture function
- 4. Real time clock (RTC): 1 channel
 - · Clock (hour, minute and second)
 - · Calendar (month, week, date and leap year)
 - Time correction + or 30seconds (by software)
 - Alarm (Alarm output)
 - Alarm interrupt
- 5. Watchdog timer (WDT): 1 channel

1.1 Features TMPM332FWUG

Watchdog timer (WDT) generates a reset or a non-maskable interrupt (NMI).

6. General-purpose serial interface (SIO/UART): 2 channels

Either UART mode or synchronous mode can be selected (4byte FIFO equipped)

7. Serial bus interface (I2C/SIO): 2channels

Either I2C bus mode or synchronous mode can be selected.

8. CEC function (CEC): 1 channel

Transmission and reception per 1 byte.

9. Remote control signal preprocessor (RMC): 1 channels

Can receive up to 72bit data at a time

- 10. 10-bit AD converter (ADC): 8 channels
 - · Start by an internal timer trigger
 - Fixed channel/scan mode
 - · Single/repeat mode
 - · AD monitoring 2ch
 - Conversion speed 1.15μsec. (@fsys = 40MHz)
- 11. Interrupt source
 - Internal: 32 factors...The order of precedence can be set over 7 levels (except the watchdog timer interrupt).
 - External: 5 factors...The order of precedence can be set over 7 levels.
- 12. Non-maskable interrupt (NMI)

Non-maskable interrupt (NMI) is generated by a watchdog timer or a NMI pin.

- 13. Input/ output ports (PORT): 44 pins
- 14. Standby mode
 - · Standby modes: IDLE, SLOW, SLEEP, STOP
 - Sub clock operation(32.768kHz):SLOW, SLEEP
- 15. Clock generator (CG)
 - On-chip PLL (quadrupled)
 - Clock gear function: The high-speed clock can be divided into 1/1, 1/2, 1/4 or 1/8.
- 16. Endian

Little endian

- 17. Maximum operating frequency: 40 MHz
- 18. Operating voltage range

2.7 V to 3.6 V (with on-chip regulator)

- 19. Temperature range
 - -20 to 85 degrees (except during Flash writing/ erasing)
 - 0 to 70 degrees (during Flash writing/ erasing)
- 20. Package

LQFP64-P-1010-0.50E (10mm × 10mm, 0.5mm pitch)

1.2 Block Diagram




Figure 1-1 TMPM332FWUGBlock Diagram

1.3 Pin Layout (Top view) TMPM332FWUG

1.3 Pin Layout (Top view)

Figure 1-2 shows the pin layout of TMPM332FWUG.




Figure 1-2 Pin Layout (LQFP64)

1.4 Pin names and Functions

Table 1-1 and Table 1-2 sort the input and output pins of the TMPM332FWUG by pin or port. Each table includes alternate pin names and functions for multi-function pins.

1.4.1 Sorted by Pin

Table 1-1 Pin Names and Functions Sorted by Pin (1/4)

Туре	Pin No.	Pin Name	Input/ Output	Function
Function	1	PD6 AIN10	1	Input port Analog input
Function	2	PD7 AIN11	1	Input port Analog input
PS	3	AVSS	ı	AD converter: GND pin (0V) (note) AVSS must be connected to GND even if the A/D converter is not used.
PS	4	VREFH	I	Supplying the AD converter with a reference power supply. (note) VREFH must be connected to power supply even if A/D converter is not used.
PS	5	AVDD3	I	Supplying the AD converter with a power supply. (note) AVDD must be connected to power supply even if A/D converter is not used.
Function	6	PG3 INT4	I/O I	I/O port External interrupt pin
Test	7	TEST2	-	TEST pin: (note) TEST pin must be left OPEN.
PS	8	DVSS	-	GND pin
PS	9	DVDD3	-	Power supply pin
Test	10	TEST1	-	TEST pin: (note) TEST pin must be left OPEN.
Function	21	PE0 TXD0	I/O O	I/O port Sending serial data
Function	12	PE1 RXD0	I/O I	I/O port Receiving serial data
Function	13	PE2 SCLK0 CTS0	I/O I/O I	I/O port Serial clock input/ output Handshake input pin
Function	14	PE4 TXD1	I/O O	I/O port Sending serial data
Function	15	PE5 RXD1	I/O I	I/O port Receiving serial data
Function	16	PE6 SCLK1 CTS1	I/O I/O I	I/O port Serial clock input/ output Handshake input pin
Function	17	PG0 SDA0/SO0	I/O I/O	I/O port -in the I2C mode: data pin -in the SIO mode: data pin
Function	18	PG1 SCL0/SI0	I/O I/O	I/O port -in the I2C mode: clock pin -in the SIO mode: data pin

Table 1-1 Pin Names and Functions Sorted by Pin (2/4)

Туре	Pin No.	Pin Name	Input/ Output	Function
Function	19	PG2 SCK0	I/O I/O	I/O port Inputting and outputting a clock if the serial bus interface operates in the SIO mode.
Function/ Control	20	PH0 TB0IN0 BOOT	I/O I I	I/O port Inputting the timer B capture trigger Setting a single boot mode: (note) This pin goes into single boot mode by sampling "Low" at the rise of a RESET signal.
Function	21	PH1 TB0IN1	I/O I	I/O port Inputting the timer B capture trigger
Function	22	PH2 TB1IN0	I/O I	I/O port Inputting the timer B capture trigger
Function	23	PH3 TB1IN1	I/O I	I/O port Inputting the timer B capture trigger
Function	24	PI0 TB0OUT	I/O O	I/O port Timer B output
Function	25	PI1 TB1OUT	I/O O	I/O port Timer B output
Function	26	PI2 TB2OUT	I/O O	I/O port Timer B output
Function	27	PF4 SDA1/SO1	I/O I/O	I/O port -in the I2C mode: data pin -in the SIO mode: data pin
Function	28	PF5 SCL1/SI1	I/O I/O	I/O port -in the I2C mode: clock pin -in the SIO mode: data pin
Function	29	PF6 SCK1	I/O I/O	I/O port Inputting and outputting a clock if the serial bus interface operates in the SIO mode.
Function	30	PI3 TB3OUT	I/O O	I/O port Timer B output
Function	31	PJ1 INT1	I/O I	I/O port External interrupt pin
Function	32	PK0 CEC	I/O I/O	I/O port CEC Pin (note) Nch open drain port.
Function	33	PK1 SCOUT ALARM	I/O O O	I/O port System clock output Alarm output
Function	34	PI4 TB4OUT	I/O O	I/O port Timer B output
Function	35	PI5 TB5OUT	I/O O	I/O port Timer B output
Function/ Debug	36	PB0 SWV	I/O O	I/O port Debug pin

Table 1-1 Pin Names and Functions Sorted by Pin (3/4)

Туре	Pin No.	Pin Name	Input/ Output	Function
Function/ Debug	37	PA0 SWDIO	I/O I/O	I/O port Debug pin
Function/ Debug	38	PA1 SWCLK	I/O I	I/O port Debug pin
PS	39	DVDD3	-	Power supply pin
PS	40	DVSS	-	GND pin
Function/ Debug	41	PA2 TRACECLK	I/O O	I/O port Debug pin
Function/ Debug	42	PA3 TRACEDATA0	I/O O	I/O port Debug pin
Function	43	PJ0 INT0	I/O I	I/O port External interrupt pin
PS	44	DVDD3	-	Power supply pin
Clock	45	X2	0	Connected to a high-speed oscillator.
PS	46	DVSS	-	GND pin
Clock	47	X1	1	Connected to a high-speed oscillator.
PS	48	RVSS	-	GND pin
PS	49	RVDD3	-	Power supply pin
Clock	50	XT1	I	Connected to a low-speed oscillator.
Clock	51	XT2	0	Connected to a low-speed oscillator.
Function	52	NMI	1	Non-maskable interrupt (note) With a noise filter (about 30ns (typical value))
Control	53	MODE	I	Mode pin: (note) MODE pin must be connected to GND.
Function	54	RESET	I	Reset input pin (note) With a pull-up and a noise filter (about 30ns (typical value))
Function	55	PJ2 INT2	I/O I	I/O port External interrupt pin
Function	56	PJ3 INT3	I/O I	I/O port External interrupt pin
Function	57	PJ4 TB6OUT	I/O O	I/O port Timer B output
Function	58	PE3 RXIN	I/O I	I/O port Inputting signal to remote controller
Function	59	PD0 AIN4 TB5IN0		Input port Analog input Inputting the timer B capture trigger

Table 1-1 Pin Names and Functions Sorted by Pin (4/4)

Туре	Pin No.	Pin Name	Input/ Output	Function
Function	60	PD1 AIN5 TB5IN1	 - -	Input port Analog input Inputting the timer B capture trigger
Function	61	PD2 AIN6 TB6IN0	1	Input port Analog input Inputting the timer B capture trigger
Function	62	PD3 AIN7 TB6IN1	1	Input port Analog input Inputting the timer B capture trigger
Function	63	PD4 AIN8	1	Input port Analog input
Function	64	PD5 AIN9	I I	Input port Analog input

1.4.2 Sorted by Port

Table 1-2 Pin Names and Functions Sorted by Port (1/4)

PORT	Туре	Pin No.	Pin Name	Input/ Output	Function
PORT A	Function/ Debug	37	PA0 SWDIO	I/O I/O	I/O port Debug pin
PORT A	Function/ Debug	38	PA1 SWCLK	I/O I	I/O port Debug pin
PORT A	Function/ Debug	41	PA2 TRACECLK	I/O O	I/O port Debug pin
PORT A	Function/ Debug	42	PA3 TRACEDATA0	I/O O	I/O port Debug pin
PORT B	Function/ Debug	36	PB0 SWV	I/O O	I/O port Debug pin
PORT D	Function	59	PD0 AIN4 TB5IN0		Input port Analog input Inputting the timer B capture trigger
PORT D	Function	60	PD1 AIN5 TB5IN1		Input port Analog input Inputting the timer B capture trigger
PORT D	Function	61	PD2 AIN6 TB6IN0		Input port Analog input Inputting the timer B capture trigger
PORT D	Function	62	PD3 AIN7 TB6IN1		Input port Analog input Inputting the timer B capture trigger
PORT D	Function	63	PD4 AIN8	I I	Input port Analog input
PORT D	Function	64	PD5 AIN9	I I	Input port Analog input
PORT D	Function	1	PD6 AIN10	I I	Input port Analog input
PORT D	Function	2	PD7 AIN11	I I	Input port Analog input
PORT E	Function	11	PE0 TXD0	I/O O	I/O port Sending serial data
PORT E	Function	12	PE1 RXD0	I/O I	I/O port Receiving serial data
PORT E	Function	13	PE2 SCLK0 CTS0	I/O I/O I	I/O port Serial clock input/ output Handshake input pin
PORT E	Function	58	PE3 RXIN	I/O I	I/O port Inputting signal to remote controller

Table 1-2 Pin Names and Functions Sorted by Port (2/4)

PORT	Туре	Pin No.	Pin Name	Input/ Output	Function
PORT E	Function	14	PE4 TXD1	I/O O	I/O port Sending serial data
PORT E	Function	15	PE5 RXD1	I/O I	I/O port Receiving serial data
PORT E	Function	16	PE6 SCLK1 CTS1	I/O I/O I	I/O port Serial clock input/ output Handshake input pin
PORT F	Function	27	PF4 SDA1/SO1	I/O I/O	I/O port -in the I2C mode: data pin -in the SIO mode: data pin
PORT F	Function	28	PF5 SCL1/SI1	I/O I/O	I/O port -in the I2C mode: clock pin -in the SIO mode: data pin
PORT F	Function	29	PF6 SCK1	I/O I/O	I/O port Inputting and outputting a clock if the serial bus interface operates in the SIO mode.
PORT G	Function	17	PG0 SDA0/SO0	I/O I/O	I/O port -in the I2C mode: data pin -in the SIO mode: data pin
PORT G	Function	18	PG1 SCL0/SI0	I/O I/O	I/O port -in the I2C mode: clock pin -in the SIO mode: data pin
PORT G	Function	19	PG2 SCK0	I/O I/O	I/O port Inputting and outputting a clock if the serial bus interface operates in the SIO mode.
PORT G	Function	6	PG3 INT4	I/O I	I/O port External interrupt pin
PORT H	Function/ Control	20	PH0 TB0IN0 BOOT	I/O I I	I/O port Inputting the timer B capture trigger Setting a single boot mode: This pin goes into single boot mode by sampling "Low" at the rise of a RESET signal.
PORT H	Function	21	PH1 TB0IN1	I/O I	I/O port Inputting the timer B capture trigger
PORT H	Function	22	PH2 TB1IN0	I/O I	I/O port Inputting the timer B capture trigger
PORT H	Function	23	PH3 TB1IN1	I/O I	I/O port Inputting the timer B capture trigger
PORTI	Function	24	PI0 TB0OUT	I/O O	I/O port Timer B output
PORTI	Function	25	PI1 TB1OUT	I/O O	I/O port Timer B output
PORTI	Function	26	PI2 TB2OUT	I/O O	I/O port Timer B output

Table 1-2 Pin Names and Functions Sorted by Port (3/4)

PORT	Туре	Pin No.	Pin Name	Input/ Output	Function
PORT I	Function	30	PI3 TB3OUT	I/O O	I/O port Timer B output
PORT I	Function	34	PI4 TB4OUT	I/O O	I/O port Timer B output
PORTI	Function	35	PI5 TB5OUT	I/O O	I/O port Timer B output
PORT J	Function	43	PJ0 INT0	I/O I	I/O port External interrupt pin
PORT J	Function	31	PJ1 INT1	I/O I	I/O port External interrupt pin
PORT J	Function	55	PJ2 INT2	I/O I	I/O port External interrupt pin
PORT J	Function	56	PJ3 INT3	I/O I	I/O port External interrupt pin
PORT J	Function	57	PJ4 TB6OUT	I/O O	I/O port Timer B output
PORT K	Function	32	PK0 CEC	I/O I/O	I/O port CEC Pin (note) Nch open drain port.
PORT K	Function	33	PK1 SCOUT ALARM	I/O O O	I/O port System clock output Alarm output
-	Function	54	RESET	ı	Reset input pin (note) With a pull-up and a noise filter (about 30ns (typical value))
-	Function	52	NMI	ı	Non-maskable interrupt (note) With a noise filter (about 30ns (typical value))
-	Control	53	MODE	I	Mode pin: (note) MODE pin must be connected to GND.
-	Clock	45	X2	0	Connected to a high-speed oscillator.
-	Clock	47	X1	ı	Connected to a high-speed oscillator.
-	Clock	50	XT1	1	Connected to a low-speed oscillator.
-	Clock	51	XT2	0	Connected to a low-speed oscillator.
-	Test	7	TEST2	-	TEST pin: (note) TEST pin must be left OPEN.
-	Test	10	TEST1	-	TEST pin: (note) TEST pin must be left OPEN.
-	PS	3	AVSS	ı	AD converter: GND pin (0V) (note) AVSS must be connected to GND even if the A/D converter is not used.
-	PS	4	VREFH	I	Supplying the AD converter with a reference power supply. (note) VREFH must be connected to power supply even if A/D converter is not used.

Table 1-2 Pin Names and Functions Sorted by Port (4/4)

PORT	Туре	Pin No.	Pin Name	Input/ Output	Function
-	PS	5	AVDD3	ı	Supplying the AD converter with a power supply. (note) AVDD must be connected to power supply even if A/D converter is not used.
-	PS	8	DVSS	-	GND pin
-	PS	9	DVDD3	-	Power supply pin
-	PS	39	DVDD3	-	Power supply pin
-	PS	40	DVSS	-	GND pin
-	PS	44	DVDD3	-	Power supply pin
-	PS	46	DVSS	-	GND pin
-	PS	48	RVSS	-	GND pin
-	PS	49	RVDD3	-	Power supply pin

1.5 Pin Numbers and Power Supply Pins

Table 1-3 Pin Numbers and Power Supplies

Power supply	Voltage range	Pin No.	Pin name
DVDD3		9, 39, 44	PA,PB,PE,PF,PG,PH,PI,PJ,PK,X1,X2,XT1, XT2,RESET,NMI,MODE
AVDD3	2.7 to 3.6V	5	PD
RVDD3		49	-

TOSHIBA TMPM332FWUG

Processor Core

The TX03 series has a high-performance 32-bit processor core (the ARM Cortex-M3 processor core). For information on the operations of this processor core, please refer to the "Cortex-M3 Technical Reference Manual" issued by ARM Limited. This chapter describes the functions unique to the TX03 series that are not explained in that document.

2.1 Information on the processor core

The following table shows the revision of the processor core in the TMPM332FWUG.

Refer to the detailed information about the CPU core and architecture, refer to the ARM manual "Cortex-M series processors" in the following URL:

http://infocenter.arm.com/help/index.jsp

Product Name	Core Revision
TMPM332FWUG	r1p1-01rel0

2.2 Configurable Options

The Cortex-M3 core has optional blocks. The optional blocks of the revision r1p1 are ETM[™] and MPU. The following tables shows the configurable options in the TMPM332FWUG.

Configurable Options	Implementation
MPU	Not implementable
ETM	Implementable

2.3 Exceptions/ Interruptions

Exceptions and interruptions are described in the following section.

2.3.1 Number of Interrupt Inputs

The number of interrupt inputs can optionally be defined from 1 to 240 in the Cortex-M3 core.

TMPM332FWUG has 37 interrupt inputs. The number of interrupt inputs is reflected in <INTLINESNUM [4:0]> bit of NVIC register. In this product, if read <INTLINESNUM[4:0]> bit, "0y00001" is read out.

2.3.2 Number of Priority Level Interrupt Bits

The Cortex-M3 core can optionally configure the number of priority level interrupt bits from 3 bits to 8 bits.

TMPM332FWUG has three priority level interrupt bits. The number of priority level interrupt bits is used for assigning a priority level in the interrupt priority registers and system handler priority registers.

2.3.3 SysTick

The Cortex-M3 core has a SysTick timer which can generate SysTick exception.

In the TMPM332FWUG, the clock that is input from X1 pin dividing by 32 is used as a count clock for the Systic timer. SysTick calibration register can set a calibration value to measure 10ms. In this product, when 8MHz is input to X1 pin, calibration value is set to 0x9C4 which can measure 10ms. Additionally, if this value is read as "0" both of <NOREF> bit and <SKEW> bit, it indicates that external reference clock are available and the calibration value is accurate as 10ms.

2.3.4 SYSRESETREQ

The Cortex-M3 core outputs SYSRESETREQ signal when <SYSRESETREQ> bit of Application Interrupt and Reset Control Register are set.

TMPM332FWUG provides the same operation when SYSRESETREQ signal are output.

Note: Do not reset with <SYSRESETREQ> in SLOW mode.

2.3.5 LOCKUP

When irreparable exception generates, the Cortex-M3 core outputs LOCKUP signal to show a serious error included in software.

TMPM332FWUG does not use this signal. To return from LOCKUP status, it is necessary to use non-maskable interruput (NMI) or reset.

2.3.6 Auxiliary Fault Status register

The Cortex-M3 core provides auxiliary fault status registers to supply additional system fault information to software.

However, TMPM332FWUG is not defined this function. If auxiliary fault status register is read, always "0x0000_0000" is read out.

TOSHIBA TMPM332FWUG

2.4 Events

The Cortex-M3 core has event output signals and event input signals. An event output signal is output by SEV instruction execution. If an event is input, the core returns from low-power consumption mode caused by WFE instruction

TMPM332FWUG does not use event output signals and event input signals. Please do not use SEV instruction and WFE instruction.

2.5 Power Management

The Cortex-M3 core provides power management system which uses SLEEPING signals and SLEEPDEEP signals. SLEEPDEEP signals are output when <SLEEPDEEP> bit of System Control Register is set.

These signals are output in the following circumstances:

- -Wait-For-Interrupt (WFI) instruction execution
- -Wait-For-Event (WFE) instruction execution

-the timing when interrupt-service-routine (ISR) exit in case that <SLEEPONEXIT> bit of System Control Register is set.

TMPM332FWUG does not use SLEEPDEEP signals so that <SLEEPDEEP> bit must not be set. And also event signals are not used so that please do not use WFE instruction.

For detail of power management, refer to the Chapter "Clock/Mode control."

2.6 Exclusive access

In Cortex-M3 core, the DCode bus system supports exclusive access. However TMPM332FWUG does not use this function.

2. Processor Core

2.6 Exclusive access TMPM332FWUG

TOSHIBA TMPM332FWUG

3. Debug Interface

3.1 Specification Overview

TMPM332FWUG contains the Serial Wire Debug Port (SW-DP) unit for interfacing with the debugging tools and the Embedded Trace MacrocellTM(ETM) unit for instruction trace output. Trace data is output to the dedicated pins (TRACEDATA0, SWV) for the debugging via the on-chip Trace Port Interface Unit (TPIU).

For details about SW-DP, ETM and TPIU, refer to "Cortex-M3 Technical Reference Manual".

3.2 SW-DP

SW-DP supports the SWDCK and the SWDIO.

3.3 ETM

ETM supports one data signal pins (TRACEDATA0), one clock signal pin (TRACECLK) and trace output from SWV.

3. Debug Interface

3.4 Pin Functions TMPM332FWUG

3.4 Pin Functions

The debug interface pins can also be used as general-purpose ports.

The PA0 and PA1 pins are used as the Serial Wire Debug Port function. The PB0 pin is used as the SWV trace output function.

Table 3-1 SW-DP,ETM Debug Functions

SW-DP	General-	SW Debug Function				
Pin Name	purpose Port Name	1/0	Explanation			
SWDIO	PA0	I / O Serial Wire Data Input/Ou				
SWCLK	PA1	Input	Serial Wire Clock			
SWV	PB0	(Output)(Note) (Serial Wire Viewer Out				
TRACECLK	PA2	TRACE Clock Output				
TRACEDATA0	PA3	TRACE DATA Output0				

Note: When SWV function is enabled.

After reset, PA0, PA1 and PB0 pins are configured as debug port function pins. The functions of other debug interface pins need to be programmed as required.

When using a low power consumption mode, take note of the following points.

- Note 1: If PA0 and PB0 are configured as SWDIO and SWV, output continues to be enabled even in STOP mode regardless of the setting of the CGSTBYCR<DRVE> bit.
- Note 2: If PA1 is configured as a debug function pin, it prevents a low power consumption mode from being fully effective. Configure PA1 to function as a general-purpose port if the debug function is not used.

Table 3-2 summarizes the debug interface pin and related port settings after reset.

Table 3-2 Debug Interface Pins and Related Port Settings after Reset

David Names		Value of Related port settings after reset						
Port Name (Bit Name)	Debug Function	Function (PxFR)	Input (PxIE)	Output (PxCR)	Pull-up (PxPUP)	Pull-down (PxPDN)		
PA0	SWDIO	1	1	1	1	-		
PA1	SWCLK	1	1	0	-	1		
PB0	SWV	1	0	1	0	-		
PA2	TRACECLK	0	0	0	0	-		
PA3	TRACEDATA0	0	0	0	0	-		

^{- :} Don't care

3.5 Peripheral Functions in Halt Mode

When the Cortex-M3 core enters in the halt mode, the watchdog-timer (WDT) automatically stops. Other peripheral functions continue to operate.

TMPM332FWUG

3.6 Reset Vector Break

TMPM332FWUG is prohibited from transmission with debug tools while reset caused by RESET pin is effective. When setting a stop by using reset vector, set the following procedure after reset; set break points from the debug tools, then set the application interrupt and the <SYSRESETREQ> bit of the reset control register to reset again.

Note: Do not reset with <SYSRESETREQ> in SLOW mode.

3.7 Connection with a Debug Tool

3.7.1 About connection with debug tool

Concerning a connection with debug tools, refer to manufactures recommendations.

Debug interface pins contain a pull-up resistor and a pull-down resistor. When debug interface pins are connected with external pull-up or pull-down, please pay attention to input level.

3.7.2 Important points of using debug interface pins used as general-purpose ports

TMPM332FWUG is prohibited from transmission with debug tools while reset caused by \overline{RESET} pin is effective. Therefor it cannot change to the debug mode.

The PA0, PA1 and PB0 ports are the debug interface pins after reset however if these pins are changed to the general-purpose port immediately after reset, the control from the debug tools are not accepted under some circumstances. When changing the settings, please pay attention to the status of debug interface pins.

Table 3-3 Table of using debug interface pins

	Debug interface pins						
	SWCLK	SWDIO	SWV	TRACE DATA0	TRACE CLK		
SW+SWV (After reset)	0	0	0	×	×		
SW	0	0	×	×	×		
SW+TRACE	0	0	×	0	0		
Debugging function disabled	×	×	×	×	×		

o : Enabled × : Disabled (Usable as general-purpose port)

Debug Interface

3.7 Connection with a Debug Tool TMPM332FWUG

TOSHIBA TMPM332FWUG

4. Memory Map

4.1 Memory map

The memory maps for the TMPM332FWUG are based on the ARM Cortex-M3 processor core memory map.

The internal ROM is mapped to the code of the Cortex-M3 core memory, the internal RAM is mapped to the SRAM region and the special function register (SFR) is mapped to the peripheral region respectively.

The special function register (SFR) indicates I/O ports and control registers for the peripheral function. The SRAM and SFR regions are all included in the bit-band region.

The CPU register region is the processor core's internal register region.

For more information on each region, see the "Cortex-M3 Technical Reference Manual".

Note that access to regions indicated as "Fault" causes a memory fault if memory faults are enabled or a hard fault if memory faults are disabled. Do not access the vendor-specific region.

4.1 Memory map TMPM332FWUG

4.1.1 Memory Map of TMPM332FWUG

Figure 4-1 shows the memory map of the TMPM332FWUG.




Figure 4-1 Memory Map (TMPM332FWUG)

4.2 SFR area detail

This section contains the list of addresses in the SFR area (0x4000_0000 through 0x4007_FFFF) assigned to peripheral function.

Access to the Reserved areas in the Table 4-1 is prohibited. As for the SFR area, reading the areas not described in the Table 4-1 yields undefined value. Writing these area is ignored.

Table 4-1 SFR area detail

Start Address	End Address	Peripheral	Reserved		ed
			0x4000_0080	to	0x4000_0083
			0x4000_00AC	to	0x4000_00AF
			0x4000_00B8	to	0x4000_00BB
0x4000 0000	0x4000 02BF	PORT(A to B,D to K)	0x4000_014C	to	0x4000_014F
0000_0000	0X4000_02B1	T OITT(/Tto B,B to It)	0x4000_0190	to	0x4000_0193
			0x4000_01D0	to	0x4000_01D3
			0x4000_0210	to	0x4000_0213
			0x4000_0250	to	0x4000_0253
0x4001_0000	0x4001_027F	TMRB(10ch)			
0x4002_0000	0x4002_007F	I2C/SIO(2ch)	0x4002_0040	to	0x4002_0057
0x4002_0080	0x4002_013F	SIO/UART(2ch)	0x4002_0100	to	0x4002_0133
0x4003_0000	0x4003_007F	ADC(8ch)	0x4003_0024	to	0x4003_002F
0x4004_0000	0x4004_003F	WDT			
0x4004_0100	0x4004_013F	RTC	0x4004_010D		
0x4004_0200	0x4004_023F	CG	0x4004_0230	to	0x4004_023F
0x4004_0300	0x4004_033F	CEC			
04004 0400	0-4004 0404	DMC(4-b)	0x4004_0428		0x4004_0433
0x4004_0400	0x4004_0424	RMC(1ch)	0x4004 _ 0440	to	0x4004_ 0473
0x4004_0500	0x4004 053F	FLASH	0x4004_0504	to	0x4004_0507
0,4004_0500	0x4004_055F	FLASH	0x4004_0524	to	0x4004_052B
			0x4004_0540	to	0x4004_0547
0x4004_0540	0x4004_05BF	Reserved	0x4004_0550	to	0x4004_0553
			0x4004_0560	to	0x4004_0593
0x4004_0700	0x4004_073F	Reserved	0x4004_0700	to	0x4004_0707

	4.	Memory	Map
--	----	--------	-----

4.2 SFR area detail TMPM332FWUG

TOSHIBA TMPM332FWUG

5. Reset

The TMPM332FWUG has three reset sources: an external reset pin (\overline{RESET}), a watchdog timer (WDT) and the setting $\langle SYSRESETREQ \rangle$ in the Application Interrupt and Reset Control Register.

For reset from the WDT, refer to the chapter on the WDT.

For reset from <SYSRESETREQ>, refer to "Cortex-M3 Technical Reference Manual".

Note: Do not reset with <SYSRESETREQ> in SLOW mode.

5.1 Cold reset

The power-on sequence must consider the time for the internal regulator and oscillator to be stable. In the TMPM332FWUG, the internal regulator requires at least 700 µs to be stable.

The time required to achieve stable oscillation varies with system. At cold reset, the external reset pin must be kept "Low" for a duration of time sufficiently long enough for the internal regulator and oscillator to be stable.

Figure 5-1 shows the power-on sequence.




Figure 5-1 Cold Reset Sequence

Note 1: The power supply must be raised (from 0V to 2.7V) at a speed of 0.37ms/V or slower.

Note 2: Turn on the power while the RESET pin is fixed to "Low". Release the reset while all the power supplies are stabilized within operating voltage.

Reset

5.2 Warm reset TMPM332FWUG

5.2 Warm reset

5.2.1 Reset period

As a precondition, ensure that the power supply voltage is within the operating range and the internal high-frequency oscillator is providing stable oscillation.

To reset the TMPM332FWUG, assert the \overline{RESET} signal (active low) for a minimum duration of 12 system clocks.

5.2.2 After reset

A warm reset initializes the majority of the Cortex-M3 processor core's system control registers and internal function registers.

The processor core's system debug components (FPB, DWT, ITM) register, the clock generator's CGRSTFLG register and the FCSECBIT register are initialized by a only cold reset.

After reset, the PLL multiplication circuit is inactive and must be enabled in the CGPLLSEL register if needed.

When the reset exception handling is completed, the program branches to the reset interrupt service routine.

Note: The reset operation may alter the internal RAM state.

TOSHIBA TMPM332FWUG

6. Clock/Mode control

6.1 Features

The clock/mode control block enables to select clock gear, prescaler clock and warm-up of the PLL clock multiplication circuit and oscillator.

There is also the low power consumption mode which can reduce power consumption by mode transitions.

This chapter describes how to control clock operating modes and mode transitions.

The clock/mode control block has the following functions:

- · Controls the system clock
- · Controls the prescaler clock
- · Controls the PLL multiplication circuit
- · Controls the warm-up timer

In addition to NORMAL mode, the TMPM332FWUG can operate in three types of low power mode to reduce power consumption according to its usage conditions.

6.2 Registers TMPM332FWUG

6.2 Registers

6.2.1 Register List

The following table shows the CG-related registers and addresses.

Base Address = 0x4004_0200

Register name	Address (Base+)	
System control register	CGSYSCR	0x0000
Oscillation control register	CGOSCCR	0x0004
Standby control register	CGSTBYCR	0x0008
PLL selection register	CGPLLSEL	0x000C
System clock selection register	CGCKSEL	0x0010

6.2.2 CGSYSCR (System control register)

N								
	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	sco	OSEL
After reset	0	0	0	0	0	0	0	1
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	FPSEL	-	PRCK		
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	GEAR		
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-18	-	R	Read as 0.
17-16	SCOSEL[1:0]	R/W	SCOUT out
	' '		00: fs
			01: fsys/2
			10: fsys
			11: φΤ0
			Enables to output the specified clock from SCOUT pin.
15-13	_	R	Read as 0.
12	FPSEL	R/W	fperiph
			0: fgear
			1: fc
			Specifies the source clock to fperiph.
11	_	R	Read as 0.
10-8	PRCK[2:0]	R/W	Prescaler clock
			000: fperiph
			001: fperiph/2
			010: fperiph/4
			011: fperiph/8
			100: fperiph/16
			101: fperiph/32
			110: Reserved
			111: Reserved
			Specifies the prescaler clock to peripheral I/O.
7-3	-	R	Read as 0.
2-0	GEAR[2:0]	R/W	High-speed clock gear (fc) gear
			000: fc
			001: Reserved
			010: Reserved
			011: Reserved
			100: fc/2
			101: fc/4
			110: fc/8
			111: Reserved

6.2 Registers TMPM332FWUG

6.2.3 CGOSCCR (Oscillation control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	XTEN	XEN
After reset	0	0	0	0	0	0	1	1
	7	6	5	4	3	2	1	0
bit symbol	-		WUPT		WUPSEL	PLLON	WUEF	WUEON
After reset	0	0	0	1	0	0	0	0

Bit	Bit Symbol	Туре	F	unction
31-14	-	R	Read as 0.	
13-12	-	R/W	Write "0".	
11-10	-	R	Read as 0	
9	XTEN	R/W	Low-speed oscillator	
			0: Stop	
			1:Oscillation	
8	XEN	R/W	High-speed oscillator	
			0: stop	
			1:Oscillation	
7	_	R	Read as 0	
6-4	WUPT[2:0]	R/W	Warm-up time	
			X1 XT1	
			000: No warm-up 000:No warm-up	
			001: 2 ¹⁰ / input freq. 001: 2 ⁶ / input fred	ļ.
			010: 2 ¹¹ / input freq. 010: 2 ⁷ / input free	ļ.
			011: 2 ¹² / input freq. 011: 2 ⁸ / input free	ļ.
			100: 2 ¹³ /input freq. 100: 2 ¹⁵ / input fre	q.
			101: 2 ¹⁴ / input freq. 101: 2 ¹⁶ / input fre	q.
			110: 2 ¹⁵ / input freq. 110: 2 ¹⁷ / input fre	q.
			111: 2 ¹⁶ / input freq. 111: 2 ¹⁸ / input fre	q .
3	WUPSEL	R/W	Warm-up counter	
			0: X1	
			1: XT1	
			Specifies the oscillator to warm-up.	
			A clock generated by the specified oscillator is used	for the warm-up timer count.
2	PLLON	R/W	PLL operation	
			0: Stop	
			1: Oscillation	
			Specifies operation of the PLL.	
			It stops after reset.Setting the bit is required.	
1	WUEF	R	Status of Warm-up timer (WUP)	
			0:Warm-up completed	
			1: Warm-up operation	
			Enables to monitor the status of the warm-up timer.	
0	WUEON	w	Operation of warm-up timer	
			0: don't care	
			1: starting warm-up	
			Enables to start the warm-up timer.	

6.2.4 CGSTBYCR (Standby control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	DRVE
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	RXTEN	RXEN
After reset	0	0	0	0	0	0	0	1
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	STBY		
After reset	0	0	0	0	0	0	1	1

Bit	Bit Symbol	Туре	Function
31-18	-	R	Read as 0.
17	-	R/W	Write "0".
16	DRVE	R/W	Pin status in STOP mode.
			0: Inactive
			1:Active
15-10	-	R	Read as 0
9	RXTEN	R/W	Low-speed oscillator operation after releasing the STOP mode.
			0: Stop
			1:Oscillation
8	RXEN	R/W	High-speed oscillator operation after releasing the STOP mode.
			0: Stop
			1:Oscillation
7-3	-	R	Read as 0.
2-0	STBY[2:0]	R/W	Low power consumption mode
			000: Reserved
			001: STOP
			010: SLEEP
			011: IDLE
			100: Reserved
			101: Reserved
			110: Reserved
			111: Reserved

6.2 Registers TMPM332FWUG

6.2.5 CGPLLSEL (PLL Selection Register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	-	PLLSEL
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function			
31-1	-	R	Read as 0.			
0	PLLSEL	R/W	Use of PLL			
			: Disuse. X1 selected			
			1: Use			
			Specifies use or disuse of the clock multiplied by the PLL.			
			"X1" is automatically set after reset. Resetting is required when using the PLL.			

6.2.6 CGCKSEL (System clock selection register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	SYSCK	SYSCKFLG
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-2	-	R	Read as 0.
1	SYSCK	R/W	System clock 0: High-speed (fc) 1: Low-speed (fs) Enables to specify the system clock. Setting CGOSCCR <xen> and <xten> to "1" in advance is required.</xten></xen>
0	SYSCKFLG	R	System clock status 0: High-speed (fc) 1: Low-speed (fs) Shows the status of the system clock. Switching the oscillator with <sysck> generates time lag to complete. If the output of the oscillator specified in <sysck> is read out by <sysclkflg>, the switching has been completed.</sysclkflg></sysck></sysck>

6.3 Clock control TMPM332FWUG

6.3 Clock control

6.3.1 Clock System Block Diagram

Each clock is defined as follows:

fosc : Clock input from the X1 and X2 pins

fs : Clock input from the XT1 and XT2 (low-speed clock)

fpll : Clock quadrupled by PLL

fc : Clock specified by CGPLLSEL<PLLSEL> (high-speed clock)

fgear : Clock specified by CGSYSCR<GEAR[2:0]>

fsys : Clock specified by CGCKSEL<SYSCK> (system clock)

fperiph : Clock specified by CGSYSCR<FPSEL>

φT0 : Clock specified by CGSYSCR<PRCK[2:0]> (prescaler clock)

The high-speed clock fc and the prescaler clock Φ T0 are dividable as follows.

High-speed clock : fc, fc/2, fc/4, fc/8

Prescaler clock : fperiph/2, fperiph/4, fperiph/8, fperiph/16, fperiph/32

CPU uses the following clocks. HCLK and FCLK stop in the low power consumption mode (IDLE,SLEEP,STOP.)

HCLK,FCLK : fsys STCLK (Systick timer) : fosc/32

6.3.2 Initial Values after Reset

Reset operation initializes the clock configuration as follows.

High-speed oscillator : oscillating
Low-speed oscillator : oscillating
PLL (phase locked loop circuit) : stop

High-speed clock gear : fc (no frequency dividing)

Reset operation causes all the clock configurations excluding the low-speed clock (fs) to be the same as fosc.

fc = fosc fsys = fosc $\phi T0 = fosc$

For example, reset operation configures fsys as 10MHz when a 10MHz oscillator is connected to the X1 or X2 pin.

6.3.3 Clock system Diagram

Figure 6-1 shows the clock system diagram.




Figure 6-1 Clock Block Diagram

The input clocks to selector shown with an arrow are set as default after reset.

6.3 Clock control TMPM332FWUG

6.3.4 Clock Multiplication Circuit (PLL)

This circuit outputs the fpll clock that is quadruple of the high-speed oscillator output clock (fosc.) As a result, the input frequency to oscillator can be low, and the internal clock be made high-speed.

The PLL is disabled after reset. To enable the PLL, set "1" to the CGOSCCR<PLLON> bit.

The PLL requires a certain amount of time to be stabilized, which should be secured using the warm-up function.

Note: It takes approximately 200µs for the PLL to be stabilized.

6.3.5 Warm-up function

The warm-up function secures the stability time for the oscillator and the PLL with the warm-up timer.

The warm-up function is used when returning from STOP/SLEEP mode.

In this case, an interrupt for returning from the low power consumption mode triggers the automatic timer count. After the specified time is reached, the system clock is output and the CPU starts operation.

In STOP/ SLEEP modes, the PLL is disabled. When returning from these modes, configure the warm-up time in consideration of the stability time of the PLL and the internal oscillator.

How to configure the warm-up function.

Specify the count up clock for the warm-up counter in the CGOSCCR<WUPSEL> bit.

The warm-up time can be selected by setting the CGOSCCR<WUPT[2:0]>.

The CGOSCCR<WUEON><WUEF> is used to confirm the start and completion of warm-up through software (instruction). After the completion of warm-up is confirmed, switch the system clock by setting the CGCKSEL<SYSCK>.

When clock switching occurs, the current system clock can be checked by monitoring the CGCKSEL<SYSCKFLG>

Table 6-1 shows the warm-up time.

Table 6-1 Warm-up Time (fosc = 10MHz, fs = 32.768kHz)

Warm-up time options CGOSCCR <wupt[2:0]></wupt[2:0]>	High-speed clock (fosc) CGOSCCR <wupsel> = "0"</wupsel>		Low-speed clock (fs) CGOSCCR <wupsel> = "1"</wupsel>		
000	-	Without WUP	-	With WUP	
001	210/input frequency	102.4 (µs)	26/input frequency	1.953 (ms)	
010	211/input frequency	204.8 (µs)	2 ⁷ /input frequency	3.906 (ms)	
011	212/input frequency	409.6 (µs)	28/input frequency	7.813 (ms)	
100	2 ¹³ /input frequency	819.2 (µs)	2 ¹⁵ /input frequency	1.0 (s)	
101	214/input frequency	1.638 (ms)	216/input frequency	2.0 (s)	
110	215/input frequency	3.277 (ms)	217/input frequency	4.0 (s)	
111	2 ¹⁶ /input frequency	6.554 (ms)	2 ¹⁸ /input frequency	8.0 (s)	

Note: The warm-up timer operates according to the oscillation clock, and it may contain errors if there is any fluctuation in the oscillation frequency. Therefore, the warm-up time should be taken as approximate time.

The following are the examples of the warm-up function configuration.

<Example1> Securing the stability time for the PLL

CGOSCCR<WUPSEL> = "0" : Specify the warm-up counter CGOSCCR<WUPT[2:0]> = "010" : Specify the warm-up time (204.8 μ s) CGOSCCR<WUEON> = "1" : Start the warm-up timer (WUP)

CGOSCCR<WUEF> Read : Wait until the state becomes "0" (warm-up is finished)

<Example2> Transition from the NORMAL mode to the SLOW mode

CGOSCCR<WUPSEL> = "1" : Specify the warm-up counter
CGOSCCR<WUPT[2:0]> = "xxx" : Specify the warm-up time

CGOSCCR<XTEN> = "1" : Enable the low-speed oscillation (fs)

CGOSCCR<WUEON> = "1" : Start the warm-up timer

CGOSCCR<WUEF> Read : Wait until the state becomes "0" (warm-up is finished)

CGCKSEL<SYSCK> = "1" : Switch the system clock to low speed (fs)

CGCKSEL<SYSCKFLG> Read : Confirm that the current state is "1" (the current system clock is fs)

CGOSCCR<XEN> = "0" : Disable the high-speed oscillation (fosc)

<Example3> Transition from the SLOW mode to the NORMAL mode

CGOSCCR<WUPSEL> = "0" : Specify the warm-up counter
CGOSCCR<WUPT[2:0]> = "xxx" : Specify the warm-up time

CGOSCCR<XEN> = "1" : Enable the high-speed oscillation (fosc)

CGOSCCR<WUEON> = "1" :Start the warm-up timer

CGOSCCR<WUEF> Read : Wait until the state becomes "0" (warm-up is finished)

CGCKSEL<SYSCK> = "0" : Switch the system clock to high speed (fgear)

CGCKSEL<SYSCKFLG> Read : Confirm that the current state is "0" (the current system clock is fgear)

CGOSCCR<XTEN> = "0" : Disable the low-speed oscillation (fs)

Note: When switching the system clock, ensure that the switching has been completed by reading the CGSYSCR<SYSCKFLG>.

6.3 Clock control TMPM332FWUG

6.3.6 System Clock

The TMPM332FWUG offers two selectable system clocks: low-speed or high-speed. The high-speed clock is dividable.

- Note 1: Switching of clock gear is executed when a value is written to the CGSYSCR<GEAR[2:0]> register.

 The actual switching takes place after a slight delay.
- Note 2: The CEC function uses the low-speed clock as a sampling clock. The allowable margin of error when the CEC function is used is approximately ±4% at 32.768 kHz.

6.3.6.1 High speed clock

- Input frequency from X1 and X2: 8MHz to 10MHz
- · Allows for oscillator connection or external clock input
- Clock gear: 1/1, 1/2, 1/4, 1/8 (after reset: 1/1)

Table 6-2 Range of High Speed frequency

	Min. oper-	Max oner-	After reset (PLL = OFF, CG = 1/1)	Clock gear (CG) PLL = @ON				Clock gear (CG) PLL = @OFF			
	ating freq.	ating freq.		1/1	1/2	1/4	1/8	1/1	1/2	1/4	1/8
8MHz	4 MILE	1 MHz 40 MHz	8	32	16	8	4	8	4	2	1
10MHz	1 MHz		10	40	20	10	5	10	5	2.5	1.25

Note: PLL=ON/OFF setting: available in CGOSCCR<PLLON> Clock gear setting: available in CGSYSCR<GEAR[2:0]>.

6.3.6.2 Low speed clock

Input frequency from XT1 and XT2

Table 6-3 Range of Low Speed Frequency

Input Frequency	Maximum Operating	Minimum Operating
Range	Frequency	Frequency
30 to 34 (kHz)	34 kHz	30 kHz

6.3.7 Prescaler Clock Control

Each peripheral function has a prescaler for dividing a clock. As the clock $\phi T0$ to be input to each prescaler, the "fperiph" clock specified in the CGSYSCR<FPSEL> can be divided according to the setting in the CGSYSCR<PRCK[2:0]>. After the controller is reset, fperiph/1 is selected as $\phi T0$.

Note:To use the clock gear, ensure that you make the time setting such that prescaler output φTn from each peripheral function is slower than fsys (φTn < fsys). Do not switch the clock gear while the timer counter or other peripheral function is operating.

6.3.8 System Clock Pin Output Function

The TX03 enables to output the system clock from a pin. The PK1/SCOUT pin can output the low speed clock fs, the system clock fsys and fsys/2, and the prescaler input clock for peripheral I/O ϕ T0. By setting the port K registers, the PKCR<PK1C> and PKFR1<PK1F1> to "1", the PK1/SCOUT pin (pin number 33) becomes the SCOUT output pin. The output clock is selected by setting the CGSYSCR<SCOSEL[1:0]>.

Table 6-4 shows the pin status in each mode when the SCOUT pin is set to the SCOUT output.

Table 6-4 SCOUT Output Status in Each Mode

Mode			Low power consumption mode			
SCOUT selection CGSYSCR	NORMAL	SLOW	IDLE	SLEEP	STOP	
<scosel[1:0]> = "00"</scosel[1:0]>		Output th	e fs clock			
<scosel[1:0]> = "01"</scosel[1:0]>	Output the fsys/2 clock					
<scosel[1:0]> = "10"</scosel[1:0]>	C	output the fsys cloc	k			
<scosel[1:0]> = "11"</scosel[1:0]>	Output the φT0 clock		Fixed to '	'0" or "1".		

Note: The phase difference (AC timing) between the system clock output by the SCOUT and the internal clock is not guaranteed.

6.4 Modes and Mode Transitions

6.4.1 Mode Transitions

The NORMAL mode and the SLOW mode use the high-speed and low-speed clocks for the system clock respectively.

The IDLE, SLEEP and STOP modes can be used as the low power consumption mode that enables to reduce power consumption by halting processor core operation.

When the low-speed clock is not used, the SLOW and SLEEP modes cannot be used.

Figure 6-2 shows a mode transition diagram.

For a detail of sleep-on-exit, refer to "Cortex-M3 Technical Reference Manual."




Figure 6-2 Mode Transition Diagram

TMPM332FWUG

6.5 Operation mode

Two operation modes, NORMAL and SLOW, are available. The features of each mode are described in the following section.

6.5.1 NORMAL mode

This mode is to operate the CPU core and the peripheral hardware by using the high-speed clock.

It is shifted to the NORMAL mode after reset. The low-speed clock can also be used.

6.5.2 SLOW mode

This mode is to operate the CPU core and the peripheral hardware by using the low-speed clock with high-speed clock stopped. The SLOW mode reduces power consumption compared to the NORMAL mode.

This mode allows only the following peripheral functions to operate: I/O ports, real-time clock (RTC), CEC and remote control signal preprocessor (RMC).

- Note 1: Be sure to stop peripheral functions except for the CPU, RTC, I/O ports, CEC and RMC before switching to the SLOW mode.
- Note 2: In the slow mode, be sure not to perform reset using the Application Interrupt and Reset Control Register <SYSRESETREQ> of the Cortex-M3 NVIC register.

6.6 Low Power Consumption Modes

The TX03 has three low power consumption modes: IDLE, SLEEP and STOP. To shift to the low power consumption mode, specify the mode in the system control register CGSTBYCR<STBY[2:0]> and execute the WFI (Wait For Interrupt) instruction. In this case, execute reset or generate the interrupt to release the mode. Releasing by the interrupt requires settings in advance. See the chapter "Exceptions" for details.

- Note 1: The TX03 does not offer any event for releasing the low power consumption mode. Transition to the low power consumption mode by executing the WFE (Wait For Event) instruction is prohibited.
- Note 2: The TX03 does not support the low power consumption mode configured with the SLEEPDEEP bit in the Cortex-M3 core. Setting the <SLEEPDEEP> bit of the system control register is prohibited.

The features of each mode are described as follows.

6.6.1 IDLE mode

Only the CPU is stopped in this mode.

Each peripheral function has one bit in its control register for enabling or disabling operation in the IDLE mode.

When the IDLE mode is entered, peripheral functions for which operation in the IDLE mode is disabled stop operation and hold the state at that time.

The following peripheral functions can be enabled or disabled in the IDLE mode. For setting details, see the chapter on each peripheral function.

- 16-bit timer/event counter (TMRB)
- Serial channel (SIO/UART)
- Serial bus interface (I2C/SIO)
- CEC
- Remote control signal preprocessor (RMC)
- Analog Digital converter (ADC)
- Watch dog timer (WDT)

6.6.2 SLEEP mode

In the SLEEP mode, the internal low-speed oscillator, real time clock, CEC and RMC can be operated.

By releasing the SLEEP mode, the device returns to the preceding mode of the SLEEP mode and starts operation.

Note: When PA1 (pin number 38) is configured as a debug function pin, it prevents the low power consumption mode from being fully effective. Configure PA1 to function as a general-purpose port if the debug function is not used.

6.6.3 STOP mode

All the internal circuits including the internal oscillator are brought to a stop in the STOP mode.

By releasing the STOP mode, the device returns to the preceding mode of the STOP mode and starts operation.

The STOP mode enables to select the pin status by setting the CGSTBYCR<DRVE>. Table 6-5 shows the pin status in the STOP mode.

Note: When PA1 (pin number 38) is configured as a debug function pin, it prevents the low power consumption mode from being fully effective. Configure PA1 to function as a general-purpose port when the debug function is not used.

Table 6-5 Pin States in the STOP Mode

	Pin Name	I/O	<drve> = 0</drve>	<drve> = 1</drve>	
	X1, XT1	Input only	×	×	
Not Ports	X2, XT2	Output only	"High" level output.	"High" level output.	
1 0113	RESET, NMI, MODE	Input only	0	0	
	PA0, PB0	Input	×	Depends on (PxIE[m])	
	[When used as a debug pin (PxFRn <pxmfn>=1) and output is enabled (PxCR<pxmc>=1)] (Note)</pxmc></pxmfn>	Output	Enabled when data is valid. Disabled when data is invalid.		
Ports	PG3, PJ0, PJ1, PJ2, PJ3	Input	0	0	
1 0110	[When used as an interrupt pin (PxFRn <pxmfn>=1) and input is enabled (PxIE<pxmie>=1)] (Note)</pxmie></pxmfn>	Output	×	Depends on (PxCR[m])	
	ath an and aire	Input	×	Depends on (PxIE[m])	
	other port pins	Output	×	Depends on (PxCR[m])	

o: Input or output enabled.

Note:x: port number / m: corresponding bit / n: function register number

6.6.4 Low power Consumption Mode Setting

The low power consumption mode is specified by the setting of the standby control register CGSTBYCR<STBY[2:0]>.

Table 6-6 shows the mode setting in the <STBY[2:0]>.

Table 6-6 Low power consumption mode setting

Mode	CGSTBYCR <stby[2:0]></stby[2:0]>
STOP	001
SLEEP	010
IDLE	011

Note: Do not set any value other than those shown above in <STBY[2:0]>.

^{× :} Input or output disabled.

6.6.5 Operational Status in Each Mode

Table 6-7 show the operational status in each mode.

For I/O port, "o" and "×" indicate that input/output is enabled and disabled respectively.

For other functions, "o" and "×" indicate that clock is supplied and is not supplied respectively.

Table 6-7 Operational Status in Each Mode

Block	NORMAL	SLOW	IDLE	SLEEP	STOP
Processor core	0	0	×	×	×
I/O port	0	0	О	0	* (Note 3)
ADC	0	× (Note 1)		×	×
SIO	0	× (Note 1)	ON/OFF select-	×	×
SBI	0	× (Note 1)	able for each	×	×
TMRB	0	× (Note 1)	module	×	×
WDT	0	× (Note 1)		×	×
CEC	0	0	О	0	×
RMC	o	О	О	o	×
RTC	0	0	О	0	×
CG	0	0	0	0	×
PLL	0	×	О	×	×
High-speed oscilla- tor (fc)	0	* (Note 2)	0	×	×
Low-speed oscillator (fs)	0	0	0	0	×

Note 1: In the SLOW mode, the ADC, SIO, SBI, TMRB and WDT cannot be used and must be stopped.

Note 2: The high-speed oscillator does not stop automatically and must be stopped by setting the CGOSCCR<XEN> bit.

Note 3: The status depends on the CGSTBYCR<DRVE> bit.

6.6.6 Releasing the Low Power Consumption Mode

The low power consumption mode can be released by an interrupt request, Non-Maskable Interrupt (NMI) or reset. The release source that can be used is determined by the low power consumption mode selected.

Details are shown in Table 6-8

Table 6-8 Release Source in Each Mode

	Low pow	er consumption mode	IDLE	SLEEP	STOP
	Interrupt	INT0 to 4 (Note1)	0	0	0
		INTRTC	o	0	×
		INTTB0 to 9	o	×	×
Release source		INTCAP00, 10, 50, 60 INTCAP01, 11, 51, 61	o	×	×
		INTRX0 to 1, INTTX0 to 1	О	×	×
		INTSBI0 to 1	О	×	×
		INTCECRX, INTCECTX	О	0	×
		INTRMCRX	О	0	×
		INTAD/INTADHP/INTADM0, 1	0	×	×
	NMI (INTWDT)		0	×	×
	NMI (NMI pin)		0	0	0
	RESET (RESET pin)		0	0	0

o: Starts the interrupt handling after the mode is released. (The reset initializes the LSI)

Note 1: To release the low power consumption mode by using the level mode interrupt, keep the level until the interrupt handling is started. Changing the level before then will prevent the interrupt handling from starting properly.

Note 2: For shifting to the low power consumption mode, set the CPU to prohibit all the interrupts other than the release source. If not, releasing may be executed by an unspecified interrupt.

Release by interrupt request

To release the low power consumption mode by an interrupt, the CPU must be set in advance to detect the interrupt. In addition to the setting in the CPU, the clock generator must be set to detect the interrupt to be used to release the SLEEP and STOP modes.

· Release by Non-Maskable Interrupt (NMI)

There are two kinds of NMI sources: WDT interrupt (INTWDT) and NMI pin. INTWDT can only be used in the IDLE mode. The NMI pin can be used to release all the lower power consumption modes.

· Release by reset

Any low power consumption mode can be released by reset from the \overline{RESET} pin. After that, the mode switches to the NORMAL mode and all the registers are initialized as is the case with normal reset

Note that returning to the STOP mode by reset does not induce the automatic warm-up. Keep the reset signal valid until the oscillator operation becomes stable.

Refer to "Interrupts" for details.

^{×:} Unavailable

6.6.7 Warm-up

Mode transition may require the warm-up so that the internal oscillator provides stable oscillation.

In the mode transition from STOP to the NORMAL/SLOW or from SLEEP to NORMAL, the warm-up counter is activated automatically. And then the system clock output is started after the elapse of configured warm-up time. It is necessary to select a oscillator to be used for warm-up in the CGOSCCR<WUPSEL> and to set a warm-up time in the CGOSCCR<WUPT[2:0]> before executing the instruction to enter the STOP/SLEEP mode.

Note: In STOP/ SLEEP modes, the PLL is disabled. When returning from these modes, configure the warm-up time in consideration of the stability time of the PLL and the internal oscillator. It takes approximately 200µs for the PLL to be stabilized.

In the transition from NORMAL to SLOW/ SLEEP, the warm-up is required so that the internal oscillator to stabilize if the low-speed clock is disabled. Enable the low-speed clock and then activate the warm-up by software.

In the transition from SLOW to NORMAL when the high-speed clock is disabled, enable the high-speed clock and then activate the warm-up.

Table 6-9 shows whether the warm-up setting of each mode transition is required or not.

Mode transition	Warm-up setting	
$NORMAL \rightarrow IDLE$	Not required	
$NORMAL \rightarrow SLEEP$	(Note1)	
$NORMAL \to SLOW$	(Note 1)	
$NORMAL \rightarrow STOP$	Not required	
$IDLE \rightarrow NORMAL$	Not required	
$SLEEP \rightarrow NORMAL$	Auto-warm-up	
$SLEEP \to SLOW$	Not required	
$SLOW \to NORMAL$	(Note 2)	
$SLOW \to SLEEP$	Not required	
$SLOW \to STOP$	Not required	
$STOP \to NORMAL$	Auto-warm-up (Note 3)	
STOP → SLOW	Auto-warm-up	

Table 6-9 Warm-up setting in mode transition

- Note 1: If the low-speed clock is disabled, enable the low-speed clock and then activate the warm-up by software.
- Note 2: If the high-speed clock is disabled, enable the high-speed clock and then activate the warm-up by software.
- Note 3: Returning to NORMAL mode by reset does not induce the automatic warm-up. Keep the reset signal valid until the oscillator operation becomes stable.


6.6.8 Clock Operations in Mode Transition

The clock operations in mode transition are described in Chapter 6.6.8.1 to 6.6.8.4.

6.6.8.1 Transition of operation modes: NORMAL \rightarrow STOP \rightarrow NORMAL

When returning to the NORMAL mode from the STOP mode, the warm-up is activated automatically. It is necessary to set the warm-up time before entering the STOP mode.


Returning to the NORMAL mode by reset does not induce the automatic warm-up. Keep the reset signal asserted until the oscillator operation becomes stable.



6.6.8.2 Transition of operation modes: NORMAL → SLEEP → NORMAL


When returning to the NORMAL mode from the SLEEP mode, the warm-up is activated automatically. It is necessary to set the warm-up time before entering the SLEEP mode.

Returning to the NORMAL mode by reset does not induce the automatic warm-up. Keep the reset signal asserted until the oscillator operation becomes stable.




6.6.8.3 Transition of operation modes: SLOW \rightarrow STOP \rightarrow SLOW

The warm-up is activated automatically. It is necessary to set the warm-up time before entering the STOP mode.



6.6.8.4 Transition of operation modes: SLOW \rightarrow SLEEP \rightarrow SLOW

The low-speed clock continues oscillation in the SLEEP mode. There is no need to make a warm-up setting.



TOSHIBA TMPM332FWUG

7. Exceptions

This chapter describes features, types and handling of exceptions.

Exceptions have close relation to the CPU core. Refer to "Cortex-M3 Technical Reference Manual" if needed.

7.1 Overview

An exception causes the CPU to stop the currently executing process and handle another process.

There are two types of exceptions: those that are generated when some error condition occurs or when an instruction to generate an exception is executed; and those that are generated by hardware, such as an interrupt request signal from an external pin or peripheral function.

All exceptions are handled by the Nested Vectored Interrupt Controller (NVIC) in the CPU according to the respective priority levels. When an exception occurs, the CPU stores the current state to the stack and branches to the corresponding interrupt service routine (ISR). Upon completion of the ISR, the information stored to the stack is automatically restored.

7.1.1 Exception Types

The following types of exceptions exist in the Cortex-M3.

For detailed descriptions on each exception, refer to "Cortex-M3 Technical Reference Manual".

- Reset
- Non-Maskable Interrupt (NMI)
- · Hard Fault
- · Memory Management
- · Bus Fault
- · Usage Fault
- SVCall (Supervisor Call)
- · Debug Monitor
- PendSV
- SysTick
- External Interrupt

7. Exceptions

7.1 Overview TMPM332FWUG

7.1.2 Handling Flowchart

The follow	ving shows how an exception/inter	rrupt is handle	d. In the following descriptions
	indicates hardware handling.	I	ndicates software handling.

Each step is described later in this chapter.

Processing	Description	See
Detection by CG/CPU	The CG/CPU detects the exception request.	Section 7.1.2.1
Handling by CPU	The CPU handles the exception request.	
		Section 7.1.2.2
Branch to ISR	The CPU branches to the corresponding interrupt service routine (ISR).	
\Box		
Execution of ISR	Necessary processing is executed.	Section 7.1.2.3
\Box		
Return from exception	The CPU branches to another ISR or returns to the previous program.	Section 7.1.2.4

7.1.2.1 Exception Request and Detection

(1) Exception occurrence

Exception sources include instruction execution by the CPU, memory accesses, and interrupt requests from external interrupt pins or peripheral functions.

An exception occurs when the CPU executes an instruction that causes an exception or when an error condition occurs during instruction execution.

An exception also occurs by an instruction fetch from the Execute Never (XN) region or an access violation to the Fault region.

An interrupt request is generated from an external interrupt pin or peripheral function. For interrupts that are used for releasing a standby mode, relevant settings must be made in the clock generator. For details, refer to "7.5 Interrupts".

(2) Exception detection

If multiple exceptions occur simultaneously, the CPU takes the exception with the highest priority.

Table 7-1 shows the priority of exceptions. "Configurable" means that you can assign a priority level to that exception. Memory Management, Bus Fault and Usage Fault exceptions can be enabled or disabled. If a disabled exception occurs, it is handled as Hard Fault.

Table 7-1 Exception Types and Priority

No.	Exception type	Priority	Description
1	Reset	-3 (highest)	Reset pin, WDT or SYSRETREQ
2	Non-Maskable Interrupt	-2	NMI pin or WDT
3	Hard Fault	-1	Fault that cannot activate because a higher-priority fault is being handled or it is disabled
4	Memory Management	Configurable	Exception from the Memory Protection Unit (MPU) (Note 1) Instruction fetch from the Execute Never (XN) region
5	Bus Fault	Configurable	Access violation to the Hard Fault region of the memory map
6	Usage Fault	Configurable	Undefined instruction execution or other faults related to instruction execution
7~10	Reserved	-	
11	SVCall	Configurable	System service call with SVC instruction
12	Debug Monitor	Configurable	Debug monitor when the CPU is not faulting
13	Reserved	-	
14	PendSV	Configurable	Pendable system service request
15	SysTick	Configurable	Notification from system timer
16~	External Interrupt	Configurable	External interrupt pin or peripheral function (Note 2)

Note 1: This product does not contain the MPU.

Note 2: External interrupts have different sources and numbers in each product. For details, see "7.5.1.5 List of Interrupt Sources".

(3) Priority setting

· Priority levels

The external interrupt priority is set to the interrupt priority register and other exceptions are set to <PRI_n> bit in the system handler priority register.

The configuration <PRI_n> can be changed, and the number of bits required for setting the priority varies from 3 bits to 8 bits depending on products. Thus, the range of priority values you can specify is different depending on products.

In the case of 8-bit configuration, the priority can be configured in the range from 0 to 255. The highest priority is "0". If multiple elements with the same priority exist, the smaller the number, the higher the priority becomes.

Note: <PRI_n> bit is defined as a 3-bit configuration with this product.

· Priority grouping

The priority group can be split into groups. By setting the <PRIGROUP> of the application interrupt and reset control register, <PRI_n> can be divided into the pre-emption priority and the sub priority.

A priority is compared with the pre-emption priority. If the priority is the same as the preemption priority, then it is compared with the sub priority. If the sub priority is the same as the priority, the smaller the exception number, the higher the priority. 7.1 Overview TMPM332FWUG

The Table 7-2 shows the priority group setting. The pre-emption priority and the sub priority in the table are the number in the case that <PRI n> is defined as an 8-bit configuration.

Table 7-2 Priority grouping setting

4DDIODOLIDIO.035	<pri_< th=""><th>n[7:0]></th><th>Number of</th><th colspan="2">Number of</th></pri_<>	n[7:0]>	Number of	Number of	
<prigroup[2:0]> setting</prigroup[2:0]>	Pre-emption field	Subpriority field	pre-emption priorities	subpriorities	
000	[7:1]	[0]	128	2	
001	[7:2]	[1:0]	64	4	
010	[7:3]	[2:0]	32	8	
011	[7:4]	[3:0]	16	16	
100	[7:5]	[4:0]	8	32	
101	[7:6]	[5:0]	4	64	
110	[7]	[6:0]	2	128	
111	None	[7:0]	1	256	

Note: If the configuration of <PRI_n> is less than 8 bits, the lower bit is "0". For the example, in the case of 3-bit configuration, the priority is set as <PRI_n[7:5]> and <PRI_n[4:0]> is "00000".

7.1.2.2 Exception Handling and Branch to the Interrupt Service Routine (Pre-emption)

When an exception occurs, the CPU suspends the currently executing process and branches to the interrupt service routine. This is called "pre-emption".

(1) Stacking

When the CPU detects an exception, it pushes the contents of the following eight registers to the stack in the following order:

- Program Counter (PC)
- Program Status Register (xPSR)
- r0 r3
- r12
- · Link Register (LR)

The SP is decremented by eight words by the completion of the stack push. The following shows the state of the stack after the register contents have been pushed.

$Old\;SP\to$	<pre><pre><pre><pre><pre><pre><pre><pre></pre></pre></pre></pre></pre></pre></pre></pre>
	xPSR
	PC
	LR
	r12
	r3
	r2
	r1
$SP \to$	r0

(2) Fetching an ISR

The CPU enables instruction to fetch the interrupt processing with data store to the register.

Prepare a vector table containing the top addresses of ISRs for each exception. After reset, the vector table is located at address 0x0000_0000 in the Code area. By setting the Vector Table Offset Register, you can place the vector table at any address in the Code or SRAM space.

The vector table should also contain the initial value of the main stack.

(3) Late-arriving

If the CPU detects a higher priority exception before executing the ISR for a previous exception, the CPU handles the higher priority exception first. This is called "late-arriving".

A late-arriving exception causes the CPU to fetch a new vector address for branching to the corresponding ISR, but the CPU does not newly push the register contents to the stack.

(4) Vector table

The vector table is configured as shown below.

You must always set the first four words (stack top address, reset ISR address, NMI ISR address, and Hard Fault ISR address). Set ISR addresses for other exceptions if necessary.

Offset	Exception	Contents	Setting
0x00	Reset	Initial value of the main stack	Required
0x04	Reset	ISR address	Required
0x08	Non-Maskable Interrupt	ISR address	Required
0x0C	Hard Fault	ISR address	Required
0x10	Memory Management	ISR address	Optional
0x14	Bus Fault	ISR address	Optional
0x18	Usage Fault	ISR address	Optional
0x1C ~ 0x28	Reserved		
0x2C	SVCall	ISR address	Optional
0x30	Debug Monitor	ISR address	Optional
0x34	Reserved		
0x38	PendSV	ISR address	Optional
0x3C	SysTick	ISR address	Optional
0x40	External Interrupt	ISR address	Optional

7.1 Overview TMPM332FWUG

7.1.2.3 Executing an ISR

An ISR performs necessary processing for the corresponding exception. ISRs must be prepared by the user.

An ISR may need to include code for clearing the interrupt request so that the same interrupt will not occur again upon return to normal program execution.

For details about interrupt handling, see "7.5 Interrupts".

If a higher priority exception occurs during ISR execution for the current exception, the CPU abandons the currently executing ISR and services the newly detected exception.

7.1.2.4 Exception exit

(1) Execution after returning from an ISR

When returning from an ISR, the CPU takes one of the following actions:

· Tail-chaining

If a pending exception exists and there are no stacked exceptions or the pending exception has higher priority than all stacked exceptions, the CPU returns to the ISR of the pending exception.

In this case, the CPU skips the pop of eight registers and push of eight registers when exiting one ISR and entering another. This is called "tail-chaining".

Returning to the last stacked ISR

If there are no pending exceptions or if the highest priority stacked exception is of higher priority than the highest priority pending exception, the CPU returns to the last stacked ISR.

· Returning to the previous program

If there are no pending or stacked exceptions, the CPU returns to the previous program.

(2) Exception exit sequence

When returning from an ISR, the CPU performs the following operations:

· Pop eight registers

Pops the eight registers (PC, xPSR, r0 to r3, r12 and LR) from the stack and adjust the SP.

• Load current active interrupt number

Loads the current active interrupt number from the stacked xPSR. The CPU uses this to track which interrupt to return to.

· Select SF

If returning to an exception (Handler Mode), SP is SP_main. If returning to Thread Mode, SP can be SP main or SP process.

TMPM332FWUG

7.2 Reset Exceptions

Reset exceptions are generated from the following three sources.

Use the Reset Flag (CGRSTFLG) Register of the Clock Generator to identify the source of a reset.

· External reset pin

A reset exception occurs when an external reset pin changes from "Low" to "High".

· Reset exception by WDT

The watchdog timer (WDT) has a reset generating feature. For details, see the chapter on the WDT.

Reset exception by SYSRESETREQ

A reset can be generated by setting the SYSRESETREQ bit in the NVIC's Application Interrupt and Reset Control Register.

Note: Do not reset with <SYSRESETREQ> in SLOW mode.

7.3 Non-Maskable Interrupts (NMI)

Non-maskable interrupts are generated from the following two sources.

Use the NMI Flag (CGNMIFLG) Register of the clock generator to identify the source of a non-maskable interrupt.

External NMI pin

A non-maskable interrupt is generated when an external NMI pin changes from "High" to "Low".

· Non-maskable interrupt by WDT

The watchdog timer (WDT) has a non-maskable interrupt generating feature. For details, see the chapter on the WDT.

7.4 SysTick

SysTick provides interrupt features using the CPU's system timer.

When you set a value in the SysTick Reload Value Register and enable the SysTick features in the SysTick Control and Status Register, the counter loads with the value set in the Reload Value Register and begins counting down. When the counter reaches "0", a SysTick exception occurs. You may be pending exceptions and use a flag to know when the timer reaches "0".

The SysTick Calibration Value Register holds a reload value for counting 10 ms with the system timer. The count clock frequency varies with each product, and so the value set in the SysTick Calibration Value Register also varies with each product.

Note: In this product, the system timer counts based on a clock obtained by dividing the clock input from the X1 pin by 32. The SysTick Calibration Value Register is set to 0x9C4, which provides 10 ms timing when the clock input from X1 is 8 MHz.

7.5 Interrupts

This chapter describes routes, sources and required settings of interrupts.

The CPU is notified of interrupt requests by the interrupt signal from each interrupt source.

It sets priority on interrupts and handles an interrupt request with the highest priority.

Interrupt requests for clearing a standby mode are notified to the CPU via the clock generator. Therefore, appropriate settings must be made in the clock generator.

7.5.1 Interrupt Sources

7.5.1.1 Interrupt Route

Figure 7-1 shows an interrupt request route.

The interrupts issued by the peripheral function that is not used to release standby are directly input to the CPU (route1).

The peripheral function interrupts used to release standby (route 2) and interrupts from the external interrupt pin (route 3) are input to the clock generator and are input to the CPU through the logic for releasing standby (route 4 and 5).

If interrupts from the external interrupt pins are not used to release standby, they are directly input to the CPU, not through the logic for standby release (route 6).




Figure 7-1 Interrupt Route

7.5 Interrupts TMPM332FWUG

7.5.1.2 Generation

An interrupt request is generated from an external pin or peripheral function assigned as an interrupt source or by setting the NVIC's Interrupt Set-Pending Register.

· From external pin

Set the port control register so that the external pin can perform as an interrupt function pin.

· From peripheral function

Set the peripheral function to make it possible to output interrupt requests.

See the chapter of each peripheral function for details.

By setting Interrupt Set-Pending Register (forced pending)

An interrupt request can be generated by setting the relevant bit of the Interrupt Set-Pending Register.

7.5.1.3 Transmission

An interrupt signal from an external pin or peripheral function is directly sent to the CPU unless it is used to exit a standby mode.

Interrupt requests from interrupt sources that can be used for clearing a standby mode are transmitted to the CPU via the clock generator. For these interrupt sources, appropriate settings must be made in the clock generator in advance. External interrupt sources not used for exiting a standby mode can be used without setting the clock generator.

7.5.1.4 Precautions when using external interrupt pins

If you use external interrupts, be aware the followings not to generate unexpected interrupts.

If input disabled (PxIE<PxmIE>="0"), inputs from external interrupt pins are "High". Also, if external interrupts are not used as a trigger to release standby (route 6 of "Figure 7-1 Interrupt Route"), input signals from the external interrupt pins are directly sent to the CPU. Since the CPU recognizes "High" input as an interrupt, interrupts occur if corresponding interrupts are enabled by the CPU as inputs are being disabled.

To use the external interrupt without setting it as a standby trigger, set the interrupt pin input as "Low" and enable it. Then, enable interrupts on the CPU.

7.5.1.5 List of Interrupt Sources

Table 7-3 shows the list of interrupt sources.

Table 7-3 List of Interrupt Sources

No.		Interrupt Source	active level (Clearing standby)	CG interrupt mode control register
0	INT0	Interrupt pin (PJ0/43pin)		
1	INT1	Interrupt pin (PJ1/31pin)		0011001
2	INT2	Interrupt pin (PJ2/55pin)	Selectable	CGIMCGA
3	INT3	Interrupt pin (PJ3/56pin)		
4	INT4	Interrupt pin (PG3/6pin)		CGIMCGB
5	Reserved	-		
6	INTRX0	Serial reception (channel.0)		
7	INTTX0	Serial transmission (channel.0)		
8	INTRX1	Serial reception (channel.1)		
9	INTTX1	Serial transmission (channel.1)	-	
10	INTSBI0	Serial bus interface 0	-	
11	INTSBI1	Serial bus interface 1		
12	INTCECRX	CEC reception		CGIMCGB
13	INTCECTX	CEC transmission	Rising edge	CGIMCGD
14	INTRMCRX	Remote control signal reception		CGIMCGB
15	INTADHP	Highest priority AD conversion complete interrupt		
16	INTADM0	AD conversion monitoring function interrupt 0		
17	INTADM1	AD conversion monitoring function interrupt 1		
18	INTTB0	16-bit TMRB match detection 0		
19	INTTB1	16-bit TMRB match detection 1	-	
20	INTTB2	16-bit TMRB match detection 2		
21	INTTB3	16-bit TMRB match detection 3		
22	INTTB4	16-bit TMRB match detection 4		
23	INTTB5	16-bit TMRB match detection 5		
24	INTTB6	16-bit TMRB match detection 6		
25	INTRTC	Real time clock	Falling edge	CGIMCGC
26	INTCAP00	16-bit TMRB input capture 00		
27	INTCAP01	16-bit TMRB input capture 01		
28	INTCAP10	16-bit TMRB input capture 10		
29	INTCAP11	16-bit TMRB input capture 11		
30	INTCAP50	16-bit TMRB input capture 50		
31	INTCAP51	16-bit TMRB input capture 51		
32	INTCAP60	16-bit TMRB input capture 60		
33	INTCAP61	16-bit TMRB input capture 61		
34	Reserved	-		
35	Reserved	-		
36	Reserved	-		
37	Reserved	-		
38	Reserved	-		
39	Reserved	-		

7.5 Interrupts TMPM332FWUG

Table 7-3 List of Interrupt Sources

No.		Interrupt Source	active level (Clearing standby)	CG interrupt mode control register
40	INTTB7	16-bit TMRB match detection 7		
41	INTTB8	16-bit TMRB match detection 8		
42	INTTB9	16-bit TMRB match detection 9		
43	Reserved	-		
44	Reserved	-		
45	Reserved	-		
46	Reserved	-		
47	Reserved	-		
48	Reserved	-		
49	INTAD	A/D conversion completion		

7.5.1.6 Active level

The active level indicates which change in signal of an interrupt source triggers an interrupt. The CPU recognizes interrupt signals in "High" level as interrupt. Interrupt signals directly sent from peripheral functions to the CPU are configured to output "High" to indicate an interrupt request.

Active level is set to the clock generator for interrupts which can be a trigger to release standby. Interrupt requests from peripheral functions are set as rising-edge or falling-edge triggered. Interrupt requests from interrupt pins can be set as level-sensitive ("High" or "Low") or edge-triggered (rising or falling).

If an interrupt source is used for clearing a standby mode, setting the relevant clock generator register is also required. Enable the CGIMCGx<INTxEN> bit and specify the active level in the CGIMCGx<EMCGx> bits. You must set the active level for interrupt requests from each peripheral function as shown in Table 7-3

An interrupt request detected by the clock generator is notified to the CPU with a signal in "High" level.

Note: For the CEC reception/transmission, remote control signal reception and real time clock interrupts, set the <INTxEN> bit to "1" and specify the active level, even when they are not used for clearing a standby mode.

TOSHIBA TMPM332FWUG

7.5.2 Interrupt Handling

7.5.2.1 Flowchart


The following shows how an interrupt is handled.

In the following descriptions, indicates hardware handling. indicates software handling.

Processing Details See Set the relevant NVIC registers for detecting interrupts. Set the clock generator as well if each interrupt source is used to clear a standby Settings for detection oCommon setting **NVIC** registers oSetting to clear standby mode Clock generator "7.5.2.2 Preparation" Execute an appropriate setting to send the interrupt signal depending on the interrupt type. oSetting for interrupt from external pin Settings for sending interrupt Port signal oSetting for interrupt from peripheral function Peripheral function (See the chapter of each peripheral function for details.)

Interrupt generation

An interrupt request is generated.



Interrupt lines used for clearing a standby mode are connected to the CPU via the clock generator.

"7.5.2.3 Detection by Clock Generator"

The CPU detects the interrupt.

If multiple interrupt requests occur simultaneously, the interrupt request with the highest priority is detected according to the priority order.

"7.5.2.4 Detection by CPU"



CPU handles interrupt


The CPU handles the interrupt.

The CPU pushes register contents to the stack before entering the ISR.

"7.5.2.5 CPU processing"



7.5 Interrupts TMPM332FWUG



7.5.2.2 Preparation

When preparing for an interrupt, you need to pay attention to the order of configuration to avoid any unexpected interrupt on the way.

Initiating an interrupt or changing its configuration must be implemented in the following order basically. Disable the interrupt by the CPU. Configure from the farthest route from the CPU. Then enable the interrupt by the CPU.

To configure the clock generator, you must follow the order indicated here not to cause any unexpected interrupt. First, configure the precondition. Secondly, clear the data related to the interrupt in the clock generator and then enable the interrupt.

The following sections are listed in the order of interrupt handling and describe how to configure them.

- 1. Disabling interrupt by CPU
- 2. CPU registers setting
- 3. Preconfiguration (1) (Interrupt from external pin)
- 4. Preconfiguration (2) (Interrupt from peripheral function)
- 5. Preconfiguration (3) (Interrupt Set-Pending Register)
- 6. Configuring the clock generator
- 7. Enabling interrupt by CPU

(1) Disabling interrupt by CPU

To make the CPU for not accepting any interrupt, write "1" to the corresponding bit of the PRIMASK Register. All interrupts and exceptions other than non-maskable interrupts and hard faults can be masked.

Use "MSR" instruction to set this register.



Note 1: PRIMASK register cannot be modified by the user access level.

Note 2: If a fault causes when "1" is set to the PRIMASK register, it is treated as a hard fault.

(2) CPU registers setting

You can assign a priority level by writing to <PRI_n> field in an Interrupt Priority Register of the NVIC register.

Each interrupt source is provided with eight bits for assigning a priority level from 0 to 255, but the number of bits actually used varies with each product. Priority level 0 is the highest priority level. If multiple sources have the same priority, the smallest-numbered interrupt source has the highest priority.

You can assign grouping priority by using the PRIGROUP field in the Application Interrupt and Reset Control Register.

NVIC register			
<pri_n> ←</pri_n>		"priority"	
<prigroup> ←</prigroup>		"group priority"(This is configurable if required.)	

Note: "n" indicates the corresponding exceptions/interrupts.

This product uses three bits for assigning a priority level.

(3) Preconfiguration (1) (Interrupt from external pin)

Set "1" to the port function register of the corresponding pin. Setting PxFRn[m] allows the pin to be used as the function pin. Setting PxIE[m] allows the pin to be used as the input port.

Port register				
PxFRn <pxmfn></pxmfn>	←	"1"		
PxIE <pxmie></pxmie>		"1"		

Note:x: port number / m: corresponding bit / n: function register number

In modes other than STOP mode, setting PxIE to enable input enables the corresponding interrupt input regardless of the PxFR setting. Be careful not to enable interrupts that are not used. Also, be aware of the description of "7.5.1.4 Precautions when using external interrupt pins".

(4) Preconfiguration (2) (Interrupt from peripheral function)

The setting varies depending on the peripheral function to be used. See the chapter of each peripheral function for details.

(5) Preconfiguration (3) (Interrupt Set-Pending Register)

To generate an interrupt by using the Interrupt Set-Pending Register, set "1" to the corresponding bit of this register.

NVIC register		
Interrupt Set-Pending [m]	←	"1"

Note: m: corresponding bit

(6) Configuring the clock generator

For an interrupt source to be used for exiting a standby mode, you need to set the active level and enable interrupts in the CGIMCG register of the clock generator. The CGIMCG register is capable of configuring each source.

7.5 Interrupts TMPM332FWUG

Before enabling an interrupt, clear the corresponding interrupt request already held. This can avoid unexpected interrupt. To clear corresponding interrupt request, write a value corresponding to the interrupt to be used to the CGICRCG register. See "7.6.3.5 CGICRCG(CG Interrupt Request Clear Register)" for each value.

Interrupt requests from external pins can be used without setting the clock generator if they are not used for exiting a standby mode. However, an "High" pulse or "High"-level signal must be input so that the CPU can detect it as an interrupt request. Also, be aware of the description of "7.5.1.4 Precautions when using external interrupt pins".

Clock generator register				
CGIMCGn <emcgm> ← active level</emcgm>		active level		
CGICRCG <icrcg> ←</icrcg>		Value corresponding to the interrupt to be used		
CGIMCGn <intmen></intmen>	←	"1" (interrupt enabled)		

Note: n: register number / m: number assigned to interrupt source

(7) Enabling interrupt by CPU

Enable the interrupt by the CPU as shown below.

Clear the suspended interrupt in the Interrupt Clear-Pending Register. Enable the intended interrupt with the Interrupt Set-Enable Register. Each bit of the register is assigned to a single interrupt source.

Writing "1" to the corresponding bit of the Interrupt Clear-Pending Register clears the suspended interrupt. Writing "1" to the corresponding bit of the Interrupt Set-Enable Register enables the intended interrupt.

To generate interrupts in the Interrupt Set-Pending Register setting, factors to trigger interrupts are lost if pending interrupts are cleared. Thus, this operation is not necessary.

At the end, PRIMASK register is zero cleared.

NVIC register						
Interrupt Clear-Pending [m]	←	"1"				
Interrupt Set-Enable [m]	←	"1"				
Interrupt mask register						
PRIMASK	←	"0"				

Note 1: m: corresponding bit

Note 2: PRIMASK register cannot be modified by the user access level.

7.5.2.3 Detection by Clock Generator

If an interrupt source is used for exiting a standby mode, an interrupt request is detected according to the active level specified in the clock generator, and is notified to the CPU.

An edge-triggered interrupt request, once detected, is held in the clock generator. A level-sensitive interrupt request must be held at the active level until it is detected, otherwise the interrupt request will cease to exist when the signal level changes from active to inactive.

When the clock generator detects an interrupt request, it keeps sending the interrupt signal in "High" level to the CPU until the interrupt request is cleared in the CG Interrupt Request Clear (CGICRCG) Register. If a standby mode is exited without clearing the interrupt request, the same interrupt will be detected again when normal operation is resumed. Be sure to clear each interrupt request in the ISR.

7.5.2.4 Detection by CPU

The CPU detects an interrupt request with the highest priority.

7.5.2.5 CPU processing

On detecting an interrupt, the CPU pushes the contents of PC, PSR, r0-r3, r12 and LR to the stack then enter the ISR.

7.5.2.6 Interrupt Service Routine (ISR)

An ISR requires specific programming according to the application to be used. This section describes what is recommended at the service routine programming and how the source is cleared.

(1) Pushing during ISR

An ISR normally pushes register contents to the stack and handles an interrupt as required. The Cortex-M3 core automatically pushes the contents of PC, PSR, r0-r3, r12 and LR to the stack. No extra programming is required for them.

Push the contents of other registers if needed.

Interrupt requests with higher priority and exceptions such as NMI are accepted even when an ISR is being executed. We recommend you to push the contents of general-purpose registers that might be rewritten.

(2) Clearing an interrupt source

If an interrupt source is used for clearing a standby mode, each interrupt request must be cleared with the CG Interrupt Request Clear (CGICRCG) Register.

If an interrupt source is set as level-sensitive, an interrupt request continues to exist until it is cleared at its source. Therefore, the interrupt source must be cleared. Clearing the interrupt source automatically clears the interrupt request signal from the clock generator.

If an interrupt is set as edge-sensitive, clear an interrupt request by setting the corresponding value in the CGICRCG register. When an active edge occurs again, a new interrupt request will be detected.

Exception/Interrupt-Related Registers

The CPU's NVIC registers and clock generator registers described in this chapter are shown below with their respective addresses.

7.6.1 Register List

NVIC registers

Base Address = 0xE000 E000

NVIC registers	Base Address = UXEUUU_EUUU
Register name	Address
SysTick Control and Status Register	0x0010
SysTick Reload Value Register	0x0014
SysTick Current Value Register	0x0018
SysTick Calibration Value Register	0x001C
Interrupt Set-Enable Register 1	0x0100
Interrupt Set-Enable Register 2	0x0104
Interrupt Clear-Enable Register 1	0x0180
Interrupt Clear-Enable Register 2	0x0184
Interrupt Set-Pending Register 1	0x0200
Interrupt Set-Pending Register 2	0x0204
Interrupt Clear-Pending Register 1	0x0280
Interrupt Clear-Pending Register 2	0x0284
Interrupt Priority Register	0x0400 ~ 0x0430
Vector Table Offset Register	0x0D08
Application Interrupt and Reset Control Register	0x0D0C
System Handler Priority Register	0x0D18, 0x0D1C, 0x0D20
System Handler Control and State Register	0x0D24

Clock generator registers

Base Address = 0x4004_0200

Register name		Address
CG Interrupt Request Clear Register	CGICRCG	0x0014
NMI Flag Register	CGNMIFLG	0x0018
Reset Flag Register	CGRSTFLG	0x001C
CG Interrupt Mode Control Register A	CGIMCGA	0x0020
CG Interrupt Mode Control Register B	CGIMCGB	0x0024
CG Interrupt Mode Control Register C	CGIMCGC	0x0028
CG Interrupt Mode Control Register D	CGIMCGD	0x002C
Reserved	-	0x0030
Reserved	-	0x0034
Reserved	-	0x0038
Reserved	-	0x003C

Note: Access to the "Reserved" areas is prohibited.

7.6.2 NVIC Registers

7.6.2.1 SysTick Control and Status Register

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	COUNTFLAG
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	CLKSOURCE	TICKINT	ENABLE
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-17	-	R	Read as 0.
16	COUNTFLAG	R/W	0: Timer not counted to 0 1: Timer counted to 0 Returns "1" if timer counted to "0" since last time this was read. Clears on read of any part of the SysTick Control and Status Register.
15-3	-	R	Read as 0.
2	CLKSOURCE	R/W	0: External reference clock 1: CPU clock
1	TICKINT	R/W	0: Do not pend SysTick 1: Pend SysTick
0	ENABLE	R/W	0: Disable 1: Enable If "1" is set, it reloads with the value of the Reload Value Register and starts operation.

7.6.2.2 SysTick Reload Value Register

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol				REL	OAD			
After reset				Unde	efined			
	15	14	13	12	11	10	9	8
bit symbol				REL	OAD			
After reset				Unde	efined			
	7	6	5	4	3	2	1	0
bit symbol				REL	OAD			
After reset				Unde	efined			

Bit	Bit Symbol	Туре	Function
31-24	_	R	Read as 0.
23-0	RELOAD	R/W	Reload value Set the value to load into the SysTick Current Value Register when the timer reaches "0".

Note: In this product, the system timer counts based on a clock obtained by dividing the clock input from the X1 pin by 32.

7.6.2.3 SysTick Current Value Register

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol				CURI	RENT			
After reset				Unde	efined			
	15	14	13	12	11	10	9	8
bit symbol				CURI	RENT			
After reset				Unde	efined			
	7	6	5	4	3	2	1	0
bit symbol				CURI	RENT			-
After reset				Unde	efined			

Bit	Bit Symbol	Туре	Function
31-24	-	R	Read as 0.
23-0	CURRENT	R/W	[Read] Current SysTick timer value [Write] Clear Writing to this register with any value clears it to 0. Clearing this register also clears the <countflag> bit of the SysTick Control and Status Register.</countflag>

7.6.2.4 SysTick Calibration Value Register

	31	30	29	28	27	26	25	24
bit symbol	NOREF	SKEW	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol				TEN	MS			
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol				TEN	MS			
After reset	0	0	0	0	1	0	0	1
	7	6	5	4	3	2	1	0
bit symbol				TEN	MS			
After reset	1	1	0	0	0	1	0	0

Bit	Bit Symbol	Туре	Function
31	NOREF	R	0: Reference clock provided 1: No reference clock
30	SKEW	R	0: Calibration value is 10 ms. 1: Calibration value is not 10 ms.
29-24	-	R	Read as 0.
23-0	TENMS	R	Calibration value Reload value to use for 10 ms timing (0x9C4). (Note)

Note: In this product, the system timer counts based on a clock obtained by dividing the clock input from the X1 pin by 32. The SysTick Calibration Value Register is set to a value that provides 10 ms timing when the cock input from X1 is 8 MHz.

7.6.2.5 Interrupt Set-Enable Register 1

	31	30	29	28	27	26	25	24
bit symbol	SETENA (Interrupt 31)	SETENA (Interrupt 30)	SETENA (Interrupt 29)	SETENA (Interrupt 28)	SETENA (Interrupt 27)	SETENA (Interrupt 26)	SETENA (Interrupt 25)	SETENA (Interrupt 24)
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	SETENA (Interrupt 23	SETENA (Interrupt 22)	SETENA (Interrupt 21)	SETENA (Interrupt 20)	SETENA (Interrupt 19)	SETENA (Interrupt 18)	SETENA (Interrupt 17)	SETENA (Interrupt 16)
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	15 SETENA (Interrupt 15)	14 SETENA (Interrupt 14)	13 SETENA (Interrupt 13)	12 SETENA (Interrupt 12)	SETENA (Interrupt 11)	10 SETENA (Interrupt 10)	9 SETENA (Interrupt 9)	8 SETENA (Interrupt 8)
bit symbol After reset	SETENA	SETENA	SETENA	SETENA	SETENA	SETENA	SETENA	SETENA
	SETENA (Interrupt 15)	SETENA (Interrupt 14)	SETENA (Interrupt 13)	SETENA (Interrupt 12)	SETENA (Interrupt 11)	SETENA (Interrupt 10)	SETENA (Interrupt 9)	SETENA (Interrupt 8)
	SETENA (Interrupt 15)	SETENA (Interrupt 14)	SETENA (Interrupt 13)	SETENA (Interrupt 12)	SETENA (Interrupt 11)	SETENA (Interrupt 10)	SETENA (Interrupt 9)	SETENA (Interrupt 8)

Bit	Bit Symbol	Туре	Function
31-6	SETENA	R/W	Interrupt number [31:6]
			[Write]
			1: Enable
			[Read]
			0: Disabled
			1: Enabled
			Each bit corresponds to the specified number of interrupts.
			Writing "1" to a bit in this register enables the corresponding interrupt. Writing "0" has no effect.
			Reading the bits can see the enable/disable condition of the corresponding interrupts.
5	-	R/W	Write "0".
4-0	SETENA	R/W	Interrupt number [4:0]
			[Write]
			1: Enable
			[Read]
			0: Disabled
			1: Enabled
Ī			Each bit corresponds to the specified number of interrupts.
			Writing "1" to a bit in this register enables the corresponding interrupt. Writing "0" has no effect.
			Reading the bits can see the enable/disable condition of the corresponding interrupts.

Interrupt Set-Enable Register 2 7.6.2.6

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	SETENA (Interrupt 49)	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	SETENA (Interrupt 42)	SETENA (Interrupt 41)	SETENA (Interrupt 40)
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	SETENA (Interrupt 33)	SETENA (Interrupt 32)
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-18	-	R	Read as 0.
17	SETENA	R/W	Interrupt number [49] [Write] 1: Enable [Read] 0: Disabled
			1: Enable Each bit corresponds to the specified number of interrupts. Writing "1" to a bit in this register enables the corresponding interrupt. Writing "0" has no effect. Reading the bits can see the enable/disable condition of the corresponding interrupts.
16-11	-	R/W	Write "0".
10-8	SETENA	R/W	Interrupt number [42:40] [Write] 1: Enable [Read] 0: Disabled 1: Enable Each bit corresponds to the specified number of interrupts. Writing "1" to a bit in this register enables the corresponding interrupt. Writing "0" has no effect. Reading the bits can see the enable/disable condition of the corresponding interrupts.
7-2	-	R/W	Write "0".
1-0	SETENA	R/W	Interrupt number [33:32] [Write] 1: Enable [Read] 0: Disabled 1: Enable Each bit corresponds to the specified number of interrupts. Writing "1" to a bit in this register enables the corresponding interrupt. Writing "0" has no effect. Reading the bits can see the enable/disable condition of the corresponding interrupts.

7.6.2.7 Interrupt Clear-Enable Register 1

	31	30	29	28	27	26	25	24
bit symbol	CLRENA (Interrupt 31)	CLRENA (Interrupt 30)	CLRENA (Interrupt 29)	CLRENA (Interrupt 28)	CLRENA (Interrupt 27)	CLRENA (Interrupt 26)	CLRENA (Interrupt 25)	CLRENA (Interrupt 24)
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	CLRENA (Interrupt 23)	CLRENA (Interrupt 22)	CLRENA (Interrupt 21)	CLRENA (Interrupt 20)	CLRENA (Interrupt 19)	CLRENA (Interrupt 18)	CLRENA (Interrupt 17)	CLRENA (Interrupt 16)
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	15 CLRENA (Interrupt 15)	14 CLRENA (Interrupt 14)	13 CLRENA (Interrupt 13)	12 CLRENA (Interrupt 12)	11 CLRENA (Interrupt 11)	10 CLRENA (Interrupt 10)	9 CLRENA (Interrupt 9)	8 CLRENA (Interrupt 8)
bit symbol After reset	CLRENA	CLRENA	CLRENA	CLRENA	CLRENA	CLRENA	CLRENA	CLRENA
	CLRENA (Interrupt 15)	CLRENA (Interrupt 14)	CLRENA (Interrupt 13)	CLRENA (Interrupt 12)	CLRENA (Interrupt 11)	CLRENA (Interrupt 10)	CLRENA (Interrupt 9)	CLRENA (Interrupt 8)
	CLRENA (Interrupt 15)	CLRENA (Interrupt 14)	CLRENA (Interrupt 13)	CLRENA (Interrupt 12)	CLRENA (Interrupt 11)	CLRENA (Interrupt 10)	CLRENA (Interrupt 9)	CLRENA (Interrupt 8)

Bit	Bit Symbol	Туре	Function
31-6	CLRENA	R/W	Interrupt number [31:6]
			[Write]
			1: Disabled
			[Read]
			0: Disabled
			1: Enable
			Each bit corresponds to the specified number of interrupts. It can be performed to enable interrupts and to check if interrupts are disabled.
			Writing "1" to a bit in this register disables the corresponding interrupt. Writing "0" has no effect.
			Reading the bits can see the enable/disable condition of the corresponding interrupts.
5	-	R/W	Write "0".
4-0	CLRENA	R/W	Interrupt number [4:0]
			[Write]
			1: Disabled
			[Read]
			0: Disabled
			1: Enable
			Each bit corresponds to the specified number of interrupts. It can be performed to enable interrupts and to check if interrupts are disabled.
			Writing "1" to a bit in this register disables the corresponding interrupt. Writing "0" has no effect.
			Reading the bits can see the enable/disable condition of the corresponding interrupts.

7.6 Exception/Interrupt-Related Registers

7.6.2.8 Interrupt Clear-Enable Register 2

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	CLRENA (Interrupt 49)	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	CLRENA (Interrupt 42)	CLRENA (Interrupt 41)	CLRENA (Interrupt 40)
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	CLRENA (Interrupt 33)	CLRENA (Interrupt 32)
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-18	-	R	Read as 0.
17	CLRENA	R/W	Interrupt number [49]
			[Write]
			1: Disabled
			[Read]
			0: Disabled
			1: Enable
			Each bit corresponds to the specified number of interrupts. It can be performed to enable interrupts and to check if interrupts are disabled.
			Writing "1" to a bit in this register disables the corresponding interrupt. Writing "0" has no effect.
			Reading the bits can see the enable/disable condition of the corresponding interrupts.
16-11	-	R/W	Write "0".
10-8	CLRENA	R/W	Interrupt number [42:40]
			[Write]
			1: Disabled
			[Read]
			0: Disabled
			1: Enable
			Each bit corresponds to the specified number of interrupts. It can be performed to enable interrupts and to check if interrupts are disabled.
			Writing "1" to a bit in this register disables the corresponding interrupt. Writing "0" has no effect.
			Reading the bits can see the enable/disable condition of the corresponding interrupts.
7-2	-	R/W	Write "0".
1-0	CLRENA	R/W	Interrupt number [33:32]
			[Write]
			1: Disabled
			[Read]
			0: Disabled
			1: Enable
			Each bit corresponds to the specified number of interrupts. It can be performed to enable interrupts and to check if interrupts are disabled.
			Writing "1" to a bit in this register disables the corresponding interrupt. Writing "0" has no effect.
			Reading the bits can see the enable/disable condition of the corresponding interrupts.

7.6.2.9 Interrupt Set-Pending Register 1

	31	30	29	28	27	26	25	24
hit aymhal	SETPEND							
bit symbol	(Interrupt 31)	(Interrupt 30)	(Interrupt 29)	(Interrupt 28)	(Interrupt 27)	(Interrupt 26)	(Interrupt 25)	(Interrupt 24)
After reset	Undefined							
	23	22	21	20	19	18	17	16
hit aymhal	SETPEND							
bit symbol	(Interrupt 23)	(Interrupt 22)	(Interrupt 21)	(Interrupt 20)	(Interrupt 19)	(Interrupt 18)	(Interrupt 17)	(Interrupt 16)
After reset	Undefined							
	15	14	13	12	11	10	9	8
hit aymhal	SETPEND							
bit symbol	(Interrupt 15)	(Interrupt 14)	(Interrupt 13)	(Interrupt 12)	(Interrupt 11)	(Interrupt 10)	(Interrupt 9)	(Interrupt 8)
After reset	Undefined							
	Ondonnod	Ondonnod	Ondenned	Orideniiled	Orideniiled	Oridefilied	Ondomiod	0.10000
	7	6	5	4	3	2	1	0
hit overhol							1 SETPEND	
bit symbol	7	6		4	3	2	1	0

Bit	Bit Symbol	Туре	Function
31-6	SETPEND	R/W	Interrupt number [31:6]
			[Write]
			1: Pend
			[Read]
			0: Not pending
			1: Pending
			Each bit corresponds to the specified number can force interrupts into the pending state and determines which interrupts are currently pending.
			Writing "1" to a bit in this register pends the corresponding interrupt. However, writing "1" has no effect on
			an interrupt that is already pending or is disabled. Writing "0" has no effect.
			Reading the bit returns the current state of the corresponding interrupts.
			Writing "1" to a corresponding bit in the Interrupt Clear-Pending Register clears the bit in this register.
5	-	R/W	Write "0".
4-0	SETPEND	R/W	Interrupt number [4:0]
			[Write]
			1: Pend
			[Read]
			0: Not pending
			1: Pending
			Each bit corresponds to the specified number can force interrupts into the pending state and determines which interrupts are currently pending.
			Writing "1" to a bit in this register pends the corresponding interrupt. However, writing "1" has no effect on
			an interrupt that is already pending or is disabled. Writing "0" has no effect.
			Reading the bit returns the current state of the corresponding interrupts.
			Writing "1" to a corresponding bit in the Interrupt Clear-Pending Register clears the bit in this register.

7.6 Exception/Interrupt-Related Registers

7.6.2.10 Interrupt Set-Pending Register 2

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	SETPEND (Interrupt 49)	-
After reset	0	0	0	0	0	0	Undefined	Undefined
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	SETPEND (Interrupt 42)	SETPEND (Interrupt 41)	SETPEND (Interrupt 40)
After reset	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	SETPEND (Interrupt 33)	SETPEND (Interrupt 32)
After reset	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined

Bit	Bit Symbol	Туре	Function
31-18	-	R	Read as 0.
17	SETPEND	R/W	Interrupt number [49]
			[Write]
			1: Pend
			[Read]
			0: Not pending
			1: Pending
			Each bit corresponds to the specified number can force interrupts into the pending state and determines which interrupts are currently pending.
			Writing "1" to a bit in this register pends the corresponding interrupt. However, writing "1" has no effect on an interrupt that is already pending or is disabled. Writing "0" has no effect.
			Reading the bit returns the current state of the corresponding interrupts.
			Clear and Interrupt Set-Pending Register bit by writing "1" to the corresponding bit in the Interrupt Clear-Pending Register.
16-11	-	R/W	Write "0".
10-8	SETPEND	R/W	Interrupt number [42:40]
			[Write]
			1: Pend
			[Read]
			0: Not pending
			1: Pending
			Each bit corresponds to the specified number can force interrupts into the pending state and determines which interrupts are currently pending.
			Writing "1" to a bit in this register pends the corresponding interrupt. However, writing "1" has no effect on an interrupt that is already pending or is disabled. Writing "0" has no effect.
			Reading the bit returns the current state of the corresponding interrupts.
			Clear and Interrupt Set-Pending Register bit by writing "1" to the corresponding bit in the Interrupt Clear-Pending Register.
7-2	-	R/W	Write "0".
1-0	SETPEND	R/W	Interrupt number [33:32]
			[Write]
			1: Pend
			[Read]
			0: Not pending
			1: Pending
			Each bit corresponds to the specified number can force interrupts into the pending state and determines which interrupts are currently pending.
			Writing "1" to a bit in this register pends the corresponding interrupt. However, writing "1" has no effect on an interrupt that is already pending or is disabled. Writing "0" has no effect.
			Reading the bit returns the current state of the corresponding interrupts.
			Clear and Interrupt Set-Pending Register bit by writing "1" to the corresponding bit in the Interrupt Clear-Pending Register.

Interrupt Clear-Pending Register 1 7.6.2.11

	31	30	29	28	27	26	25	24
bit symbol	CLRPEND (Interrupt 31)	CLRPEND (Interrupt 30)	CLRPEND (Interrupt 29)	CLRPEND (Interrupt 28)	CLRPEND (Interrupt 27)	CLRPEND (Interrupt 26)	CLRPEND (Interrupt 25)	CLRPEND (Interrupt 24)
After reset	Undefined							
	23	22	21	20	19	18	17	16
bit symbol	CLRPEND (Interrupt 23)	CLRPEND (Interrupt 22)	CLRPEND (Interrupt 21)	CLRPEND (Interrupt 20)	CLRPEND (Interrupt 19)	CLRPEND (Interrupt 18)	CLRPEND (Interrupt 17)	CLRPEND (Interrupt 16)
After reset	Undefined							
	15	14	13	12	11	10	9	8
bit symbol	CLRPEND (Interrupt 15)	CLRPEND (Interrupt 14)	CLRPEND (Interrupt 13)	CLRPEND (Interrupt 12)	CLRPEND (Interrupt 11)	CLRPEND (Interrupt 10)	CLRPEND (Interrupt 9)	CLRPEND (Interrupt 8)
After reset	Undefined							
	7	6	5	4	3	2	1	0
bit symbol	CLRPEND (Interrupt 7)	CLRPEND (Interrupt 6)	-	CLRPEND (Interrupt 4)	CLRPEND (Interrupt 3)	CLRPEND (Interrupt 2)	CLRPEND (Interrupt 1)	CLRPEND (Interrupt 0)

Bit	Bit Symbol	Туре	Function
31-6	CLRPEND	R/W	Interrupt number [31:6]
			[Write]
			1: Clear pending interrupt
			[Read]
			0: Not pending
			1: Pending
			Each bit corresponds to the specified number can force interrupts into the pending state and determines which interrupts are currently pending.
			Writing "1" to a bit in this register clears the corresponding pending interrupt. However, writing "1" has no effect on an interrupt that is already being serviced. Writing "0" has no effect.
			Reading the bit returns the current state of the corresponding interrupts.
5	-	R/W	Write "0".
4-0	CLRPEND	R/W	Interrupt number [4:0]
			[Write]
			1: Clear pending interrupt
			[Read]
			0: Not pending
			1: Pending
			Each bit corresponds to the specified number can force interrupts into the pending state and determines which interrupts are currently pending.
			Writing "1" to a bit in this register clears the corresponding pending interrupt. However, writing "1" has no effect on an interrupt that is already being serviced. Writing "0" has no effect.
			Reading the bit returns the current state of the corresponding interrupts.

7.6.2.12 Interrupt Clear-Pending Register 2

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	CLRPEND (Interrupt 49)	-
After reset	0	0	0	0	0	0	Undefined	Undefined
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	CLRPEND (Interrupt 42)	CLRPEND (Interrupt 41)	CLRPEND (Interrupt 40)
After reset	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	CLRPEND (Interrupt 33)	CLRPEND (Interrupt 32)
After reset	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined

Bit	Bit Symbol	Туре	Function
31-18	-	R	Read as 0.
17	CLRPEND	R/W	Interrupt number [49]
			[Write]
			1: Clear pending interrupt
			[Read]
			0: Not pending
			1: Pending
			Each bit corresponds to the specified number can force interrupts into the pending state and determines which interrupts are currently pending.
			Writing "1" to a bit in this register clears the corresponding pending interrupt. However, writing "1" has no effect on an interrupt that is already being serviced. Writing "0" has no effect.
			Reading the bit returns the current state of the corresponding interrupts.
16-11	-	R/W	Write "0".
10-8	CLRPEND	R/W	Interrupt number [42:40]
			[Write]
			1: Clear pending interrupt
			[Read]
			0: Not pending
			1: Pending
			Each bit corresponds to the specified number can force interrupts into the pending state and determines which interrupts are currently pending.
			Writing "1" to a bit in this register clears the corresponding pending interrupt. However, writing "1" has no effect on an interrupt that is already being serviced. Writing "0" has no effect.
			Reading the bit returns the current state of the corresponding interrupts.
7-2	-	R/W	Write "0".
1-0	CLRPEND	R/W	Interrupt number [33:32]
			[Write]
			1: Clear pending interrupt
			[Read]
			0: Not pending
			1: Pending
			Each bit corresponds to the specified number can force interrupts into the pending state and determines which interrupts are currently pending.
			Writing "1" to a bit in this register clears the corresponding pending interrupt. However, writing "1" has no effect on an interrupt that is already being serviced. Writing "0" has no effect.
			Reading the bit returns the current state of the corresponding interrupts.

7.6.2.13 Interrupt Priority Register

Each interrupt is provided with eight bits of an Interrupt Priority Register.

The following shows the addresses of the Interrupt Priority Registers corresponding to interrupt numbers.

	31 24	23 16	15 8	7 0
0xE000_E400	PRI_3	PRI_2	PRI_1	PRI_0
0xE000_E404	PRI_7	PRI_6	-	PRI_4
0xE000_E408	PRI_11	PRI_10	PRI_9	PRI_8
0xE000_E40C	PRI_15	PRI_14	PRI_13	PRI_12
0xE000_E410	PRI_19	PRI_18	PRI_17	PRI_16
0xE000_E414	PRI_23	PRI_22	PRI_21	PRI_20
0xE000_E418	PRI_27	PRI_26	PRI_25	PRI_24
0xE000_E41C	PRI_31	PRI_30	PRI_29	PRI_28
0xE000_E420	-	-	PRI_33	PRI_32
0xE000_E424	-	_	1	-
0xE000_E428	_	PRI_42	PRI_41	PRI_40
0xE000_E42C	-	-	ı	-
0xE000_E430	_	_	PRI_49	-

The number of bits to be used for assigning a priority varies with each product. This product uses three bits for assigning a priority.

The following shows the fields of the Interrupt Priority Registers for interrupt numbers 0 to 3. The Interrupt Priority Registers for all other interrupt numbers have the identical fields. Unused bits return "0" when read, and writing to unused bits has no effect.

	31	30	29	28	27	26	25	24
bit symbol		PRI_3		-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol		PRI_2		-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol		PRI_1		-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol		PRI_0		-	-	-	-	-
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-29	PRI_3	R/W	Priority of interrupt number 3
28-24	-	R	Read as 0.
23-21	PRI_2	R/W	Priority of interrupt number 2
20-16	-	R	Read as 0.
15-13	PRI_1	R/W	Priority of interrupt number 1
12-8	-	R	Read as 0.
7-5	PRI_0	R/W	Priority of interrupt number 0
4-0	-	R	Read as 0.

7.6.2.14 Vector Table Offset Register

	31	30	29	28	27	26	25	24			
bit symbol	-	TBLBASE TBLOFF									
After reset	0	0	0	0	0	0	0	0			
	23	22	21	20	19	18	17	16			
bit symbol		TBLOFF									
After reset	0	0	0	0	0	0	0	0			
	15	14	13	12	11	10	9	8			
bit symbol				TBL	OFF						
After reset	0	0	0	0	0	0	0	0			
	7	6	5	4	3	2	1	0			
bit symbol	TBLOFF	-	-	-	-	-	-	-			
After reset	0	0	0	0	0	0	0	0			

Bit	Bit Symbol	Туре	Function
31-30	-	R	Read as 0.
29	TBLBASE	R/W	Table base The vector table is in: 0: Code space 1: SRAM space
28-7	TBLOFF	R/W	Offset value Set the offset value from the top of the space specified in TBLBASE. The offset must be aligned based on the number of exceptions in the table. This means that the minimum alignment is 32 words that you can use for up to 16 interrupts. For more interrupts, you must adjust the alignment by rounding up to the next power of two.
6-0	-	R	Read as 0.

7.6.2.15 Application Interrupt and Reset Control Register

	31	30	29	28	27	26	25	24				
bit symbol		VECTKEY/VECTKEYSTAT										
After reset	0	0	0	0	0	0	0	0				
	23	22	21	20	19	18	17	16				
bit symbol				VECTKEY/VE	CTKEYSTAT							
After reset	0	0	0	0	0	0	0	0				
	15	14	13	12	11	10	9	8				
bit symbol	ENDIANESS	-	-	-	-		PRIGROUP					
After reset	0	0	0	0	0	0	0	0				
	7	6	5	4	3	2	1	0				
bit symbol	-	-	-	-	-	SYSRESET REQ	VECTCLR ACTIVE	VECTRESET				
After reset	0	0	0	0	0	0	0	0				

Bit	Bit Symbol	Туре	Function
31-16	VECTKEY (Write)/ VECTKEY- STAT(Read)	R/W	Register key [Write] Writing to this register requires 0x5FA in the <vectkey> field. [Read] Read as 0xFA05.</vectkey>
15	ENDIANESS	R/W	Endianness bit:(Note1) 1: big endian 0: little endian
14-11	-	R	Read as 0.
10-8	PRIGROUP	R/W	Interrupt priority grouping 000: seven bits of pre-emption priority, one bit of subpriority 001: six bits of pre-emption priority, two bits of subpriority 010: five bits of pre-emption priority, three bits of subpriority 011: four bits of pre-emption priority, four bits of subpriority 100: three bits of pre-emption priority, five bits of subpriority 101: two bits of pre-emption priority, six bits of subpriority 110: one bit of pre-emption priority, seven bits of subpriority 111: no pre-emption priority, eight bits of subpriority The bit configuration to split the interrupt priority register <pri_n> into pre-emption priority and sub priority.</pri_n>
7-3	-	R	Read as 0.
2	SYSRESET REQ	R/W	System Reset Request. 1=CPU outputs a SYSRESETREQ signal. (note2)
1	VECTCLR ACTIVE	R/W	Clear active vector bit 1: clear all state information for active NMI, fault, and interrupts 0: do not clear. This bit self-clears. It is the responsibility of the application to reinitialize the stack.
0	VECTRESET	R/W	System Reset bit 1: reset system 0: do not reset system Resets the system, with the exception of debug components (FPB, DWT and ITM) by setting "1" and this bit is also zero cleared.

Note 1: Little-endian is the default memory format for this product.

Note 2: When SYSRESETREQ is output, warm reset is performed on this product. <SYSRESETREQ> is cleared by warm reset.

7.6.2.16 System Handler Priority Register

Each exception is provided with eight bits of a System Handler Priority Register.

The following shows the addresses of the System Handler Priority Registers corresponding to each exception.

	31 24	23 16	15 8	7 0
0vE000 ED40	PRI_7	PRI_6	PRI_5	PRI_4
0xE000_ED18		(Usage Fault)	(Bus Fault)	(Memory Management)
0vE000 ED40	PRI_11	PRI_10	PRI_9	PRI_8
0xE000_ED1C	(SVCall)			
0vE000 ED20	PRI_15	PRI_14	PRI_13	PRI_12
0xE000_ED20	(SysTick)	(PendSV)		(Debug Monitor)

The number of bits to be used for assigning a priority varies with each product. This product uses three bits for assigning a priority.

The following shows the fields of the System Handler Priority Registers for Memory Management, Bus Fault and Usage Fault. Unused bits return "0" when read, and writing to unused bits has no effect.

	31	30	29	28	27	26	25	24
bit symbol		PRI_7		-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol		PRI_6		-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol		PRI_5		-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol		PRI_4		-	-	-	-	-
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-29	PRI_7	R/W	Reserved
28-24	_	R	Read as 0.
23-21	PRI_6	R/W	Priority of Usage Fault
20-16	_	R	Read as 0.
15-13	PRI_5	R/W	Priority of Bus Fault
12-8	_	R	Read as 0.
7-5	PRI_4	R/W	Priority of Memory Management
4-0	-	R	Read as 0.

System Handler Control and State Register 7.6.2.17

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	1	-	-	1	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	USGFAULT ENA	BUSFAULT ENA	MEMFAULT ENA
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	SVCALL PENDED	BUSFAULT PENDED	MEMFAULT PENDED	USGFAULT PENDED	SYSTICKACT	PENDSVACT	-	MONITOR ACT
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	SVCALLACT	-	-	-	USGFAULT ACT	-	BUSFAULT ACT	MEMFAULT ACT
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-19	-	R	Read as 0.
18	USGFAULT	R/W	Usage Fault
	ENA		0: Disabled
			1: Enable
17	BUSFAUL	R/W	Bus Fault
	TENA		0: Disabled
			1: Enable
16	MEMFAULT	R/W	Memory Management
	ENA		0: Disabled
			1: Enable
15	SVCALL	R/W	SVCall
	PENDED		0: Not pended
			1: Pended
14	BUSFAULT	R/W	Bus Fault
	PENDED		0: Not pended
			1: Pended
13	MEMFAULT	R/W	Memory Management
	PENDED		0: Not pended
			1: Pended
12	USGFAULT	R/W	Usage Fault
	PENDED		0: Not pended
			1: Pended
11	SYSTICKACT	R/W	SysTick
			0: Inactive
			1: Active
10	PENDSVACT	R/W	PendSV
			0: Inactive
			1: Active
9	_	R	Read as 0.
8	MONITORACT	R/W	Debug Monitor
			0: Inactive
			1: Active
7	SVCALLACT	R/W	SVCall
			0: Inactive
			1: Active
6-4	-	R	Read as 0.

Bit	Bit Symbol	Туре	Function
3	USGFAULT	R/W	Usage Fault
	ACT		0: Inactive
			1: Active
2	-	R	Read as 0.
1	BUSFAULT	R/W	Bus Fault
	ACT		0: Inactive
			1: Active
0	MEMFAULT	R/W	Memory Management
	ACT		0: Inactive
			1: Active

Note: You must clear or set the active bits with extreme caution because clearing and setting these bits does not repair stack contents.

7.6.3 Clock generator registers

CGIMCGA(CG Interrupt Mode Control Register A) 7.6.3.1

	31	30	29	28	27	26	25	24
bit symbol	-	EMCG3			EMST3		-	INT3EN
After reset	0	0	1	0	0	0	Undefined	0
	23	22	21	20	19	18	17	16
bit symbol	-	EMCG2			EM	ST2	-	INT2EN
After reset	0	0	1	0	0	0	Undefined	0
	15	14	13	12	11	10	9	8
bit symbol	-	EMCG1			EMST1		-	INT1EN
After reset	0	0	1	0	0	0	Undefined	0
	7	6	5	4	3	2	1	0
bit symbol	-	EMCG0			EMST0		-	INT0EN
After reset	0	0	1	0	0	0	Undefined	0

Bit	Bit Symbol	Туре	Function				
31	-	R	Read as 0.				
30-28	EMCG3[2:0]	R/W	active level setting of INT3 standby clear request. (101~111: setting prohibited) 000: "Low" level 001: "High" level 010: Falling edge 011: Rising edge 100: Both edges				
27-26	EMST3[1:0]	R	active level of INT3 standby clear request 00: - 01: Rising edge 10: Falling edge 11: Both edges				
25	_	R	Reads as undefined.				
24	INT3EN	R/W	INT3 clear input 0:Disable 1: Enable				
23	-	R	Read as 0.				
22-20	EMCG2[2:0]	R/W	active level setting of INT2 standby clear request. (101~111: setting prohibited) 000: "Low" level 001: "High" level 010: Falling edge 011: Rising edge 100: Both edges				
19-18	EMST2[1:0]	R	active level of INT2 standby clear request 00: - 01: Rising edge 10: Falling edge 11: Both edges				
17	_	R	Reads as undefined.				
16	INT2EN	R/W	INT2 clear input 0:Disable 1: Enable				
15	-	R	Read as 0.				

Bit	Bit Symbol	Туре	Function
14-12	EMCG1[2:0]	R/W	active level setting of INT1 standby clear request. (101~111: setting prohibited) 000: "Low" level 001: "High" level 010: Falling edge 011: Rising edge 100: Both edges
11-10	EMST1[1:0]	R	active level of INT1 standby clear request 00: - 01: Rising edge 10: Falling edge 11: Both edges
9	-	R	Reads as undefined.
8	INT1EN	R/W	INT1 clear input 0:Disable 1: Enable
7	-	R	Read as 0.
6-4	EMCG0[2:0]	R/W	active level setting of INT0 standby clear request. (101~111: setting prohibited) 000: "Low" level 001: "High" level 010: Falling edge 011: Rising edge 100: Both edges
3-2	EMST0[1:0]	R	active level of INT0 standby clear request 00: - 01: Rising edge 10: Falling edge 11: Both edges
1	_	R	Reads as undefined.
0	INT0EN	R/W	INTO clear input 0:Disable 1: Enable

Note 1: <EMSTx> is effective only when <EMCGx[2:0]> is set to "100" for both rising and falling edge. The active level used for the reset of standby can be checked by referring <EMSTx>. If interrupts are cleared with the CGICRCG register, <EMSTx> is also cleared.

7.6.3.2 CGIMCGB(CG Interrupt Mode Control Register B)

	31	30	29	28	27	26	25	24
bit symbol	-		EMCG7		EM	ST7	-	INT7EN
After reset	0	0	1	0	0	0	Undefined	0
	23	22	21	20	19	18	17	16
bit symbol	-		EMCG6		EM	ST6	-	INT6EN
After reset	0	0	1	0	0	0	Undefined	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	1	0	0	0	Undefined	0
	7	6	5	4	3	2	1	0
bit symbol	-	EMCG4			EM	ST4	-	INT4EN
After reset	0	0	1	0	0	0	Undefined	0

Bit	Bit Symbol	Туре	Function
31	-	R	Read as 0.
30-28	EMCG7[2:0]	R/W	active level setting of INTRMCRX standby clear request
			Set it as shown below.
			011: Rising edge
27-26	EMST7[1:0]	R	active level of INTRMCRX standby clear request
			00: -
			01: Rising edge
			10: Falling edge
05		 	11: Both edges
25	+	R	Reads as undefined.
24	INT7EN	R/W	INTRMCRX clear input
			0:Disable 1: Enable
23	-	R	Read as 0.
22-20	+	R/W	
22-20	EMCG6[2:0]	F/VV	active level setting of INTCECRX standby clear request Set it as shown below.
			011: Rising edge
19-18	EMST6[1:0]	R	active level of INTCECRX standby clear request
10 10		``	00: -
			01: Rising edge
			10: Falling edge
			11: Both edges
17	_	R	Reads as undefined.
16	INT6EN	R/W	INTCECRX clear input
			0:Disable
			1: Enable
15	-	R	Read as 0.
14-12	-	R/W	Write any value.
11-10	-	R	Read as 0.
9	_	R	Reads as undefined.
8	_	R/W	Write "0".
7	-	R	Read as 0.
6-4	EMCG4[2:0]	R/W	active level setting of INT4 standby clear request (101~111: setting prohibited)
			000: "Low" level
			001: "High" level
			010: Falling edge
			011: Rising edge
			100: Both edges

Bit	Bit Symbol	Туре	Function			
3-2	EMST4[1:0]	R	active level of INT4 standby clear request			
			00: -			
			01: Rising edge			
			10: Falling edge			
			11: Both edges			
1	-	R	Reads as undefined.			
0	INT4EN	R/W	INT4 clear input			
			0:Disable			
			1: Enable			

Note 1: <EMSTx> is effective only when <EMCGx[2:0]> is set to "100" for both rising and falling edge. The active level used for the reset of standby can be checked by referring <EMSTx>. If interrupts are cleared with the CGICRCG register, <EMSTx> is also cleared.

7.6.3.3 CGIMCGC(CG Interrupt Mode Control Register C)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	1	0	0	0	Undefined	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	1	0	0	0	Undefined	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	1	0	0	0	Undefined	0
	7	6	5	4	3	2	1	0
bit symbol	-		EMCG8		EM	ST8	-	INT8EN
After reset	0	0	1	0	0	0	Undefined	0

Bit	Bit Symbol	Туре	Function						
31	-	R	Read as 0.						
30-28	-	R/W	Vrite any value.						
27-26	-	R	ead as 0.						
25	_	R	Reads as undefined.						
24	-	R/W	Write "0".						
23	-	R	Read as 0.						
22-20	_	R/W	Write any value.						
19-18	-	R	Read as 0.						
17	-	R	Reads as undefined.						
16	-	R/W	Write "0".						
15	-	R	Read as 0.						
14-12	-	R/W	Write any value.						
11-10	-	R	Read as 0.						
9	-	R	Reads as undefined.						
8	_	R/W	Write "0".						
7	_	R	Read as 0.						
6-4	EMCG8[2:0]	R/W	active level setting of INTRTC standby clear request.						
			Set it as shown below.						
			010: Falling edge						
3-2	EMST8[1:0]	R	active level of INTRTC standby clear request.						
			00: -						
			01: Rising edge						
			10: Falling edge 11: Both edges						
1	_	R	Reads as undefined.						
0	INT8EN	R/W	INTRTC clear input						
J	INTOEN	IK/VV	·						
			0:Disable 1: Enable						

Note 1: <EMSTx> is effective only when <EMCGx[2:0]> is set to "100" for both rising and falling edge. The active level used for the reset of standby can be checked by referring <EMSTx>. If interrupts are cleared with the CGICRCG register, <EMSTx> is also cleared.

7.6.3.4 CGIMCGD(CG Interrupt Mode Control Register D)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	1	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	1	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	1	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-		EMCGC		EM	STC	-	INTCEN
After reset	0	0	1	0	0	0	Undefined	0

Bit	Bit Symbol	Туре	Function
31	-	R	Read as 0.
30-28	-	R/W	Write any value.
27-25	-	R	Read as 0.
24	-	R/W	Write as 0.
23	-	R	Read as 0.
22-20	-	R/W	Write any value.
19-17	-	R	Read as 0.
16	-	R/W	Write as 0.
15	-	R	Read as 0.
14-12	-	R/W	Write any value.
11-9	-	R	Read as 0.
8	-	R/W	Write as 0.
7	-	R	Read as 0.
6-4	EMCGC[2:0]	R/W	active level setting of INTCECTX standby clear request.
			Set it as shown below.
			011: Rising edge
3-2	EMSTC[1:0]	R	active level of INTCECTX standby clear request.
			00: -
			01: Rising edge
			10: Falling edge
			11: Both edges
1	-	R	Reads as undefined.
0	INTCEN	R/W	INTCECTX Clear input
			0:Disable
			1: Enable

Note 1: <EMSTx> is effective only when <EMCGx[2:0]> is set to "100" for both rising and falling edge. The active level used for the reset of standby can be checked by referring <EMSTx>. If interrupts are cleared with the CGICRCG register, <EMSTx> is also cleared.

7.6 Exception/Interrupt-Related Registers

7.6.3.5 CGICRCG(CG Interrupt Request Clear Register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	ICRCG				
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-5	-	R	Read as 0.
4-0	ICRCG[4:0]	W	Clear interrupt requests.
			0_0000: INT0
			0_0001: INT1
			0_0010: INT2
			0_0011: INT3
			0_0100: INT4
			0_0101: Reserved
			0_0110: INTCECRX
			0_0111: INTRMCRX
			0_1000: INTRTC
			0_1001: Reserved
			0_1010: Reserved
			0_1011: Reserved
			0_1100: INTCECTX
			0_1101 to 1_1111: setting prohibited.
			Read as 0.

7.6.3.6 CGNMIFLG(NMI Flag Register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	NMIFLG1	NMIFLG0
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-2	_	R	Read as 0.
1	NMIFLG1	R	NMI source generation flag 0: not applicable 1: generated from NMI pin
0	NMIFLG0	R	NMI source generation flag 0: not applicable 1: generated from WDT

Note: <NMIFLG> are cleared to "0" when they are read.

7.6.3.7 CGRSTFLG (Reset Flag Register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After pin reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After pin reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After pin reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	SYSRSTF	-	WDTRSTF	PINRSTF	PONRSTF
After pin reset	0	0	0	0	0	0	1	1/0

Bit	Bit Symbol	Туре	Function
31-5	-	R	Read as 0.
4	SYSRSTF	R/W	Debug reset flag(Note1) 0: "0" is written 1: Reset from SYSRESETREQ
3	-	R/W	Write as 0.
2	WDTRSTF	R/W	WDT reset flag 0: "0" is written 1: Reset from WDT
1	PINRSTF	R/W	RESET pin flag 0: "0" is written 1: Reset from RESET pin
0	PONRSTF	R/W	Power-on flag 0: "0" is written 1: "1" is set to this bit in initial reset state right after power-on.

Note 1: This flag indicates a reset generated by the SYSRESETREQ bit of the Application Interrupt and Reset Control Register of the CPU's NVIC.

Note 2: This register is not cleared automatically. Write "0" to clear the register.

TOSHIBA TMPM332FWUG

8. Input/Output Ports

8.1 Port Functions

8.1.1 Function Lists

TMPM332FWUG has 44 ports. Besides the ports function, these ports can be used as I/O pins for peripheral functions.

Table 8-1 and Table 8-2 show the port function table.

Table 8-1 Port Function List (Port A to Port B and PortD to PortG)

Port	Pin	Input/ Output	Pull-up Pull-down	Schmitt input	Noise Filter	Program- mable Open-drain	Function pin
	PA0	I/O	Pull-up	0	-	-	SWDIO
Dort A	PA1	I/O	Pull-down	-	-	-	SWCLK
Port A	PA2	I/O	Pull-up	-	-	-	TRACECLK
	PA3	I/O	Pull-up	-	_	-	TRACEDATA0
Port B	PB0	I/O	Pull-up	-	-	-	SWV
	PD0	Input	Pull-up	1	-	-	AIN4, TB5IN0
	PD1	Input	Pull-up	-	_	-	AIN5, TB5IN1
	PD2	Input	Pull-up	ı	-	-	AIN6, TB6IN0
Port D	PD3	Input	Pull-up	-	-	-	AIN7, TB6IN1
Poil D	PD4	Input	Pull-up	-	-	-	AIN8
	PD5	Input	Pull-up	-	-	-	AIN9
	PD6	Input	Pull-up	-	-	-	AIN10
	PD7	Input	Pull-up	-	-	-	AIN11
	PE0	I/O	Pull-up	-	-	0	TXD0
	PE1	I/O	Pull-up	0	-	0	RXD0
	PE2	I/O	Pull-up	0	-	О	SCLK0, CTS0
Port E	PE3	I/O	Pull-up	0	-	О	RXIN
	PE4	I/O	Pull-up	ı	-	О	TXD1
	PE5	I/O	Pull-up	0	_	О	RXD1
	PE6	I/O	Pull-up	0	-	О	SCLK1, CTS1
	PF4	I/O	Pull-up	0	-	0	SDA1/ SO1
Port F	PF5	I/O	Pull-up	0	-	0	SCL1/SI1
	PF6	I/O	Pull-up	0	-	0	SCK1
	PG0	I/O	Pull-up	0	_	0	SDA0/ SO0
Port G	PG1	I/O	Pull-up	0	-	0	SCL0/ SI0
FUILG	PG2	I/O	Pull-up	0	-	О	SCK0
	PG3	I/O	Pull-up	0	0	0	INT4

o : Exist

Note: The noise elimination width of the noise filter is approximately 30 ns under typical conditions.

^{- :} Not exist

8.1 Port Functions TMPM332FWUG

Table 8-2 Port Function List (Port H to Port K)

Port	Pin	Input/Out- put	Pull-up Pull-down	Schmitt input	Noise Filter	Program- mable Open-drain	Function pin
	PH0	I/O	Pull-up	0	-	-	TB0IN0, BOOT
D. (III	PH1	I/O	Pull-up	0	-	-	TB0IN1
Port H	PH2	I/O	Pull-up	0	-	-	TB1IN0
	PH3	I/O	Pull-up	0	-	-	TB1IN1
	PI0	I/O	Pull-up	-	-	-	TB0OUT
	PI1	I/O	Pull-up	-	-	-	TB1OUT
	PI2	I/O	Pull-up	-	-	-	TB2OUT
Port I	PI3	I/O	Pull-up	-	-	-	TB3OUT
	PI4	I/O	Pull-up	-	-	-	TB4OUT
	PI5	I/O	Pull-up	-	-	_	TB5OUT
	PJ0	I/O	Pull-up	0	0	-	INT0
	PJ1	I/O	Pull-up	0	0	-	INT1
Port J	PJ2	I/O	Pull-up	0	0	-	INT2
	PJ3	I/O	Pull-up	0	0	-	INT3
	PJ4	I/O	Pull-up	-	-	-	TB6OUT
Dodk	PK0	I/O	-	0	-	o (Note1)	CEC
Port K	PK1	I/O	Pull-up	-	-	-	SCOUT, ALARM

o : Exist

Note 1: N-ch open drain port.

Note 2: The noise elimination width of the noise filter is approximately 30 ns under typical conditions.

^{- :} Not exist

8.1.2 Port Registers Outline

The following registers need to be configured to use ports.

• PxDATA: Port x data register

To read/write port data.

PxCR: Port x output control register

To control output.

PxIE needs to be configured to control input.

• PxFRn: Port x function register n

To set functions.

An assigned function can be activated by setting "1".

• PxOD: Port x open drain control register

To control the programmable open drain.

Programmable open drain is function to be materialized pseudo-open-drain by setting the PxOD.

When PxOD is set "1", output buffer is disabled and pseudo-open-drain is materialized.

• PxPUP: Port x pull-up control register

To control program pull ups.

• PxPDN: Port x pull-down control register

To control programmable pull downs.

PxIE: Port x input control register

To control inputs.

For avoided through current, default setting prohibits inputs.

8.1 Port Functions TMPM332FWUG

8.1.3 Port States in STOP Mode

Input and output in STOP mode are enabled/disabled by the CGSTBYCR<DRVE> bit.

If PxIE or PxCR is enabled with <DRVE>=1, input or output is enabled respectively in STOP mode.If <DRVE>=0, both input and output are disabled in STOP mode except for some ports even if PxIE or PxCR are enabled.

Table 8-3 shows the pin conditions in STOP mode.

Table 8-3 Port conditions in STOP mode

	Pin Name	I/O	<drve> = 0</drve>	<drve> = 1</drve>		
Exclud-	X1, XT1	Input only	×	×		
ing port	X2, XT2	Output only	"High" Level Output	"High" Level Output		
port	X1, XT1	0				
	PA0, PB0	Input	×	Depends on PxIE[m]		
	and output is enabled (PxCR <pxmc>=1)]</pxmc>	Output	Enabled when data is valid. Disabled when data is invalid.			
Dort	PG3, PJ0 to PJ3	Input	0	0		
Port	(PxFRn <pxmfn>=1) and input is enabled</pxmfn>	Output	×	Depends on PxCR[m].		
	Other perto	Input	×	Depends on PxIE[m].		
	Other ports	Output	×	Depends on PxCR[m].		

o :Input or output enabled

Note: "x" indicates a port number, "m" a corresponding bit and "n" a function register number.

8.1.4 Precautions for Mode Transition between STOP and SLEEP

If PA1 is configured as a debug function pin of SWCLK, it prevents the low power consumption mode from being fully effective.

Configure PA1 to function as a general-purpose port if the debug function is not used.

^{× :}Input or output disabled

8.2 Port functions

This chapter describes the port registers detail.

This chapter describes only "circuit type" reading circuit configuration. For detailed circuit diagram, refer to "8.3 Block Diagrams of Ports".

8.2.1 Port A (PA0 to PA3)

The port A is a general-purpose, 4-bit input/output port. For this port, inputs and outputs can be specified in units of bits. Besides the general-purpose input/output function, the port A performs the debug interface and the debug trace output.

PA0 and PA1 are assigned as the debug interface after reset. PA0 is initialized as the SWDIO pin with input, output and pull-up enabled. PA1 is initialized as the SWCLK pin with input and pull-down enabled. Pins from PA2 to PA3 operate as general-purpose-ports, and input, output and pull-up are disabled.

- Note 1: If PA0 is configured as the SWDIO pin, output is enabled even in STOP mode regardless of the CGSTBYCR<DRVE> bit setting
- Note 2: If PA1 is configured as the SWCLK pin, it prevents the low power consumption mode from being fully effective. Configure PA1 to function as a general-purpose port if the SWCLK is not used.

8.2.1.1 Port A Circuit Type

	7	6	5	4	3	2	1	0
Туре	-	-	-	-	Т9	Т9	Т6	T12

8.2.1.2 Port A register

Base Address = 0x4000_0000

Register name		Address (Base+)	
Port A data register	PADATA	0x0000	
Port A output control register	PACR	0x0004	
Port A function register 1	PAFR1	0x0008	
Port A pull-up control register	PAPUP	0x002C	
Port A pull-down control register	PAPDN	0x0030	
Port A input control register	PAIE	0x0038	

8.2.1.3 PADATA (Port A data register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	PA3	PA2	PA1	PA0
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-4	-	R/W	Write 0.
3-0	PA3-PA0	R/W	Port A data register.

8.2.1.4 PACR (Port A output control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	PA3C	PA2C	PA1C	PA0C
After reset	0	0	0	0	0	0	0	1

Bit	Bit Symbol	Type	Function
31-8 -		R	Read as 0.
7-4 -	-	R/W	Write 0.
3-0 P/	PA3C-PA0C	R/W	Output 0: disable 1: enable

8.2.1.5 PAFR1 (Port A function register 1)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	PA3F1	PA2F1	PA1F1	PA0F1
After reset	0	0	0	0	0	0	1	1

Bit	Bit Symbol	Туре	Function
31-7	-	R	Read as 0.
6-4	-	R/W	Write 0.
3	PA3F1	R/W	0: PORT 1: TRACEDATA0
2	PA2F1	R/W	0: PORT 1: TRACECLK
1	PA1F1	R/W	0: PORT 1: SWCLK
0	PA0F1	R/W	0: PORT 1: SWDIO

8.2.1.6 PAPUP (Port A pull-up control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	PA3UP	PA2UP	-	PA0UP
After reset	0	0	0	0	0	0	0	1

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-4	-	R/W	Write 0.
3-2	PA3UP-PA2UP	R/W	Pull-up 0: Disable 1: Enable
1	-	R	Read as 0.
0	PA0UP	R/W	Pull-up 0:Disable 1:Enable

8.2.1.7 PAPDN (Port A pull-down control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	1	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	PA1DN	-
After reset	0	0	0	0	0	0	1	0

Bit	Bit Symbol	Туре	Function
31-2	_	R	Read as 0.
1	PA1DN	R/W	Pull-down 0: Disable 1: Enable
0	-	R	Read as 0.

8.2.1.8 PAIE (Port A input control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	PA3IE	PA2IE	PA1IE	PA0IE
After reset	0	0	0	0	0	0	1	1

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-4	-	R/W	Write 0.
3-0	PA3IE-PA0IE	R/W	Input 0: DIsable 1: Enable

8.2 Port functions TMPM332FWUG

8.2.2 Port B (PB0)

The port B is a general-purpose, 1-bit input/output port. Besides the general-purpose input/output function, the port B performs the debug interface.

Reset configures PB0 as debug interface.PB0 is initialized as the SWV pin with output enabled.

Note:If PB0 is configured as the SWV pin, output is enabled even in STOP mode regardless of the CGSTBYCR<DRVE> bit setting.

8.2.2.1 Port B Circuit Type

	7	6	5	4	3	2	1	0
Туре	-	-	-	-	-	-	-	T11

8.2.2.2 Port B Register

Base Address = 0x4000_0040

Register name		Address (Base+)
Port B data register	PBDATA	0x0000
Port B output control register	PBCR	0x0004
Port B function register 1	PBFR1	0x0008
Port B pull-up control register	PBPUP	0x002C
Port B input control register	PBIE	0x0038

8.2.2.3 PBDATA (Port B data register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	-	PB0
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-1	-	R/W	Write 0.
0	PB0	R/W	Port B data register.

8.2.2.4 PBCR (Port B output control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	1	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	1	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	-	PB0C
After reset	0	0	0	0	0	0	0	1

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-1	-	R/W	Write 0.
0	PB0C	R/W	Output 0: Disable 1: Enable

8.2 Port functions TMPM332FWUG

8.2.2.5 PBFR1 (Port B function register 1)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	-	PB0F1
After reset	0	0	0	0	0	1	1	1

Bit	Bit Symbol	Туре	Function
31-3	-	R	Read as 0.
2-1	_	R/W	Write 0.
0	PB0F1	R/W	0: PORT
			1: SWV

8.2.2.6 PBPUP (Port B pull-up control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	-	PB0UP
After reset	0	0	0	0	0	1	1	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-1	_	R/W	Write 0.
0	PB0UP	R/W	Pull-up 0: Disable
			1: Enable

8.2.2.7 PBIE (Port B input control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	-	PB0IE
After reset	0	0	0	0	0	1	1	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-1	-	R/W	Write 0.
0	PB0IE	R/W	Input 0: Disable 1: Enable

8.2 Port functions TMPM332FWUG

8.2.3 Port D (PD0 to PD7)

The port D is an 8-bit input port. Besides the general-purpose input function, the port D receives an analog input of the AD converter and a 16-bit timer input.

Reset initializes all bits of the port D as general-purpose input ports with input and pull-up disabled.

Set the PDFR1 and PDIE when you use the port D as input pins of the 16-bit timer.

To use the Port D as an analog input of the AD converter, disable input on PDIE and disable pull-up on PDPUP.

Note: Unless you use all the bits of port D as analog input pins, conversion accuracy may be reduced. Be sure to verify that this causes no problem on your system.

8.2.3.1 Port D Circuit Type

	7	6	5	4	3	2	1	0
Туре	T17	T17	T17	T17	T18	T18	T18	T18

8.2.3.2 Port D Register

Base Address = 0x4000_00C0

Register name		Address (Base+)
Port D data register	PDDATA	0x0000
Port D function register 1	PDFR1	0x0008
Port D pull-up control register	PDPUP	0x002C
Port D input control register	PDIE	0x0038

8.2.3.3 PDDATA (Port D data register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	PD7	PD6	PD5	PD4	PD3	PD2	PD1	PD0
After reset	1	1	1	1	1	1	1	1

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-0	PD7-PD0	R	Port D data register.

8.2.3.4 PDFR1 (Port D function register 1)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	PD3F1	PD2F1	PD1F1	PD0F1
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-4	_	R	Read as 0.
3	PD3F1	R/W	0: PORT
			1: TB6IN1
2	PD2F1	R/W	0: PORT
			1: TB6IN0
1	PD1F1	R/W	0: PORT
			1: TB5IN1
0	PD0F1	R/W	0: PORT
			1: TB5IN0

8.2.3.5 PDPUP (Port D pull-up control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	PD7UP	PD6UP	PD5UP	PD4UP	PD3UP	PD2UP	PD1UP	PD0UP
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-0	PD7UP-PD0UP	R/W	Pull-up
			0: Disable
			1: Enable

8.2.3.6 PDIE (Port D input control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	PD7IE	PD6IE	PD5IE	PD4IE	PD3IE	PD2IE	PD1IE	PD0IE
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	_	R	Read as 0.
7-0	PD7IE-PD0IE	R/W	Input 0: Disable
			1: Enable

8.2.4 Port E (PE0 to PE6)

The port E is a general-purpose, 7-bit input/output port. For this port, inputs and outputs can be specified in units of bits.

Besides the general-purpose port function, the port E performs the serial interface function and the remote control signal preprocessor input function.

Reset initializes all bits of the port E as general-purpose ports with input, output and pull-up disabled.

The port E has two types of function register. If you use the port E as a general-purpose port, set "0" to the corresponding bit of the two registers. If you use the port E as other than a general-purpose port, set "1" to the corresponding bit of the function register. Do not set "1" to the both function registers at the same time.

8.2.4.1 Port E Circuit Type

	7	6	5	4	3	2	1	0
Туре	-	T16	T4	T10	T4	T16	T4	T10

8.2.4.2 Port E Register

Base Address = 0x4000_0100

Register name		Address (Base+)
Port E data register	PEDATA	0x0000
Port E output control register	PECR	0x0004
Port E function register 1	PEFR1	0x0008
Port E function register 2	PEFR2	0x000C
Port E open drain control register	PEOD	0x0028
Port E pull-up control register	PEPUP	0x002C
Port E input control register	PEIE	0x0038

8.2.4.3 PEDATA (Port E data register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	PE6	PE5	PE4	PE3	PE2	PE1	PE0
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-7	-	R	Read as 0.
6-0	PE6-PE0	R/W	Port E data register

8.2.4.4 PECR (Port E output control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	PE6C	PE5C	PE4C	PE3C	PE2C	PE1C	PE0C
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-7	-	R	Read as 0.
6-0	PE6C-PE0C	R/W	Output
			0: Disable
			1: Enable

8.2.4.5 PEFR1(Port E function register 1)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	PE6F1	PE5F1	PE4F1	PE3F1	PE2F1	PE1F1	PE0F1
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-7	-	R	Read as 0.
6	PE6F1	R/W	0: PORT
			1: SCLK1
5	PE5F1	R/W	0: PORT
			1: RXD1
4	PE4F1	R/W	0: PORT
			1: TXD1
3	PE3F1	R/W	0: PORT
			1: RXIN
2	PE2F1	R/W	0: PORT
			1: SCLK0
1	PE1F1	R/W	0: PORT
			1: RXD0
0	PE0F1	R/W	0: PORT
			1: TXD0

8.2.4.6 PEFR2(Port E function register 2)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	PE6F2	-	-	-	PE2F2	-	-
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-7	-	R	Read as 0.
6	PE6F2	R/W	0: PORT 1: CTS1
5-3	-	R	Read as 0.
2	PE2F2	R/W	0: PORT 1: CTS0
1-0	-	R	Read as 0.

8.2.4.7 PEOD (Port E open drain control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	PE6OD	PE5OD	PE4OD	PE3OD	PE2OD	PE10D	PE0OD
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-7	_	R	Read as 0.
6-0	PE6OD- PE0OD	R/W	0: CMOS 1: Open-drain

8.2.4.8 PEPUP (Port E pull-up control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	PE6UP	PE5UP	PE4UP	PE3UP	PE2UP	PE1UP	PE0UP
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-7	-	R	Read as 0.
6-0	PE6UP-PE0UP	R/W	Pull-up
			0: Disable
			1: Enable

8.2.4.9 PEIE (Port E input control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	PE6IE	PE5IE	PE4IE	PE3IE	PE2IE	PE1IE	PE0IE
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-7	-	R	Read as 0.
6-0	PE6IE-PE0IE	R/W	Input
			0: Disable
			1: Enable

8.2.5 Port F (PF4 to PF6)

The port F is a general-purpose, 3-bit input/output port. For this port, inputs and outputs can be specified in units of bits. Besides the general-purpose port function, the port F performs the functions of the serial bus interface.

Reset initializes all bits of the port F as general-purpose ports with input, output and pull-up disabled.

The port F has function register. If you use the port F as a general-purpose port, set "0" to the corresponding bit of the register. If you use the port F as other than a general-purpose port, set "1" to the corresponding bit of the function register.

To use the external interrupt input for releasing STOP mode, select this function in the PFFR1 and enable input in the PFIE register.

These settings enable the interrupt input even if the CGSTBYCR<DRVE> bit in the clock/mode control block is set to stop driving of pins during STOP mode.

Note: In modes other than STOP mode, interrupt input is enabled regardless of the PFFR register setting if input is enabled in PxIE. Make sure to disable unused interrupts when programming the device.

8.2.5.1 Port F Circuit Type

	7	6	5	4	3	2	1	0
Туре	-	T13	T13	T13	-	-	-	-

8.2.5.2 Port F Register

Base Address = 0x4000_0140

Register name		Address (Base+)
Port F data register	PFDATA	0x0000
Port F output control register	PFCR	0x0004
Port F function register 1	PFFR1	0x0008
Reserved	-	0x000C
Port F open drain control register	PFOD	0x0028
Port F pull-up control register	PFPUP	0x002C
Port F input control register	PFIE	0x0038

Note: Access to the "reserved" areas is prohibited.

8.2.5.3 PFDATA (Port F data register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	PF6	PF5	PF4	-	-	-	-
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7	-	R/W	Write 0.
6-4	PF6-PF4	R/W	Port F data register
3-0	-	R/W	Write 0.

8.2.5.4 PFCR (Port F output control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	PF6C	PF5C	PF4C	-	-	-	-
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7	-	R/W	Write 0.
6-4	PF6C-PF4C	R/W	Output
			0: Disable
			1: Enable
3-0	-	R/W	Write 0.

8.2 Port functions TMPM332FWUG

8.2.5.5 PFFR1(Port F function register 1)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	PF6F1	PF5F1	PF4F1	-	-	-	-
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7	-	R/W	Write 0.
6	PF6F1	R/W	0: PORT
			1: SCK1
5	PF5F1	R/W	0: PORT
			1: SI1/SCL1
4	PF4F1	R/W	0: PORT
			1: SO1/SDA1
3-0	-	R/W	Write 0.

8.2.5.6 PFOD (Port F open drain control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	PF6OD	PF5OD	PF4OD	-	-	-	-
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7	_	R/W	Write 0.
6-4	PF6OD-PF4OD	R/W	0: CMOS
			1: Open-drain
3-0	_	R/W	Write 0.

8.2.5.7 PFPUP (Port F pull-up control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	1	1	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	ı	-	-	1	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	PF6UP	PF5UP	PF4UP	-	-	-	-
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	_	R	Read as 0.
7	_	R/W	Write 0.
6-4	PF6UP-PF4UP	R/W	Pull-up
			0: Disable
			1: Enable
3-0	_	R/W	Write 0.

8.2.5.8 PFIE (Port F input control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	PF6IE	PF5IE	PF4IE	-	-	-	-
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7	_	R/W	Write 0.
6-4	PF6IE-PF4IE	R/W	Input 0: Disable 1: Enable
3-0	-	R/W	Write 0.

8.2.6 Port G (PG0 to PG3)

The port G is a general-purpose, 4-bit input/output port. For this port, inputs and outputs can be specified in units of bits. Besides the general-purpose port function, the port G performs the functions of the serial bus interface and the external interrupt input.

Reset initializes all bits of the port G as general-purpose ports with input, output and pull-up disabled.

To use the external interrupt input for releasing STOP mode, select function in the PGFR register and enable input in the PGIE register.

These settings enable the interrupt input even if the CGSTBYCR<DRVE> bit in the clock/mode control block is set to stop driving of pins during STOP mode.

Note: In modes other than STOP mode, interrupt input is enabled regardless of the PGFR register setting if input is enabled in PGIE. Make sure to disable unused interrupts when programming the device.

8.2.6.1 Port G Circuit Type

	7	6	5	4	3	2	1	0
Туре	-	-	-	-	T8	T13	T13	T13

8.2.6.2 Port G Register

Base Address = 0x4000_0180

Register name	Address (Base+)		
Port G data register	PGDATA	0x0000	
Port G output control register	PGCR	0x0004	
Port G function register 1	PGFR1	0x0008	
Reserved	-	0x0010	
Port G open drain control register	PGOD	0x0028	
Port G pull-up control register	PGPUP	0x002C	
Port G input control register	PGIE	0x0038	

Note: Access to the "reserved" areas is prohibited.

8.2.6.3 PGDATA (Port G data register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	PG3	PG2	PG1	PG0
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-4	_	R/W	Write 0.
3-0	PG3-PG0	R/W	Port G data register.

8.2.6.4 PGCR (Port G output control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	PG3C	PG2C	PG1C	PG0C
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-4	-	R/W	Write 0.
3-0	PG3C-PG0C	R/W	Output 0: Disable 1: Enable

8.2.6.5 PGFR1(Port G function register 1)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	PG3F1	PG2F1	PG1F1	PG0F1
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	_	R	Read as 0.
7-4	-	R/W	Write 0.
3	PG3F1	R/W	0: PORT
			1: INT4
2	PG2F1	R/W	0: PORT
			1: SCK0
1	PG1F1	R/W	0: PORT
			1: SI0/SCL0
0	PG0F1	R/W	0: PORT
			1: SO0/SDA0

8.2.6.6 PGOD (Port G open drain control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	PG3OD	PG2OD	PG10D	PG0OD
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-4	_	R/W	Write 0.
3-0	PG3OD-	R/W	0: CMOS
	PG0OD		1: Open-drain

8.2.6.7 PGPUP (Port G pull-up control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	PG3UP	PG2UP	PG1UP	PG0UP
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-4	-	R/W	Write 0.
3-0	PG3UP- PG0UP	R/W	Pull-up 0: Disable 1: Enable

8.2.6.8 PGIE (Port G input control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	PG3IE	PG2IE	PG1IE	PG0IE
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-4	_	R/W	Write 0.
3-0	PG3IE-PG0IE	R/W	Input 0: Disable 1: Enable

8.2 Port functions TMPM332FWUG

8.2.7 Port H (PH0 to PH3)

The port H is a general-purpose, 4-bit input/output port. For this port, inputs and outputs can be specified in units of bits. Besides the general-purpose port function, the port H performs the functions of the 16-bit timer input and the operation mode setting.

While a reset signal is in "Low" state, the $\lceil PH0/\overline{BOOT} \rfloor$ input and pull-up are enabled. At the rising edge of the reset signal, if $\lceil PH0 \rfloor$ is "High", the device enters single mode and boots from the on-chip flash memory. If $\lceil PH0 \rfloor$ is "Low", the device enters single BOOT mode and boots from the internal BOOT program. For details of single boot mode, refer to "Flash Memory Operation".

Reset initializes PH0 to PH3 bits of the port H as general-purpose ports with input and output disabled. Pull-up is enabled for PH0 and disabled for PH1 to PH3.

8.2.7.1 Port H Circuit Type

	7	6	5	4	3	2	1	0
Туре	-	-	-	-	Т3	Т3	Т3	T5

8.2.7.2 Port H Register

Base Address = 0x4000_01C0

Register name		Address (Base+)
Port H data register	PHDATA	0x0000
Port H output control register	PHCR	0x0004
Port H function register 1	PHFR1	0x0008
Reserved	-	0x0010
Port H pull-up control register	PHPUP	0x002C
Port H input control register	PHIE	0x0038

Note: Access to the "reserved" areas is prohibited.

8.2.7.3 PHDATA (Port H data register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	PH3	PH2	PH1	PH0
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-4	-	R/W	Write 0.
3-0	PH3-PH0	R/W	Port H data register.

8.2.7.4 PHCR (Port H output control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	PH3C	PH2C	PH1C	PH0C
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-4	-	R/W	Write 0.
3-0	PH3C-PH0C	R/W	Output 0: Disable 1: Enable

8.2.7.5 PHFR1(Port H function register 1)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	PH3F1	PH2F1	PH1F1	PH0F1
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-4	-	R/W	Write 0.
3	PH3F1	R/W	0: PORT
			1: TB1IN1
2	PH2F1	R/W	0: PORT
			1: TB1IN0
1	PH1F1	R/W	0: PORT
			1: TB0IN1
0	PH0F1	R/W	0: PORT
			1: TB0IN0

8.2.7.6 PHPUP (Port H pull-up control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	PH3UP	PH2UP	PH1UP	PH0UP
After reset	0	0	0	0	0	0	0	1

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-4	-	R/W	Write 0.
3-0	PH3UP-PH0UP	R/W	Pull-up
			0: Disable
			1: Enable

8.2.7.7 PHIE (Port H input control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	PH3IE	PH2IE	PH1IE	PH0IE
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-4	_	R/W	Write 0.
3-0	PH3IE-PH0IE	R/W	Input 0: Disable 1: Enable

8.2 Port functions TMPM332FWUG

8.2.8 Port I (PI0 to PI5)

The port I is a general-purpose, 6-bit input/output port. For this port, inputs and outputs can be specified in units of bits. Besides the general-purpose port function, the port I performs the 16-bit timer input/output function.

Reset initializes all bits of the port I as general-purpose ports with input, output and pull-up disabled.

8.2.8.1 Port I Circuit Type

	7	6	5	4	3	2	1	0
Туре	-	-	Т9	Т9	Т9	Т9	Т9	Т9

8.2.8.2 Port I Register

Base Address = 0x4000_0200

Register name	Address (Base+)	
Port I data register	PIDATA	0x0000
Port I output control register	PICR	0x0004
Port I function register 1	PIFR1	0x0008
Reserved	-	0x0010
Port I pull-up control register	PIPUP	0x002C
Port I input control register	PIIE	0x0038

Note: Access to the "reserved" areas is prohibited.

8.2.8.3 PIDATA (Port I data register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	PI5	PI4	PI3	PI2	PI1	PI0
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-6	-	R/W	Write 0.
5-0	PI5-PI0	R/W	Port I data register.

8.2.8.4 PICR (Port I output control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	PI5C	PI4C	PI3C	PI2C	PI1C	PI0C
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-6	-	R/W	Write 0.
5-0	PI5C-PI0C	R/W	Output 0: Disable 1: Enable

8.2.8.5 PIFR1(Port I function register 1)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	PI5F1	PI4F1	PI3F1	PI2F1	PI1F1	PI0F1
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-6	-	R/W	Write 0.
5	PI5F1	R/W	0: PORT 1: TB5OUT
4	PI4F1	R/W	0: PORT 1: TB4OUT
3	PI3F1	R/W	0: PORT 1: TB3OUT
2	PI2F1	R/W	0: PORT 1: TB2OUT
1	PI1F1	R/W	0: PORT 1: TB10UT
0	PI0F1	R/W	0: PORT 1: TB0OUT

8.2.8.6 PIPUP (Port I pull-up control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	1	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	PI5UP	PI4UP	PI3UP	PI2UP	PI1UP	PIOUP
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-6	-	R/W	Write 0.
5-0	PI5UP-PI0UP	R/W	Pull-up 0: Disable
			1: Enable

8.2.8.7 PIIE (Port I input control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	PI5IE	PI4IE	PI3IE	PI2IE	PI1IE	PI0IE
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-6	-	R/W	Write 0.
5-0	PI5IE-PI0IE	R/W	Input 0: Disable 1: Enable

8.2 Port functions TMPM332FWUG

8.2.9 Port J (PJ0 to PJ4)

The port J is a general-purpose, 5-bit input/output port. For this port, inputs and outputs can be specified in units of bits. Besides the general-purpose port function, the port J performs the functions of the 16-bit timer output and the external interrupt input.

Reset initializes all bits of the port J as to perform as the general-purpose ports with input, output and pull-up disabled.

To use the external interrupt input for releasing STOP mode, select this function in the PJFR1 register and enable input in the PJIE register.

These settings enable the interrupt input even if the CGSTBYCR<DRVE> bit in the clock/mode control block is set to stop driving of pins during STOP mode.

Note: In modes other than STOP mode, interrupt input is enabled regardless of the PJFR register setting if input is enabled in PJIE. Make sure to disable unused interrupts when programming the device.

8.2.9.1 Port J Circuit Type

	7	6	5	4	3	2	1	0
Туре	-	-	-	Т9	T7	T7	T7	T7

8.2.9.2 Port J Register

Base Address = 0x4000_0240

Register name	Address (Base+)	
Port J data register	PJDATA	0x0000
Port J output control register	PJCR	0x0004
Port J function register 1	PJFR1	0x0008
Reserved	-	0x0010
Port J pull-up control register	PJPUP	0x002C
Port J input control register	PJIE	0x0038

Note: Access to the "reserved" areas is prohibited.

8.2.9.3 PJDATA (Port J data register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	PJ4	PJ3	PJ2	PJ1	PJ0
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-5	-	R/W	Write 0
4-0	PJ4-PJ0	R/W	Port J data register.

8.2.9.4 PJCR (Port J output control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	PJ4C	PJ3C	PJ2C	PJ1C	PJ0C
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-5	-	R/W	Write 0
4-0	PJ4C-PJ0C	R/W	Output 0 : Disable 1 : Enable

8.2.9.5 PJFR1(Port J function register 1)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	PJ4F1	PJ3F1	PJ2F1	PJ1F1	PJ0F1
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	T-	R	Read as 0.
7-5	-	R/W	Write 0.
4	PJ4F1	R/W	0: PORT 1: TB6OUT
3	PJ3F1	R/W	0: PORT 1: INT3
2	PJ2F1	R/W	0: PORT 1: INT2
1	PJ1F1	R/W	0: PORT 1: INT1
0	PJ0F1	R/W	0: PORT 1: INT0

8.2.9.6 PJPUP (Port J pull-up control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	PJ4UP	PJ3UP	PJ2UP	PJ1UP	PJ0UP
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-5	_	R/W	Write 0.
4-0	PJ4UP-PJ0UP	R/W	Pull-up
			0: Disable
			1: Enable

8.2.9.7 PJIE (Port J input control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	PJ4IE	PJ3IE	PJ2IE	PJ1IE	PJ0IE
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-5	_	R/W	Write 0.
4-0	PJ4IE-PJ0IE	R/W	Input 0: Disable 1: Enable

8.2 Port functions TMPM332FWUG

8.2.10 Port K (PK0 to PK1)

The port K is a general-purpose, 2-bit input/output port. For this port, inputs and outputs can be specified in units of bits. Besides the general-purpose port function, the port K performs the functions of the CEC input, the clock output and the alarm output.

Reset initializes all bits of the port K as general-purpose ports with input, output and pull-up disabled.

Note: PK0 is an N-ch open drain port.

8.2.10.1 Port K Circuit Type

	7	6	5	4	3	2	1	0
Туре	-	-	-	-	-	-	T15	T14

8.2.10.2 Port K Register

Base Address = 0x4000_0280

Register name	Address (Base+)	
Port K data register	PKDATA	0x0000
Port K output control register	PKCR	0x0004
Port K function register 1	PKFR1	0x0008
Port K function register 2	PKFR2	0x000C
Port K pull-up control register	PKPUP	0x002C
Port K input control register	PKIE	0x0038

8.2.10.3 PKDATA (Port K data register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	PK1	PK0
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-3	-	R	Read as 0.
2	-	R/W	Write 0.
1-0	PK1-PK0	R/W	Port K data register.

8.2.10.4 PKCR (Port K output control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	PK1C	PK0C
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-3	-	R	Read as 0.
2	_	R/W	Write 0.
1-0	PK1C-PK0C	R/W	Output 0: Disable 1: Enable

8.2 Port functions TMPM332FWUG

8.2.10.5 PKFR1(Port K function register 1)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	PK1F1	PK0F1
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-3	_	R	Read as 0.
2	_	R/W	Write 0.
1	PK1F1	R/W	0: PORT
			1: SCOUT
0	PK0F1	R/W	0: PORT
			1: CEC

8.2.10.6 PKFR2(Port K function register 2)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	PK1F2	-
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-2	-	R	Read as 0.
1	PK1F2	R/W	0: PORT 1: ALARM
0	-	R	Read as 0.

8.2.10.7 PKPUP (Port K pull-up control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	PK1UP	-
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-3	-	R	Read as 0.
2	-	R/W	Write 0.
1	PK1UP	R/W	Pull-up
			0: Disable
			1: Enable
0	-	R	Read as 0.

8.2 Port functions TMPM332FWUG

8.2.10.8 PKIE (Port K input control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	PK1IE	PK0IE
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-3	-	R	Read as 0.
2	_	R/W	Write 0.
1-0	PK1IE-PK0IE	R/W	Input 0: Disable 1: Enable

TMPM332FWUG

8.3 Block Diagrams of Ports

8.3.1 Port Types

The ports are classified as shown below. Please refer to the following pages for the block diagrams of each port type.

Dot lines in the figure indicate the part of the equivalent circuit described in the "Block diagrams of ports".

Table 8-4 Function Lists

Туре	GP Port	Function 1	Function 2	Analog	Pull-up	Pull-down	Programma- ble open-drain	Note
Т3	I/O	Input	-	-	R	-	-	
T4	I/O	Input	-	-	R	-	0	
T5	I/O	Input	-	-	NoR	-	-	BOOT input enabled during reset
Т6	I/O	Input	-	-	-	NoR	-	
T7	I/O	Input (int)	ı	ı	R	-	-	
Т8	I/O	Input (int)	-	-	R	-	0	
Т9	I/O	Output	-	-	R	-	-	
T10	I/O	Output	1	ı	R	-	0	
T11	I/O	Output	ı	-	R	-	-	Function output triggered by enable signal
T12	I/O	I/O	-	-	NoR	-	-	Function output triggered by enable signal
T13	I/O	I/O	-	-	R	-	0	
T14	I/O	I/O	-	-	-	-	-	Nch open drain port
T15	I/O	Output	Output	ı	R	-	-	
T16	I/O	I/O	Input	-	R	-	0	
T17	Input	-	-	0	R	-	-	
T18	Input	Input	-	0	R	-	-	

int: Interrupt input

NoR: Unaffected by reset.

^{-:} Not exist

o: Exist

R: Forced disable during reset.




Figure 8-1 Port Type T3

8.3.3 Type T4




Figure 8-2 Port Type T4

8.3.4 Type5 T5




Figure 8-3 Port Type T5

8.3.5 Type T6




Figure 8-4 Port Type T6




Figure 8-5 Port Type T7

8.3.7 Type T8




Figure 8-6 Port Type T8

8.3.8 Type T9




Figure 8-7 Port Type T9

8.3.9 Type T10




Figure 8-8 Port Type T10




Figure 8-9 Port Type T11

8.3.11 Type T12




Figure 8-10 Port Type T12

8.3.12 Type T13




Figure 8-11 Port Type T13

8.3.13 Type T14




Figure 8-12 Port Type T14




Figure 8-13 Port Type T15

8.3.15 Type T16




Figure 8-14 Port Type T16




Figure 8-15 Port Type T17

8.3.17 Type T18




Figure 8-16 Port TypeT18

8.4 Appendix (Port setting List)

The following table shows the register setting for each function.

Initialization of the ports where the [•] does not exist in the "After reset" field is set to "0" for all register settings. Setting for the bit "x" can be arbitrarily-specified.

8.4.1 Port A Setting

Table 8-5 Port Setting List (Port A)

Pin	Port Type	Function	After reset	PACR	PAFR1	PAPUP	PAPDN	PAIE
		Input Port		0	0	х	0	1
PA0	T12	Output Port		1	0	×	0	0
		SWDIO(I/O)		1	1	1	0	1
		Input Port		0	0	0	х	1
PA1	PA1 T6	Output Port		1	0	0	x	0
		SWCLK (Input)		0	1	0	1	1
		Input Port		0	0	х	0	1
PA2	Т9	Output Port		1	0	х	0	0
		TRACECLK (Output)		1	1	х	0	0
		Input Port		0	0	х	0	1
PA3	PA3 T9	Output Port		1	0	х	0	0
		TRACEDATA0(Output)		1	1	×	0	0

8.4.2 Port B Setting

Table 8-6 Port Setting List (Port B)

Pin	Port Type	Function	After re- set	PBCR	PBFR1	PBPUP	PBIE
		Input Port		0	0	х	1
PB0	T11	Output Port		1	0	х	0
		SWV (Output)		1	1	0	0

8.4.3 Port D Setting

Table 8-7 Port Setting List (Port D)

Pin	Port Type	Function	After re- set	PDFR1	PDPUP	PDIE
		Input Port		0	х	1
PD0	T18	TB5IN0(Input)		1	x	1
		Analog Input		x	0	0
		Input Port		0	х	1
PD1	T18	TB5IN1(Input)		1	х	1
		Analog Input		х	0	0
		Input Port		0	х	1
PD2	T18	TB6IN0(Input)		1	х	1
		Analog Input		х	0	0
		Input Port		0	х	1
PD3	T18	TB6IN1(Input)		1	х	1
		Analog Input		х	0	0
PD4	T17	Input Port		0	х	1
PD4	117	Analog Input		x	0	0
PD5	T17	Input Port		0	х	1
PD5	117	Analog Input		х	0	0
PD6	T17	Input Port		0	Х	1
PD6	117	Analog Input		х	0	0
PD7	T17	Input Port		0	х	1
PD/	117	Analog Input		х	0	0

8.4.4 Port E Setting

Table 8-8 Port Setting List (Port E)

Pin	Port Type	Function	After re- set	PECR	PEFR1	PEFR2	PEOD	PEPUP	PEIE
	PE0 T10	Input Port		0	0	0	х	х	1
PE0		Output Port		1	0	0	х	х	0
		TXD0(Output)		1	1	0	х	х	0
		Input Port		0	0	0	х	х	1
PE1	T4	Output Port		1	0	0	х	х	0
		RXD0(Input)		0	1	0	х	x	1
		Input Port		0	0	0	х	х	1
		Output Port		1	0	0	х	x	0
PE2	T16	SCLK0(Input)		0	1	0	х	х	1
		SCLK0(Output)		1	1	0	х	х	0
		CTS0(Input)		0	0	1	х	х	1
		Input Port		0	0	0	х	х	1
PE3	T4	Output Port		1	0	0	х	х	0
		RXIN(Input)		0	1	0	х	х	1
		Input Port		0	0	0	х	х	1
PE4	T10	Output Port		1	0	0	х	x	0
		TXD1(Output)		1	1	0	х	x	0
		Input Port		0	0	0	х	х	1
PE5	T4	Output Port		1	0	0	х	x	0
		RXD1(Input)		0	1	0	х	х	1
		Input Port		0	0	0	х	х	1
		Output Port		1	0	0	х	х	0
PE6	T16	SCLK1(Input)		0	1	0	х	×	1
		SCLK1(Output)		1	1	0	х	х	0
		CTS1(Input)		0	0	1	х	х	1

8.4.5 Port F Setting

Table 8-9 Port Setting List (Port F)

Pin	Port Type	Function	After re- set	PFCR	PFFR1	PFFR2	PFOD	PFPUP	PFIE
		Input Port		0	0	0	Х	х	1
PF4	T13	Output Port		1	0	0	х	х	0
PF4	113	SO1(Output)		1	1	0	х	х	0
		SDA1(Input/Output)		1	1	0	1	х	1
		Input Port		0	0	0	х	х	1
PF5	T13	Output Port		1	0	0	х	х	0
PFS	113	SI1(Input)		0	1	0	х	х	1
		SCL1(Input/Output)		1	1	0	1	х	1
		Input Port		0	0	0	х	х	1
DEC	PF6 T13	Output Port		1	0	0	х	х	0
PF6		SCK1(Input)		0	1	0	Х	х	1
		SCK1(Output)		1	1	0	Х	Х	0

8.4.6 Port G Setting

Table 8-10 Port Setting List (Port G)

Pin	Port Type	Function	After re- set	PGCR	PGFR1	PGOD	PGPUP	PGIE
		Input Port		0	0	х	х	1
B00	T40	Output Port		1	0	х	х	0
PG0	T13	SO0(Output)		1	1	×	х	0
		SDA0(Input/Output)		1	1	1	х	1
		Input Port		0	0	x	х	1
BO4	T40	Output Port		1	0	х	х	0
PG1	T13	SI0(Input)		0	1	x	х	1
		SCL0(Input/Output)		1	1	1	х	1
		Input Port		0	0	x	х	1
B00	T40	Output Port		1	0	х	х	0
PG2	T13	SCK0(Input)		0	1	х	х	1
		SCK0(Output)		1	1	х	х	0
		Input Port		0	0	х	х	1
PG3	Т8	Output Port		1	0	х	х	0
		INT4(Input)		0	1	Х	х	1

8.4.7 Port H Setting

Table 8-11 Port Setting List (Port H)

Pin	Port Type	Function	After re- set	PHCR	PHFR1	PHPUP	PHIE
		Input Port		0	0	x	1
PH0	T5	Output Port		1	0	х	0
		TB0IN0(Input)		0	1	х	1
		Input Port		0	0	х	1
PH1	Т3	Output Port		1	0	х	0
		TB0IN1(Input)		0	1	х	1
		Input Port		0	0	х	1
PH2	Т3	Output Port		1	0	х	0
		TB1IN0(Input)		0	1	х	1
		Input Port		0	0	х	1
PH3	PH3 T3	Output Port		1	0	х	0
		TB1IN1(Input)		0	1	х	1

Note: The PH0 input and pull-up are enabled and act as $\overline{\text{BOOT}}$ input pin while a $\overline{\text{RESET}}$ is in "Low" state.

8.4.8 Port I Setting

Table 8-12 Port Setting List (Port I)

Pin	Port Type	Function	After re- set	PICR	PIFR1	PIPUP	PIIE
		Input Port		0	0	х	1
PI0	Т9	Output Port		1	0	х	0
		TB0OUT(Output)		1	1	х	0
		Input Port		0	0	x	1
PI1	Т9	Output Port		1	0	х	0
		TB1OUT(Output)		1	1	х	0
		Input Port		0	0	х	1
PI2	Т9	Output Port		1	0	х	0
		TB2OUT(Output)		1	1	х	0
		Input Port		0	0	х	1
PI3	Т9	Output Port		1	0	х	0
		TB3OUT(Output)		1	1	х	0
		Input Port		0	0	×	1
PI4	Т9	Output Port		1	0	х	0
		TB4OUT(Output)		1	1	х	0
		Input Port		0	0	х	1
PI5	Т9	Output Port		1	0	х	0
		TB5OUT(Output)		1	1	х	0

8.4.9 Port J Setting

Table 8-13 Port Setting List (Port J)

pin	Port Type	Function	After re- set	PJCR	PJFR1	PJPUP	PJIE
		Input Port		0	0	х	1
PJ0	Т7	Output Port		1	0	х	0
		INT0(Input)		0	1	х	1
		Input Port		0	0	х	1
PJ1	T7	Output Port		1	0	х	0
		INT1(Input)		0	1	х	1
		Input Port		0	0	х	1
PJ2	T7	Output Port		1	0	х	0
		INT2(Input)		0	1	х	1
		Input Port		0	0	х	1
PJ3	T7	Output Port		1	0	х	0
		INT3(Input)		0	1	х	1
		Input Port		0	0	х	1
PJ4	Т9	Output Port		1	0	х	0
		TB6OUT(Output)		1	1	Х	0

8.4.10 Port K Setting

Table 8-14 Port Setting List (Port K)

Pin	Port Type	Function	After re- set	PKCR	PKFR1	PKFR2	PKPUP	PKIE
		Input Port		0	0	0	0	1
PK0	T14	Output Port		1	0	0	0	0
		CEC (Input/Output)		1	1	0	0	1
		Input Port		0	0	0	х	1
DICA	T45	Output Port		1	0	0	х	0
PK1 T15	SCOUT (Output)		1	1	0	х	0	
		ALARM (Output)		1	0	1	х	0

Note: PK0 is an N-ch open drain port.

8. Input/Output Ports

8.4 Appendix (Port setting List) TMPM332FWUG

TOSHIBA TMPM332FWUG

9. 16-bit Timer/Event Counters(TMRB)

9.1 Outline

TMRB operate in the following four operation modes:

- 16-bit interval timer mode
- 16-bit event counter mode
- 16-bit programmable pulse generation mode (PPG)
- · Timer synchronous mode

The use of the capture function allows TMRB to perform the following three measurements.

- Frequency measurement
- · Pulse width measurement
- · Time difference measurement

In the following explanation of this section, "x" indicates a channel number.

9.2 Differences in the Specifications

TMPM332FWUG contains 10-channel of TMRB.

Each channel functions independently and the channels operate in the same way except for the differences in their specification as shown in Table 9-1.

Some of the channels can put the capture trigger and the synchronous start trigger on other channels.

- 1. The flip-flop output of TMRB 7 through TMRB 9 can be used as the capture trigger of other channels.
 - TB7OUT → available for TMRB0 through TMRB1
 - TB8OUT → available for TMRB2 through TMRB4
 - TB9OUT → available for TMRB5 through TMRB6
- 2. The start trigger of the timer synchronous mode (with TBxRUN)
 - TMRB0 → can start TMRB0 through TMRB3 synchronously
 - TMRB4 → can start TMRB4 through TMRB7 synchronously

Table 9-1 Differences in the Specifications of TMRB Modules

Specification		Extern	al pins		Trigger function	on between timers	Inte	errupt
Channel		nal clock/ gger input pins	Timer flip-f	lop output pin	Capture	Synchronous	Capture	TMRB
Channel	Signal	Port (Pin number)	Signal	Port (Pin number)	trigger	start trigger channel	interrupt	interrupt
TMRB0	TB0IN0 TB0IN1	PH0 (20) PH1 (21)	TB0OUT	PI0 (24)	TB7OUT	-	INTCAP00 INTCAP01	INTTB0
TMRB1	TB1IN0 TB1IN1	PH2 (22) PH3 (23)	TB1OUT	PI1 (25)	TB7OUT	TMRB0	INTCAP10 INTCAP11	INTTB1
TMRB2	1	-	TB2OUT	PI2 (26)	TB8OUT	TMRB0	ı	INTTB2
TMRB3	-	-	TB3OUT	PI3 (30)	TB8OUT	TMRB0	-	INTTB3
TMRB4	-	-	TB4OUT	PI4 (34)	TB8OUT	_	-	INTTB4
TMRB5	TB5IN0 TB5IN1	PD0 (59) PD1 (60)	TB5OUT	PI5 (35)	TB9OUT	TMRB4	INTCAP50 INTCAP51	INTTB5
TMRB6	TB6IN0 TB6IN1	PD2 (61) PD3 (62)	TB6OUT	PJ4 (57)	TB9OUT	TMRB4	INTCAP60 INTCAP61	INTTB6
TMRB7	-	-	-	-	-	TMRB4	-	INTTB7
TMRB8		-		-		-		INTTB8
TMRB9	-	-	-	-	_	-	-	INTTB9

9.3 Configuration

Each channel consists of a 16-bit up-counter, two 16-bit timer registers (double-buffered), two 16-bit capture registers, two comparators, a capture input control, a timer flip-flop and its associated control circuit. Timer operation modes and the timer flip-flop are controlled by a register.




Figure 9-1 TMRBx Block Diagram(x= 0 to 9)

9.4 Registers TMPM332FWUG

9.4 Registers

9.4.1 Register list according to channel

The following table shows the register names and addresses of each channel.

Channel x	Base Address
Channel0	0x4001_0000
Channel1	0x4001_0040
Channel2	0x4001_0080
Channel3	0x4001_00C0
Channel4	0x4001_0100
Channel5	0x4001_0140
Channel6	0x4001_0180
Channel7	0x4001_01C0
Channel8	0x4001_0200
Channel9	0x4001_0240

Register name(x=	=0 to 9)	Address(Base+)
Enable register	TBxEN	0x0000
RUN register	TBxRUN	0x0004
Control register	TBxCR	0x0008
Mode register	TBxMOD	0x000C
Flip-flop control register	TBxFFCR	0x0010
Status register	TBxST	0x0014
Interrupt mask register	TBxIM	0x0018
Up counter capture register	TBxUC	0x001C
Timer register 0	TBxRG0	0x0020
Timer register 1	TBxRG1	0x0024
Capture register 0	TBxCP0	0x0028
Capture register 1	TBxCP1	0x002C

9.4.2 TBxEN (Enable register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	TBEN	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7	TBEN	R/W	TMRBx operation
			0: Disabled
			1: Enabled
			Specifies the TMRB operation. When the operation is disabled, no clock is supplied to the other registers in the TMRB module. This can reduce power consumption. (This disables reading from and writing to the other registers except TBxEN register.)
			To use the TMRB, enable the TMRB operation (set to "1") before programming each register in the TMRB module. If the TMRB operation is executed and then disabled, the settings will be maintained in each register.
6-0	-	R	Read as 0.

9.4.3 TBxRUN(RUN register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	TBPRUN	-	TBRUN
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-3	_	R	Read as 0.
2	TBPRUN	R/W	Prescaler operation
			0: Stop & clear
			1: Count
1	_	R	Read as 0.
0	TBRUN	R/W	Count operation
			0: Stop & clear
			1: Count

9.4.4 TBxCR(Control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	TBWBF	-	TBSYNC	-	I2TB	-	-	-
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7	TBWBF	R/W	Double Buffer
			0: Disabled
			1: Enabled
6	-	R/W	Write 0.
5	TBSYNC	R/W	Synchronous mode switching
			0: individual (unit of channel)
			1: synchronous
4	-	R	Read as 0.
3	I2TB	R/W	Operation at IDLE mode
			0: Stop
			1:Operation
2-0	-	R	Read as 0.

9.4.5 TBxMOD(Mode register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	TBCP	TBO	CPM	TBCLE	TB	CLK
After reset	0	0	1	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-7	-	R	Read as 0.
6	-	R/W	Write 0.
5	ТВСР	W	Capture control by software 0: Capture by software 1: Don't care When "0" is written, the capture register 0 (TBxCP0) takes count value. Read as 1.
4-3	TBCPM[1:0]	R/W	Capture timing 00: Disable Capture timing 01: TBxIN0↑ TBxIN1↑ Takes count values into capture register 0 (TBxCP0) upon rising of TBxIN0 pin input. Takes count values into capture register 1 (TBxCP1) upon rising of TBxIN1 pin input. 10: TBxIN0↑ TBxIN0↓ Takes count values into capture register 0 (TBxCP0) upon rising of TBxIN0 pin input. Takes count values into capture register 1 (TBxCP1) upon falling of TBxIN0 pin input. 11: TBxOUT↑ TBxOUT↓ Takes count values into capture register 0 (TBxCP0) upon rising of 16-bit timer match output (TBxOUT) and into capture register 1 (TBxCP1) upon falling of TBxOUT. (TMRB0 and TMRB1:TB7OUT, TMRB2 through TMRB4:TB8OUT, TMRB5 and TMRB6:TB9OUT).
2	TBCLE	R/W	Up-counter control 0: Disables clearing of the up-counter. 1: Enables clearing of the up-counter. Clears and controls the up-counter. When "0" is written, it disables clearing of the up-counter. When "1" is written, it clears up counter when there is a match with Timer Regsiter1 (TBxRG1).
1-0	TBCLK[1:0]	R/W	Selects the TMRBx source clock. 00: TBxIN0 pin input 01: φT1 10: φT4 11: φT16

9.4.6 TBxFFCR(Flip-flop control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	TBC1T1	TBC0T1	TBE1T1	TBE0T1	TBF	F0C
After reset	1	1	0	0	0	0	1	1

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-6	-	R	Read as 1.
5	TBC1T1	R/W	TBxFF0 reverse trigger when the up-counter value is taken into the TBxCP1. 0: Disable trigger
			Enable trigger By setting "1", the timer-flip-flop reverses when the up-counter value is taken into the Capture register 1 (TBxCP1).
4	TBC0T1	R/W	TBxFF0 reverse trigger when the up-counter value is taken into the TBxCP0. 0: Disable trigger 1: Enable trigger By setting "1", the timer-flip-flop reverses when the up-counter value is taken into the Capture register 0 (TBxCP0).
3	TBE1T1	R/W	TBxFF0 reverse trigger when the up-counter value is matched with TBxRG1. 0: Disable trigger 1: Enable trigger By setting "1", the timer-flip-flop reverses when the up-counter value is matched with the Timer register 1 (TBxRG1).
2	TBE0T1	R/W	TBxFF0 reverse trigger when the up-counter value is matched with TBxRG0. 0: Disable trigger 1: Enable trigger By setting "1", the timer-flip-flop reverses when an up-counter value is matched with the Timer register 0 (TBxRG0).
1-0	TBFF0C[1:0]	R/W	TBxFF0 control 00: Invert Reverses the value of TBxFF0 (reverse by using software). 01: Set Sets TBxFF0 to "1". 10: Clear Clears TBxFF0 to "0". 11: Don't care * This is always read as "11".

9.4.7 TBxST(Status register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	INTTBOF	INTTB1	INTTB0
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-3	-	R	Read as 0.
2	INTTBOF	R	Overflow flag 0:No overflow occurs 1:Overflow occurs When an up-counter is overflow, "1" is set.
1	INTTB1	R	Match flag (TBxRG1) 0:No detection of a mach 1:Detects a match with TBxRG1 When a match with the timer register 1 (TBxRG1) is detected,"1" is set.
0	INTTB0	R	Match flag (TBxRG0) 0:No match is detected 1:Detects a match with TBxRG0 When a match with the timer register 0 (TBxRG0) is detected, "1" is set.

Note 1: The factors only which is not masked by TBxIM output interrupt request to the CPU. Even if the mask setting is done, the flag is set.

Note 2: The flag is cleared by reading the TBxST register.To clear the flag, TBxST register should be read.

9.4.8 TBxIM(Interrupt mask register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	TBIMOF	TBIM1	TBIM0
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-3	-	R	Read as 0.
2	TBIMOF	R/W	Overflow interrupt mask
			0:Disable
			1:Enable
			Sets the up-counter overflow interrupt to disable or enable.
1	ТВІМ1	R/W	Match interrupt mask (TBxRG1)
			0:Disable
			1:Enable
			Sets the match interrupt mask with the Timer register 1 (TBxRG1) to enable or disable.
0	ТВІМ0	R/W	Match interrupt mask (TBxRG0)
			0:Disable
			1:Enable
			Sets the match interrupt mask with the Timer register 0 (TBxRG0) to enable or disable.

9.4.9 TBxUC(Up counter capture register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol				ТВ	UC			
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol				ТВ	UC			
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-16	-	R	Read as 0.
15-0	TBUC[15:0]	R	Captures a value by reading up-counter out. If TBxUC is read, current up-counter value can be captured.

9.4 Registers TMPM332FWUG

9.4.10 TBxRG0(Timer register 0)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol			-	TBI	RG0			
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol		-		TBI	RG0			
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-16	-	R	Read as 0.
15-0	TBRG0[15:0]	R/W	Sets a value comparing to the up-counter.

9.4.11 TBxRG1(Timer register 1)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol				TBF	RG1			
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol				TBF	RG1			
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-16	_	R	Read as 0.
15-0	TBRG1[15:0]	R/W	Sets a value comparing to the up-counter.

9.4.12 TBxCP0(Capture register 0)

	31	30	29	28	27	26	25	24			
bit symbol	-	-	-	-	-	-	-	-			
After reset	0	0	0	0	0	0	0	0			
	23	22	21	20	19	18	17	16			
bit symbol	-	-	-	-	-	-	-	-			
After reset	0	0	0	0	0	0	0	0			
	15	14	13	12	11	10	9	8			
bit symbol				TBO	CP0						
After reset	Undefined										
	7	6	5	4	3	2	1	0			
bit symbol		TBCP0									
After reset	Undefined										

Bit	Bit Symbol	Туре	Function
31-16	-	R	Read as 0.
15-0	TBCP0[15:0]	R	A value captured from the up-counter is read.

9.4.13 TBxCP1(Capture register 1)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol				TBO	CP1			
After reset	Undefined							
	7	6	5	4	3	2	1	0
bit symbol				TBO	CP1			
After reset	Undefined							

Bit	Bit Symbol	Туре	Function
31-16	-	R	Read as 0.
15-0	TBCP1[15:0]	R	A value captured from the up-counter is read.

9.5 Description of Operations for Each Circuit

The channels operate in the same way, except for the differences in their specifications as shown in Table 9-1.

9.5.1 Prescaler

There is a 4-bit prescaler to generate the source clock for up-counter UC.

The prescaler input clock ϕ T0 is fperiph/1, fperiph/2, fperiph/4, fperiph/8, fperiph/16 or fperiph/32 selected by CGSYSCR<PRCK[2:0]> in the CG. The peripheral clock, fperiph, is either fgear, a clock selected by CGSYSCR<FPSEL> in the CG, or fc, which is a clock before it is divided by the clock gear.

The operation or the stoppage of a prescaler is set with TBxRUN<TBPRUN> where writing "1" starts counting and writing "0" clears and stops counting. Table 9-2 and Table 9-3 show prescaler output clock resolutions.

Table 9-2 Prescaler Output Clock Resolutions(fc = 40MHz)

Select	Clock gear value	Select	Pre	scaler output clock fund	ction
peripheral clock CGSYSCR <fpsel></fpsel>	CGSYSCR <gear[2:0]></gear[2:0]>	prescaler clock CGSYSCR <prck[2:0]></prck[2:0]>	φΤ1	φΤ4	φΤ16
		000 (fperiph/1)	fc/2¹ (0.05 µs)	fc/2³ (0.2 µs)	fc/2 ⁵ (0.8 µs)
		001 (fperiph/2)	fc/2² (0.1 µs)	fc/2 ⁴ (0.4 µs)	fc/2 ⁶ (1.6 µs)
	000 (5-)	010 (fperiph/4)	fc/2³ (0.2 µs)	fc/2 ⁵ (0.8 µs)	fc/2 ⁷ (3.2 μs)
	000 (fc)	011 (fperiph/8)	fc/2 ⁴ (0.4 µs)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)
		100 (fperiph/16)	fc/2 ⁵ (0.8 µs)	fc/2 ⁷ (3.2 μs)	fc/2º (12.8 µs)
		101 (fperiph/32)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)	fc/2 ¹⁰ (25.6 µs)
		000 (fperiph/1)	fc/2² (0.1 µs)	fc/2 ⁴ (0.4 µs)	fc/2 ⁶ (1.6 µs)
		001 (fperiph/2)	fc/2 ³ (0.2 µs)	fc/2 ⁵ (0.8 µs)	fc/2 ⁷ (3.2 µs)
	100 (fc/2)	010 (fperiph/4)	fc/2 ⁴ (0.4 µs)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)
		011 (fperiph/8)	fc/2 ⁵ (0.8 µs)	fc/2 ⁷ (3.2 μs)	fc/2º (12.8 µs)
		100 (fperiph/16)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)	fc/2 ¹⁰ (25.6 µs)
0 (5)		101 (fperiph/32)	fc/2 ⁷ (3.2 µs)	fc/29 (12.8 µs)	fc/2 ¹¹ (51.2 µs)
0 (fgear)		000 (fperiph/1)	fc/2 ³ (0.2 µs)	fc/2 ⁵ (0.8 µs)	fc/2 ⁷ (3.2 µs)
		001 (fperiph/2)	fc/2 ⁴ (0.4 µs)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)
	404 (5-14)	010 (fperiph/4)	fc/2 ⁵ (0.8 µs)	fc/2 ⁷ (3.2 μs)	fc/2º (12.8 µs)
	101 (fc/4)	011 (fperiph/8)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)	fc/2 ¹⁰ (25.6 µs)
		100 (fperiph/16)	fc/2 ⁷ (3.2 µs)	fc/2 ⁹ (12.8 µs)	fc/2 ¹¹ (51.2 µs)
		101 (fperiph/32)	fc/28 (6.4 µs)	fc/2 ¹⁰ (25.6 µs)	fc/2 ¹² (102.4 µs)
		000 (fperiph/1)	fc/2 ⁴ (0.4 µs)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)
		001 (fperiph/2)	fc/2 ⁵ (0.8 µs)	fc/2 ⁷ (3.2 μs)	fc/2 ⁹ (12.8 µs)
	440 (5-10)	010 (fperiph/4)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)	fc/2 ¹⁰ (25.6 µs)
	110 (fc/8)	011 (fperiph/8)	fc/2 ⁷ (3.2 µs)	fc/2 ⁹ (12.8 µs)	fc/2 ¹¹ (51.2 µs)
		100 (fperiph/16)	fc/28 (6.4 µs)	fc/2 ¹⁰ (25.6 µs)	fc/2 ¹² (102.4 µs)
		101 (fperiph/32)	fc/2 ⁹ (12.8 μs)	fc/2 ¹¹ (51.2 µs)	fc/2 ¹³ (204.8 µs)

Table 9-2 Prescaler Output Clock Resolutions(fc = 40MHz)

Select	Clock gear value	Select	Pres	scaler output clock fund	ction
peripheral clock CGSYSCR <fpsel></fpsel>	CGSYSCR <gear[2:0]></gear[2:0]>	prescaler clock CGSYSCR <prck[2:0]></prck[2:0]>	φΤ1	φΤ4	φT16
		000 (fperiph/1)	fc/2¹ (0.05 µs)	fc/2³ (0.2 µs)	fc/2 ⁵ (0.8 µs)
		001 (fperiph/2)	fc/2² (0.1 µs)	fc/2 ⁴ (0.4 µs)	fc/2 ⁶ (1.6 μs)
	000 (fa)	010 (fperiph/4)	fc/2 ³ (0.2 µs)	fc/2 ⁵ (0.8 µs)	fc/2 ⁷ (3.2 μs)
	000 (fc)	011 (fperiph/8)	fc/2 ⁴ (0.4 µs)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)
		100 (fperiph/16)	fc/2 ⁵ (0.8 µs)	fc/2 ⁷ (3.2 µs)	fc/2 ⁹ (12.8 μs)
		101 (fperiph/32)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)	fc/2 ¹⁰ (25.6 µs)
		000 (fperiph/1)	-	fc/2³ (0.2 µs)	fc/2 ⁵ (0.8 μs)
		001 (fperiph/2)	fc/2² (0.1 µs)	fc/2 ⁴ (0.4 µs)	fc/2 ⁶ (1.6 µs)
	400 (5: (0)	010 (fperiph/4)	fc/2³ (0.2 µs)	fc/2 ⁵ (0.8 µs)	fc/2 ⁷ (3.2 μs)
	100 (fc/2)	011 (fperiph/8)	fc/2 ⁴ (0.4 µs)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)
		100 (fperiph/16)	fc/2 ⁵ (0.8 µs)	fc/2 ⁷ (3.2 µs)	fc/2 ⁹ (12.8 μs)
4 (5)		101 (fperiph/32)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)	fc/2 ¹⁰ (25.6 µs)
1 (fc)		000 (fperiph/1)	-	fc/2³ (0.2 µs)	fc/2 ⁵ (0.8 μs)
		001 (fperiph/2)	-	fc/2 ⁴ (0.4 µs)	fc/2 ⁶ (1.6 µs)
	404 (5:14)	010 (fperiph/4)	fc/2 ³ (0.2 µs)	fc/2 ⁵ (0.8 µs)	fc/2 ⁷ (3.2 µs)
	101 (fc/4)	011 (fperiph/8)	fc/2 ⁴ (0.4 µs)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)
		100 (fperiph/16)	fc/2 ⁵ (0.8 μs)	fc/2 ⁷ (3.2 µs)	fc/2 ⁹ (12.8 μs)
		101 (fperiph/32)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)	fc/2 ¹⁰ (25.6 µs)
		000 (fperiph/1)	-	-	fc/2 ⁵ (0.8 µs)
		001 (fperiph/2)	-	fc/24 (0.4 µs)	fc/2 ⁶ (1.6 μs)
	440 (5-10)	010 (fperiph/4)	-	fc/2 ⁵ (0.8 µs)	fc/2 ⁷ (3.2 μs)
	110 (fc/8)	011 (fperiph/8)	fc/2 ⁴ (0.4 µs)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)
		100 (fperiph/16)	fc/2 ⁵ (0.8 μs)	fc/2 ⁷ (3.2 μs)	fc/2 ⁹ (12.8 µs)
		101 (fperiph/32)	fc/2 ⁶ (1.6 μs)	fc/28 (6.4 µs)	fc/2 ¹⁰ (25.6 µs)

Note 1: The prescaler output clock ϕTn must be selected so that ϕTn < fsys is satisfied (so that ϕTn is slower than fsys).

Note 2: Do not change the clock gear while the timer is operating.

Note 3: "-" denotes a setting prohibited.

Table 9-3 Prescaler Output Clock Resolutions(fc = 32MHz)

Select	Clock gear value	Select	Pres	scaler output clock fund	ction
peripheral clock CGSYSCR <fpsel></fpsel>	CGSYSCR <gear[2:0]></gear[2:0]>	prescaler clock CGSYSCR <prck[2:0]></prck[2:0]>	φΤ1	φΤ4	φT16
		000 (fperiph/1)	fc/21 (0.0625 µs)	fc/2³ (0.25 µs)	fc/2 ⁵ (1.0 µs)
		001 (fperiph/2)	fc/2² (0.125 µs)	fc/2 ⁴ (0.5 µs)	fc/2 ⁶ (2.0 µs)
	000 (f-)	010 (fperiph/4)	fc/2³ (0.25 µs)	fc/2 ⁵ (1.0 μs)	fc/2 ⁷ (4.0 µs)
	000 (fc)	011 (fperiph/8)	fc/2 ⁴ (0.5 μs)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)
		100 (fperiph/16)	fc/2 ⁵ (1.0 μs)	fc/2 ⁷ (4.0 μs)	fc/2 ⁹ (16.0 µs)
		101 (fperiph/32)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)	fc/2 ¹⁰ (32.0 µs)
		000 (fperiph/1)	fc/2 ² (0.125 µs)	fc/2 ⁴ (0.5 µs)	fc/2 ⁶ (2.0 μs)
		001 (fperiph/2)	fc/2³ (0.25 µs)	fc/2 ⁵ (1.0 μs)	fc/2 ⁷ (4.0 µs)
		010 (fperiph/4)	fc/2 ⁴ (0.5 µs)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)
	100 (fc/2)	011 (fperiph/8)	fc/2 ⁵ (1.0 µs)	fc/2 ⁷ (4.0 µs)	fc/2 ⁹ (16.0 µs)
		100 (fperiph/16)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)	fc/2 ¹⁰ (32.0 µs)
2,5		101 (fperiph/32)	fc/2 ⁷ (4.0 μs)	fc/2 ⁹ (16.0 µs)	fc/2 ¹¹ (64.0 µs)
0 (fgear)		000 (fperiph/1)	fc/2 ³ (0.25 µs)	fc/2 ⁵ (1.0 µs)	fc/2 ⁷ (4.0 µs)
		001 (fperiph/2)	fc/2 ⁴ (0.5 µs)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)
	404 (5: (4)	010 (fperiph/4)	fc/2 ⁵ (1.0 µs)	fc/2 ⁷ (4.0 µs)	fc/2 ⁹ (16.0 µs)
	101 (fc/4)	011 (fperiph/8)	fc/2 ⁶ (2.0 μs)	fc/28 (8.0 µs)	fc/2 ¹⁰ (32.0 µs)
		100 (fperiph/16)	fc/2 ⁷ (4.0 µs)	fc/2 ⁹ (16.0 µs)	fc/2 ¹¹ (64.0 µs)
		101 (fperiph/32)	fc/28 (8.0 µs)	fc/2 ¹⁰ (32.0 µs)	fc/2 ¹² (128.0 µs)
		000 (fperiph/1)	fc/2 ⁴ (0.5 μs)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)
		001 (fperiph/2)	fc/2 ⁵ (1.0 μs)	fc/2 ⁷ (4.0 µs)	fc/2 ⁹ (16.0 µs)
	140 (5 (0)	010 (fperiph/4)	fc/2 ⁶ (2.0 μs)	fc/28 (8.0 µs)	fc/2 ¹⁰ (32.0 µs)
	110 (fc/8)	011 (fperiph/8)	fc/2 ⁷ (4.0 µs)	fc/2 ⁹ (16.0 µs)	fc/2 ¹¹ (64.0 µs)
		100 (fperiph/16)	fc/28 (8.0 µs)	fc/2 ¹⁰ (32.0 µs)	fc/2 ¹² (128.0 µs)
		101 (fperiph/32)	fc/2 ⁹ (16.0 µs)	fc/2 ¹¹ (64.0 µs)	fc/2 ¹³ (256.0 µs)

Table 9-3 Prescaler Output Clock Resolutions(fc = 32MHz)

Select	Clock gear value	Select	Pres	scaler output clock fund	ction
peripheral clock CGSYSCR <fpsel></fpsel>	CGSYSCR <gear[2:0]></gear[2:0]>	prescaler clock CGSYSCR <prck[2:0]></prck[2:0]>	φΤ1	φΤ4	φT16
		000 (fperiph/1)	fc/21 (0.0625 µs)	fc/2³ (0.25 µs)	fc/2 ⁵ (1.0 μs)
		001 (fperiph/2)	fc/2² (0.125 µs)	fc/2 ⁴ (0.5 µs)	fc/2 ⁶ (2.0 μs)
	000 (f-)	010 (fperiph/4)	fc/2³ (0.25 μs)	fc/2 ⁵ (1.0 μs)	fc/2 ⁷ (4.0 μs)
	000 (fc)	011 (fperiph/8)	fc/2 ⁴ (0.5 µs)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)
		100 (fperiph/16)	fc/2 ⁵ (1.0 µs)	fc/2 ⁷ (4.0 µs)	fc/2 ⁹ (16.0 µs)
		101 (fperiph/32)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)	fc/2 ¹⁰ (32.0 µs)
		000 (fperiph/1)	-	fc/2 ³ (0.25 µs)	fc/2 ⁵ (1.0 μs)
		001 (fperiph/2)	fc/2² (0.125 µs)	fc/2 ⁴ (0.5 µs)	fc/2 ⁶ (2.0 µs)
	100 (5: (0)	010 (fperiph/4)	fc/2³ (0.25 μs)	fc/2 ⁵ (1.0 μs)	fc/2 ⁷ (4.0 μs)
	100 (fc/2)	011 (fperiph/8)	fc/2 ⁴ (0.5 µs)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)
		100 (fperiph/16)	fc/2 ⁵ (1.0 µs)	fc/2 ⁷ (4.0 µs)	fc/2 ⁹ (16.0 µs)
4 (5)		101 (fperiph/32)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)	fc/2 ¹⁰ (32.0 µs)
1 (fc)		000 (fperiph/1)	-	fc/23 (0.25 µs)	fc/2 ⁵ (1.0 μs)
		001 (fperiph/2)	-	fc/2 ⁴ (0.5 µs)	fc/2 ⁶ (2.0 µs)
	404 (5-14)	010 (fperiph/4)	fc/2³ (0.25 μs)	fc/2 ⁵ (1.0 μs)	fc/2 ⁷ (4.0 μs)
	101 (fc/4)	011 (fperiph/8)	fc/2 ⁴ (0.5 µs)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)
		100 (fperiph/16)	fc/2 ⁵ (1.0 µs)	fc/2 ⁷ (4.0 µs)	fc/2 ⁹ (16.0 µs)
		101 (fperiph/32)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)	fc/2 ¹⁰ (32.0 µs)
		000 (fperiph/1)	-	-	fc/2 ⁵ (1.0 μs)
		001 (fperiph/2)	-	fc/2 ⁴ (0.5 μs)	fc/2 ⁶ (2.0 µs)
	140 (5-(0)	010 (fperiph/4)	-	fc/2 ⁵ (1.0 μs)	fc/2 ⁷ (4.0 μs)
	110 (fc/8)	011 (fperiph/8)	fc/2 ⁴ (0.5 μs)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)
		100 (fperiph/16)	fc/2 ⁵ (1.0 µs)	fc/2 ⁷ (4.0 μs)	fc/2 ⁹ (16.0 μs)
		101 (fperiph/32)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)	fc/2 ¹⁰ (32.0 µs)

Note 1: The prescaler output clock ϕTn must be selected so that ϕTn < fsys is satisfied (so that ϕTn is slower than fsys).

Note 2: Do not change the clock gear while the timer is operating.

Note 3: "-" denotes a setting prohibited.

9.5.2 Up-counter (UC)

UC is a 16-bit binary counter.

· Source clock

UC source clock, specified by TBxMOD<TBCLK[1:0]>, can be selected from either three types $-\phi$ T1, ϕ T4 and ϕ T16 - of prescaler output clock or the external clock of the TBxIN0 pin.

Count start/ stop

Counter operation is specified by TBxRUN<TBRUN>. UC starts counting if <TBRUN> = "1", and stops counting and clears counter value if <TBRUN> = "0".

- Timing to clear UC
 - 1. When a match is detected

By setting TBxMOD<TBCLE> = "1", UC is cleared if when the comparator detects a match between counter value and the value set in TBxRG1. UC operates as a free-running counter if TBxMOD<TBCLE> = "0".

2. When UC stops

UC stops counting and clears counter value if TBxRUN<TBRUN> = "0".

· UC overflow

If UC overflow occurs, the INTTBx overflow interrupt is generated.

9.5.3 Timer registers (TBxRG0, TBxRG1)

TBxRG0 and TBxRG1 are registers for setting values to compare with up-counter values and two registers are built into each channel. If the comparator detects a match between a value set in this timer register and that in a UC up-counter, it outputs the match detection signal.

TBxRG0 and TBxRG1 are consisted of the double-buffered configuration which are paired with register buffers. The double buffering is disabled in the initial state.

Controlling double buffering disable or enable is specified by TBxCR < TBWBF > bit. If < TBWBF > = "0", the double buffering becomes disable. If < TBWBF > = "1", it becomes enable. When the double buffering is enabled, a data transfer from the register buffer to the timer register (TBxRG0/1) is done in the case that UC is matched with TBxRG1. When the counter is stopped even if double buffering is enabled, the double buffering operates as a single buffer, and an immediate data can be written to the TBxRG0 and TBxRG1.

9.5.4 Capture

This is a circuit that controls the timing of latching values from the UC up-counter into the TBxCP0 and TBxCP1 capture registers. The timing with which to latch data is specified by TBxMOD<TBCPM[1:0]>.

Software can also be used to import values from the UC up-counter into the capture register; specifically, UC values are taken into the TBxCP0 capture register each time "0" is written to TBxMOD<TBCP>.

9.5.5 Capture registers (TBxCP0, TBxCP1)

This register captures an up-counter (UC) value.

9.5.6 Up-counter capture register (TBxUC)

Other than the capturing functions shown above, the current count value of the UC can be captured by reading the TBxUC registers.

9.5.7 Comparators (CP0, CP1)

This register compares with the up-counter (UC) and the value setting of the Timer Register (TBxRG0 and TBxRG1) to detect whether there is a match or not. If a match is detected, INTTBx is generated.

9.5.8 Timer Flip-flop (TBxFF0)

The timer flip-flop (TBxFF0) is reversed by a match signal from the comparator and a latch signal to the capture registers. It can be enabled or disabled to reverse by setting the TBxFFCR<TBC1T1, TBC0T1, TBE1T1, TBE0T1>.

The value of TBxFF0 becomes undefined after a reset. The flip-flop can be reversed by writing "00" to TBxFFCR<TBFF0C[1:0]>. It can be set to "1" by writing "01," and can be cleared to "0" by writing "10."

The value of TBxFF0 can be output to the Timer output pin (TBxOUT). If the timer output is performed, the corresponding port settings must be programmed beforehand.

9.5.9 Capture interrupt (INTCAPx0, INTCAPx1)

Interrupts INTCAPx0 and INTCAPx1 can be generated at the timing of latching values from the UC up-counter into the TBxCP0 and TBxCP1 capture registers. The interrupt timing is specified by the CPU.

9.6 Description of Operations for Each Mode

9.6.1 16-bit Interval Timer Mode

In the case of generating constant period interrupt, set the interval time to the Timer register (TBxRG1) to generate the INTTBx interrupt.

		7	6	5	4	3	2	1	0	
TBxEN	←	1	Χ	Χ	Χ	Χ	Χ	Χ	Χ	Enables TMRBx operation.
TBxRUN	←	Χ	Χ	Χ	Χ	Χ	0	Χ	0	Stops count operation.
Interrupt Set-Enable Register	←	*	*	*	*	*	*	*	*	Permits INTTBx interrupt by setting corresponding bit to "1".
TBxFFCR	←	Χ	Χ	0	0	0	0	1	1	Disable to TBxFF0 reverse trigger
TBxMOD	←	Χ	0	1	0	0	1	*	*	Changes to prescaler output clock as input clock. Specifies
							(** =	01, 10	0, 11)	Capture function to disable.
TBxRG1	←	*	*	*	*	*	*	*	*	Specifies a time interval. (16 bits)
	←	*	*	*	*	*	*	*	*	
TBxRUN	←	*	*	*	*	*	1	Χ	1	Starts TMRBx.

Note:X; Don't care -; No change

9.6.2 16-bit Event Counter Mode

It is possible to make it the event counter by using an input clock as an external clock (TBxIN0 pin input).

The up-counter counts up on the rising edge of TBxIN0 pin input. It is possible to read the count value by capturing value using software and reading the captured value.

		7	6	5	4	3	2	1	0	
TBxEN	←	1	Χ	Χ	Χ	Χ	Χ	Χ	Χ	Enables TMRBx operation.
TBxRUN	←	Χ	Χ	Χ	Χ	Χ	0	Χ	0	Stops count operation.
PxIE[m]	←								1	Allocates corresponding part to TDVINO
PxFR1[m]	←								1	Allocates corresponding port toTBxIN0.
TBxFFCR	←	Χ	Χ	0	0	0	0	1	1	Disables to TBxFF0 reverse trigger
TBxMOD	←	Χ	0	1	0	0	0	0	0	Changes toTBxIN0 as an input clock
TBxRUN	←	*	*	*	*	*	1	Χ	1	Starts TMRBx.
TBxMOD	←	Χ	0	0	0	0	0	0	0	Software capture is done.

Note 1: m: corresponding bit of port

Note 2: X; Don't care -; No change

9.6.3 16-bit PPG (Programmable Pulse Generation) Output Mode

Square waves with any frequency and any duty (programmable square waves) can be output. The output pulse can be either low-active or high-active.

Programmable square waves can be output from the TBxOUT pin by triggering the timer flip-flop (TBxFF) to reverse when the set value of the up-counter (UC) matches the set values of the timer registers (TBxRG0 and TBxRG1). Note that the set values of TBxRG0 and TBxRG1 must satisfy the following requirement:

(Set value of TBxRG0) < (Set value of TBxRG1)




Figure 9-2 Example of Output of Programmable Pulse Generation (PPG)

In this mode, by enabling the double buffering of TBxRG0, the value of register buffer 0 is shifted into TBxRG0 when the set value of the up-counter matches the set value of TBxRG1. This facilitates handling of small duties.




Figure 9-3 Register Buffer Operation

The block diagram of this mode is shown below.




Figure 9-4 Block Diagram of 16-bit PPG Mode

Each register in the 16-bit PPG output mode must be programmed as listed below.

		7	6	5	4	3	2	1	0	
TBxEN	←	1	Χ	Χ	Χ	Χ	Х	Χ	X	Enables TMRBx operation.
TBxRUN	←	Χ	Χ	Χ	Χ	Χ	0	Χ	0	Stops count operation.
TBxCR	←	0	0	-	Χ	-	Χ	Χ	X	Disables double buffering.
TBxRG0	←	*	*	*	*	*	*	*	*	Specifies a duty. (16 bits)
	←	*	*	*	*	*	*	*	*	
TBxRG1	←	*	*	*	*	*	*	*	*	Specifies a cycle. (16 bits)
	←	*	*	*	*	*	*	*	*	
TBxCR	←	1	0	Χ	0	0	0	0	0	Enables the TBxRG0 double buffering.
										(Changes the duty/cycle when the INTTBx interrupt is generated)
TBxFFCR	←	X	Х	0	0	1	1	1	0	Specifies to trigger TBxFF0 to reverse when a match with TBxRG0 or TBxRG1 is detected, and sets the initial value of TBxFF0 to "0."
TBxMOD	←	Χ	0	1	0	0	1	*	*	Designates the prescaler output clock as the input clock,and
							(** =	01, 10	0, 11)	disables the capture function.
PxCR[m]	←								1	Allocates corresponding port to TBxOUT.
PxFR1[m]	\leftarrow								1	Allocates corresponding port to TBXOOT.
TBxRUN	\leftarrow	*	*	*	*	*	1	Χ	1	Starts TMRBx.

Note 1: m: corresponding bit of port

Note 2: X; Don't care -; No change

9.6.4 Timer synchronous mode

This mode enables the timers to start synchronously.

If the mode is used with PPG output, the output can be applied to drive a motor.

TMRB is consisted of two pairs of 4-channel TMRB. If one channel starts, remaining 3 channels can be start synchronously. In the TMPM332FWUG, the following combinations allow to use.

Start trigger channel (Master channel)	Synchronous operation channel (Slave channel)
TMRB0	TMRB1, TMRB2, TMRB3
TMRB4	TMRB5, TMRB6, TMRB7

Use of the timer synchronous mode is specified in TBxCR<TBSYNC> bit.

- <TBSYNC> = "0" : Timer operates individually.
- <TBSYNC> = "1" : Timers operates synchronously.

Set "0" to the <TBSYNC> bit in the master channel.

If <TBSYNC>= "1" is set in the slave channel, the start timing is synchronized with master channel start timing. Setting of start timing for TBxRUN<TBPRUN, TBRUN> bit in the slave channel is not required.

9.7 Applications using the Capture Function

The capture function can be used to develop many applications, including those described below:

- 1. One-shot pulse output triggered by an external pulse
- 2. Frequency measurement
- 3. Pulse width measurement
- 4. Time difference measurement

9.7.1 One-shot pulse output triggered by an external pulse

One-shot pulse output triggered by an external pulse is carried out as follows:

The 16-bit up-counter is made to count up by putting it in a free-running state using the prescaler output clock. An external pulse is input through the TBxIN0 pin. A trigger is generated at the rising of the external pulse by using the capture function and the value of the up-counter is taken into the capture registers (TBxCP0).

The CPU must be programmed so that an interrupt INTCAPx0 is generated at the rising of an external trigger pulse. This interrupt is used to set the timer registers (TBxRG0) to the sum of the TBxCP0 value (c) and the delay time (d), (c + d), and set the timer registers (TBxRG1) to the sum of the TBxRG0 values and the pulse width (p) of one-shot pulse, (c + d + p).[TBxRG1 change must be completed before the next match.]

In addition, the timer flip-flop control registers(TBxFFCR<TBE1T1, TBE0T1>) must be set to "11". This enables triggering the timer flip-flop (TBxFF0) to reverse when TBxUC matches TBxRG0 and TBxRG1. This trigger is disabled by the INTTBx interrupt after a one-shot pulse is output.

Symbols (c), (d) and (p) used in the text correspond to symbols c, d and p in "Figure 9-5 One-shot Pulse Output (With Delay)".




Figure 9-5 One-shot Pulse Output (With Delay)

The followings show the settings in the case that 2 ms width one-shot pulse is output after 3ms by triggering TBxIN0 input at the rising edge. (ΦT1 is selected for counting.)

Changes source clock to ΦT1. Fetches a count value into the TBxCP0 at the rising edge of TBxIN0.

		7	6	5	4	3	2	1	0	
[Main processing] Capture	settii	ng by	TBxII	۷0						
PxIE[m]	←								1	Allegates corresponding part to TDVINO
PxFR1[m]	←								1	Allocates corresponding port to TBxIN0.
TBxEN	←	1	Χ	Х	Χ	Χ	Χ	Χ	Χ	Enables TMRBx operation.
TBxRUN	←	Χ	Χ	Χ	Χ	Χ	0	Χ	0	Stops count operation.
TBxMOD	←	Х	0	1	0	1	0	0	1	Changes source clock to Φ T1. Fetches a count value into the TBxCP0 at the rising edge of TBxIN0.
TBxFFCR	←	Χ	Χ	0	0	0	0	1	0	Clears TBxFF0 reverse trigger and disables.
PxCR[m]	←								1	Allegates corresponding part to TDVOLIT
PxFR1[m]	←								1	Allocates corresponding port toTBxOUT.
Interrupt Set-Enable Register	←	*	*	*	*	*	*	*	*	Permits to generate interrupts specified by INTCAPx0 interrupt corresponding bit by setting to "1".
TBxRUN	←	*	*	*	*	*	1	Χ	1	Starts the TMRBx module.
[Processing of INTCAPx0	interr	upt s	ervice	routir	ne] Pu	ılse o	utput	setting	9	
TBxRG0	←	*	*	*	*	*	*	*	*	Sets count value. (TBxCAP0 + 3ms/ΦT1)
TBxRG1	←	*	*	*	*	*	*	*	*	Sets count value.(TBxCAP0 + (3+2)ms/ΦT1)
TBxFFCR	←	Χ	Χ	-	-	1	1	-	-	Reverses TBxFF0 if TBxRG0 consistent with TBxRG1.
TBxIM	←	Χ	Χ	Х	Χ	Χ	1	0	1	Masks except TBxRG1 correspondence interrupt.
Interrupt Set-Enable Register	←	*	*	*	*	*	*	*	*	Permits to generate interrupt specified by INTTBx interrupt corresponding bit setting to "1".
[Processing of INTTBx inte	errupt	serv	ice rou	utine]	Outp	ut disa	able			
TBxFFCR	←	Χ	Χ	-	-	0	0	-	-	Clears TBxFF0 reverse trigger setting.
Interrupt enable clear register	←	*	*	*	*	*	*	*	*	Prohibits interrupts specified by INTTBx interrupt corresponding bit by setting to "1".

Note 1: m: corresponding bit of port Note 2: X; Don't care -; No change

If a delay is not required, TBxFF0 is reversed when data is taken into TBxCP0, and TBxRG1 is set to the sum of the TBxCP0 value (c) and the one-shot pulse width (p), (c + p), by generating the INTCAPx0 interrupt. (TBxRG1 change must be completed before the next match.)

TBxFF0 is enabled to reverse when UC matches with TBxRG1, and is disabled by generating the INTTBx interrupt.




Figure 9-6 One-shot Pulse Output Triggered by an External Pulse (Without Delay)

9.7.2 Frequency measurement

The frequency of an external clock can be measured by using the capture function.

To measure frequency, another 16-bit timer is used in combination with the 16-bit event counter mode. As an example, we explain with TMRB3 and TMRB8. TB8OUT of the 16-bit timer TMRB8 is used to specify the measurement time.

TMRB3 count clock selects TB3IN0 input and performs count operation by using external clock input. If TB3MOD<TBCPM[1:0]> is set "11", TMRB3 count clock takes the counter value into the TB3CP0 at the rising edge of TB8OUT and takes the counter value into TB3CP1 at the falling edge of TB8OUT.

This setting allows a count value of the 16-bit up-counter UC to be taken into the capture register (TB3CP0) upon rising of a timer flip-flop output (TB8OUT) of the 16-bit timer (TMRB8), and an UC counter value to be taken into the capture register (TB3CP1) upon falling of TB8OUT of the 16-bit timer (TMRB8).

A frequency is then obtained from the difference between TB3CP0 and TB3CP1 based on the measurement, by generating the INTTB8 16-bit timer interrupt.

For example, if the difference between TB3CP0 and TB3CP1 is 100 and the level width setting value of TB8OUT is 0.5 s, the frequency is 200 Hz ($100 \div 0.5 \text{ s} = 200 \text{ Hz}$).




Figure 9-7 Frequency Measurement

9.7.3 Pulse width measurement

By using the capture function, the "High" level width of an external pulse can be measured. Specifically, by putting it in a free-running state using the prescaler output clock, an external pulse is input through the TBxIN0 pin and the up-counter (UC) is made to count up. A trigger is generated at each rising and falling edge of the external pulse by using the capture function and the value of the up-counter is taken into the capture registers (TBxCP0, TBxCP1). The CPU must be programmed so that INTCAPx1 is generated at the falling edge of an external pulse input through the TBxIN0 pin.

The "High" level pulse width can be calculated by multiplying the difference between TBxCP0 and TBxCP1 by the clock cycle of an internal clock.

For example, if the difference between TBxCP0 and TBxCP1 is 100 and the cycle of the prescaler output clock is $0.5 \,\mu s$, the pulse width is $100 \times 0.5 \,\mu s = 50 \,\mu s$.

Caution must be exercised when measuring pulse widths exceeding the UC maximum count time which is dependant upon the source clock used. The measurement of such pulse widths must be made using software.

The "Low" level width of an external pulse can also be measured. In such cases, the difference between C2 generated the first time and C1 generated the second time is initially obtained by performing the second stage of INTCAPx0 interrupt processing as shown in "Figure 9-8 Pulse Width Measurement" and this difference is multiplied by the cycle of the prescaler output clock to obtain the "Low" level width.




Figure 9-8 Pulse Width Measurement

9.7.4 Time Difference Measurement

The time difference of two events can be measured by the capture function. The up-counter (UC) is made to count up by putting it in a free-running state using the prescaler output clock.

The value of UC is taken into the capture register (TBxCP0) at the rising edge of the TBxIN0 pin input pulse. The CPU must be programmed to generate INTCAPx0 interrupt at this time.

The value of UC is taken into the capture register (TBxCP1) at the rising edge of the TBxIN1 pin input pulse. The CPU must be programmed to generate INTCAPx1 interrupt at this time.

The time difference can be calculated by multiplying the difference between TBxCP1 and TBxCP0 by the clock cycle of an internal clock.




Figure 9-9 Time Difference Measurement

TOSHIBA TMPM332FWUG

10. Serial Channel (SIO/UART)

10.1 Overview

This device has two mode for the serial channel, one is the synchronous communication mode (I/O interface mode), and the other is the asynchronous communication mode (UART mode).

Their features are given in the following.

- · Transfer Clock
 - Dividing by the prescaler, from the peripheral clock (Φ T0) frequency into 1/2, 1/8, 1/32, 1/128.
 - Make it possible to divide from the prescaler output clock frequency into 1-16.
 - Make it possible to divide from the prescaler output clock frequency into 1, N+m/16 (N=2-15, m=1-15), 16. (only UART mode)
 - The usable system clock (only UART mode).
- · Double Buffer /FIFO

The usable double buffer function, and the usable FIFO buffers of transmit and receive in all for maximum 4-byte.

- · I/O Interface Mode
 - Transfer Mode: the half duplex (transmit/receive), the full duplex
 - Clock: Output (fixed rising edge) /Input (selectable rising/falling edge)
 - Make it possible to specify the interval time of continuous transmission.
- · UART Mode
 - Data length: 7 bits, 8bits, 9bits
 - Add parity bit (to be against 9bits data length)
 - Serial links to use wake-up function
 - Handshaking function with CTS pin

In the following explanation, "x" represents channel number.

10.2 Difference in the Specifications of SIO Modules

TMPM332FWUG has two SIO channels.

Each channel functions independently. The used pins and interrupt in each channel are collected in the following.

Table 10-1 Difference in the Specifications of SIO Modules

		Channel 0	Channel 1	
	TXD	PE0(11pin)	PE4(14pin)	
Pin name	RXD	PE1(12pin)	PE5(15pin)	
	CTS/SLCK	PE2(13pin)	PE6(16pin)	
lata	Receive Interrupt	INTRX0	INTRX1	
Interrupt	Transmit Interrupt	INTTX0	INTTX1	

10.3 Configuration TMPM332FWUG

10.3 Configuration

Figure 10-1 shows SIO block diagram.




Figure 10-1 SIO Block Diagram

10.4 Registers Description

10.4.1 Registers List in Each Channel

The each channel registers and addresses are shown here.

Channel x	Base Address
Channel0	0x4002_0080
Channel1	0x4002_00C0

Register name (x=0 to 1)		Address (Base+)
Enable register	SCxEN	0x0000
Buffer register	SCxBUF	0x0004
Control register	SCxCR	0x0008
Mode control register 0	SCxMOD0	0x000C
Baud rate generator control register	SCxBRCR	0x0010
Baud rate generator control register 2	SCxBRADD	0x0014
Mode control register 1	SCxMOD1	0x0018
Mode control register 2	SCxMOD2	0x001C
RX FIFO configuration register	SCxRFC	0x0020
TX FIFO configuration register	SCxTFC	0x0024
RX FIFO status register	SCxRST	0x0028
TX FIFO status register	SCxTST	0x002C
FIFO configuration register	SCxFCNF	0x0030

Note: Do not modify any control register when data is being transmitted or received.

10.4.2 SCxEN (Enable Register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	-	SIOE
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-1	-	R	Read as 0.
0	SIOE	R/W	SIO operation
			0: Disabled
			1: Enabled
			Specified the SIO operation.
			To use the SIO, set <sioe> = "1".</sioe>
			When the operation is disabled, no clock is supplied to the other registers in the SIO module. This can reduce the power consumption.
			If the SIO operation is executed and then disabled, the settings will be maintained in each register except for SCxTFC <til>.</til>

10.4.3 SCxBUF (Buffer Register)

SCxBUF works as a transmit buffer or FIFO for write operation and as a receive buffer or FIFO for read operation.

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol				ТВ	/ RB		_	
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-0	TB[7:0] / RB [7:0]	R/W	[write] TB : Transmit buffer / FIFO [read] RB : Receive buffer / FIFO

10.4.4 SCxCR (Control Register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	RB8	EVEN	PE	OERR	PERR	FERR	SCLKS	IOC
After reset	0	0	0	0	0	0	0	0

Bit Symbol	Туре	Function
-	R	Read as 0.
RB8	R	Receive data bit 8 (For UART)
		9th bit of the received data in the 9 bits UART mode.
EVEN	R/W	Parity (For UART)
		0: Odd
		1: Even
		Selects even or odd parity.
		"0" : odd parity, "1" : even parity.
		The parity bit may be used only in the 7- or 8-bit UART mode.
PE	R/W	Add parity (For UART)
		0: Disabled
		1: Enabled
		Controls enabling/ disabling parity.
		The parity bit may be used only in the 7- or 8-bit UART mode.
OERR	R	Overrun error flag (Note)
		0: Normal operation
		1: Error
PERR	R	Parity / Underrun error flag (Note)
		0: Normal operation
		1: Error
FERR	R	Framing error flag (Note)
		0: Normal operation
		1: Error
SCLKS	R/W	Selecting input clock edge (For I/O Interface)
		0: Rising edges
		1: Falling edges
		Selects input clock edge for data transmission and reception.
		Set to "0" in the clock output mode.
IOC	R/W	Selecting clock (For I/O Interface)
		0: Baud rate generator
		1: SCLK pin input
	PE OERR PERR SCLKS	- R RB8 R EVEN R/W PE R/W OERR R FERR R SCLKS R/W

Note: Any error flag (OERR, PERR, FERR) is cleared to "0" when read.

10.4.5 SCxMOD0 (Mode Control Register 0)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	TB8	CTSE	RXE	WU	SM		SC	
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7	TB8	R/W	Transmit data bit 8 (For UART)
			Writes the 9th bit of transmit data in the 9 bits UART mode.
6	CTSE	R/W	Handshake function control (For UART)
			0: CTS disabled
			1: CTS enabled
			Controls handshake function.
			Setting "1" enables handshake function using CTS pin.
5	RXE	R/W	Receive control (Note)
			0: Disabled
			1: Enabled
4	wu	R/W	Wake-up function (For UART)
			0: Disabled
			1: Enabled
			This function is available only at 9-bit UART mode. In other mode, this function has no meaning.
			In it is Enabled, Interrupt only when RB9 = "1" at 9-bit UART mode.
3-2	SM[1:0]	R/W	Specifies transfer mode.
			00: I/O interface mode
			01: 7-bit length UART mode
			10: 8-bit length UART mode
			11: 9-bit length UART mode
1-0	SC[1:0]	R/W	Serial transfer clock (For UART)
			00: Timer TB9OUT
			01: Baud rate generator
			10: Internal clock fsys
			11: External clock (SCLK input)
			(As for the I/O interface mode, the serial transfer clock can be set in the control register (SCxCR).

Note 1: With <RXE> set to "0", set each mode register (SCxMOD0, SCxMOD1 and SCxMOD2). Then set <RXE> to "1".

Note 2: Do not stop the receive operation (by setting SCxMOD0<RXE> = "0") when data is being received.

10.4.6 SCxMOD1 (Mode Control Register 1)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	I2SC	FDPX		TXE	SINT			-
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7	I2SC	R/W	IDLE 0: Stop 1: Operate Specifies the IDLE mode operation.
6-5	FDPX[1:0]	R/W	Transfer mode setting 00: Transfer prohibited 01: Half duplex (Recieve) 10: Half duplex (Trasmitt) 11: Full duplex Configures the transfer mode in the I/O interface mode. Also configures the FIFO if it is enabled. In the UART mode, it is used only to specify the FIFO configuration.
4	TXE	R/W	Transmit control (Note) 0 :Disabled 1: Enabled This bit enables transmission and is valid for all the transfer modes.
3-1	SINT[2:0]	R/W	Interval time of continuous transmission (For I/O interface) 000: None 001: 1SCLK 010: 2SCLK 011: 4SCLK 100: 8SCLK 101: 16SCLK 101: 16SCLK 111: 64SCLK This parameter is valid only for the I/O interface mode when SCLK pin output is selected. In other modes, this function has no meaning. Specifies the interval time of continuous transmission when double buffering or FIFO is enabled in the I/O interface mode.
0	-	R/W	Write a "0".

Note 1: Specify the all mode first and then enable the <TXE> bit.

Note 2: Do not stop the transmit operation (by setting <TXE> = "0")when data is being transmitted.

10.4.7 SCxMOD2 (Mode Control Register 2)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	TBEMP	RBFLL	TXRUN	SBLEN	DRCHG	WBUF	SW	RST
After reset	1	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре			Function					
31-8	-	R	Read as 0.							
7	ТВЕМР	R	Transmit buffer empty flag.							
			0: Full	0: Full						
			1: Empty							
			If double buffering is	disabled, this flag	is insignificant.					
					e buffers are empty. When data in the transmit doub uble buffers are empty, this bit is set to "1".	ole buffers is moved				
			Writing data again to	the double buffers	s sets this bit to "0".					
6	RBFLL	R	Receive buffer full fla	ıg.						
			0: Empty							
			1: Full							
			This is a flag to show	that the receive d	ouble buffers are full.					
					and received data is moved from the receive shift re while reading this bit changes it to "0".	gister to the receive				
			If double buffering is	disabled, this flag	is insignificant.					
5	TXRUN	R	In transmission flag							
			0: Stop							
			1: Operate							
			This is a status flag t	o show that data to	ransmission is in progress.					
			<txrun> and <tbe< td=""><td>MP> bits indicate</td><td>the following status.</td><td>1</td></tbe<></txrun>	MP> bits indicate	the following status.	1				
			<txrun></txrun>	<tbemp></tbemp>	Status					
			1	_	Transmission in progress]				
			0	1	Transmission completed					
			U U	0	Wait state with data in Transmitt buffer					
4	SBLEN	R/W	STOP bit (for UART)							
			0 : 1-bit							
			1 : 2-bit							
			·	•	n stop bit in the UART mode.					
			On the receive side,	the decision is ma	de using only a single bit regardless of the <sblen< td=""><td>l> setting.</td></sblen<>	l> setting.				
3	DRCHG	R/W	Setting transfer direct	tion						
			0: LSB first							
			1: MSB first							
					in the I/O interface mode.					
			In the UART mode, s	et this bit to LSB f	irst.					

Bit	Bit Symbol	Туре	Function							
2	WBUF	R/W	Double-buffer							
			0: Disabled							
			1 : Enabled							
				his parameter enables or disables the transmit/receive double buffers to transmit (in both SCLK output/inpu odes) and receive (in SCLK output mode) data in the I/O interface mode and to transmit data in the UART						
				in the I/O interface mode (SCLK input) and UA I is set to <wbuf> bit.</wbuf>	ART mode, double buffering is enabled in					
1-0	SWRST[1:0]	R/W	Software reset							
				ace of "10" generates a software reset. When the transmit/receive circuit, the transmit circu						
			Register	Bit						
			SCxMOD0	RXE						
			SCxMOD1	TXE						
			SCxMOD2	SCxMOD2 TBEMP, RBFLL, TXRUN						
			SCxCR	OERR, PERR, FERR						

Note 1: While data transmission is in progress, any software reset operation must be executed twice in succession.

Note 2: A software reset requires 2 clocks-duration at the time between the end of recognition and the start of execution of software reset instruction.

10.4.8 SCxBRCR (Baud Rate Generator Control Register), SCxBRADD (Baud Rate Generator Control Register 2)

The division ratio of the baud rate generator can be specified in the registers shown below.

SCxBRCR

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	15 -	14 -	13 -	12 -	11 -	10 -	9	8 -
bit symbol After reset				- 0	11 - 0	10 - 0	9 - 0	- 0
	-	-	-	-	-	-	-	-
	-	- 0	- 0 5	- 0	- 0	- 0 2	-	- 0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7	-	R/W	Write "0".
6	BRADDE	R/W	N + (16 - K)/16 divider function (For UART) 0: disabled 1: enabled This division function can only be used in the UART mode.
5-4	BRCK[1:0]	R/W	Select input clock to the baud rate generator. 00: φT1 01: φT4 10: φT16 11: φT64
3-0	BRS[3:0]	R/W	Division ratio "N" 0000: 16 0001: 1 0010: 2 1111: 15

SCxBRADD

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	BRK			
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-4	_	R	Read as 0.
3-0	BRK[3:0]	R/W	Specify K for the "N + (16 - K)/16" division (For UART) 0000: Prohibited 0001: K = 1 0010: K = 2
			1111: K = 15

Table 10-2 lists the settings of baud rate generator division ratio.

Table 10-2 Setting division ratio

	<bradde> = "0"</bradde>	<bradde> = "1" (Note1) (Only UART mode)</bradde>		
<brs></brs>	Specify "I	N" (Note2) (Note3)		
<brk></brk>	No setting required	Specify "K" (Note4)		
Division ratio	Divide by N	$N + \frac{(16 - K)}{16}$ division.		

- Note 1: To use the "N + (16 K)/16" division function, be sure to set <BRADDE> to "1" after setting the K value to <BRK>. The "N + (16 K)/16" division function can only be used in the UART mode.
- Note 2: As a division ratio, 1 ("0001") or 16 ("0000") can not be applied to N when using the "N + (16 K)/16" division function in the UART mode.
- Note 3: The division ratio "1" of the baud rate generator can be specified only when the double buffering is used in the I/O interface mode.
- Note 4: Specifying "K = 0" is prohibited.

10.4.9 SCxFCNF (FIFO Configuration Register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	1	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	RFST	TFIE	RFIE	RXTXCNT	CNFG
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function						
31-8	-	R	Read as 0	Read as 0					
7-5	-	R/W	Be sure to write "000"						
4	RFST	R/W	Bytes used in RX FI	Bytes used in RX FIFO					
			0:Maximum						
			1:Same as FILL leve	el of RX FIFO					
			When RX FIFO is er	nabled, the number of RX FIFO bytes to be	e used is selected (Note1)				
				nber of bytes of the FIFO configured (see a	,				
			1: Same as the fill le	vel for receive interrupt generation specific	ed by SCxRFC <ril[1:0]></ril[1:0]>				
3	TFIE	R/W	TX interrupt for TX F	TIFO					
			0: Disabled						
			1:Enabled						
_				abled, transmit interrupts are enabled or d	isabled by this parameter.				
2	RFIE	R/W	RX interrupt for RX I	FIFO					
			0: Disabled 1:Enabled						
				nabled, receive interrupts are enabled or di	isabled by this parameter				
1	RXTXCNT	R/W	Automatic disable of	•	sabled by this parameter.				
'	RATACINI	FC/VV	0: None	RAE/TAE					
			1: Auto diabled						
				lisabling of transmission and reception.					
			Setting "1" enables t	o operate as follows					
			Half duplex RX	When receive shift register, the receive SCxMOD0 <rxe> is automatically set to</rxe>					
			Half duplex TX	When the TX FIFO, the transmit buffer a SCxMOD1 <txe> is automatically set to</txe>					
			Full duplex	When either of the above two conditions set to "0" to inhibit further transmission a	s is satisfied, TXE/RXE are automatically and reception.				
0	CNFG	R/W	Enables FIFO.						
			0: Disabled						
			1: Enabled						
			If enabled, the SCxMOD1 <fdpx[1:0]> setting automatically configures FIFO as follows:</fdpx[1:0]>						
				can be specified in the mode control regist	er 1 SCxMOD1 <fdpx[1:0]>). I</fdpx[1:0]>				
			Half duplex RX	•					
			Half duplex TX	TX FIFO 4byte					
			Full duplex	RX FIFO 2byte + TX FIFO 2byte					

Note 1: Regarding TX FIFO, the maximum number of bytes being configured is always available. The available number of bytes is the bytes already written to the TX FIFO.

Note 2: The FIFO can not use in 9bit UART mode.

10.4.10 SCxRFC (RX FIFO Configuration Register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	RFCS	RFIS	-	-	-	-	R	IL
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре				Function		
31-8	-	R	Read as 0.					
7	RFCS	W	RX FIFO cle	RX FIFO clear				
			1: Clear					
			Setting "1" o	etting "1" clears RX FIFO and "0" is always read.				
6	RFIS	R/W	Select interr	upt generation cor	dition			
			0: when the	data reaches to th	e specified fill leve	l.		
			l	data reaches to the	e specified fill leve	or the data exceeds the specified fill level at the time data is		
			read.					
5-2	-	R	Read as 0.					
1-0	RIL[1:0]	R/W	FIFO fill leve	el to generate RX i	nterrupts			
				Half duplex	Full duplex			
			00	4byte	2byte			
			01	1byte	1byte			
			10	2byte	2byte			
			11	3byte	1byte			

Note: To use TX/RX FIFO buffer, TX/RX FIFO must be cleared after setting the SIO transfer mode (half duplex/full duplex) and enabling FIFO (SCxFCNF<CNFG> = "1").

10.4.11 SCxTFC (TX FIFO Configuration Register) (Note2)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	TFCS	TFIS	-	-	-	-	TIL	
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре		Function					
31-8	-	R	Read as 0.	Read as 0.					
7	TFCS	W	1: Clears T	TX FIFO clear (Note 1) 1: Clears TX FIFO. Setting "1" clears TX FIFO and "0" is always read.					
6	TFIS	R/W	0: An interru	Selects interrupt generation condition. O: An interrupt is generated when the data reaches to the specified fill level. 1: An interrupt is generated when the data reaches to the specified fill level or the data can not reach the specified fill level at the time new data is read.					
5-2	_	R	Read as 0.						
1-0	TIL[1:0]	R/W	Selects FIF	O fill level.					
				Other than full duplex	Full duplex				
			00	Empty	Empty				
			01	1 byte	1 byte				
			10	2 byte	Empty				
			11	3 byte	1 byte				

Note 1: To use TX/RX FIFO buffer, TX/RX FIFO must be cleared after setting the SIO transfer mode (half duplex/full duplex) and enabling FIFO (SCxFCNF<CNFG> = "1").

Note 2: After you perform the following operations, configure the SCxTFC register again.

SCxEN<SIOE> = "0" (SIO operation stop)

Conditions are as follows:SCxMOD1<I2SC> = "0" (operation is prohibited in IDLE mode) and releasing the low power consumption mode which started by the WFI (Wait For Interrupt) instruction.

10.4.12 SCxRST (RX FIFO Status Register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	ROR	-	-	-	-	RLVL		
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7	ROR	R	RX FIFO Overrun (Note) 0: Not generated 1: Generated
6-3	_	R	Read as 0.
2-0	RLVL[2:0]	R	Status of RX FIFO fill level. 000: Empty 001: 1 byte 010: 2 byte 011: 3 byte 100: 4 byte

Note: The <ROR> bit is cleared to "0" when receive data is read from the SCxBUF register.

10.4.13 SCxTST (TX FIFO Status Register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	15 -	14 -	13 -	12 -	11 -	10 -	9	8 -
bit symbol After reset				12 - 0	- 0	10 - 0	9 - 0	- 0
<u> </u>	-	-	-	-	-	-	-	-
<u> </u>	-	- 0	- 0	- 0	- 0	- 0	-	- 0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7	TUR	R	TX FIFO under run (Note) 0: Not generated 1: Generated.
6-3	_	R	Read as 0.
2-0	TLVL[2:0]	R	Status of TX FIFO fill level. 000: Empty 001: 1 byte 010: 2 byte 011: 3 byte 100: 4 byte

 $\label{thm:continuous} \mbox{Note:The $$\mbox{TUR}$$ bit is cleared to "0" when transmit data is written to the SCxBUF register.}$

10.5 Operation in Each Mode

Table 10-3 shows the modes and data formats.

Table 10-3 Mode and Data format

Mode	Mode type	Data length	Transfer direction	Specifies whether to use parity bits.	STOP bit length (transmit)	
Mode 0	Synchronous communication mode (IO interface mode)	8 bit	LSB first/MSB first	-	-	
Mode 1	Asynchronous communication	7 bit		0		
Mode 2	mode	8 bit	LSB first	0	1 bit or 2 bit	
Mode 3	(UART mode)	9 bit		×		

Mode 0 is a synchronous communication and can be used to extend I/O. This mode transmits and receives data in synchronization with SCLK. SCLK can be used for both input and output.

The direction of data transfer can be selected from LSB first and MSB first. This mode is not allowed either to use parity bits or STOP bits.

The mode 1, mode 2 and mode 3 are asynchronous modes and the transfer direction is fixed to the LSB first.

Parity bits can be added in the mode 1 and mode 2. The mode 3 has a wakeup function in which the master controller can start up slave controllers via the serial link (multi-controller system).

STOP bit in transmission can be selected from 1 bit and 2 bits. The STOP bit length in reception is fixed to a one bit.

TMPM332FWUG

10.6 Data Format

10.6.1 Data Format List

Figure 10-2 shows data format.




Figure 10-2 Data Format

10.6 Data Format TMPM332FWUG

10.6.2 Parity Control

The parity bit can be added only in the 7- or 8-bit UART mode.

Setting "1" to SCxCR<PE> enables the parity.

The <EVEN> bit of SCxCR selects either even or odd parity.

10.6.2.1 Transmission

Upon data transmission, the parity control circuit automatically generates the parity with the data in the transmit buffer.

After data transmission is complete, the parity bit will be stored in SCxBUF<TB7> in the 7-bit UART mode and SCxMOD<TB8> in the 8-bit UART mode.

The <PE> and <EVEN> settings must be completed before data is written to the transmit buffer.

10.6.2.2 Receiving Data

If the received data is moved from the receive shift register to the receive buffer, a parity is generated.

In the 7-bit UART mode, the generated parity is compared with the parity stored in SCxBUF<RB7>, while in the 8-bit UART mode, it is compared with the one in SCxCR<RB8>.

If there is any difference, a parity error occurs and the <PERR> of the SCxCR register is set to "1".

In use of the FIFO, <RERR> indicates that a parity error was generated in one of the recieved data.

10.6.3 STOP Bit Length

The length of the STOP bit in the UART transmission mode can be selected from one bit or two bits by setting the SCxMOD2<SBLEN>. The length of the STOP bit data is determined as one-bit when it is received regardless of the setting of this bit.

10.7 Clock Control

10.7.1 Prescaler

There is a 7-bit prescaler to divide a prescaler input clock Φ T0 by 2, 8, 32 and 128.

Use the CGSYSCR register in the clock/mode control block to select the input clock Φ T0 of the prescaler.

The prescaler becomes active only when the baud rate generator is selected as a transfer clock by SCxMOD0 < SC[1:0] > = "11".

Table 10-4 (operation frequency 40MHz), Table 10-5 (operation frequency 32MHz) show the resolution of the input clock to the baud rate generator.

Table 10-4 Clock Resolution to the Baud Rate Generator fc = 40 MHz

peripheral clock	Clock gear	Prescaler clock se-		Prescaler output clock resolution					
selection CGSYSCR <fpsel></fpsel>	value CGSYSCR <gear[2:0]></gear[2:0]>	lection CGSYSCR <prck[2:0]></prck[2:0]>	φΤ1	φΤ4	φΤ16	φΤ64			
		000 (fperiph/1)	fc/2¹ (0.05 μs)	fc/2 ³ (0.2 µs)	fc/2 ⁵ (0.8 µs)	fc/2 ⁷ (3.2 µs)			
		001 (fperiph/2)	fc/2 ² (0.1 µs)	fc/2 ⁴ (0.4 µs)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)			
	000 (f-)	010 (fperiph/4)	fc/2 ³ (0.2 µs)	fc/2 ⁵ (0.8 μs)	fc/2 ⁷ (3.2 μs)	fc/2 ⁹ (12.8 µs)			
	000 (fc)	011 (fperiph/8)	fc/2 ⁴ (0.4 µs)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)	fc/2 ¹⁰ (25.6 µs)			
		100 (fperiph/16)	fc/2 ⁵ (0.8 µs)	fc/2 ⁷ (3.2 µs)	fc/2 ⁹ (12.8 µs)	fc/2 ¹¹ (51.2 μs)			
		101 (fperiph/32)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)	fc/2 ¹⁰ (25.6 µs)	fc/2 ¹² (102.4 µs)			
		000 (fperiph/1)	fc/2 ² (0.1 µs)	fc/2 ⁴ (0.4 µs)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)			
		001 (fperiph/2)	fc/2 ³ (0.2 µs)	fc/2 ⁵ (0.8 µs)	fc/2 ⁷ (3.2 µs)	fc/2 ⁹ (12.8 µs)			
	400 (5: (0)	010 (fperiph/4)	fc/2 ⁴ (0.4 µs)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)	fc/2 ¹⁰ (25.6 µs)			
	100 (fc/2)	011 (fperiph/8)	fc/2 ⁵ (0.8 µs)	fc/2 ⁷ (3.2 μs)	fc/2 ⁹ (12.8 µs)	fc/2 ¹¹ (51.2 µs)			
		100 (fperiph/16)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)	fc/2 ¹⁰ (25.6 µs)	fc/2 ¹² (102.4 µs)			
0 (5)		101 (fperiph/32)	fc/2 ⁷ (3.2 µs)	fc/2 ⁹ (12.8 μs)	fc/2 ¹¹ (51.2 μs)	fc/2 ¹³ (204.8 µs)			
0 (fgear)		000 (fperiph/1)	fc/2 ³ (0.2 µs)	fc/2 ⁵ (0.8 µs)	fc/2 ⁷ (3.2 µs)	fc/2 ⁹ (12.8 µs)			
		001 (fperiph/2)	fc/24 (0.4 µs)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)	fc/2 ¹⁰ (25.6 µs)			
	404 (5: (4)	010 (fperiph/4)	fc/2 ⁵ (0.8 µs)	fc/2 ⁷ (3.2 μs)	fc/2 ⁹ (12.8 µs)	fc/2 ¹¹ (51.2 µs)			
	101 (fc/4)	011 (fperiph/8)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)	fc/2 ¹⁰ (25.6 µs)	fc/2 ¹² (102.4 µs)			
		100 (fperiph/16)	fc/2 ⁷ (3.2 µs)	fc/2 ⁹ (12.8 μs)	fc/2 ¹¹ (51.2 μs)	fc/2 ¹³ (204.8 µs)			
		101 (fperiph/32)	fc/28 (6.4 µs)	fc/2 ¹⁰ (25.6 µs)	fc/2 ¹² (102.4 µs)	fc/2 ¹⁴ (409.6 µs)			
		000 (fperiph/1)	fc/24 (0.4 µs)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)	fc/2 ¹⁰ (25.6 µs)			
		001 (fperiph/2)	fc/2 ⁵ (0.8 μs)	fc/2 ⁷ (3.2 μs)	fc/2 ⁹ (12.8 µs)	fc/2 ¹¹ (51.2 µs)			
	440 (5-10)	010 (fperiph/4)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)	fc/2 ¹⁰ (25.6 µs)	fc/2 ¹² (102.4 µs)			
	110 (fc/8)	011 (fperiph/8)	fc/2 ⁷ (3.2 μs)	fc/2 ⁹ (12.8 µs)	fc/2 ¹¹ (51.2 μs)	fc/2 ¹³ (204.8 µs)			
		100 (fperiph/16)	fc/28 (6.4 µs)	fc/2 ¹⁰ (25.6 µs)	fc/2 ¹² (102.4 µs)	fc/2 ¹⁴ (409.6 µs)			
		101 (fperiph/32)	fc/2 ⁹ (12.8 μs)	fc/2 ¹¹ (51.2 µs)	fc/2 ¹³ (204.8 µs)	fc/2 ¹⁵ (819.2 μs)			

10.7 Clock Control TMPM332FWUG

Table 10-4 Clock Resolution to the Baud Rate Generator fc = 40 MHz

peripheral clock	Clock gear	Prescaler clock se-		Prescaler output	clock resolution	
selection CGSYSCR <fpsel></fpsel>	value CGSYSCR <gear[2:0]></gear[2:0]>	lection CGSYSCR <prck[2:0]></prck[2:0]>	φΤ1	φΤ4	φΤ16	φΤ64
		000 (fperiph/1)	fc/2¹ (0.05 μs)	fc/2³ (0.2 µs)	fc/2 ⁵ (0.8 µs)	fc/2 ⁷ (3.2 μs)
		001 (fperiph/2)	fc/2 ² (0.1 µs)	fc/2 ⁴ (0.4 µs)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)
	000 (5:)	010 (fperiph/4)	fc/2 ³ (0.2 µs)	fc/2 ⁵ (0.8 µs)	fc/2 ⁷ (3.2 µs)	fc/2 ⁹ (12.8 µs)
	000 (fc)	011 (fperiph/8)	fc/24 (0.4 µs)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)	fc/2 ¹⁰ (25.6 µs)
		100 (fperiph/16)	fc/2 ⁵ (0.8 μs)	fc/2 ⁷ (3.2 µs)	fc/2 ⁹ (12.8 µs)	fc/2 ¹¹ (51.2 μs)
		101 (fperiph/32)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)	fc/2 ¹⁰ (25.6 µs)	fc/2 ¹² (102.4 µs)
		000 (fperiph/1)	-	fc/2 ³ (0.2 µs)	fc/2 ⁵ (0.8 µs)	fc/2 ⁷ (3.2 µs)
		001 (fperiph/2)	fc/2 ² (0.1 µs)	fc/2 ⁴ (0.4 µs)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)
	100 (5 (0)	010 (fperiph/4)	fc/2 ³ (0.2 µs)	fc/2 ⁵ (0.8 µs)	fc/2 ⁷ (3.2 µs)	fc/2 ⁹ (12.8 µs)
	100 (fc/2)	011 (fperiph/8)	fc/24 (0.4 µs)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)	fc/2 ¹⁰ (25.6 µs)
		100 (fperiph/16)	fc/2 ⁵ (0.8 μs)	fc/2 ⁷ (3.2 µs)	fc/2 ⁹ (12.8 μs)	fc/2 ¹¹ (51.2 µs)
4 (5:)		101 (fperiph/32)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)	fc/2 ¹⁰ (25.6 µs)	fc/2 ¹² (102.4 µs)
1 (fc)		000 (fperiph/1)	-	fc/2 ³ (0.2 µs)	fc/2 ⁵ (0.8 µs)	fc/2 ⁷ (3.2 μs)
		001 (fperiph/2)	-	fc/2 ⁴ (0.4 µs)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)
		010 (fperiph/4)	fc/2 ³ (0.2 µs)	fc/2 ⁵ (0.8 µs)	fc/2 ⁷ (3.2 µs)	fc/2 ⁹ (12.8 µs)
	101 (fc/4)	011 (fperiph/8)	fc/2 ⁴ (0.4 μs)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)	fc/2 ¹⁰ (25.6 µs)
		100 (fperiph/16)	fc/2 ⁵ (0.8 μs)	fc/2 ⁷ (3.2 µs)	fc/2 ⁹ (12.8 µs)	fc/2 ¹¹ (51.2 µs)
		101 (fperiph/32)	fc/2 ⁶ (1.6 μs)	fc/28 (6.4 µs)	fc/2 ¹⁰ (25.6 µs)	fc/2 ¹² (102.4 µs)
		000 (fperiph/1)	-	-	fc/2 ⁵ (0.8 µs)	fc/2 ⁷ (3.2 μs)
		001 (fperiph/2)	-	fc/2 ⁴ (0.4 µs)	fc/2 ⁶ (1.6 μs)	fc/28 (6.4 µs)
	140 (5 (0)	010 (fperiph/4)	-	fc/2 ⁵ (0.8 µs)	fc/2 ⁷ (3.2 µs)	fc/2 ⁹ (12.8 µs)
	110 (fc/8)	011 (fperiph/8)	fc/24 (0.4 µs)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)	fc/2 ¹⁰ (25.6 µs)
		100 (fperiph/16)	fc/2 ⁵ (0.8 µs)	fc/2 ⁷ (3.2 µs)	fc/2 ⁹ (12.8 µs)	fc/2 ¹¹ (51.2 µs)
		101 (fperiph/32)	fc/2 ⁶ (1.6 µs)	fc/28 (6.4 µs)	fc/2 ¹⁰ (25.6 µs)	fc/2 ¹² (102.4 μs)

Note 1: The prescaler output clock φTn must be selected so that the relationship "φTn ≤ fsys / 2" is satisfied (so that φTn is slower than fsys).

Note 2: Do not change the clock gear while SIO is operating.

Note 3: The dashes in the above table indicate that the setting is prohibited.

Table 10-5 Clock Resolution to the Baud Rate Generator fc = 32 MHz

peripheral clock	Clock gear	Prescaler clock se-		Prescaler output	t clock resolution	
selection CGSYSCR <fpsel></fpsel>	value CGSYSCR <gear[2:0]></gear[2:0]>	lection CGSYSCR <prck[2:0]></prck[2:0]>	φΤ1	φΤ4	φΤ16	φΤ64
		000 (fperiph/1)	fc/21 (0.0625 µs)	fc/2³ (0.25 µs)	fc/2 ⁵ (1.0 µs)	fc/2 ⁷ (4.0 µs)
		001 (fperiph/2)	fc/2² (0.125 µs)	fc/2 ⁴ (0.5 µs)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)
	000 (5-)	010 (fperiph/4)	fc/2³ (0.25 µs)	fc/2 ⁵ (1.0 µs)	fc/2 ⁷ (4.0 µs)	fc/2 ⁹ (16.0 µs)
	000 (fc)	011 (fperiph/8)	fc/2 ⁴ (0.5 µs)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)	fc/2 ¹⁰ (32.0 µs)
		100 (fperiph/16)	fc/2 ⁵ (1.0 μs)	fc/2 ⁷ (4.0 µs)	fc/2 ⁹ (16.0 µs)	fc/2 ¹¹ (64.0 µs)
		101 (fperiph/32)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)	fc/2 ¹⁰ (32.0 µs)	fc/2 ¹² (128.0 µs)
		000 (fperiph/1)	fc/21 (0.0625 µs)	fc/2 ⁴ (0.5 µs)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)
		001 (fperiph/2)	fc/2 ³ (0.25 µs)	fc/2 ⁵ (1.0 µs)	fc/2 ⁷ (4.0 µs)	fc/2 ⁹ (16.0 µs)
	400 (5 (0)	010 (fperiph/4)	fc/2 ⁴ (0.5 μs)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)	fc/2 ¹⁰ (32.0 µs)
	100 (fc/2)	011 (fperiph/8)	fc/2 ⁵ (1.0 μs)	fc/2 ⁷ (4.0 µs)	fc/2 ⁹ (16.0 µs)	fc/2 ¹¹ (64.0 µs)
		100 (fperiph/16)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)	fc/2 ¹⁰ (32.0 µs)	fc/2 ¹² (128.0 µs)
0 (5)		101 (fperiph/32)	fc/2 ⁷ (4.0 µs)	fc/2 ⁹ (16.0 µs)	fc/2 ¹¹ (64.0 µs)	fc/2 ¹³ (256.0 µs)
0 (fgear)		000 (fperiph/1)	fc/21 (0.0625 µs)	fc/2 ⁵ (1.0 µs)	fc/2 ⁷ (4.0 µs)	fc/2 ⁹ (16.0 µs)
		001 (fperiph/2)	fc/2 ⁴ (0.5 µs)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)	fc/2 ¹⁰ (32.0 µs)
	404 (5 (4)	010 (fperiph/4)	fc/2 ⁵ (1.0 μs)	fc/2 ⁷ (4.0 µs)	fc/2 ⁹ (16.0 µs)	fc/2 ¹¹ (64.0 µs)
	101 (fc/4)	011 (fperiph/8)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)	fc/2 ¹⁰ (32.0 µs)	fc/2 ¹² (128.0 µs)
		100 (fperiph/16)	fc/2 ⁷ (4.0 µs)	fc/2 ⁹ (16.0 µs)	fc/2 ¹¹ (64.0 µs)	fc/2 ¹³ (256.0 µs)
		101 (fperiph/32)	fc/28 (8.0 µs)	fc/2 ¹⁰ (32.0 µs)	fc/2 ¹² (128.0 µs)	fc/2 ¹⁴ (512.0 µs)
		000 (fperiph/1)	fc/21 (0.0625 µs)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)	fc/2 ¹⁰ (32.0 µs)
		001 (fperiph/2)	fc/2 ⁵ (1.0 μs)	fc/2 ⁷ (4.0 µs)	fc/2 ⁹ (16.0 µs)	fc/2 ¹¹ (64.0 µs)
	440 (5: (0)	010 (fperiph/4)	fc/2 ⁶ (2.0 μs)	fc/28 (8.0 µs)	fc/2 ¹⁰ (32.0 µs)	fc/2 ¹² (128.0 µs)
	110 (fc/8)	011 (fperiph/8)	fc/2 ⁷ (4.0 µs)	fc/2 ⁹ (16.0 µs)	fc/2 ¹¹ (64.0 µs)	fc/2 ¹³ (256.0 µs)
		100 (fperiph/16)	fc/28 (8.0 µs)	fc/2 ¹⁰ (32.0 µs)	fc/2 ¹² (128.0 µs)	fc/2 ¹⁴ (512.0 µs)
		101 (fperiph/32)	fc/2 ⁹ (16.0 µs)	fc/2 ¹¹ (64.0 µs)	fc/2 ¹³ (256.0 µs)	fc/2 ¹⁵ (1024 µs)

10.7 Clock Control TMPM332FWUG

Table 10-5 Clock Resolution to the Baud Rate Generator fc = 32 MHz

peripheral clock	Clock gear	Prescaler clock se-		Prescaler output	clock resolution	
selection CGSYSCR <fpsel></fpsel>	value CGSYSCR <gear[2:0]></gear[2:0]>	lection CGSYSCR <prck[2:0]></prck[2:0]>	φΤ1	φΤ4	φΤ16	φΤ64
		000 (fperiph/1)	fc/2¹ (0.0625 µs)	fc/2³ (0.25 µs)	fc/2 ⁵ (1.0 µs)	fc/2 ⁷ (4.0 µs)
		001 (fperiph/2)	fc/2² (0.125 µs)	fc/2 ⁴ (0.5 µs)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)
	000 (f-)	010 (fperiph/4)	fc/2³ (0.25 µs)	fc/2 ⁵ (1.0 μs)	fc/2 ⁷ (4.0 μs)	fc/2 ⁹ (16.0 µs)
	000 (fc)	011 (fperiph/8)	fc/2 ⁴ (0.5 µs)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)	fc/2 ¹⁰ (32.0 µs)
		100 (fperiph/16)	fc/2 ⁵ (1.0 µs)	fc/2 ⁷ (4.0 μs)	fc/2 ⁹ (16.0 µs)	fc/2 ¹¹ (64.0 µs)
		101 (fperiph/32)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)	fc/2 ¹⁰ (32.0 µs)	fc/2 ¹² (128.0 µs)
		000 (fperiph/1)	-	fc/2³ (0.25 µs)	fc/2 ⁵ (1.0 μs)	fc/2 ⁷ (4.0 µs)
		001 (fperiph/2)	fc/2² (0.125 µs)	fc/2 ⁴ (0.5 µs)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)
	100 (fc/2)	010 (fperiph/4)	fc/2³ (0.25 µs)	fc/2 ⁵ (1.0 μs)	fc/2 ⁷ (4.0 μs)	fc/2 ⁹ (16.0 µs)
		011 (fperiph/8)	fc/2 ⁴ (0.5 µs)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)	fc/2 ¹⁰ (32.0 µs)
		100 (fperiph/16)	fc/2 ⁵ (1.0 μs)	fc/2 ⁷ (4.0 μs)	fc/2 ⁹ (16.0 µs)	fc/2 ¹¹ (64.0 µs)
4 (5)		101 (fperiph/32)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)	fc/2 ¹⁰ (32.0 µs)	fc/2 ¹² (128.0 µs)
1 (fc)		000 (fperiph/1)	-	fc/2 ³ (0.25 μs)	fc/2 ⁵ (1.0 µs)	fc/2 ⁷ (4.0 µs)
		001 (fperiph/2)	-	fc/2 ⁴ (0.5 µs)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)
	404 (5 (4)	010 (fperiph/4)	fc/2³ (0.25 µs)	fc/2 ⁵ (1.0 µs)	fc/2 ⁷ (4.0 µs)	fc/2 ⁹ (16.0 µs)
	101 (fc/4)	011 (fperiph/8)	fc/2 ⁴ (0.5 µs)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)	fc/2 ¹⁰ (32.0 µs)
		100 (fperiph/16)	fc/2 ⁵ (1.0 µs)	fc/2 ⁷ (4.0 µs)	fc/2 ⁹ (16.0 µs)	fc/2 ¹¹ (64.0 µs)
		101 (fperiph/32)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)	fc/2 ¹⁰ (32.0 µs)	fc/2 ¹² (128.0 µs)
		000 (fperiph/1)	-	-	fc/2 ⁵ (1.0 µs)	fc/2 ⁷ (4.0 µs)
		001 (fperiph/2)	-	fc/2 ⁴ (0.5 μs)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)
	440 (5-10)	010 (fperiph/4)	-	fc/2 ⁵ (1.0 μs)	fc/2 ⁷ (4.0 µs)	fc/2 ⁹ (16.0 µs)
	110 (fc/8)	011 (fperiph/8)	fc/2 ⁴ (0.5 μs)	fc/2 ⁶ (2.0 µs)	fc/28 (8.0 µs)	fc/2 ¹⁰ (32.0 µs)
		100 (fperiph/16)	fc/2 ⁵ (1.0 μs)	fc/2 ⁷ (4.0 µs)	fc/2 ⁹ (16.0 µs)	fc/2 ¹¹ (64.0 µs)
		101 (fperiph/32)	fc/2 ⁶ (2.0 μs)	fc/2 ⁸ (8.0 μs)	fc/2 ¹⁰ (32.0 µs)	fc/2 ¹² (128.0 µs)

Note 1: The prescaler output clock φTn must be selected so that the relationship "φTn ≤ fsys / 2" is satisfied (so that φTn is slower than fsys / 2).

Note 2: Do not change the clock gear while SIO is operating.

Note 3: The dashes in the above table indicate that the setting is prohibited.

10.7.2 Serial Clock Generation Circuit

The serial clock circuit is a block to generate transmit and receive clocks (SIOCLK) and consists of the circuits in which clocks can be selected by the settings of the baud rates generator and modes.

10.7.2.1 Baud Rate Generator

The baud rate generator generates transmit and receive clocks to determine the serial channel transfer rate.

(1) Baud Rate Generator input clock

The input clock of the baud rate generator is selected from the prescaler outputs divided by 2, 8, 32 and 128.

This input clock is selected by setting the SCxBRCR<BRCK>.

(2) Baud Rate Generator output clock

The frequency division ratio of the output clock in the baud rate generator is set by SCxBRCR and SCxBRADD.

The following frequency divide ratios can be used; 1/N frequency division in the I/O interface mode ,either 1/N or N + (16-K)/16 in the UART mode.

The table below shows the frequency division ratio which can be selected.

Mode	Divide Function Setting SCxBRCR <bradde></bradde>	Divide by N SCxBRCR <brs></brs>	Divide by K SCxBRADD <brk></brk>
I/O interface	Divide by N	1 to 16 (Note)	-
LIADT	Divide by N	1 to 16	-
UART	N + (16-K)/16 division	2 to 15	1 to 15

Note: 1/N (N=1)frequency division ratio can be used only when a double buffer is enabled.

10.7 Clock Control TMPM332FWUG

10.7.2.2 Clock Selection Circuit

A clock can be selected by setting the modes and the register.

Modes can be specified by setting the SCxMOD0<SM>.

The input clock in I/O interface mode is selected by setting SCxCR. The clock in UART mode is selected by setting SCxMOD0<SC>.

(1) Transfer Clock in I/O interface mode

Table 10-6 shows clock selection in I/O interface mode.

Table 10-6 Clock Selection in I/O Interface Mode

Mode SCxMOD0 <sm></sm>	Input/Output selection SCxCR <ioc></ioc>	Clock edge selection SCxCR <sclks></sclks>	Clock of use
	SCLK output	Set to "0". (Fixed to the rising edge)	Divided by 2 of the baud rate generator output.
I/O interface mode	SCLK input	Rising edge	SCLK input rising edge
		Falling edge	SCLK input falling edge

To get the highest baud rate, the baud rate generator must be set as below.

Note: When deciding clock settings, make sure that AC electrical character is satisfied.

- <u>Clock/mode control block settings</u>
 - fc = 40MHz
 - fgear = 40MHz (CGSYSCR<GEAR[2:0]> = "000" : fc selected)
 - Φ T0 = 40MHz (CGSYSCR<PRCK[2:0]> = "000" : 1 division ratio)
- SIO settings (if double buffer is used)
 - Clock (SCxBRCR<BRCK[1:0]> = "00" : Φ T1 selected) = 20MHz
 - Divided clock frequency (SCxBRCR<BRS[3:0]> = "0001" : 1 division ratio) = 20MHz

1 division ratio can be selected if double buffer is used. In this case, baud rate is 10Mbps because 20MHz is divided by 2.

- SIO settings (if double buffer is not used)
 - Clock (SCxBRCR<BRCK[1:0]> = "00" : Φ T1 selected) = 20MHz
 - Divided clock frequency (SCxBRCR<BRS[3:0]> = "0010" : 2 division ratio) = 10MHz

2 division ratio is the highest if double buffer is not used. In this case, baud rate is 5Mbps because 10MHz is divided by 2.

To use SCLK input, the following conditions must be satisfied.

- · If double buffer is used
 - SCLK cycle > 6/fsys

The highest band rate is less than $40 \div 6 = 6.66$ Mbps.

- If double buffer is not used
 - SCLK cycle > 8/fsys

The highest band rate is less than $40 \div 8 = 5.0$ Mbps.

(2) Transfer clock in the UART mode

Table 10-7 shows the clock selection in the UART mode. In the UART mode, selected clock is divided by 16 in the receive counter or the transmit counter before use.

Table 10-7 Clock Selection in UART Mode

Mode SCxMOD0 <sm></sm>	Clock selection SCxMOD0 <sc></sc>	
	Timer output	
UART Mode	Baud rate generator	
	fsys	
	SCLK input	

The examples of baud rate in each clock settings.

- If the baud rate generator is used
 - fc = 40MHz
 - fgear = 40MHz (CGSYSCR<GEAR[2:0]> = "000" : fc selected)
 - Φ T0 = 40MHz (CGSYSCR<PRCK[2:0]> = "000" : 1 division ratio)
 - Clock = Φ T1 = 20MHz (SCxBRCR<BRCK[1:0]> = "00" : Φ T1 selected)

The highest baud rate is 1.25Mbps because 20MHz is divided by 16.

Table 10-8 shows examples of baud rate when the baud rate generator is used with the following clock settings.

- fc = 9.8304MHz
- fgear = 9.8304MHz (CGSYSCR<GEAR[2:0]> = "000": fc selected)
- Φ T0 = 4.9152MHz (CGSYSCR<PRCK[2:0]> = "001" : 2 division ratio)

Table 10-8 Example of UART Mode Baud Rate (Using the Baud Rate Generator)

fc [MHz]	Division ratio N (SCxBRCR <brs>)</brs>	φT1 (fc/4)	φT4 (fc/16)	φT16 (fc/64)	φT64 (fc/256)
	2	76.800	19.200	4.800	1.200
0.820400	4	38.400	9.600	2.400	0.600
9.830400	8	19.200	4.800	1.200	0.300
	16	9.600	2.400	0.600	0.150

Unit : kbps

• If the SCLK input is used

To use SCLK input, the following conditions must be satisfied.

- SCLK cycle > 2/fsys

The highest band rate must be less than $40 \div 2 \div 16 = 1.25$ Mbps.

· If fsys is used

Since the highest value of fsys is 40MHz, the highest band rate is $40 \div 16 = 2.5$ Mbps.

10.7 Clock Control TMPM332FWUG


· If timer output is used

To enable the timer output, the following condition must be set: a timer flip-flop output inverts when the value of the counter and that of TBxRG0 match. The SIOCLK clock frequency is "Setting value of $TBxRG0 \times 2$ ".

Baud rates can be obtained by using the following formula.

Baud rate calculation

Transfer rate =






Table 10-9 shows the examples of baud rates when the timer output is used with the following clock settings.

- fc = 32MHz / 9.8304MHz / 8MHz
- fgear = 32MHz / 9.8304MHz / 8MHz (CGSYSCR<GEAR[2:0]> = "000" : fc selected)
- ΦT0 = 16MHz / 4.9152MHz / 4MHz (CGSYSCR<PRCK[2:0]> = "001" : 2 division ratio)
- Timer count clock = 4MHz / 1.2287MHz / 1MHz (TBxMOD<TBCLK[1:0]> = "01" : ΦT1 selected)

Table 10-9 Example of UART Mode Baud Rate (Using the Timer Output)

TD::DOO - attica	fc			
TBxRG0 setting	32MHz	9.8304MHz	8MHz	
0x0001	250	76.8	62.5	
0x0002	125	38.4	31.25	
0x0003	-	25.6	-	
0x0004	62.5	19.2	15.625	
0x0005	50	15.36	12.5	
0x0006	=	12.8	-	
0x0008	31.25	9.6	-	
0x000A	25	7.68	6.25	
0x0010	15.625	4.8	-	
0x0014	12.5	3.84	3.125	

Unit : kbps

TMPM332FWUG

10.8 Transmit/Receive Buffer and FIFO

10.8.1 Configuration

Figure 10-3 shows the configuration of transmit buffer, receive buffer and FIFO.

Appropriate settings are required for using buffer and FIFO. The configuration may be predefined depending on the mode.




Figure 10-3 The Configuration of Buffer and FIFO

10.8.2 Transmit/Receive Buffer

Transmit buffer and receive buffer are double-buffered. The buffer configuration is specified by SCxMOD2<WBUF>.

In the case of using a receive buffer, if SCLK input is set to generate clock output in the I/O interface mode or the UART mode is selected, it's double buffered despite the <WBUF> settings. In other modes, it's according to the <WBUF> settings.

Table 10-10 shows correlation between modes and buffers.

Table 10-10 Mode and buffer Composition

Mode		SCxMOD2 <wbuf></wbuf>		
		"0"	"1"	
UART	Transmit	Single	Double	
UART	Receive	Double	Double	
I/O interface (SCLK input)	Transmit	Single	Double	
	Receive	Double	Double	
I/O interface	Transmit	Single	Double	
(SCLK output)	Receive	Single	Double	

10.8.3 FIFO

In addition to the double buffer function above described, 4-byte FIFO can be used.

10.9 Status Flag TMPM332FWUG

To enable FIFO, enable the double buffer by setting SCxMOD2<WBUF> to "1" and SCxFCNF<CNFG> to "1". The FIFO buffer configuration is specified by SCxMOD1<FDPX[1:0]>.

Note: To use TX/RX FIFO buffer, TX/RX FIFO must be cleared after setting the SIO transfer mode (half duplex/full duplex) and enabling FIFO (SCxFCNF<CNFG> = "1").

Table 10-11 shows correlation between modes and FIFO.

Table 10-11 Mode and FIFO Composition

	SCxMOD1 <fdpx[1:0]></fdpx[1:0]>	RX FIFO	TX FIFO
Half duplex RX	"01"	4byte	-
Half duplex TX	"10"	-	4byte
Full duplex	"11"	2byte	2byte

10.9 Status Flag

The SCxMOD2 register has two types of flag. This bit is significant only when the double buffer is enabled.

<RBFLL> is a flag to show that the receive buffer is full. When one frame of data is received and the data is moved from the receive shift register to the receive buffers, this bit changes to "1" while reading this bit changes it to "0".

<TBEMP> shows that the transmit buffers are empty. When data in the transmit buffers is moved to the transmit shift register, this bit is set to "1" When data is set to the transmit buffers, the bit is cleared to "0".

10.10 Error Flag

Three error flags are provided in the SCxCR register. The meaning of the flags is changed depending on the modes. The table below shows the meanings in each mode.

These flags are cleared to "0" after reading the SCxCR register.

Mada	Flag			
Mode	<oerr></oerr>	<perr></perr>	<ferr></ferr>	
UART	Overrun error	Parity error	Framing error	
I/O Interface (SCLK input)	Overrun error	Underrun error (When using double buffer or FIFO)	Final 4a O	
		Fixed to 0 (When a double buffer and FIFO unused)	Fixed to 0	
I/O Interface (SCLK output)	Undefined	Undefined	Fixed to 0	

10.10.1 OERR Flag

In both UART and I/O interface modes, this bit is set to "1" when an error is generated by completing the reception of the next frame of receive data before the receive buffer has been read. If the receive FIFO is enabled, the received data is automatically moved to the receive FIFO and no overrun error will be generated until the receive FIFO is full (or until the usable bytes are fully occupied).

In the I/O interface with SCLK output mode, the SCLK output stops upon setting the flag.

Note: To switch the I/O interface SCLK output mode to other modes, read the SCxCR register and clear the overrun flag.

10.10.2 PERR Flag

This flag indicates a parity error in the UART mode and an under-run error in the I/O interface mode.

In the UART mode, <PERR> is set to "1" when the parity generated from the received data is different from the parity received.

In the I/O interface mode, <PERR> is set to "1" under the following conditions when a double buffer is enabled.

In the SCLK input mode, <PERR> is set to "1" when the SCLK is input after completing data output of the transmit shift register with no data in the tarnsmit buffer.

In the SCLK output mode, <PERR> is set to "1" after completing output of all data and the SCLK output stops.

Note:To switch the I/O interface SCLK output mode to other modes, read the SCxCR register and clear the under-run flag.

10.10.3 FERR Flag

A framing error is generated if the corresponding stop bit is determined to be "0" by sampling the bit at around the center. Regardless of the stop bit length settings in the SCxMOD2<SBLEN>register, the stop bit status is determined by only 1.

This bit is fixed to "0" in the I/O interface mode.

10.11 Receive TMPM332FWUG

10.11 Receive

10.11.1 Receive Counter

The receive counter is a 4-bit binary counter and is up-counted by SIOCLK. In the UART mode, sixteen SIOCLK clock pulses are used in receiving a single data bit and the data symbol is sampled at the seventh, eighth, and ninth pulses. From these three samples, majority logic is applied to decide the received data.

10.11.2 Receive Control Unit

10.11.2.1 I/O interface mode

In the SCLK output mode with SCxCR <IOC> set to "0", the RXD pin is sampled on the rising edge of the shift clock outputted to the SCLK pin.

In the SCLK input mode with SCxCR <IOC> set to "1", the serial receive data RXD pin is sampled on the rising or falling edge of SCLK input signal depending on the SCxCR <SCLKS> setting.

10.11.2.2 UART Mode

The receive control unit has a start bit detection circuit, which is used to initiate receive operation when a normal start bit is detected.

10.11.3 Receive Operation

10.11.3.1 Receive Buffer

The received data is stored by 1 bit in the receive shift register. When a complete set of bits has been stored, the interrupt INTRXx is generated.

When the double buffer is enabled, the data is moved to the receive buffer (SCxBUF) and the receive buffer full flag (SCxMOD2<RBFLL>) is set to "1". The receive buffer full flag is "0" cleared by reading the receive buffer.




Figure 10-4 Receive Buffer Operation

10.11.3.2 Receive FIFO Operation

When FIFO is enabled, the received data is moved from receive buffer to receive FIFO and the receive buffer full flag is cleared immediately. An interrupt will be generated according to the SCxRFC<RIL> setting.

Note: When the data with parity bit are received in UART mode by using the FIFO, the parity error flag is shown the occurring the parity error in the received data.

The following describes configurations and operations in the half duplex RX mode.

SCxMOD1[6:5] =01 : Transfer mode is set to half duplex mode

SCxFCNF[4:0] = 10111 : Automatically inhibits continuous reception after reaching the fill level.

: The number of bytes to be used in the receive FIFO is the same as the interrupt generation fill level.

SCxRFC[1:0] = 00 : The fill level of FIFO in which generated receive interrupt is set to 4-byte.

SCxRFC[7:6] = 11 : Clears receive FIFO and sets the condition of interrupt generation.

After setting of the above FIFO configuration, the data reception is started by writing "1" to the SCxMOD0 <RXE>. When the data is stored all in the receive shift register, receive buffer and receive FIFO, SCxMOD0<RXE> is automatically cleared and the receive operation is finished.

In this above condition, if the cotinuous reception after reaching the fill level is enabed, and it is possible to receive a data continuously with and reading the data in the FIFO.




Figure 10-5 Receive FIFO Operation

10.11 Receive TMPM332FWUG

10.11.3.3 I/O interface mode with SCLK output

In the I/O interface mode and SCLK output setting, SCLK output stops when all received data is stored in the receive buffer and FIFO. So, in this mode, the overrun error flag has no meaning.

The timing of SCLK output stop and re-output depends on receive buffer and FIFO.

(1) Case of single buffer

Stop SCLK output after receiving a data. In this mode, I/O interface can transfer each data with the transfer device by hand-shake.

When the data in a buffer is read, SCLK output is restarted.

(2) Case of double buffer

Stop SCLK output after receiving the data into a receive shift register and a receive buffer.

When the data is read, SCLK output is restarted.

(3) Case of FIFO

Stop SCLK output after receiving the data into a shift register, received buffer and FIFO.

When one byte data is read, the data in the received buffer is transferred into FIFO and the data in the receive shift register is transferred into received buffer and SCLK output is restarted.

And if SCxFCNF<RXTXCNT>is set to "1", SCLK stops and receive operation stops with clearing SCxMOD0<RXE> bit too.

10.11.3.4 Read Received Data

In spite of enabling or disabling FIFO, read the received data from the receive buffer (SCxBUF).

When receive FIFO is disabled, the buffer full flag SCxMOD2<RBFLL> is cleared to "0" by this reading. In the case of the next data can be received in the receive shift register before reading a data from the receive buffer. The parity bit to be added in the 8-bit UART mode as well as the most significant bit in the 9-bit UART mode will be stored in SCxCR<RB8>.

When the receive FIFO is available, the 9-bit UART mode is prohibited because up to 8-bit data can be stored in FIFO. In the 8-bit UART mode, the parity bit is lost but parity error is determined and the result is stored in SCxCR<PERR>.

10.11.3.5 Wake-up Function

In the 9-bit UART mode, the slave controller can be operated in the wake-up mode by setting the wake-up function SCxMOD0 <WU> to "1." In this case, the interrupt INTRXx will be generated only when SCxCR <RB8> is set to "1."

10.11.3.6 Overrun Error

When FIFO is disabled, the overrun errorr is occurred and set overrun flag without completing data read before receiveing the next data. When overrun error is occurred, a content of receive buffer and SCxCR<RB8> is not lost, but a content of receive shift register is lost.

When FIFO is enabled, overrun error is ocurred and set overrun flag by no reading the data before moving the next data into received buffer when FIFO is full . In this case, the contens of FIFO are not lost.

In the I/O interface mode with SCLK output setting, the clock output automatically stops, so this flag has no meaning.

Note: When the mode is changed from I/O interface SCLK outout mode to the other mode, read SCxCR and clear overrun flag.

10.12 Transmission TMPM332FWUG

10.12 Transmission

10.12.1 Transmission Counter

The transmit counter is a 4-bit binary counter and is counted by SIOCLK as in the case of the receive counter. In UART mode, it generates a transmit clock (TXDCLK) on every 16th clock pulse.




Figure 10-6 Generation of Transmission Clock

10.12.2 Transmission Control

10.12.2.1 I/O Interface Mode

In the SCLK output mode with SCxCR<IOC> set to "0", each bit of data in the transmit buffer is outputted to the TXD pin on the falling edge of the shift clock outputted from the SCLK pin.

In the SCLK input mode with SCxCR<IOC> set to "1", each bit of data in the transmit buffer is outputted to the TXD pin on the rising or falling edge of the SCLK input signal according to the SCxCR<SCLKS> setting.

10.12.2.2 UART Mode

When the transmit data is written in the transmit buffer, data transmission is initiated on the rising edge of the next TXDCLK and the transmit shift clock signal is also generated.

10.12.3 Transmit Operation

10.12.3.1 Operation of Transmission Buffer

If double buffering is disabled, the CPU writes data only to Transmit shift Buffer and the transmit interrupt INTTXx is generated upon completion of data transmission.

If double buffering is enabled (including the case the transmit FIFO is enabled), data written to the transmit buffer is moved to the transmit shift register. The INTTXx interrupt is generated at the same time and the transmit buffer empty flag (SCxMOD2<TBEMP>) is set to "1". This flag indicates that the next transmit data can be written. When the next data is written to the transmit buffer, the <TBEMP> flag is cleared to "0".




Figure 10-7 Operation of Transmission Buffer (Double-buffer is enabled)

10.12.3.2 Transmit FIFO Operation

When FIFO is enabled, the maximum 5-byte data can be stored using the transmit buffer and FIFO. Once transmission is enabled, data is transferred to the transmit shift register from the transmit buffer and start transmission. If data exists in the FIFO, the data is moved to the transmit buffer immediately, and the <TBEMP> flag is cleared to "0".

Note: To use TX FIFO buffer, TX FIFO must be cleared after setting the SIO transfer mode (half duplex/full duplex) and enabling FIFO (SCxFCNF<CNFG> = "1").

Settings and operations to transmit 4-byte data stream by setting the transfer mode to half duplex are shown as below.

SCxMOD1[6:5] =10 : Transfer mode is set to half duplex.

SCxFCNF[4:0] = 11011 : Transmission is automatically disabled if FIFO becomes empty.

The number of bytes to be used in the receive FIFO is the same as the interrupt

generation fill level.


SCxTFC[1:0] = 00 : Sets the interrupt generation fill level to "0".

SCxTFC[7:6] = 11 : Clears receive FIFO and sets the condition of interrupt generation.

After above settings are configured, data transmission can be initiated by writing 5 bytes of data to the transmit buffer or FIFO, and setting the SCxMOD1<TXE> bit to "1". When the last transmit data is moved to the transmit buffer, the transmit FIFO interrupt is generated. When transmission of the last data is completed, the clock is stopped and the transmission sequence is terminated.

Once above settings are configured, if the transmission is not set as auto disabled, the transmission should lasts by writing transmit data.

10.12 Transmission TMPM332FWUG



10.12.3.3 I/O interface Mode/Transmission by SCLK Output

If SCLK is set to generate clock the I/O interface mode, the SCLK output automatically stops when all data transmission is completed and underrun error will not occur.

The timing of suspension and resume of SCLK output is different depending on the buffer and FIFO usage.

(1) Single Buffer

The SCLK output stops each time one frame of data is transferred. Handshaking for each data with the other side of communication can be enabled. The SCLK output resumes when the next data is written in the buffer.

(2) Double Buffer

The SCLK output stops upon completion of data transmission of the transmit shift register and the transmit buffer. The SCLK output resumes when the next data is written in the buffer.

(3) FIFO

The transmission of all data stored in the transmit shift register, transmit buffer and FIFO is completed, the SCLK output stops. The next data is written, SCLK output resumes.

If SCxFCNF<RXTXCNT> is configured, SCxMOD0<TXE> bit is cleared at the same time as SCLK stop and the transmission stops.

10.12.3.4 Under-run error

If the transmit FIFO is disabled in the I/O interface SCLK input mode and if no data is set in transmit buffer before the next frame clock input, which occurs upon completion of data transmission from transmit shift register, an under-run error occurs and SCxCR<PERR> is set to "1".

TMPM332FWUG

In the I/O interface mode with SCLK output setting, the clock output automatically stops, so this flag has no meaning.

Note: Before switching the I/O interface SCLK output mode to other modes, read the SCxCR register and clear the underrun flag.

1.13 Handshake function TMPM332FWUG

10.13 Handshake function

The function of the handshake is to enable frame-by-frame data transmission by using the CTS (Clear to send) pin and to prevent overrun errors. This function can be enabled or disabled by SCxMOD0<CTSE>.

When the \overline{CTS} pin is set to "High" level, the current data transmission can be completed but the next data transmission is suspended until the \overline{CTS} pin returns to the "Low" level. However in this case, the INTTXx interrupt is generated in the normal timing, the next transmit data is written in the transmit buffer, and it waits until it is ready to transmit data.

Note: (1) If the CTS signal is set to "H" during transmission, the next data transmission is suspended after the current transmission is completed.

(2) Data transmission starts on the first falling edge of the TXDCLK clock after CTS is set to "L".

Although no \overline{RTS} pin is provided, a handshake control function can easily implemented by assigning one bit of the port for the \overline{RTS} function. By setting the port to "High" level upon completion of data reception (in the receive interrupt routine), the transmit side can be requested to suspend data transmission.




Figure 10-8 Handshake Function




Figure 10-9 CTS Signal timing

TOSHIBA TMPM332FWUG

10.14 Interrupt/Error Generation Timing

10.14.1 RX Interrupts

Figure 10-10 shows the data flow of receive operation and the route of read.




Figure 10-10 Receive Buffer/FIFO Configuration Diagram

10.14.1.1 Single Buffer / Double Buffer

RX interrupts are generated at the time depends on the transfer mode and the buffer configurations, which are given as follows.

Buffer Configurations	UART modes	IO interface modes
Single Buffer	-	Immediately after the raising / falling edge of the last SCLK (Rising or falling is determined according to SCxCR <sclks> setting.)</sclks>
Double Buffer	Around the center of the first stop bit	Immediately after the raising / falling edge of the last SCLK (Rising or falling is determined according to SCxCR <sclks> setting.) On data transfer from the shift register to the buffer by reading buffer.</sclks>

Note: Interrupts are not generated when an overrun error is occurred.

10.14.1.2 FIFO

In use of FIFO, receive interrupt is generated on the condition that the following either operation and SCxRFC<RFIS > setting are established.

- · Reception completion of all bits of one frame.
- · Reading FIFO

Interrupt conditions are decided by the SCxRFC<RFIS> settings as described in Table 10-12.

Table 10-12 Receive Interrupt conditions in use of FIFO

SCxRFC <rfis></rfis>	Interrupt conditions				
"0"	"The fill level of FIFO" is equal to "the fill level of FIFO interruption generation."				
"1"	"The fill level of FIFO" is greater than or equal to "the fill level of FIFO intrruption generation."				

10.14.2 TX interrupts

Figure 10-11 shows the data flow of transmit operation and the route of read.




Figure 10-11 Transmit Buffer/FIFO Configuration Diagram

10.14.2.1 Single Buffer / Double Buffer

TX interrupts are generated at the time depends on the transfer mode and the buffer configurations, which are given as follows.

Buffer Configurations	UART modes	IO interface modes				
Single Buffer	Just before the stop bit is sent	Immediately after the raising / falling edge of the last SCLK (Rising or falling is determined according to SCxCR <sclks> setting.)</sclks>				
Double Buffer	When a data is moved from the transmit buffet to the transmit shift register.					

Note: If double buffer is enabled, a interrupt is also generated when the data is moved from the buffer to the shift register by writing to the buffer.

10.14.2.2 FIFO

In use of FIFO, transmit interrupt is generated on the condition that the fllowing either operation and SCxTFC<TFIS> setting are established.

- · Transmittion completion of all bits of one frame.
- · Writing FIFO

Interrupt conditions are decided by the SCxTFC<TFIS> settings as described in Table 10-13.

Table 10-13 Transmit Interrupt conditions in use of FIFO

SCxTFC <tfis></tfis>	Interrupt conditions				
"0"	"The fill level of FIFO" is equal to "the fill level of FIFO interruption generation."				
"1"	"The fill level of FIFO" is smaller than or equal to "the fill level of FIFO intrruption generation."				

10.14.3 Error Generation

10.14.3.1 UART Mode

modes	9 bits	7 bits 8 bits 7 bits+ Parity 8 bits + Parity	
Framing Error Overrun Error	Around the center of stop bit		
Parity Error	 Around the center of parity bit 		

10.14.3.2 IO Interface Mode

Overrun Error	Immediately after the raising / falling edge of the last SCLK (Rising or falling is determined according to SCxCR <sclks> setting.)</sclks>			
Underrun Error	Immediately after the rising or falling edge of the next SCLK. (Rising or falling is determined according to SCxCR <sclks> setting.)</sclks>			

Note: Over-run error and Under-run error have no meaning in SCLK output mode.

10.15 Software Reset

Software reset is generated by writing SCxMOD2<SWRST[1:0]> as "10" followed by "01".

As a result, SCxMOD0<RXE>, SCxMOD1<TXE>, SCxMOD2<TBEMP><RBFLL><TXRUN>, SCxCR

<OERR><PERR> are initialized. And the receive circuit, the transmit circuit and the FIFO become initial stete. Other states are maintained.

10.16 Operation in Each Mode

10.16.1 Mode 0 (I/O interface mode)

Mode 0 consists of two modes, the SCLK output mode to output synchronous clock and the SCLK input mode to accept synchronous clock from an external source.

The following operational descriptions are for the case use of FIFO is disabled. For details of FIFO operation, refer to the previous sections describing receive/transmit FIFO functions.

10.16.1.1 Transmitting Data

(1) SCLK Output Mode


• If the transmit double buffer is disabled (SCxMOD2<WBUF> = "0")

Data is output from the TXD pin and the clock is output from the SCLK pin each time the CPU writes data to the transmit buffer. When all data is output, an interrupt (INTTXx) is generated.


• If the transmit double buffer is enabled (SCxMOD2<WBUF> = "1")

Data is moved from the transmit buffer to the transmit shift register when the CPU writes data to the transmit buffer while data transmission is halted or when data transmission from the transmit buffer (shift register) is completed. Simultaneously, the transmit buffer empty flag SCxMOD2<TBEMP> is set to "1", and the INTTXx interrupt is generated.

When data is moved from the transmit buffer to the transmit shift register, if the transmit buffer has no data to be moved to the transmit shift register, INTTXx interrupt is not generated and the SCLK output stops.



<WBUF> = "0" (if double buffering is disabled)






Figure 10-12 Transmit Operation in the I/O Interface Mode (SCLK Output Mode)

(2) SCLK Input Mode

• If double buffering is disabled (SCxMOD2<WBUF> = "0")

If the SCLK is input in the condition where data is written in the transmit buffer, 8-bit data is outputted from the TXD pin. When all data is output, an interrupt INTTXx is generated. The next transmit data must be written before the timing point "A" as shown in Figure 10-13.

• If double buffer is enabled (SCxMOD2<WBUF> = "1")

Data is moved from the transmit buffer to the transmit shift register when the CPU writes data to the transmit buffer before the SCLK input becomes active or when data transmission from the transmit shift register is completed. Simultaneously, the transmit buffer empty flag SCxMOD2<TBEMP> is set to "1", and the INTTXx interrupt is generated.

If the SCLK input becomes active while no data is in the transmit buffer, although the internal bit counter is started, an under-run error occurs and 8-bit dummy data (0xFF) is sent.




Figure 10-13 Transmit Operation in the I/O Interface Mode (SCLK Input Mode)

10.16.1.2 Receive

(1) SCLK Output Mode

The SCLK output can be started by setting the receive enable bit SCxMOD0<RXE> to "1".

• If double buffer is disabled (SCxMOD2<WBUF> = "0")

A clock pulse is outputted from the SCLK pin and the next data is stored into the shift register each time the CPU reads received data. When all the 8 bits are received, the INTRXx interrupt is generated.

• If double buffer is enabled (SCxMOD2<WBUF> = "1")

Data stored in the shift register is moved to the receive buffer and the receive buffer can receive the next frame. A data is moved from the shift register to the receive buffer, the receive buffer full flag SCxMOD2<RBFLL> is set to "1" and the INTRXx is generated.

While data is in the receive buffer, if the data cannot be read from the receive buffer before completing reception of the next 8 bits, the INTRXx interrupt is not generated and the SCLK output stops. In this state, reading data from the receive buffer allows data in the shift register to move to the receive buffer and thus the INTRXx interrupt is generated and data reception resumes.




Figure 10-14 Receive Operation in the I/O Interface Mode (SCLK Output Mode)

(2) SCLK Input Mode

In the SCLK input mode, receiving double buffering is always enabled, the received frame can be moved to the receive buffer from the shift register, and the receive buffer can receive the next frame successively.

The INTRx receive interrupt is generated each time received data is moved to the receive buffer.




Figure 10-15 Receive Operation in the I/O Interface Mode (SCLK Input Mode)

10.16.1.3 Transmit and Receive (Full-duplex)

(1) SCLK Output Mode

• If SCxMOD2<WBUF> is set to "0" and the double buffers are disabled

SCLK is outputted when the CPU writes data to the transmit buffer.

Subsequently, 8 bits of data are shifted into receive buffer and the INTRXx receive interrupt is generated. Concurrently, 8 bits of data written to the transmit buffer are outputted from the TXD pin, the INTTXx transmit interrupt is generated when transmission of all data bits has been completed. Then, the SCLK output stops.

The next round of data transmission and reception starts when the data is read from the receive buffer and the next transmit data is written to the transmit buffer by the CPU. The order of reading the receive buffer and writing to the transmit buffer can be freely determined. Data transmission is resumed only when both conditions are satisfied.

• If SCxMOD2<WBUF> is set to "1" and the double buffers are enabled

SCLK is outputted when the CPU writes data to the transmit buffer.

8 bits of data are shifted into the receive shift register, moved to the receive buffer, and the INTRXx interrupt is generated. While 8 bits of data is received, 8 bits of transmit data is outputted from the TXD pin. When all data bits are sent out, the INTTXx interrupt is generated and the next data is moved from the transmit buffer to the transmit shift register.

If the transmit buffer has no data to be moved to the transmit buffer (SCxMOD2<TBEMP> = 1) or when the receive buffer is full (SCxMOD2<RBFULL> = 1), the SCLK output is stopped. When both conditions, receive data is read and transmit data is written, are satisfied, the SCLK output is resumed and the next round of data transmission and reception is started.




Figure 10-16 Transmit/Receive Operation in the I/O Interface Mode (SCLK Output Mode)

(2) SCLK Input Mode

• If SCxMOD2<WBUF> is set to "0" and the transmit double buffer is disabled

When receiving data, double buffer is always enabled regardless of the SCxMOD2 <WBUF> settings.

8-bit data written in the transmit buffer is outputted from the TXD pin and 8 bit of data is shifted into the receive buffer when the SCLK input becomes active. The INTTXx interrupt is generated upon completion of data transmission. The INTTRXx interrupt is generated when the data is moved from shift register to receive buffer after completion of data reception.

Note that transmit data must be written into the transmit buffer before the SCLK input for the next frame (data must be written before the point A in Figure 10-17). Data must be read before completing reception of the next frame data.

• If SCxMOD2<WBUF> is set to "1" and the double buffer is enabled.

The interrupt INTRXx is generated at the timing the transmit buffer data is moved to the transmit shift register after completing data transmission from the transmit shift register. At the same time, data received is shifted to the shift register, it is moved to the receive buffer, and the INTRXx interrupt is generated.

Note that transmit data must be written into the transmit buffer before the SCLK input for the next frame (data must be written before the point A in Figure 10-17). Data must be read before completing reception of the next frame data.

Upon the SCLK input for the next frame, transmission from transmit shift register (in which data has been moved from transmit buffer) is started while receive data is shifted into receive shift register simultaneously.

If data in receive buffer has not been read when the last bit of the frame is received, an overrun error occurs. Similarly, if there is no data written to transmit buffer when SCLK for the next frame is input, an under-run error occurs.




Figure 10-17 Transmit/Receive Operation in the I/O Interface Mode (SCLK Input Mode)

TMPM332FWUG


10.16.2 Mode 1 (7-bit UART mode)

The 7-bit UART mode can be selected by setting the serial mode control register (SCxMOD<SM[1:0]>) to "01".

In this mode, parity bits can be added to the transmit data stream; the serial mode control register (SCxCR<PE>) controls the parity enable/disable setting.

When <PE> is set to "1" (enable), either even or odd parity may be selected using the SCxCR<EVEN> bit. The length of the stop bit can be specified using SCxMOD2<SBLEN>.


The following table shows the control register settings for transmitting in the following data format.



10.16.3 Mode 2 (8-bit UART mode)

The 8-bit UART mode can be selected by setting SCxMOD0<SM[1:0]> to "10." In this mode, parity bits can be added and parity enable/disable is controlled using SCxCR<PE>. If <PE> = "1" (enabled), either even or odd parity can be selected using SCxCR<EVEN>.

The control register settings for receiving data in the following format are as follows:



		7	6	5	4	3	2	1	0	
SCxMOD0	←	х	0	0	0	1	0	0	1	SEt 8-bit UART mode
SCxCR	←	х	0	1	х	х	х	0	0	Odd parity enabled
SCxBRCR	←	0	0	0	1	0	1	0	0	Set 9600bps
SCxMOD0	←	-	-	1	-	-	-	-	-	Reception enabled
x : don't care - : r	no char	nge								

10.16.4 Mode 3 (9-bit UART mode)

The 9-bit UART mode can be selected by setting SCxMOD0 \leq SM[1:0] \geq to "11." In this mode, parity bits must be disabled (SCxCR \leq PE \geq = "0").

The most significant bit (9th bit) is written to bit 7 <TB8> of the serial mode control register 0 (SCxMOD0) for transmitting data. The data is stored in bit 7 <RB8> of the serial control register SCxCR.

When writing or reading data to/from the buffers, the most significant bit must be written or read first before writing or reading to/from SCxBUF.

The stop bit length can be specified using SCxMOD2<SBLEN>.

10.16.4.1 Wakeup function

In the 9-bit UART mode, slave controllers can be operated in the wake-up mode by setting the wake-up function control bit SCxMOD0<WU> to "1."

In this case, the interrupt INTRXx will be generated only when SCxCR<RB8> is set to "1".

Note: The TXD pin of the slave controller must be set to the open drain output mode using the ODE register.





Figure 10-18 Serial Links to Use Wake-up Function

10.16.4.2 Protocol

- 1. Select the 9-bit UART mode for the master and slave controllers.
- 2. Set SCxMOD<WU> to "1" for the slave controllers to make them ready to receive data.
- 3. The master controller is to transmit a single frame of data that includes the slave controller select code (8 bits). In this, the most significant bit (bit 8) <TB8> must be set to "1".



- 4. Each slave controller receives the above data frame; if the code received matches with the controller's own select code, it clears the WU bit to "0".
- 5. The master controller transmits data to the designated slave controller (the controller of which SCxMOD<WU> bit is cleared to "0"). In this, the most significant bit (bit 8) <TB8> must be set to "0".



6. The slave controllers with the <WU> bit set to "1" ignore the receive data because the most significant bit (bit 8) <RB8> is set to "0" and thus no interrupt (INTRXx) is generated. Also, the slave controller with the <WU> bit set to "0" can transmit data to the master controller to inform that the data has been successfully received.

10.	Serial Channel (SIO/UART)

10.16 Operation in Each Mode

TMPM332FWUG

TMPM332FWUG

11. Serial Bus Interface (I2C/SIO)

The TMPM332FWUG contains two Serial Bus Interface (I2C/SIO) channels, in which the following two operating modes are included:

- I2C bus mode (with multi-master capability)
- · Clock-synchronous 8-bit SIO mode

In the I2C bus mode, the I2C/SIO is connected to external devices via SCL and SDA.

In the clock-synchronous 8-bit SIO mode, the I2C/SIO is connected to external devices via SCK, SI and SO.

The following table shows the programming required to put the I2C/SIO in each operating mode.

Table 11-1 Port settings for using serial bus interface

channel	Operating mode	pin	Port Function Regis- ter	Port Output Control Register	Port Input Control Register	Port Open Drain Output Control Register
	I2C bus mode	SCL0 :PG1 SDA0 :PG0	PGFR1[1:0] = "11"	PGCR[1:0] = "11"	PGIE[1:0] = "11"	PGOD[1:0] = "11"
SBI0	SBI0 SIO mode Si		PGFR1[2:0] = "111"	PGCR[2:0] = "101" (SCK0 output) PGCR[2:0] = "001"(SCK0 input)	PGIE[2:0] = "010" (SCK0 output) PGIE[2:0] = "110" (SCK0 input)	PGOD[2:0] = "xxx"
	I2C bus mode	SCL1 :PF5 SDA1 :PF4	PFFR1[5:4] = "11"	PFCR[5:4] = "11"	PFIE[5:4] = "11"	PFOD[5:4] = "11"
SBI1	SIO mode	SCK1 :PF6 SI1 :PF5 SO1 :PF4	PFFR1[6:4] = "111"	PFCR[6:4] = "101" (SCK1output) PFCR[6:4] = "001" (SCK1 input)	PFIE[6:4] = "010" (SCK1 output) PFIE[6:4] = "110" (SCK1 input)	PFOD[6:4] = "xxx"

Note:x: Don't care

11.1 Configuration TMPM332FWUG

11.1 Configuration

The configuration is shown in Figure 11-1.




Figure 11-1 (I2C/SIO) Block Interface

TMPM332FWUG

11.2 Register

The following registers control the serial bus interface and provide its status information for monitoring.

The register below performs different functions depending on the mode. For details, refer to "11.4 Control Registers in the I2C Bus Mode" and "11.7 Control register of SIO mode".

11.2.1 Registers for each channel


The tables below show the registers and register addresses for each channel.

Channel x	Base Address				
Channel0	0x4002_0000				
Channel1	0x4002_0020				

Register name (x=0 to 1)	Address(Base+)		
Control register 0	SBIxCR0	0x0000	
Control register 1	SBIxCR1	0x0004	
Data buffer register	SBIxDBR	0x0008	
I2C bus address register	SBIxI2CAR	0x000C	
Control register 2	SBIxCR2 (writing)	00040	
Status register	SBIxSR (reading)	0x0010	
Baud rate register 0	SBIxBR0	0x0014	

11.3 I2C Bus Mode Data Format

Figure 11-2 shows the data formats used in the I2C bus mode.



 $\begin{array}{c} \text{Note)} \quad \underline{S} : \text{Start condition} \\ R/\overline{W} : \text{Direction bit} \\ \text{ACK} : \text{Acknowledge bit} \\ P : \text{Stop condition} \end{array}$

Once

Figure 11-2 I2C Bus Mode Data Formats

Repeated

11.4 Control Registers in the I2C Bus Mode

The following registers control the serial bus interface in the I2C bus mode and provide its status information for monitoring.

11.4.1 SBIxCR0(Control register 0)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	SBIEN	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7	SBIEN	R/W	Serial bus interface operation
			0:Disable
			1:Enable
			To use the serial bus interface, enable this bit first.
			Since all clocks except SBIxCR0 stop if this bit is disabled, power consumption can be reduced by disabling
			this bit.
			If this bit is disabled after it's been enabled once, the settings of each register are retained.
6-0	-	R	Read as 0.

11.4 Control Registers in the I2C Bus Mode

11.4.2 SBIxCR1(Control register 1)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol		ВС		ACK	-	SCK2	SCK1	SCK0 / SWRMON
After reset	0	0	0	0	1	0	0	1(Note3)

Bit	Bit Symbol	Туре				Function					
31-8	-	R	Read as 0.	Read as 0.							
7-5	BC[2:0]	R/W	Select the number	of bits per transfe	er (Note 1)						
				When <a< td=""><td>CK> = 0</td><td>When <a< td=""><td>CK> = 1</td><td></td><td></td></a<></td></a<>	CK> = 0	When <a< td=""><td>CK> = 1</td><td></td><td></td></a<>	CK> = 1				
			<bc></bc>	Number of clock cycles	Data length	Number of clock cycles	Data length				
			000	8	8	9	8				
			001	1	1	2	1				
			010	2	2	3	2				
			011	3	3	4	3				
			100	4	4	5	4				
			101	5	5	6	5	1			
			110	6	6	7	6]			
			111	7	7	8	7				
			1: Acknowledgeme Slave mode 0: Acknowledgeme	Master mode 0: Acknowledgement clock pulse is not generated. 1: Acknowledgement clock pulse is generated. Slave mode 0: Acknowledgement clock pulse is not counted. 1: Acknowledgement clock pulse is counted.							
3	-	R	Read as 1.								
2-1	SCK[2:1]	R/W	Select internal SCL	output clock free	uency (Note	2).					
0	SCK[0]	W	000 001 010 011 100 101 110	n = 5 n = 6 n = 7 n = 8 n = 9 n = 10 n = 11	385 kHz 294 kHz 200 kHz 122 kHz 68 kHz 36 kHz 19 kHz reserved		n Clock: fsys (gear : fc/1 ncy = fsys 2 ⁿ + ·	= 40 MHz) 3 72 [Hz]			
	SWRMON	R	On reading <swri 0:Software reset op 1:Software reset op</swri 	eration is in prog	ress.	nonitor					

- Note 1: Clear <BC[2:0]> to "000" before switching the operation mode to the SIO mode.
- Note 2: For details on the SCL line clock frequency, refer to "11.5.1 Serial Clock".
- Note 3: After a reset, the <SCK[0]/SWRMON> bit is read as "1". However, if the SIO mode is selected at the SBIxCR2 register, the initial value of the <SCK[0]> bit is "0".
- Note 4: The initial value for selecting a frequency is <SCK[2:0]>=000 and is independent of the read initial value.

11.4 Control Registers in the I2C Bus Mode

11.4.3 SBIxCR2(Control register 2)

This register serves as SBIxSR register by reading it.

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	MST	TRX	ВВ	PIN	SBIM		SWRST	
After reset	0	0	0	1	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7	MST	W	Select master/slave
			0: Slave mode
			1: Master mode
6	TRX	W	Select transmit/ receive
			0: Receive
			1: Transmit
5	ВВ	W	Start/stop condition generation
			0: Stop condition generated
			1: Start condition generated
4	PIN	W	Clear INTSBIx interrupt request
			0: –
			1: Clear interrupt request
3-2	SBIM[1:0]	W	Select serial bus interface operating mode (Note)
			00: Port mode (Disables a serial bus interface output)
			01: SIO mode
			10: I2C bus mode
			11: Reserved
1-0	SWRST[1:0]	W	Software reset generation
			Write "10" followed by "01" to generate a reset.

Note: Make sure that modes are not changed during a communication session. Ensure that the bus is free before switching the operating mode to the port mode. Ensure that the port is at the "High" level before switching the operating mode from the port mode to the I2C bus or clock-synchronous 8-bit SIO mode.

11.4.4 SBIxSR (Status Register)

This register serves as SBIxCR2 by writing to it.

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	MST	TRX	BB	PIN	AL	AAS	ADO	LRB
After reset	0	0	0	1	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7	MST	R	Master/slave selection monitor
			0: Slave mode
			1: Master mode
6	TRX	R	Transmit/receive selection monitor
			0: Receive
			1: Transmit
5	ВВ	R	I2C bus state monitor
			0: Free
			1: Busy
4	PIN	R	INTSBlx interrupt request monitor
			0:Interrupt request generated
			1: Interrupt request cleared
3	AL	R	Arbitration lost detection
			0: –
			1:Detected
2	AAS	R	Slave address match detection
			0: –
			1: Detected
			(This bit is set when the general call is detected as well.)
1	ADO	R	General call detection
			0: –
			1:Detected
0	LRB	R	Last received bit monitor
			0:Last received bit "0"
			1:Last received bit "1"

11.4.5 SBIxBR0(Serial bus interface baud rate register 0)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	I2SBI	-	-	-	-	-	-
After reset	1	0	1	1	1	1	1	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7	-	R	Read as 1.
6	I2SBI	R/W	Operation at the IDLE mode 0: Stop 1: Operate
5-1	-	R	Read as 1.
0	-	R/W	Be sure to write "0".

11.4.6 SBIxDBR (Serial bus interface data buffer register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	1	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol					В			-
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-0	DB[7:0]	R (Receive)/ W (Transmit)	Receive data / Transmit data

Note 1: The transmission data must be written in to the register from the MSB (bit 7). The received data is stored in the LSB.

Note 2: Since SBIxI2CAR has independent buffers for writing and reading, a written data cannot be read. Thus, read-modify-write instructions, such as bit manipulation, cannot be used.

11.4.7 SBIxI2CAR (I2Cbus address register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol				SA				ALS
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-1	SA[6:0]	R/W	Set the slave address when the SBI acts as a slave device.
0	ALS	R/W	Specify address recognition mode. 0: Recognize its slave address.
			1: Do not recognize its slave address (free-data format).

Note 1: Please set the bit 0 <ALS> of I2C bus address register SBIxI2CAR to "0", except when you use a free data format. It operates as a free data format when setting it to "1". Selecting the master fixes to transmission. Selecting the slave fixes to reception.

Note 2: Do not set SBIxI2CAR to "0x00" in slave mode. (If SBIxI2CAR is set to "0x00", it's recognized that the slave address matches the START byte ("0x01") of the I2C standard received in slave mode.)

11.5 Control in the I2C Bus Mode

11.5.1 Serial Clock

11.5.1.1 Clock source

SBIxCR1<SCK[2:0]> specifies the maximum frequency of the serial clock to be output from the SCL pin in the master mode.




Figure 11-3 Clock source

Note: The maximum speeds in the standard and high-speed modes are specified to 100kHz and 400kHz respectively following the communications standards. Notice that the internal SCL clock frequency is determined by the fsys used and the calculation formula shown above.

11.5.1.2 Clock Synchronization

The I2C bus is driven by using the wired-AND connection due to its pin structure. The first master that pulls its clock line to the "Low" level overrides other masters producing the "High" level on their clock lines. This must be detected and responded by the masters producing the "High" level.

Clock synchronization assures correct data transfer on a bus that has two or more master.

For example, the clock synchronization procedure for a bus with two masters is shown below.




Figure 11-4 Example of Clock Synchronization

At the point a, Master A pulls its internal SCL output to the "Low" level, bringing the SCL bus line to the "Low" level. Master B detects this transition, resets its "High" level period counter, and pulls its internal SCL output level to the "Low" level.

Master A completes counting of its "Low" level period at the point b, and brings its internal SCL output to the "High" level. However, Master B still keeps the SCL bus line at the "Low" level, and Master A stops counting of its "High" level period counting. After Master A detects that Master B brings its internal SCL output to the "High" level and brings the SCL bus line to the "High" level at the point c, it starts counting of its "High" level period.

After that Master finishes counting the "High" level period, the Master pulls the SCL pin to "Low" and the SCL bus line becomes "Low".

This way, the clock on the bus is determined by the master with the shortest "High" level period and the master with the longest "Low" level period among those connected to the bus.

11.5.2 Setting the Acknowledgement Mode

Setting SBIxCR1<ACK> to "1" selects the acknowledge mode. When operating as a master, the SBI adds one clock for acknowledgment signal. In slave mode, the clock for acknowledgement signals is counted. In transmitter mode, the SBI releases the SDAx pin during clock cycle to receive acknowledgement signals from the receiver. In receiver mode, the SBI pulls the SDAx pin to the "Low" level during the clock cycle and generates acknowledgement signals. Also in slave mode, if a general-call address is received, the SBI pulls the SDAx pin to the "Low" level during the clock cycle and generates acknowledgement signals.

By setting <ACK> to "0", the non-acknowledgment mode is activated. When operating as a master, the SBI does not generate clock for acknowledgement signals. In slave mode, the clock for acknowledgement signals is counted.

11.5.3 Setting the Number of Bits per Transfer

SBIxCR1<BC[2:0]> specifies the number of bits of the next data to be transmitted or received.

Under the start condition, <BC[2:0]> is set to "000", causing a slave address and the direction bit to be transferred in a packet of eight bits. At other times, <BC[2:0]> keeps a previously programmed value.

11.5.4 Slave Addressing and Address Recognition Mode

Setting "0" to SBIxI2CAR<ALS> and a slave address in SBIxI2CAR<SA[6:0]> sets addressing format, and then the SBI recognizes a slave address transmitted by the master device and receives data in the addressing format.

If <ALS> is set to "1", the SBI does not recognize a slave address and receives data in the free data format. In the case of free data format, a slave address and a direction bit are not recognized; they are recognized as data immediately after generation of the start condition.

11.5.5 Operating mode

The setting of SBIxCR2<SBIM[1:0]> controls the operating mode. To operate in I2C mode, ensure that the serial bus interface pins are at "High" level before setting <SBIM[1:0]> to "10". Also, ensure that the bus is free before switching the operating mode to the port mode.

11.5.6 Configuring the SBI as a Transmitter or a Receiver

Setting SBIxCR2<TRX> to "1" configures the SBI as a transmitter. Setting <TRX> to "0" configures the SBI as a receiver.

At the slave mode:

- when data is transmitted in the addressing format.
- when the received slave address matches the value specified at SBIxI2CAR.
- when a general-call address is received; i.e., the eight bits following the start condition are all zeros.

If the value of the direction bit (R/\overline{W}) is "1", $\langle TRX \rangle$ is set to "1" by the hardware. If the bit is "0", $\langle TRX \rangle$ is set to "0".

As a master device, the SBI receives acknowledgement from a slave device. If the direction bit of "1" is transmitted, <TRX> is set to "0" by the hardware. If the direction bit is "0", <TRX> changes to "1". If the SBI does not receive acknowledgement, <TRX> retains the previous value.

<TRX> is cleared to "0" by the hardware when it detects the stop condition on the bus or the arbitration lost.

If SBI is used in free data format, <TRX> is not changed by the hardware.

11.5.7 Configuring the SBI as a Master or a Slave

Setting SBIxCR2<MST> to "1" configures the SBI to operate as a master device.

Setting <MST> to "0" configures the SBI as a slave device. <MST> is cleared to "0" by the hardware when it detects the stop condition on the bus or the arbitration lost.

11.5.8 Generating Start and Stop Conditions

When SBIxSR<BB> is "0", writing "1" to SBIxCR2<MST, TRX, BB, PIN> causes the SBI to start a sequence for generating the start condition and to output the slave address and the direction bit prospectively written in the data buffer register. <ACK> must be set to "1" in advance.




Figure 11-5 Generating the Start Condition and a Slave Address

When <BB> is "1", writing "1" to <MST, TRX, PIN> and "0" to <BB> causes the SBI to start a sequence for generating the stop condition on the bus. The contents of <MST, TRX, BB, PIN> should not be altered until the stop condition appears on the bus.

If SCL bus line is pulled "Low" by other devices when the stop condition is generated, the stop condition is generated after the SCL line is released.




Figure 11-6 Generating the Stop Condition

SBIxSR<BB> can be read to check the bus state. <BB> is set to "1" when the start condition is detected on the bus (the bus is busy), and cleared to "0" when the stop condition is detected (the bus is free).

11.5.9 Interrupt Service Request and Release

In master mode, a serial bus interface request (INTSBIx) is generated when the transfer of the number of clock cycles set by <BC> and <ACK> is completed.

In slave mode, INTSBIx is generated under the following conditions.

- After output of the acknowledge signal which is generated when the received slave address matches the slave address set to SBIxI2CAR<SA[6:0]>.
- After the acknowledge signal is generated when a general-call address is received.
- When the slave address matches or a data transfer is completed after receiving a general-call address.

In the address recognition mode (<ALS>= "0"), INTSBIx is generated when the received slave address matches the values specified at SBIxI2CAR or when a general-call (eight bits data following the start condition is all "0") is received.

When an interrupt request (INTSBIx) is generated, SBIxCR2<PIN> is cleared to "0". While <PIN> is cleared to "0", the SBI pulls the SCL line to the "Low" level.

<PIN> is set to "1" when data is written to or read from SBIxDBR. It takes a period of t_{LOW} for the SCL line to be released after <PIN> is set to "1". When the program writes "1" to <PIN>, it is set to "1". However, writing "0" does not clear this bit to "0".

Note: When arbitration is lost in master mode, <PIN> is not cleared to "0" if the slave address does not match (INTSBIx is generated).

11.5.10 Arbitration Lost Detection Monitor

The I2C bus has the multi-master capability (there are two or more masters on a bus), and requires the bus arbitration procedure to ensure correct data transfer.

A master that attempts to generate the start condition while the bus is busy loses bus arbitration, with no start condition occurring on the SDA and SCL lines. The I2C-bus arbitration takes place on the SDA line.

The arbitration procedure for two masters on a bus is shown below.

Up until the point a, Master A and Master B output the same data. At the point a, Master A outputs the "Low" level and Master B outputs the "High" level.

Then Master A pulls the SDA bus line to the "Low" level because the line has the wired-AND connection. When the SCL line goes high at the point b, the slave device reads the SDA line data, i.e., data transmitted by Master A. At this time, data transmitted by Master B becomes invalid.

This condition of Master B is called "Arbitration Lost". Master B releases its SDA pin, so that it does not affect the data transfer initiated by another master. If two or more masters have transmitted exactly the same first data word, the arbitration procedure continues with the second data word.




Figure 11-7 Lost Arbitration

A master compares the SDA bus line level and the internal SDA output level at the rising of the SCL line. If there is a difference between these two values, Arbitration Lost occurs and SBIxSR<AL> is set to "1".

When <AL> is set to "1", SBIxSR<MST, TRX> are cleared to "0", causing the SBI to operate as a slave receiver. Therefore, the serial bus interface circuit stops the clock output during data transfer after <AL> is set to "1".

<AL> is cleared to "0" when data is written to or read from SBIxDBR or data is written to SBIxCR2.




Figure 11-8 Example of Master B Lost Arbitration (D7A = D7B, D6A = D6B)

11.5.11 Slave Address Match Detection Monitor

When the SBI operates as a slave device in the address recognition mode (SBIxI2CAR<ALS>="0"), SBIxSR<AAS> is set to "1" on receiving the general-call address or the slave address that matches the value specified at SBIxI2CAR.

When <ALS> is "1", <AAS> is set to "1" when the first data word has been received. <AAS> is cleared to "0" when data is written to or read from SBIxDBR.

11.5.12 General-call Detection Monitor

When the SBI operates as a slave device, SBIxSR<AD0> is set to "1" when it receives the general-call address; i.e., the eight bits following the start condition are all zeros.

<AD0> is cleared to "0" when the start or stop condition is detected on the bus.

11.5.13 Last Received Bit Monitor

SBIxSR<LRB> is set to the SDA line value that was read at the rising of the SCL line.

In the acknowledgment mode, reading SBIxSR<LRB> immediately after generation of the INTSBIx interrupt request causes ACK signal to be read.

11.5.14 Data Buffer Register (SBIxDBR)

Reading or writing SBIxDBR initiates reading received data or writing transmitted data.

When the SBI is acting as a master, setting a slave address and a direction bit to this register generates the start condition.

11.5.15 Baud Rate Register (SBIxBR0)

The SBIxBR0<I2SBI> register determines if the SBI operates or not when it enters the IDLE mode.

This register must be programmed before executing an instruction to switch to the standby mode.

11.5.16 Software Reset

If the serial bus interface circuit locks up due to external noise, it can be initialized by using a software reset.

Writing "10" followed by "01" to SBIxCR2<SWRST[1:0]> generates a reset signal that initializes the serial bus interface circuit. After a reset, all control registers and status flags are initialized to their reset values. When the serial bus interface is initialized, <SWRST> is automatically cleared to "0".

Note: A software reset causes the SBI operating mode to switch from the I2C mode to the port mode.

11.6 Data Transfer Procedure in the I2C Bus Model2C

11.6.1 **Device Initialization**

First, program SBIxCR1<ACK, SCK[2:0]>. Writing "000" to SBIxCR1<BC[2:0]> at the time.

Next, program SBIxI2CAR by specifying a slave address at <SA[6:0]> and an address recognition mode at <ALS>. (<ALS> must be cleared to "0" when using the addressing format).

To configure the Serial Bus Interface as a slave receiver, ensure that the serial bus interface pin is at "High" first. Then write "0" to SBIxCR2<MST, TRX, BB>, "1" to <PIN>, "10" to <SBIM[1:0]> and "0" to the bit 1 and

Note: Initialization of the serial bus interface circuit must be completed within a period that any device does not generate start condition after all devices connected to the bus were initialized. If this rule is not followed, data may not be received correctly because other devices may start transfer before the initialization of the serial bus interface circuit is completed.

		7	6	5	4	3	2	1	0	
SBIxCR1	←	0	0	0	Χ	0	Χ	Χ	Χ	Specifies ACK and SCL clock.
SBIxI2CAR	←	Χ	Χ	Χ	Χ	Χ	Χ	Χ	Χ	Specifies a slave address and an address recognition mode.
SBIxCR2	←	0	0	0	1	1	0	0	0	Configures the SBI as a slave receiver.

Note: X: Don't care

11.6.2 Generating the Start Condition and a Slave Address

11.6.2.1 Master mode

In the master mode, the following steps are required to generate the start condition and a slave address.


First, ensure that the bus is free (<BB> = "0"). Then, write "1" to SBIxCR1<ACK> to select the acknowledgment mode. Write to SBIxDBR a slave address and a direction bit to be transmitted.

When <BB> = "0", writing "1111" to SBIxCR2<MST, TRX, BB, PIN> generates the start condition on the bus. Following the start condition, the SBI generates nine clocks from the SCL pin. The SBI outputs the slave address and the direction bit specified at SBIxDBR with the first eight clocks, and releases the SDA line in the ninth clock to receive an acknowledgment signal from the slave device.

The INTSBIx interrupt request is generated on the falling of the ninth clock, and <PIN> is cleared to "0". In the master mode, the SBI holds the SCL line at the "Low" level while <PIN> is = "0".<TRX> changes its value according to the transmitted direction bit at generation of the INTSBIx interrupt request, provided that an acknowledgment signal has been returned from the slave device.

Note: To output salve address, check with software that the bus is free before writing to SBIxDBR. If this rule is not followed, data being output on the bus may get ruined.

Settings in main routine



11.6.2.2 Slave mode

In the slave mode, the SBI receives the start condition and a slave address.

After receiving the start condition from the master device, the SBI receives a slave address and a direction bit from the master device during the first eight clocks on the SCL line.

If the received address matches its slave address specified at SBIxI2CAR or is equal to the general-call address, the SBI pulls the SDA line to the "Low" level during the ninth clock and outputs an acknowledgment signal.

The INTSBIx interrupt request is generated on the falling of the ninth clock, and <PIN> is cleared to "0". In the slave mode, the SBI holds the SCL line at the "Low" level while <PIN> is "0".




Figure 11-9 Generation of the Start Condition and a Slave Address

11.6.3 Transferring a Data Word

At the end of a data word transfer, the INTSBIx interrupt is generated to test <MST> to determine whether the SBI is in the master or slave mode.

11.6.3.1 Master mode (<MST> = "1")

Test <TRX> to determine whether the SBI is configured as a transmitter or a receiver.

(1) Transmitter mode (<TRX> = "1")

Test <LRB>. If <LRB> is "1", that means the receiver requires no further data.

The master then generates the stop condition as described later to stop transmission.

If <LRB> is "0", that means the receiver requires further data. If the next data to be transmitted has eight bits, the data is written into SBIxDBR. If the data has different length, <BC[2:0]> and <ACK> are programmed and the transmit data is written into SBIxDBR. Writing the data makes <PIN> to "1", causing the SCL pin to generate a serial clock for transferring a next data word, and the SDA pin to transfer the data word.

After the transfer is completed, the INTSBIx interrupt request is generated, <PIN> is cleared to "0", and the SCL pin is pulled to the "Low" level.

To transmit more data words, test <LRB> again and repeat the above procedure.

INTSBIx interrupt

if MST = 0

Then go to the slave-mode processing.

if TRX = 0

Then go to the receiver-mode processing.

if LRB = 0

Then go to processing for generating the stop condition.

Specifies the number of bits to be transmitted and specify whether ACK is required.

Writes the transmit data.

End of interrupt processing.

Note: X; Don't care




Figure 11-10 <BC[2:0]>= "000", <ACK>= "1" (Transmitter Mode)

(2) Receiver mode (<TRX> = "0")

If the next data to be transmitted has eight bits, the transmit data is written into SBIxDBR.

If the data has different length, <BC[2:0]> and <ACK> are programmed and the received data is read from SBIxDBR to release the SCL line. (The data read immediately after transmission of a slave address is undefined.)On reading the data, <PIN> is set to "1", and the serial clock is output to the SCL pin to transfer the next data word.In the last bit, when the acknowledgment signal becomes the "Low" level, "0" is output to the SDA pin.

After that, the INTSBIx interrupt request is generated, and <PIN> is cleared to "0", pulling the SCL pin to the "Low" level. Each time the received data is read from SBIxDBR, one-word transfer clock and an acknowledgement signal are output.




Figure 11-11 <BC[2:0]>= "000",<ACK>= "1" (Receiver Mode)

To terminate the data transmission from the transmitter, <ACK> must be cleared to "0" immediately before reading the data word second to last.

This disables generation of an acknowledgment clock for the last data word.

When the transfer is completed, an interrupt request is generated. After the interrupt processing, <BC [2:0]> must be set to "001" and the data must be read so that a clock is generated for 1-bit transfer.

At this time, the master receiver holds the SDA bus line at the "High" level, which signals the end of transfer to the transmitter as an acknowledgment signal.

In the interrupt processing for terminating the reception of 1-bit data, the stop condition is generated to terminate the data transfer.




Figure 11-12 Terminating Data Transmission in the Master Receiver Mode

Example: When receiving N data word

INTSBIx interrupt (after data transmission)



INTSBIx interrupt (first to (N-2)th data reception)



INTSBIx interrupt ((N-1)th data reception)



INTSBIx interrupt (Nth data reception)



INTSBIx interrupt (after completing data reception)

Processing to generate the stop condition.

End of interrupt

Terminates the data transmission.

Note: X; Don't care

TMPM332FWUG

11.6.3.2 Slave mode (<MST> = "0")

In the slave mode, the SBI generates the INTSBIx interrupt request on four occasions:

- 1) when the SBI has received any slave address from the master.
- 2) when the SBI has received a general-call address.
- 3) when the received slave address matches its address.
- 4) when a data transfer has been completed in response to a general-call.

Also, if the SBI detects Arbitration Lost in the master mode, it switches to the slave mode.

Upon the completion of data word transfer in which Arbitration Lost is detected, the INTSBIx interrupt request is generated, <PIN> is cleared to "0", and the SCL pin is pulled to the "Low" level.

When data is written to or read from SBIxDBR or when <PIN> is set to "1", the SCLx pin is released after a period of t_{LOW} .

In the slave mode, the normal slave mode processing or the processing as a result of Arbitration Lost is carried out.

SBIxSR<AL>, <TRX>, <AAS> and <AD0> are tested to determine the processing required.

"Table 11-2 Processing in Slave Mode"shows the slave mode states and required processing.

Example: When the received slave address matches the SBI's own address and the direction bit is "1" in the slave receiver mode.

INTSBIx interrupt

```
if TRX = 0
Then go to other processing.
if AL = 0
Then go to other processing.
if AAS = 0
Then go to other processing.
SBIxCR1
                                              Х
                                                   Х
                                                         Х
                                                                    Sets the number of bits to be transmitted.
SBIxDBR
                         Х
                                              Х
                                                         Χ
                                                                    Sets the transmit data
                   Х
```

Table 11-2 Processing in Slave Mode

<trx></trx>	<al></al>	<aas></aas>	<ad0></ad0>	State	Processing
	1 1		0	Arbitration Lost is detected while the slave address was being transmitted and the SBI received a slave address with the direction bit "1" transmitted by another master.	Set the number of bits in a data word to <bc[2:0]> and write the transmit data into SBIXDBR.</bc[2:0]>
1		1	0	In the slave receiver mode, the SBI received a slave address with the direction bit "1" transmitted by the master.	write the transmit data into SbixDbk.
	0	0	0	In the slave transmitter mode, the SBI has completed a transmission of one data word.	Test LRB. If it has been set to "1", that means the receiver does not require further data. Set <pin> to 1 and reset <trx> to 0 to release the bus. If <lrb> has been reset to "0", that means the receiver requires further data. Set the number of bits in the data word to <bc[2:0]> and write the transmit data to the SBIxDBR.</bc[2:0]></lrb></trx></pin>
	1	1	1/0	Arbitration Lost is detected while a slave address is being transmitted, and the SBI receives either a slave address with the direction bit "0" or a general-call address transmitted by another master.	
0		0	0	Arbitration Lost is detected while a slave address or a data word is being transmitted, and the transfer is terminated.	Read the SBIxDBR (a dummy read) to set <pin> to 1, or write "1" to <pin>.</pin></pin>
	0	1	1/0	In the slave receiver mode, the SBI received either a slave address with the direction bit "0" or a general-call address transmitted by the master.	
		0	1/0	In the slave receiver mode, the SBI has completed a reception of a data word.	Set the number of bits in the data word to <bc[2:0].> and read the received data from SBIxDBR.</bc[2:0].>

11.6.4 Generating the Stop Condition

When SBIxSR<BB> is "1", writing "1" to SBIxCR2<MST, TRX, PIN> and "0" to <BB> causes the SBI to start a sequence for generating the stop condition on the bus.

Do not alter the contents of <MST, TRX, BB, PIN> until the stop condition appears on the bus.

If another device is holding down the SCL bus line, the SBI waits until the SCL line is released.

After that, the SDA pin goes "High", causing the stop condition to be generated.

 $7 \quad 6 \quad 5 \quad 4 \quad 3 \quad 2 \quad 1 \quad 0$ SBIxCR2 $\leftarrow \quad 1 \quad 1 \quad 0 \quad 1 \quad 1 \quad 0 \quad 0 \quad 0$ Generates the stop condition.




Figure 11-13 Generating the Stop Condition

11.6.5 Restart Procedure

Restart is used when a master device changes the data transfer direction without terminating the transfer to a slave device. The procedure of generating a restart in the master mode is described below.

First, write SBIxCR2<MST, TRX, BB> to "0" and write "1" to <PIN> to release the bus. At this time, the SDAx pin is held at the "High" level and the SCLx pin is released. Because no stop condition is generated on the bus, other devices recognize that the bus is busy.

Then, test SBIxSR<BB> and wait until it becomes "0" to ensure that the SCLx pin is released.

Next, test <LRB> and wait until it becomes "1" to ensure that no other device is pulling the SCLx bus line to the "Low" level.


Once the bus is determined to be free by following the above procedures, follow the procedures described in "11.6.2 Generating the Start Condition and a Slave Address" to generate the start condition.

To satisfy the setup time of restart, at least 4.7µs wait period (in the standard mode) must be created by the software after the bus is determined to be free.

Note 1: Do not write <MST> to "0" when it is "0". (Restart cannot be initiated.)

Note 2: When the master device is acting as a receiver, data transmission from the slave device which serves as a transmitter must be completed before generating a restart. To complete data transfer, slave device must receive a "High" level acknowledge signal. For this reason, <LBR> before generating a

restart becomes "1", the rising edge of the SCL line is not detected even <LBR>= "1" is confirmed by following the restart procedure. To check the status of the SCL line, read the port.



Note:X; Don't care




Figure 11-14 Timing Chart of Generating a Restart

11.7 Control register of SIO mode

The following registers control the serial bus interface in the clock-synchronous 8-bit SIO mode and provide its status information for monitoring.

11.7.1 SBIxCR0(control register 0)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	SBIEN	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function				
31-8	-	R	Read as 0.				
7	SBIEN	R/W	Serial bus interface operation.				
			0:Disable				
			1: Enable				
			nable this bit before using the serial bus interface.				
			If this bit is disabled, power consumption can be reduced because all clocks except SBIxCR0 stop.				
			If the serial bus interface operation is enabled and then disabled, the settings will be maintained in each				
			register.				
6-0	-	R	Read as 0.				

11.7 Control register of SIO mode

11.7.2 SBIxCR1(Control register 1)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	SIOS	SIOINH	SI	OM	-		SCK	-
After reset	0	0	0	0	1	0	0	0(Note 1)

Bit	Bit Symbol	Туре	Function						
31-8	-	R	Read as 0.						
7	SIOS	R/W	Transfer Start/Stop 0: Stop						
			1: Start						
6	SIOINH	R/W	Fransfer D: Continue						
			1: Forced termination						
5-4	SIOM[1:0]	R/W	Select transfer mode 00: Transmit mode 01: Reserved 10:Transmit/receive mode 11:Receive mode						
3	-	R	Read as 1.						
2-0	SCK[2:0]	R/W	On writing <sck[2:0]>: Select serial clock frequency. (Note 1)</sck[2:0]>						
			000 n = 3 2.5 MHz						
			001 n = 4 1.25 MHz						
			010 n = 5 625 kHz (System clock: fsys						
			011 n = 6 313 kHz						
			100 n = 7 156 kHz Clock gear: fc/1						
			101						
			110 n = 9 39 kHz						
			111 - External clock						

Note 1: After a reset, the <SCK[0]> bit is read as "1". However, if the SIO mode is selected at the SBIxCR2 register, the initial value is read as "0". In this document, the value written in the column "after reset" is the value after setting the SIO mode in the initial state. The descriptions of the SBIxCR2 register and the SBIxSR register are the same.

Note 2: Set <SIOS> to "0" and <SIOINH> to "1" before programming the transfer mode and the serial clock.

11.7.3 SBIxDBR (Data buffer register)

	31	30	29	28	27	26	25	24			
bit symbol	-	-	-	-	-	-	-	-			
After reset	0	0	0	0	0	0	0	0			
	23	22	21	20	19	18	17	16			
bit symbol	-	-	-	-	-	-	-	-			
After reset	0	0	0	0	0	0	0	0			
	15	14	13	12	11	10	9	8			
bit symbol	-	-	-	-	-	-	-	-			
After reset	0	0	0	0	0	0	0	0			
	7	6	5	4	3	2	1	0			
bit symbol	DB										
After reset	0	0	0	0	0	0	0	0			

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-0	DB[7:0]	R	Receive data
		W	Transmit data

Note 1: The transmission data must be written in to the register from the MSB (bit 7). The received data is stored in the LSB

Note 2: Since SBIxI2CAR has independent buffers for writing and reading, a written data cannot be read. Thus, read-modify-write instructions, such as bit manipulation, cannot be used.

11.7.4 SBIxCR2(Control register 2)

This register serves as SBIxSR register by writing to it.

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	1	-	1	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	SE	BIM	-	-
After reset	1(Note 1)	1(Note 1)	1(Note 1)	1(Note 1)	0	0	1(Note 1)	1(Note 1)

Bit	Bit Symbol	Туре	Function			
31-8	-	R	Read as "0".			
7-4	-	R	ead as 1. (Note 1)			
3-2	SBIM[1:0]	w	Select serial bus interface operating mode (Note 2) 00: Port mode 01: SIO mode 10: I2Cbus mode 11: Reserved			
1-0	-	R	Read as 1. (Note 1)			

Note 1: In this document, the value written in the column "after reset" is the value after setting the SIO mode in the initial state.

Note 2: Make sure that modes are not changed during a communication session.

11.7.5 SBIxSR (Status Register)

This register serves as SBIxCR2 by writing to it.

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	SIOF	SEF	-	-
After reset	1(Note 1)	1(Note 1)	1(Note 1)	1(Note 1)	0	0	1(Note 1)	1(Note 1)

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-4	-	R	Read as 1.(Note 1)
3	SIOF	R	Serial transfer status monitor. 0: Completed 1: In progress
2	SEF	R	Shift operation status monitor 0: Completed. 1: In progress
1-0	-	R	Read as 1. (Note 1)

Note: In this document, the value written in the column "after reset" is the value after setting the SIO mode in the initial state.

11.7.6 SBIxBR0 (Baud rate register 0)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	I2SBI	-	-	-	-	-	-
After reset	1	0	1	1	1	1	1	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7	-	R	Read as 1.
6	I2SBI	R/W	Operation in IDLE mode. 0: Stop 1: Operate
5-1	-	R	Read as 1.
0	-	R/W	Make sure to write "0".

TOSHIBA TMPM332FWUG

11.8 Control in SIO mode

11.8.1 Serial Clock

11.8.1.1 Clock source

Internal or external clocks can be selected by programming SBIxCR1<SCK[2:0]>.

(1) Internal clocks

In the internal clock mode, one of the seven frequencies can be selected as a serial clock, which is output to the outside through the SCKx pin.

At the beginning of a transfer, the SCKx pin output becomes the "High" level.

If the program cannot keep up with this serial clock rate in writing the transmit data or reading the received data, the SBI automatically enters a wait period. During this period, the serial clock is stopped automatically and the next shift operation is suspended until the processing is completed.




Figure 11-15 Automatic Wait

(2) External clock (<SCK[2:0]> = "111")

The SBI uses an external clock supplied from the outside to the SCKx pin as a serial clock.

For proper shift operations, the serial clock at the "High" and "Low" levels must have the pulse widths as shown below.




Figure 11-16 Maximum Transfer Frequency of External Clock Input

11.8 Control in SIO mode

11.8.1.2 Shift Edge

Leading-edge shift is used in transmission. Trailing-edge shift is used in reception.

- Leading-edge shift

Data is shifted at the leading edge of the serial clock (or the falling edge of the SCKx pin input/output).

TMPM332FWUG

- Trailing-edge shift

Data is shifted at the trailing edge of the serial clock (or the rising edge of the SCKx pin input/output).




Figure 11-17 Shift Edge

TMPM332FWUG

11.8.2 Transfer Modes

The transmit mode, the receive mode or the transmit/receive mode can be selected by programming SBIxCR1<SIOM[1:0]>.

11.8.2.1 8-bit transmit mode

Set the control register to the transmit mode and write the transmit data to SBIxDBR.

After writing the transmit data, writing "1" to SBIxCR1<SIOS> starts the transmission. The transmit data is moved from SBIxDBR to a shift register and output to the SO pin, with the least-significant bit (LSB) first, in synchronization with the serial clock. Once the transmit data is transferred to the shift register, SBIxDBR becomes empty, and the INTSBIx (buffer-empty) interrupt is generated, requesting the next transmit data.

In the internal clock mode, the serial clock will be stopped and automatically enter the wait state, if next data is not loaded after the 8-bit data has been fully transmitted. The wait state will be cleared when SBIxDBR is loaded with the next transmit data.

In the external clock mode, SBIxDBR must be loaded with data before the next data shift operation is started. Therefore, the data transfer rate varies depending on the maximum latency between when the interrupt request is generated and when SBIxDBR is loaded with data in the interrupt service program.

At the beginning of transmission, the same value as in the last bit of the previously transmitted data is output in a period from setting SBIxSR<SIOF> to "1" to the falling edge of SCK.

Transmission can be terminated by clearing <SIOS> to "0" or setting <SIOINH> to "1" in the INTSBIx interrupt service program. If <SIOS> is cleared, remaining data is output before transmission ends. The program checks SBIxSR<SIOF> to determine whether transmission has come to an end. <SIOF> is cleared to "0" at the end of transmission. If <SIOINH> is set to "1", the transmission is aborted immediately and <SIOF> is cleared to "0".

When in the external clock mode, <SIOS> must be cleared to "0" before next data shifting. If <SIOS> does not be cleared to "0" before next data shifting, SBI output dummy data and stopped.

		7	6	5	4	3	2	1	0	
SBIxCR1	←	0	1	0	0	0	Χ	Χ	Χ	Selects the transmit mode.
SBIxDBR	←	Х	Χ	Х	Χ	Χ	Χ	Χ	Χ	Writes the transmit data.
SBIxCR1	←	1	0	0	0	0	Χ	Χ	Χ	Starts transmission.
INTSBIx in	terru	pt								
SBIxDBR	_	Х	Х	х	Х	х	Х	х	Х	Writes the transmit data.
CEIXDDIX	,	^	/\	^	^	/\	^	/\	, ,	TTITLOG THE HUNGHIN GUTA.

11.8 Control in SIO mode TMPM332FWUG




Figure 11-18 Transmit Mode

Example: Example of programming (external clock) to terminate transmission by <SIO>



11.8.2.2 8-bit receive mode

Set the control register to the receive mode. Then writing "1" to SBIxCR1<SIOS> enables reception.Data is taken into the shift register from the SI pin, with the least-significant bit (LSB) first, in synchronization with the serial clock. Once the shift register is loaded with the 8-bit data, it transfers the received data to SBIxDBR and the INTSBIx (buffer-full) interrupt request is generated to request reading the received data. The interrupt service program then reads the received data from SBIxDBR.

In the internal clock mode, the serial clock will be stopped and automatically be in the wait state until the received data is read from SBIxDBR.

In the external clock mode, shift operations are executed in synchronization with the external clock. The maximum data transfer rate varies, depending on the maximum latency between generating the interrupt request and reading the received data

Reception can be terminated by clearing <SIOS> to "0" or setting <SIOINH> to "1" in the INTSBIx interrupt service program. If <SIOS> is cleared, reception continues until all the bits of received data are written to SBIxDBR. The program checks SBIxSR<SIOF> to determine whether reception has come to an end.<SIOF> is cleared to "0" at the end of reception. After confirming the completion of the reception, last received data is read. If <SIOINH> is set to "1", the reception is aborted immediately and <SIOF> is cleared to "0". (The received data becomes invalid, and there is no need to read it out.)

Note: The contents of SBIxDBR will not be retained after the transfer mode is changed. The ongoing reception must be completed by clearing <SIOS> to "0" and the last received data must be read before the transfer mode is changed.



INTSBIx interrupt






Figure 11-19 Receive Mode (Example: Internal Clock)

11.8.2.3 8-bit transmit/receive mode

Set the control register to the transfer/receive mode. Then writing the transmit data to SBIxDBR and setting SBIxCR1<SIOS> to "1" enables transmission and reception. The transmit data is output through the SOx pin at the falling of the serial clock, and the received data is taken in through the SI pin at the rising of the serial clock, with the least-significant bit (LSB) first. Once the shift register is loaded with the 8-bit data, it transfers the received data to SBIxDBR and the INTSBIx interrupt request is generated. The interrupt service program reads the received data from the data buffer register and writes the next transmit data. Because SBIxDBR is shared between transmit and receive operations, the received data must be read before the next transmit data is written.

In the internal clock operation, the serial clock will be automatically in the wait state until the received data is read and the next transmit data is written.

In the external clock mode, shift operations are executed in synchronization with the external serial clock. Therefore, the received data must be read and the next transmit data must be written before the next shift operation is started. The maximum data transfer rate for the external clock operation varies depending on the maximum latency between when the interrupt request is generated and when the transmit data is written.

At the beginning of transmission, the same value as in the last bit of the previously transmitted data is output in a period from setting <SIOF> to "1" to the falling edge of SCK.

Transmission and reception can be terminated by clearing <SIOS> to "0" or setting SBIxCR1<SIOINH> to "1" in the INTSBIx interrupt service program. If <SIOS> is cleared, transmission and reception continue until the received data is fully transferred to SBIxDBR. The program checks SBIxSR<SIOF> to determine whether transmission and reception have come to an end. <SIOF> is cleared to "0" at the end of transmission and reception.If <SIOINH> is set to "1", the transmission and reception is aborted immediately and <SIOF> is cleared to "0".

Note: The contents of SBIxDBR will not be retained after the transfer mode is changed. The ongoing transmission and reception must be completed by clearing <SIOS> to "0" and the last received data must be read before the transfer mode is changed.




Figure 11-20 Transmit/Receive Mode (Example: Internal Clock)

		7	6	5	4	3	2	1	0	
SBIxCR1	←	0	1	1	0	0	Χ	Χ	Χ	Selects the transmit mode.
SBIxDBR	←	Х	Χ	Χ	Χ	Χ	Χ	Χ	Χ	Writes the transmit data.
SBIxCR1	←	1	0	1	0	0	Χ	Χ	Χ	Starts reception/transmission.
INTSBIx ir	nterru	pt								
Reg.	←	SB	IxDBF	₹						Reads the received data.
SRIVDER		~	~	~	~	Y	~	~	~	Writes the transmit data

11.8.2.4 Data retention time of the last bit at the end of transmission

Under the condition SBIxCR1<SIOS>= "0", the last bit of the transmitted data retains the data of SCK rising edge as shown below. Transmit mode and transmit/receive mode are the same.




Figure 11-21 Data retention time of the last bit at the end of transmission

Serial Bus	Interface	(I2C/SIO)
	Serial Bus	Serial Bus Interface

11.8 Control in SIO mode TMPM332FWUG

TOSHIBA TMPM332FWUG

12. Consumer Electronics Control (CEC)

12.1 Outline

This IP enables to transmit or receive data that conforms to Consumer Electronics Control (hereafter referred to as CEC) protocol.

This IP can operate conformably to HDMI 1.3a specifications.

12.1.1 Reception

- · Clock sampling at 32.768kHz
 - -Adjustable noise canceling time
- Data reception per 1byte
 - -Flexible data sampling point
 - -Data reception is available even when an address discrepancy is detected.
- · Error detection
 - -Cycle error (min./max.)
 - -ACK collision
 - -Waveform error

12.1.2 Transmission

- Data transmission per 1byte
 - -Triggered by auto-detection of bus free state
- Flexible waveform
 - -Adjustable rising edge and cycle
- Error detection
 - -Arbitration lost
 - -ACK response error

12.1.3 Precautions

Be careful about the following in the receive operation.

Address condition	Setting of CECRCR1 <cecoth></cecoth>	Precautions
Logical address match	-	
Logical address disacre-	When data reception at logical address discrepancy is enabled. (CECRCR1 <cecoth> = "1")</cecoth>	If the initiator sends a new message beginning with the start bit without having sent the last block with EOM="1", a maximum cycle error is determined for the ACK bit and an interrupt is generated. Then, the receive operation is performed in the usual way.
pancy	When data reception at logical address discrepancy is disabled. (CECRCR1 <cecoth> = "0")</cecoth>	The initiator must send the last block of data with the EOM bit set to "1". If the last block is sent with EOM="0", the subsequent operation cannot be guaranteed.

12.2 Block Diagram TMPM332FWUG

12.2 Block Diagram

Figure 12-1 shows the Block Diagram of CEC




Figure 12-1 Block Diagram of CEC

12.3 Registers

12.3.1 Register List

The control registers and address for CEC are as follows.

Base Address = 0x4004_0300

Registers		Address (Base+)	
CEC Enable Register	CECEN	0x0000	
Logical Address Register	CECADD	0x0004	
Software Reset Register	CECRESET	0x0008	
Receive Enable Register	CECREN	0x000C	
Receive Buffer Register	CECRBUF	0x0010	
Receive Control Register 1	CECRCR1	0x0014	
Receive Control Register 2	CECRCR2	0x0018	
Receive Control Register 3	CECRCR3	0x001C	
Transmit Enable Register	CECTEN	0x0020	
Transmit Buffer Register	CECTBUF	0x0024	
Transmit Control Register	CECTCR	0x0028	
Receive Interrupt Status Register	CECRSTAT	0x002C	
Transmit Interrupt Status Register	CECTSTAT	0x0030	

12.3 Registers TMPM332FWUG

12.3.2 CECEN (CEC Enable Register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	I2CEC	CECEN
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-2	-	R	Read as 0.
1	I2CEC	R/W	CEC operation at IDLE.
			0 : Disabled
			1 : Enabled
			Controls the CEC operation at the IDLE mode.
			Set this bit to "1" when using CEC at the IDLE mode.
			The <i2cec> and <cecen> bits can be set simultaneously.</cecen></i2cec>
0	CECEN	R/W	CEC operation
			0 : Disabled
			1 : Enabled
			Specifies the CEC operation.
			Enable CEC before using.
			When the CEC operation is disabled, no clocks are supplied to the CEC module except for the CECEN
			register.
			Thus power consumption can be reduced.
			When CEC is disabled after it was enabled, each register setting is maintained.

12.3.3 CECADD (Logical Address Register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol				CECAD	D[15:8]			
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol				CECAI	DD[7:0]			
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-16	-	R	Read as 0.
15-0	CECADD[15:0]	R/W	Logical address 15 to 0
			Specifies the logical address assigned to CEC.
			Multiple addresses can be set simultaneously since each bit corresponds with each address.

Note: A broadcast message is received regardless of the register setting. By allocating a logical address of a device to 15, logical "0" is sent as an ACK response to the broadcast message.

12.3 Registers TMPM332FWUG

12.3.4 CECRESET (Software Reset Register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	-	CECRESET
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	FUnction
31-1	-	R	Read as 0
0	CECRESET	W	Software reset
			0: Disabled
			1: Enabled
			Stops all the CEC operation and initializes the register.
			Setting this bit to "1" affects as follows:
			Reception: Stops immediately. The received data is discarded.
			Transmission (including the CEC line): Stops immediately.
			Register: All the registers other than CECEN are initialized.
			Read as 0.

12.3.5 CECREN (Receive Enable Register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	-	CECREN
After reset	0	0	0	0	0	0	0	Undefined

Bit	Bit Symbol	Туре	Function
31-1	-	R	Read as 0
0	CECREN	R/W	Reception control [Write] 0 : Disabled 1 : Enabled [Read] 0 : Stopped 1 : In operation
			Controls the reception operation of CEC. Writing "0" or "1" to this bit enables or disables data reception. This bit becomes ready for data reception by writing "1". The state of the reception circuit is monitored by reading this bit. It enables you to check if what you set has properly been reflected.

Note 1: Enable the <CECREN> bit after setting the CECRCR1, CECRCR2 and CECRCR3.

Note 2: It takes a little time to reflect the setting of the <CECREN> bit to the circuit. Stop transmission and reception before changing the settings or enabling the transmission and reception.

12.3 Registers TMPM332FWUG

12.3.6 CECRBUF (Receive Buffer Register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	CECACK	CECEOM
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol				CEC	RBUF			
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-10	-	R	Read as 0.
9	CECACK	R	ACK bit
			Reads the received ACK bit.
8	CECEOM	R	EOM bit
			Reads the received EOM bit.
7-0	CECRBUF[7:0]	R	Received data
			Reads one byte of data received. The bit 7 is the MSB.

Note 1: Writing to this register is ignored.

Note 2: Read this register as soon as a receive interrupt is generated. The subsequent reading data may not be ensured.

12.3.7 CECRCR1 (Receive Control Register 1)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	CECACKDIS
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	CEC	HNC	-		CECLNC	
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	CECMIN			-	CECMAX		
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	CECDAT			CEC	TOUT	CECRIHLD	CECOTH
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function				
31-25	-	R	Read as 0.				
24	CECACKDIS	R/W	Logical "0" as ACK response 0: send 1: not send Specifies if logical "0" is sent or not as an ACK response to the data block when destination address corresponds with the address set in the logical address register. (The header block sends logical "0" as an ACK response regardless of the bit setting when detecting the addresses corresponding)				
23-22	_	R	Read as 0.				
21-20	CECHNC[1:0]	R/W	The number of "High" samplings for noise cancellation. 00: None (one time of fs clock observed.) 01: 1/fs (two consecutive fs clocks observed.) 10: 2/fs (three consecutive fs clocks observed.) 11: 3/fs (four consecutive fs clocks observed.) Specifies the time of the noise cancellation for each 1/fs when detecting "High". It is considered as noise if "High"s of the same number as the specified cycles are not sampled.				
19	-	R	Read as 0.				
18-16	CECLNC[2:0]	R/W	The number of "Low" samplings for noise cancellation. 000: None (one time of fs clock observed.) 100: - (Reserved) 001: 1/fs (two consecutive fs clocks observed) 101: - (Reserved) 010: 2/fs (three consecutive fs clocks observed) 110: - (Reserved) 011: 3/fs (four consecutive fs clocks observed.) 111: - (Reserved) Specifies the time of the noise cancellation for each 1/fs when detecting "Low". It is considered as noise if "Low"s of the same number as the specified cycles are not sampled.				
15	_	R	Read as 0.				
14-12	CECMIN[2:0]	R/W	Time to identify as minimum cycle error 000: 67/fs (approx.2.045ms) 100: 67/fs – 1/fs 001: 67/fs + 1/fs 101: 67/fs – 2/fs 010: 67/fs + 2/fs 110: 67/fs – 3/fs 011: 67/fs + 3/fs 111: 67/fs – 4/fs Specifies the minimum time to identify a valid bit. Base time is 67/fs (approx.2.045) ms. Enables to specify it between the ranges –4/fs to +3/fs by the unit fs. An interrupt is generated and "Low" is output to CEC for approx. 3.63 ms when one bit cycle is shorter the specified time.				
11	-	R	Read as 0.				
10-8	CECMAX[2:0]	R/W	Read as 0. Time to identify as maximum cycle error 000: 90/fs (approx. 2.747ms) 100: 90/fs - 1/fs 001: 90/fs + 1/fs 101: 90/fs - 2/fs 010: 90/fs + 2/fs 110: 90/fs - 3/fs 011: 90/fs + 3/fs 111: 90/fs - 4/fs				

12.3 Registers TMPM332FWUG

Bit	Bit Symbol	Туре	Function					
			Specifies the maximum time to identify as a valid bit. Base time is 90/fs (approx.2.747 ms). Enables to specify it between the ranges -4/fs to +3/fs by the unit of 1/					
			fs.					
			An interrupt is generated when one bit cycle is longer than the specified time.					
7	_	R	Read as 0.					
6-4	CECDAT[2:0]	R/W	Point of determining the data as 0 or 1.					
			000: 34/fs (approx. 1.038ms) 100: 34/fs - 2/fs					
			001: 34/fs + 2/fs 101: 34/fs - 4/fs					
			010: 34/fs + 4/fs 110: 34/fs - 6/fs					
			011: 34/fs + 6/fs 111: Reserved					
			Specifies the point of determining the data as logical "0" or logical "1".					
			Base time is 34/fs (approx.1.038 ms). Enables to specify it within ±6/fs by the unit of 2/fs.					
3-2	CECTOUT[1:0]	R/W	Cycle to identify timeout					
			00: 1 bit cycle					
			01: 2 bit cycle					
			10: 3 bit cycle					
			11: Reserved					
			Specifies the time to determine a timeout. Enables to specify it between 1 bit and 3 bits for each bit cycle.					
			This setting is used to detect a timeout occurs when the <cecrihld> bit is valid.</cecrihld>					
1	CECRIHLD	R/W	Error interrupt suspend					
			0: Not suspended					
			1: Suspended					
			Specifies if a receive error interrupt (maximum cycle error, buffer overrun and waveform error) is suspended					
			or not.					
			Setting "1" generates no interrupt at the error detection. If data continues to an ACK bit, an ACK response is					
			executed by a reversed logic. If the subsequent bits are interrupted, it is determined as a timeout, based on					
			the setting in <cectout>.</cectout>					
			After the ACK response or the timeout determination, an interrupt is generated.					
0	CECOTH	R/W	Data reception at logical address discrepancy					
			0: Not received					
			1: Received					
			Specifies if data is received or not when destination address does not correspond with the address set in the					
1			CECADD register.					

- Note 1: The settings in <CECHNC>, <CECLNC> and <CECDAT> are also used in receiving an ACK response at transmission.
- Note 2: Changing the configurations during transmission or reception may harm its proper operation. Before the change, set the CECREN <CECREN> bit to disable the reception and read the <CECREN> bit and the CECTEN <CECTRANS> bit to ensure that the operation is stopped.
- Note 3: A broadcast message is received regardless of the <CECOTH> register setting.
- Note 4: <CECLNC> must be used under the same setting as CECTCR<CECDTRS>.

12.3.8 CECRCR2 (Receive Control Register 2)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-		CECSWAV3		-	CECSWAV2		
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-		CECSWAV1			CECSWAV0		
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре		Function
31-15	-	R	Read as 0.	
14-12	CECSWAV3[2:0]	R/W	Max. cycle to detect start bit.	
			000: 154/fs (approx. 4.700 ms)	100: 154/fs + 4/fs
			001: 154/fs + 1/fs	101: 154/fs + 5/fs
			001: 154/fs + 2/fs	110: 154/fs + 6/fs
			011: 154/fs + 3/fs	111: 154/fs + 7/fs
11	-	R	Read as 0.	
10-8	CECSWAV2[2:0]	R/W	Min. cycle to detect start bit.	
			000: 141/fs (approx. 4.303 ms)	100: 141/fs - 4/fs
			001: 141/fs - 1/fs	101: 141/fs - 5/fs
			001: 141/fs - 2/fs	110: 141/fs - 6/fs
			011: 141/fs - 3/fs	111: 141/fs - 7/fs
7	_	R	Read as 0.	
6-4	CECSWAV1[2:0]	R/W	Max. time of start bit rising timing.	
			000: 128/fs (approx. 3.906 ms)	100: 128/fs + 4/fs
			001: 128/fs + 1/fs	101: 128/fs + 5/fs
			001: 128/fs + 2/fs	110: 128/fs + 6/fs
			011: 128/fs + 3/fs	111: 128/fs + 7/fs
3	_	R	Read as 0.	
2-0	CECSWAV0[2:0]	R/W	Min. time of start bit rising timing.	
			000: 115/fs (approx. 3.510 ms)	100: 115/fs - 4/fs
			001: 115/fs - 1/fs	101: 115/fs - 5/fs
			001: 115/fs - 2/fs	110: 115/fs - 6/fs
			011: 115/fs - 3/fs	111: 115/fs - 7/fs

<CECSWAV3>:/ Specifies the cycles to detect a start bit.

<CECSWAV2>: <CECSWAV3> is for the maximum cycles. Base time is 154/fs (approx.4.700 ms). Enables to specify it between the ranges 0

to +7/fs by the unit of 1/fs.

<CECSWAV2> is for the minimum cycles. Base time is 141/fs (approx.4.303 ms). Enables to specify it between the ranges 0 to

-7/fs by the unit of 1/fs.

<CECSWAV1>:/ Specifies the rising timing of a start bit in its detection.

<CECSWAV1> is for the maximum time of the rising timing. Base time is 128/fs (approx.3.906 ms). Enables to specify it between

the ranges 0 to +7/fs by the unit of 1/fs.

 $<\!\!\text{CECSWAV0>} \text{ is for the minimum time of the rising timing. Base time is } 115/\text{fs (approx}. 3.510 \text{ ms)}. \text{ Enables to specify it between}$

the ranges 0 to -7/fs by the unit of 1/fs.

12. Consumer Electronics Control (CEC)

12.3 Registers TMPM332FWUG

Note: Changing the configurations during reception may harm its proper operation. Before the change, set CECREN < CECREN > to disable the reception and read the < CECREN > bit to ensure that the operation is stopped.

12.3.9 CECRCR3 (Receive Control Register 3)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-		CECWAV3		-		CECWAV2	
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-		CECWAV1	-	-	CECWAV0		
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	-	CECWAVEN
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре		Function
31-23	-	R	Read as 0.	
22-20	CECWAV3[2:0]	R/W	The latest rising timing of logical "0" dete	rmined as proper waveform.
			000: 56/fs (approx. 1.709 ms)	100: 56/fs + 4/fs
			001: 56/fs + 1/fs	101: 56/fs + 5/fs
			001: 56/fs + 2/fs	110: 56/fs + 6/fs
			011: 56/fs + 3/fs	111: 56/fs + 7/fs
19	_	R	Read as 0.	
18-16	CECWAV2[2:0]	R/W	The fastest rising timing of logical "0" det	errmined as proper.
			000: 43/fs (approx.1.312 ms)	100: 43/fs - 4/fs
			001: 43/fs - 1/fs	101: 43/fs - 5/fs
			010: 43/fs - 2/fs	110: 43/fs - 6/fs
			011: 43/fs - 3/fs	111: 43/fs - 7/fs
15	_	R	Read as 0.	
14-12	CECWAV1[2:0]	R/W	The latest rising timing of logical "1" dete	rmined as proper waveform.
			000: 26/fs (approx. 0.793 ms)	100: 26/fs + 4/fs
			001: 26/fs + 1/fs	101: 26/fs + 5/fs
			001: 26/fs + 2/fs	110: 26/fs + 6/fs
			011: 26/fs + 3/fs	111: 26/fs + 7/fs
11	-	R	Read as 0	
10-8	CECWAV0[2:0]	R/W	The fastest rising timing of logical "1" det	ermined as proper.
			000: 13/fs (approx. 0.396 ms)	100: 13/fs - 4/fs
			001: 13/fs - 1/fs	101: 13/fs - 5/fs
			010: 13/fs - 2/fs	110: 13/fs - 6/fs
			011: 13/fs - 3/fs	111: 13/fs - 7/fs
7-1	-	R	Read as 0.	
0	CECWAVEN	R/W	Waveform error detection	
			1: Enable	
			0: Disable	
			Detects a received waveform does not id	lentical to the one defined and generates waveform error interrupt.
				to the setting of <cecwav0> <cecwav1> <cecwav2></cecwav2></cecwav1></cecwav0>
			<cec wav3="">.</cec>	

<CECWAV3>: This setting is enabled when the <CECWAVEN> bit is set to "1".

By setting these bits, an error is detected if rising edge of the received waveform comes later than that of proper logical "0".

Base time is 56/fs (approx. 1.709ms). Enables to specify it between the ranges 0 to +7/fs by the unit of 1/fs.

The received waveform is considered to be an error if a rising edge is not detected from the start point of the bit to the value specified in <CECWAV3>

<CECWAV2>/ This setting is enabled when the <CECWAVEN> bit is set to "1".

<CECWAV1>: By setting these bits, an error is detected if rising edge of the received waveform comes faster than logical "0" and later than that of proper logical "1".

Base time for <CECWAV1> bit is 26/fs (approx. 0.793ms). Enables to specify it between the ranges 0 to +7/fs by the unit of 1/

Base time for <CECWAV2> bit is 43/fs (approx.1.312ms). Enables to specify it between the ranges 0 to -7/fs by the unit of 1/

If a rising edge is detected during <CECWAV2> bit and <CECWAV1> bit setting, an error occurs.

<CECWAV0>: This setting is enabled when the <CECWAVEN> bit is set to "1".

By setting these bits, an error is detected if rising edge of the received waveform comes faster than that of proper logical "1".

Base time is 13/fs (approx. 0.396ms). Enables to specify it between the ranges 0 to -7/fs by the unit of 1/fs.

The received waveform is considered to be an error if a rising edge is not detected from a start point of the bit to the value

specified in <CECWAV0>.

Note: Changing the configurations during reception may harm its proper operation. Before the change, set CECREN <CECREN> to disable the reception and read the <CECREN> bit to ensure that the operation is stopped.

12.3.10 CECTEN (Transmit Enable Register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	CECTRANS	CECTEN
After reset	0	0	0	0	0	0	0	Undefined

Bit	Bit Symbol	Туре	Function
31-2	-	R	Read as 0.
1	CECTRANS	R	Transmission state 0: not in progress 1:in progress Indicates whether the transmission is in progress or not. It indicates "1" upon starting the transmission of the start bit. It indicates "0" if transmission is completed or an interrupt is generated. Writing to this bit is ignored.
0	CECTEN	W	Transmission control 0: Disable 1: Enable Controls the CEC transmission. Writing this bit enables or disables the transmission. Writing "1" to this bit initiates the transmission. This bit is automatically cleared by a transmit completion interrupt or an error interrupt.

Note 1: Set <CECTEN> after setting the CECTBUF and CECTCR register.

Note 2: Stop transmission and reception before changing the settings or enabling the transmission and reception.

12.3.11 CECTBUF (Transmit Buffer Register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	CECTEOM
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol				CEC	TBUF			
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-9	-	R	Read as 0.
8	СЕСТЕОМ	R/W	EOM bit
			Specifies the EOM bit to transmit.
7-0	CECTBUF[7:0]	R/W	Transmitted data
			Specifies a byte of data to transmit. The bit 7 is the MSB.

12.3.12 CECTCR (Transmit Control Register)

	31	30	29	28	27	26	25	24	
bit symbol	-	-	-	-	-	-	-	-	
After reset	0	0	0	0	0	0	0	0	
	23	22	21	20	19	18	17	16	
bit symbol	-		CECSTRS		-	CECSPRD			
After reset	0	0	0	0	0	0	0	0	
	15	14	13	12	11	10	9	8	
bit symbol	-		CECDTRS		CECDPRD				
After reset	0	0	0	0	0	0	0	0	
	7	6	5	4	3	2	1	0	
bit symbol	-	-	-	CECBRD		CECFREE			
After reset	0	0	0	0	0	0	0	0	

31-23 -		Type		Function				
	-	R	Read as 0.					
22-20	CECSTRS[2:0]	R/W	Rising timing of start bit.					
			000: Base time	100: Base time- 4/fs				
			001: Base time- 1/fs	101: Base time- 5/fs				
			010: Base time- 2/fs	110: Base time- 6/fs				
			011: Base time- 3/fs	111: Base time- 7/fs				
			Specifies the rising timing of a start bit	t.				
			Base time is 121/fs (approx. 3.693 ms	s). Enables to specify it between the ranges 0 to $-7/\text{fs}$ by the unit of $1/\text{fs}$.				
19 -	-	R	Read as 0.					
18-16	CECSPRD[2:0]	R/W	Start bit cycle					
			000: Base time	100: Base time- 4/fs				
			001: Base time- 1/fs	101: Base time- 5/fs				
			010: Base time- 2/fs	110: Base time- 6/fs				
			011: Base time- 3/fs 111: Base time- 7/fs					
			Specifies a cycle of a start bit.					
			Base time is 147/fs (approx. 4.486 ms). Enables to specify it between the ranges 0 to -7 /fs by the unit of 1/fs					
15 -	-	R	Read as 0.					
14-12	CECDTRS[2:0]	R/W	Rising timing of data bit.					
			000: Base time	100: Reserved				
			001: Base time- 1/fs	101: Reserved				
			010: Base time- 2/fs	110: Reserved				
			011: Base time- 3/fs	111: Reserved				
			Specifies the rising timing of a data bit	t				
			Base time is 20/fs (approx. 0.610 ms,	when logical "1") or 49/fs (approx. 1.495 ms, when logical "0"). Enables				
			to specify it between the ranges 0 to -	-3/fs by the unit of 1/fs.				
11-8	CECDPRD[2:0]	R/W	Data bit cycle					
			0000: Base time	1000: Base time- 8/fs				
			0001: Base time- 1/fs	1001: Base time- 9/fs				
			0010: Base time- 2/fs	1010: Base time- 10/fs				
			0011: Base time- 3/fs	1011: Base time- 11/fs				
			0100: Base time- 4/fs	1100: Base time- 12/fs				
			0101: Base time- 5/fs	1101: Base time- 13/fs				
			0110: Base time- 6/fs	1110: Base time- 14/fs				
			0111: Base time- 7/fs	1111: Base time- 15/fs				
			Specifies a cycle of a data bit.					
			Base time is 79/fs (approx. 2.411 ms).	. Enables to specify it between the ranges 0 to $-15/\text{fs}$ by the unit of $1/\text{fs}$.				
7-5 -	-	R	Read as 0.					

Bit	Bit Symbol	Туре		Function				
4	CECBRD	R/W	Broadcast transmission					
			0: Not broadcast transmission					
			1: Broadcast transmission					
			Set this bit to "1" when transmitting a broadcast message.					
3-0	CECFREE[3:0]	R/W	Time of bus to be free					
			0000: 1bit cycle	1000: 9bit cycle				
			0001: 2bit cycle	1001: 10bit cycle				
			0010: 3bit cycle	1010: 11bit cycle				
			0011: 4bit cycle	1011: 12bit cycle				
			0100: 5bit cycle	1100: 13bit cycle				
			0101: 6bit cycle	1101: 14bit cycle				
			0110: 7bit cycle	1110: 15bit cycle				
			0111: 8bit cycle	1111: 16bit cycle				
I			Specifies time of a bus to be free that checked before transmission.					
			Start transmission after checking	he CEC line kept inactive during the specified cycles.				

Note: <CECDTRS> must be used under the same setting as CECRCR1<CECLNC>.

12.3.13 CECRSTAT (Receive Interrupt Status Register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	CECRIWAV	CECRIOR	CECRIACK	CECRIMIN	CECRIMAX	CECRISTA	CECRIEND
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-7	-	R	Read as 0.
6	CECRIWAV	R	Interrupt flag
			0: No wave form error
			1: Wave form error
			Indicates that waveform error is detected.
			The error occurs when waveform error detection is enabled in CECRCR3 < CECWAVEN>.
5	CECRIOR	R	Interrupt flag
			0: No receive buffer overrun
			1:Receive buffer overrun
			Indicates the receive buffer receives next data before reading the data that had already been set.
4	CECRIACK	R	Interrupt flag
			0: No ACK collision
			1: ACK collision
			Indicates "0" is detected after the specified time to output ACK bit "0".
3	CECRIMIN	R	Interrupt flag
			0: No minimum cycle error
			1:Minimum cycle error
			Indicates one bit cycle is shorter than the minimum cycle error detection time specified in
			CECRCR1 <cecmin>.</cecmin>
2	CECRIMAX	R	Interrupt flag
			0: No maximum cycle error
			1: Maximum cycle error
			Indicates one bit cycle is longer than the maximum cycle error detection time specified in
			CECRCR1 <cecmax>.</cecmax>
1	CECRISTA	R	Interrupt flag
			0: No start bit detection
			1: Start bit detection
			Indicates a start bit is detected.
0	CECRIEND	R	Interrupt flag
			0: Not one byte data reception completed
			1: Completion of 1 byte data reception
			Indicates 1 byte of data reception is completed.

Note: Writing to this bit is ignored.

12.3.14 CECTSTAT (Transmit Interrupt Status Register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	CECTIUR	CECTIACK	CECTIAL	CECTIEND	CECTISTA
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-5	_	R	Read as 0.
4	CECTIUR	R	Interrupt flag 0: No transmit buffer underrun 1: Transmit buffer underrun Indicates next data has not set to the transmission buffer within a byte of data transmission.
3	CECTIACK	R	Interrupt flag 0: No ACK error detection 1: ACK error detection Indicates one of the following conditions occurs. • When logical "0" is not detected in transmission to the specific address. • When logical "1" is not detected in transmission of a broadcast message.
2	CECTIAL	R	Interrupt flag 0: No arbitration lost 1: Arbitration lost occurs Indicates "Low" is detected while outputting "High".
1	CECTIEND	R	Interrupt flag 0: No data transmission completion 1: data transmission is completed Indicates data transmission including the EOM bit is completed.
0	CECTISTA	R	Interrupt flag 0: No start transmission 1: Start transmission Indicates 1 byte of data transmission is started.

Note: Writing to this bit is ignored.

12.4 Operations

12.4.1 Sampling clock

CEC lines are sampled by a 32.768kHz of low speed clock (fs).

12.4.2 Reception

12.4.2.1 Basic Operation

If a start bit is detected, a start bit interruption generates. By generating start bit interruption, CECR-STAT<CECRISTA> is set.


If one byte data, EOM bit and ACK bit are received, the received data is stored in CECRBUF register, and a received interruption generates. By generating the received interruption, CECRSTAT<CECRIEND> is set.

In the CECRBUF register, 8 bit data, EOM bit and ACK bit are stored. The ACK bit is not generated in the CEC circuit internally. This bit is generated from a observation of CEC signal same as other data.

After one data block is received, receiving operation continues until detecting the last block of data with EOM bit set to"1". Detecting the end of last block, CEC becomes the start bit waiting mode.

Detecting an error during data reception causes an error interrupt, and CEC waits for the next start bit. The received data is discarded.

Note: Be careful about the precautions of chapter 12.1.3 in the receive operation.



12.4.2.2 Preconfiguration

Before receiving data, reception settings to the Logical Address Register <CECADD>, the Receive Control Register 1 <CECRCR1>, the Receive Control Register 2 <CECRCR2> and the Receive Control Register 3 <CECRCR3> are required.

(1) Logical Address Configuration

Configure logical address assigned to this product to the CECADD register. Multiple addresses can be set simultaneously since every bit in this register corresponds with each address.

Note: A broadcast message is received regardless of the CECADD register setting. By allocating a logical address of a device to 15, logical "0" is sent as an ACK response to the broadcast message.


(2) Noise Cancellation Time

The noise cancellation time is configurable with the <CECHNC> and <CECLNC> bits of the CECRCR1 register. It is considered as noise if "High"or "Low"of the same number as the specified value are not sampled. You can configure the time to detect "High" and "Low" respectively.

A CEC line is monitored at each rising edge of a sampling clock. In the case that the CEC line is changed from "High" to "Low", the change is fully recognized if "Low"s of the same number as specified in the <CECLNC> bit are monitored. In the case that the CEC line is changed from "Low" to "High", the change is fully recognized if "High" of the same number as specified in the <CECHNC> bit are sampled.

Note: < CECLNC > must be used under the same setting as CECTCR < CECDTRS >.

The following illustrates the operation of a case that a noise cancelling is configured as <CECHNC [1:0]> = "10" (3 samplings) and <CECLNC[2:0]> = "011" (4 samplings). By cancelling the noise, a signal "1" shifts to "0" after "0" is sampled four times. The signal "0" shifts to "1" after "1" is sampled three times.



(3) Cycle error

Configure CECRCR1<CECMIN><CECMAX> bits to detect a cycle error.

A cycle error can be detected from each sampling clock cycle between the ranges -4/fs to +3/fs by the unit of 1/fs from the minimum value (67/fs, approx. 2.045ms) or the maximum value (90/fs approx. 2.747ms).


Detecting an error during data reception causes an error interrupt, and CEC waits for the next start bit. The received data is discarded.

(4) Point of Determining Data

Configure the CECRCR1 <CECDAT> bit for the point of determining the data as "0" or "1".

Base time is 34/fs (approx.1.038ms) from the start point and also configurable ± 6 /fs by the unit of 2/fs.

Data sampring timing that specification recommends



(5) ACK Response

Configuring the CECRCR1 <CECACKDIS> bit enables you to specify if logical "0" is sent or not as an ACK response to the data block when destination address corresponds with the address set in the logical address register.

The header block sends logical "0" as an ACK response regardless of the bit setting when detecting the addresses corresponding.

The following lists the ACK responses.


"Yes" indicates that CEC outputs "0" as a response to the ACK signal from a transmission device (ACK bit: logical "0"). "No" indicates that CEC does not output "0" as a response to the ACK signal from a transmission device (ACK bit: logical "1").

D		Header blo	ock address	Data block address		
Re	egister setting	Conformity	Discrepancy	Conformity	Discrepancy	
CECRCR1	"0" (responding logical "0")	V	Na	Yes	No	
<cecackdis></cecackdis>	"1" (not responding logical "0")	Yes	No	No	No	

The following describes the ACK response timing.

When the falling edge of the ACK bit from the initiator is detected, this IP outputs "Low" for approximately 1.526 ms. The start time of outputting "Low" is specified with CECRCR1<CECLNC> bit that sets the noise cancelling time.

Note: < CECLNC > must be used under the same setting as CECTCR < CECDTRS >.



(6) Receive Error Interrupt Suspend

Configure the CECRCR1 <CECRIHLD> bit to specify if a receive error interrupt (maximum cycle error, buffer overrun and waveform error) is suspended or not. Setting "1" generates no interrupt at the error detection.

If data continues to the ACK bit, an ACK response is executed by a reversed logic. If the subsequent bits are interrupted, it is determined as a timeout, based on the setting in <CECTOUT> of the CECRCR1 register.

After the ACK response or the timeout determination, an interrupt is generated.

(7) Cycles to Identify Timeout

Configure the CECRCR1<CECTOUT> bit to specify the time to determine a timeout.

This is used when the setting of a receive error interrupt suspension, which is specified in CECRCR1 <CECRIHLD>, is valid.

(8) Data Reception at Logical Address Discrepancy

By setting CECRCR1 < CECOTH>, you can specify if data is received or not when destination address does not correspond with the address set in the CECADD register.

In this case, data is received as usual, and an interrupt is generated by detecting an error. However, an ACK response of neither the header block nor the data block is sent.

Note 1: A broadcast message is received regardless of the <CECOTH> register setting.

Note 2: If the initiator sends a new message beginning with the start bit without having sent the last block with EOM="1", a maximum cycle error is determined for the ACK bit and an interrupt is generated. Then, the receive operation is performed in the usual way.

(9) Start Bit Detection


Configuring the CECRCR2 register allows you to specify the rising timing and a cycle of the start bit detection respectively.

<CECSWAV0> is to specify the fastest start bit rising timing. <CECSWAV1> is to specify the latest start bit rising timing (1. in the figure shown below).

<CECSWAV2> is to specify the minimum cycle of a start bit. <CECSWAV3> is to specify the maximum cycle of a start bit (2. in the figure shown below).

If a rising edge during the period 1. and a falling edge during the period 2. are detected, the start bit is considered to be valid.

Permissible value of signal transition timing on specification (Start bit)



(10) Waveform Error Detection


To detect an error when a received waveform is out of the defined tolerance range, configure the CECRCR3 register.

An error is detected when the <CECWAVEN> bit of the CECRCR3 register is enabled. You can specify the detection time in the <CECWAV0> <CECWAV1> <CECWAV2> <CECWAV3> bits.

If the rising edge is detected during the period 1. or 2. shown below, or not detected in the timing described in 3., a waveform error interrupt is generated.

- 1. A period between the beginning of a bit and the fastest logical "1" rising timing
- 2. A period between the latest logical "1" rising timing and the fastest logical "0" rising timing.
- 3. The latest logical "0" rising timing.

Permissible value of signal transition timing on specification (Data bit)



12.4.2.3 Enabling Reception

After configuring the CECADD, CECRCR1, CECRCR2 and CECRCR3 registers, CEC is ready for reception by enabling the CECREN < CECREN > bit. Detecting a start bit initiates the reception.

Note: Changing the configurations of the CECADD, CECRCR1, CECRCR2 and CECRCR3 registers during reception may harm its proper operation. Before the change of the registers shown below, set the CECREN <CECREN> bit to disable the reception and read the <CECREN> bit and the CECTEN <CECTRANS> bit to ensure that the operation is stopped.

Register name	Bit Symbol	Setting item		
CECADD	<cecadd[15:0]></cecadd[15:0]>	Logical address		
	<cechnc><ceclnc></ceclnc></cechnc>	Noise cancellation time		
CECRCR1	<cecmin><cecmax></cecmax></cecmin>	Time to identify cycle error		
020110111	<cecoth></cecoth>	Data reception at logical address discrepancy		
CECRCR2	<cecswav0><cecswav1> <cecswav2><cecswav3></cecswav3></cecswav2></cecswav1></cecswav0>	Start bit detection		
CECRCR3	<cecwav0><cecwav1> <cecwav2><cecwav3></cecwav3></cecwav2></cecwav1></cecwav0>	Waveform error detection (when enabled)		

12.4.2.4 Detecting Error Interrupt

Detecting an error during data reception causes an error interrupt, and CEC waits for the next start bit. The received data is discarded.

It is possible to suspend a receive error interrupt (maximum cycle error, receive buffer overrun and waveform error), continue reception and send the reversed ACK response.

You can check the interrupt factor by monitoring the bit of the CECRSTAT register corresponding to the interrupt.

12.4.2.5 Details of reception error

(1) Cycle error

Period between the falling edges of the two sequential bits is measured during reception. If the period does not comply with the specified minimum or maximum value, a cycle error interrupt is generated.

A setting of maximum cycle and minimum cycle time is specified by CECRCR1<CECMIN> and <CECMAX> bits. Maximum value is 90/fs (approx.2.747ms) and minimum value is 67/fs (approx. 2.045ms). It can be specified between the ranges -4/fs to +3/fs by the unit of 1/fs to detect cycle errors.

The CECRSTAT <CECRIMIN> bit or the <CECRIMAX> bit is set if a cycle error interrupt is generated.

The minimum cycle error causes CEC to output "Low" for approx. 3.63 ms.

Note 1: When minimum cycle error is detected, "Low" is output after "Low" detecting noise cancellation time.

Note 2: If the initiator sends a new message beginning with the start bit without having sent the last block with EOM="1", a maximum cycle error may be determined for the ACK bit. For detail, refer to the Chapter 12.1.3.

(2) ACK Collision


At an ACK response, detecting "Low" after the specified period to output generates an ACK collision interrupt or a minimum cycle error interrupt.

The ACK collision interrupt sets the CECRSTAT <CECRIACK> bit. The minimum cycle error interrupt sets the CECRSTAT <CECRIMIN> bit.

The following describes the period and method of detection.

Detection starts approx. 0.3 ms after the end of the period of outputting "Low" and ends approx 2.0 ms from the starting point (the falling edge) of the ACK bit.

At 0.3 ms from the end of the period of outputting "Low", CEC checks if the CEC line is "0" or not. If it is "Low", an ACK collision interrupt is generated. If it is "High", and "Low" is detected during the detection period, the minimum cycle error interrupt is generated. The minimum cycle error causes CEC to output "Low" for approx. 3.63ms.



(3) Receive Buffer Overrun

A receive buffer overrun interrupt is generated when the next data reception is completed before reading the data stored in the receive buffer.

The interrupt sets the CECRSTAT <CECRIOR> bit.

(4) Waveform Error

A waveform error occurs when waveform error detection is enabled in CECRCR3.

Detecting a waveform, which does not identical to the defined, results in the waveform error. The interrupt is generated.

The interrupt sets the CECRSTAT <CECRIWAV> bit.

(5) Suspending Receive Error Interrupt

You can specify if a maximum cycle error, a buffer overrun and a waveform error are suspended or not without generating an interrupt at error detection. This can be set in the CECRCR1 <CECRIHLD> bit. To enable the setting, a timeout setting with the CECRCR1 <CECTOUT> bit is required.

Under suspend-enable condition, if CEC keeps receiving the next bit and the entire reception including the ACK bit is completed, CEC generates an interrupt after a reversed ACK response is executed. "1" is set to the bits of the CECRSTAT register: the <CECRIEND> bit that indicates the reception completion, and the bits corresponding to the detected errors.

If the reception of the next bit is interrupted, CEC starts to measure the timeout period, and an interrupt is generated after the timeout. "1" is set to the bits of the CECRSTAT register corresponding to the detected error.

The timeout is measured from the end of the last bit received as is the case with wait time of a bus to be free in transmission.

The information that the interrupts are suspended is held until the EOM bit is received or the timeout occurs. Thus, an interrupt is generated in each reception of a byte of data if multiple bytes are received while interrupts are suspended. "1" is set to the bits of the CECRSTAT register: the <CECRIEND> bit that indicates the reception completion, and the bits corresponding to the detected errors. The flags of the suspended interrupts and the reception completion are set to the bits of the CECRSTAT register.

- Note 1: A minimum cycle error interrupt is generated upon detecting a minimum cycle error in the next received bit while interrupts are suspended. "Low" is output to CEC for approx. 3.63 ms. The flags of the suspended interrupts and the minimum cycle error are set to the bits of the CECRSTAT register.
- Note 2: If an interrupt other than a minimum cycle error interrupt is generated while interrupts are suspended, CEC continues reception until the ACK response or the timeout. All the flags of the detected interrupts are set to the bits of the CECRSTAT register.

12.4.2.6 Stopping Reception

Writing "0" to the CECREN < CECREN> bit disables data reception. The reception is stopped upon disabling the bit during reception. The received data is discarded.

Note: If the reception is disabled while "Low" is sent as a signal of minimum cycle error, the "Low" output is stopped as well.

12.4.3 Transmission

12.4.3.1 Basic Operation

In the transmission setting, CEC firstly confirms bus free wait state to check whether CEC falling edge signals is not existed for specified bit cycles and then sends a start bit. The confirmation of bus free wait is performed all the time. Thus once bus free wait condition is satisfied, a transmission will start soon when transmission setting is done.

After transmitting a start bit, CEC transmits one byte data and EOM data that are stored in the transmit buffer to the shift register. When the transmission of the first bit of the one byte data begins, transmission interrupt is generates, and CECTSTAT<CECTISTA> is set. After transmission interrupt generation, next one byte data is prepared to the transmit data buffer.

One byte data transmission completes in order of transmission of 8 bits data, EOM bit, ACK bit transmission and ACK bit response confirmation.


Data transmission continues until EOM is set to "1".

If EOM is set to "1", the end of transmission interrupt generates after confirmation of data, EOM, ACK bit transmission and ACK bit response. By the end of transmission interrupt generates, CECTSTAT<CECTIEND> is set.

Interrupt generation ends a series of transmission process, and CECTEN<CECTEN> is cleared.

If an error is generated during transmission, an error interrupt is generates to stop transmission.

Even if reception is enabled, no reception is executed during transmission.




12.4.3.2 Preconfiguration

Before transmitting data, transmission settings to the Transmit Control Register (CECTCR) and the Transmit Buffer Register (CECTBUF) are required.

(1) Bus Free Wait Time

Specify the bus free wait time in the CECTCR<CECFREE> bits. It can be specified in a range of 1 to 16 bit cycles.

Counting of the bus free wait time begins one bit cycle after the falling edge of the final bit. If the signal stays high for the specified number of bit cycles, transmission starts.



(2) Transmitting Broadcast Message


Set the CECTCR <CECBRD> bit when transmitting a broadcast message. If this bit is set, logical "0" response during an ACK cycle results in an error. If not, logical "1" response during an ACK cycle results in an error.


(3) Adjusting Transmission Waveform

Both start bit and data bit are capable of adjusting the rising timing and cycle. With the CECTCR <CECSTRS> <CECSPRD> <CECDTRS> <CECDPRD> bits, the timing can be specified between the defined fastest rising/cycle timing and the reference value.

The following figures show how the waveforms differ according to the configurations of the start bit, logical "0" and logical "1".

Note: <CECDTRS> must be used under the same setting as CECRCR1<CECLNC>.





(4) Preparing Transmission Data

Configure a byte of transmission data and EOM data with the CECTBUF register.

12.4.3.3 Detecting Transmission Error

Error detection during transmission generates an interrupt and stops transmission. It clears the CECTEN <CECTEN> bit.

To identify an error factor, the CECTSTAT register has bits that correspond with each interrupt. You can identify the interrupt factor by checking these bits.

Note: An attempt to stop transmission by an error may cause an improper waveform output to CEC. This is because output is stopped immediately after the error occurs.


12.4.3.4 Details of Transmission Error

(1) Arbitration Lost

An arbitration lost error occurs when CEC detects "Low" on completion of appropriate low duration.

Detecting an arbitration lost error sets the CECTSTAT <CECTIAL> bit.

Two types of the arbitration lost detection periods are shown below.



(2) ACK error

An ACK error interrupt occurs when an ACK response does not conform to the configuration specified in the CECTCR <CECBRD> bit.

When the ACK error interrupt occurs, the CECTSTAT <CECTIACK> bit is set.

The ACK error is detected in the following cases.

Configuration	Determined as an ACK error when	
<cecbrd> = 0 Broadcast transmission?: No</cecbrd>	ACK response is logical "1"	
<cecbrd> = 1 Broadcast transmission?: Yes</cecbrd>	ACK response is logical "0"	

(3) Transmit Buffer Underrun

A transmit buffer underrun error is caused by the following sequence.

- 1. Data in the transmit buffer is transmit to the shift register.
- 2. An interrupt occurs.
- 3. A byte of data is transmitted.
- 4. No data is set to the transmit buffer before starting transmission of a byte of subsequent data.

When an underrun error occurs, the CECTSTAT <CECTIUR> bit is set.

(4) Order of ACK Error and Transmit Buffer Overrun

If interrupt factors of the ACK error and transmit buffer underrun are detected at the end of transmission of a byte of data, the transmit buffer underrun has priority.

The transmit buffer underrun interrupt occurs first and then the ACK error interrupt occurs.

12.4.3.5 Stopping Transmission

To stop transmission, send data including the EOM bit that indicates "1". This generates a transmit completion interrupt.

Please note that proper operation is not ensured if the start bit of transmission is set to "0" during transmission.

12.4.3.6 Retransmission

Transmission is stopped by error detection. To retry the transmission, configure the condition and data of starting the transmission.

TMPM332FWUG

12.4.4 Software Reset

The entire CEC function can be initialized by software.

Setting "1" to the CECRESET < CECRESET > bit causes the following operations.

- Reception : Immediately stops. The received data is discarded.
- Transmission: Immediately stops including output to the CEC line.
- · Register: All the registers other than CECEN are initialized.

Please note that software reset during transmission may cause the CEC line waveform that does not identical to the defined.

rol (CEC)	
t	trol (CEC)

TOSHIBA TMPM332FWUG

13. Remote control signal preprocessor (RMC)

13.1 Basic operation

Remote control signal preprocessor (hereafter referred to as RMC) receives a remote control signal of which carrier is removed.

13.1.1 Reception of Remote Control Signal

- Sampled 32.768 kHz clock
- · Noise canceller
- · Leader detection
- · Batch reception up to 72bit of data

13.2 Block Diagram

Figure 13-1 shows block diagram of RMC




Figure 13-1 Block diagram of RMC

13.3 Registers

13.3.1 Register List

Addresses and names of RMC control registers are shown below.

Base Address = 0x4004_0400

Register		Address(Base+)
Remote Enable Register	RMCEN	0x0000
Receive Enable Register	RMCREN	0x0004
Receive Data Buffer Register 1	RMCRBUF1	0x0008
Receive Data Buffer Register 2	RMCRBUF2	0x000C
Receive Data Buffer Register 3	RMCRBUF3	0x0010
Receive Control Register 1	RMCRCR1	0x0014
Receive Control Register2	RMCRCR2	0x0018
Receive Control Register3	RMCRCR3	0x001C
Receive Control Register 4	RMCRCR4	0x0020
Receive Status Register	RMCRSTAT	0x0024
Reserved	-	0x0028
Reserved	-	0x002C
Reserved	-	0x0030

Note: Access to the <reserved> address is prohibited.

13.3.2 RMCEN (Enable Register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	I2RMC	RMCEN
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-2	-	R	Read as 0.
1	I2RMC	R/W	RMC in IDLE mode
			0: Disabled
			1: Enabled
			Controls RMC operation in IDLE mode.
			Set "1" to enable RMC in IDLE Mode.
			This bit and the <rmcen> bit can be set simultaneously.</rmcen>
0	RMCEN	R/W	Controls RMC operation.
			0: Disabled
			1:Enabled
			To allow RMC to function, enable the RMCEN bit first.
			If the operation is disabled, all the clocks for RMC except for the enable register are stopped, and it
			can reduce power consumption.
			If RMC is enabled and then disabled, the settings in each register remain intact.

13.3.3 RMCREN (Receive Enable Register)

					1			
	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	-	RMCREN
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-1	-	R	Read as 0.
0	RMCREN	R/W	Reception
			0: Disabled
			1: Enabled
			Controls reception of RMC.
			Setting this bit to "1" enables reception.

Note: Enable the <RMCREN> bit after setting the RMCRCR1, RMCRCR2 and RMCRCR3

13.3.4 RMCRBUF1(Receive Data Buffer Register 1)

	31	30	29	28	27	26	25	24				
bit symbol		RMCRBUF (Received data 31 to 24 bit)										
After reset	0	0 0 0 0 0 0 0										
	23	22	21	20	19	18	17	16				
bit symbol		RMCRBUF (Received data 23 to 16 bit)										
After reset	0	0	0	0	0	0	0	0				
	15	14	13	12	11	10	9	8				
bit symbol			R	MCRBUF (Recei	ved data 15 to 8b	oit)						
After reset	0	0	0	0	0	0	0	0				
	7	6	5	4	3	2	1	0				
bit symbol		RMCRBUF (Received data 7 to 0 bit)										
After reset	0	0	0	0	0	0	0	0				

Bit	Bit Symbol	Туре	Function
31-0	RMCRBUF[31:0]	R	Received data (31 to 0 bit)
			Reads 4 bytes of received data. (31 to 0 bit)

13.3.5 RMCRBUF2(Receive Data Buffer Register 2)

	31	30	29	28	27	26	25	24				
bit symbol		RMCRBUF (Received data 63 to 54 bit)										
After reset	0	0	0	0	0	0	0	0				
	23	22	21	20	19	18	17	16				
bit symbol		RMCRBUF (Received data 55 to 48 bit)										
After reset	0	0	0	0	0	0	0	0				
	15	14	13	12	11	10	9	8				
bit symbol			RN	ACRBUF (Receiv	ed data 47 to 40	bit)						
After reset	0	0	0	0	0	0	0	0				
	7	6	5	4	3	2	1	0				
bit symbol		RMCRBUF (Received data 39 to 32 bit)										
After reset	0	0	0	0	0	0	0	0				

Bit	Bit Symbol	Туре	Function			
31-0	RMCRBUF[63:32]	R	Received data (63 to 32 bit)			
			Reads 4 bytes of received data. (63 to 32 bit)			

13.3.6 RMCRBUF3(Receive Data Buffer Register 3)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	1	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol			RN	ACRBUF (Receiv	ed data 71 to 64	bit)		-
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-0	RMCRBUF[71:64]	R	Received data (71 to 64 bit).
			Reads 4 bytes of received data. (71 to 64 bit).

Note: The received bit is stored in the data buffer register in MSB-first order, and the last received bit is stored in the LSB (bit 0). If the remote control signal is received in the LSB first algorithm, the received data is stored in reverse sequence.

13.3.7 RMCRCR1(Receive Control Register 1)

	31	30	29	28	27	26	25	24				
bit symbol		RMCLCMAX										
After reset	0	0 0 0 0 0 0 0										
	23	22	21	20	19	18	17	16				
bit symbol		RMCLCMIN										
After reset	0	0	0	0	0	0	0	0				
	15	14	13	12	11	10	9	8				
bit symbol				RMCL	LMAX							
After reset	0	0	0	0	0	0	0	0				
	7	6	5	4	3	2	1	0				
bit symbol		RMCLLMIN										
After reset	0	0	0	0	0	0	0	0				

Bit	Bit Symbol	Туре	Function
31-24	RMCLCMAX[7:0]	R/W	Specifies a maximum cycle of leader detection.
			Calculating formula of the maximum cycle: <rmclcmax> × 4/fs [s].</rmclcmax>
23-16	RMCLCMIN[7:0]	R/W	Specifies a minimum cycle of leader detection.
			Calculating formula of the minimum cycle: <rmclcmin> × 4/fs [s].</rmclcmin>
15-8	RMCLLMAX[7:0]	R/W	Specifies a maximum low width of leader detection.
			Calculating formula of the maximum low width: <rmcllmax> × 4/fs [s]</rmcllmax>
7-0	RMCLLMIN[7:0]	R/W	Specifies a minimum low width of leader detection.
			Calculating formula for the minimum low width: <rmcllmin> × 4/fs [s]</rmcllmin>
			When RMCRCR2 <rmcld> = 1, a value of the low-pulse width is less than the specified value,</rmcld>
			it is defined as data bit.

Note: When you configure the register, you must follow the rule shown below.

Leader	Rules
Low width + High width	<pre><rmclcmax[7:0]> > <rmclcmin[7:0]> <rmcllmax[7:0]> > <rmcllmin[7:0]> <rmclcmin[7:0]> > <rmcllmax[7:0]></rmcllmax[7:0]></rmclcmin[7:0]></rmcllmin[7:0]></rmcllmax[7:0]></rmclcmin[7:0]></rmclcmax[7:0]></pre>
Only high width	<pre><rmclcmax[7:0]> > <rmclcmin[7:0]> <rmcllmax[7:0]> = 0x00 <rmcllmin[7:0]> = don't care</rmcllmin[7:0]></rmcllmax[7:0]></rmclcmin[7:0]></rmclcmax[7:0]></pre>
No Leader	<rmclcmax[7:0]> = 0x00 <rmclcmin[7:0]> = don't care <rmcllmax[7:0]> = don't care <rmcllmin[[7:0]> = don't care</rmcllmin[[7:0]></rmcllmax[7:0]></rmclcmin[7:0]></rmclcmax[7:0]>

13.3.8 RMCRCR2(Receive Control Register 2)

	31	30	29	28	27	26	25	24
bit symbol	RMCLIEN	RMCEDIEN	-	-	-	-	RMCLD	RMCPHM
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol		-	-	RM	CLL	-		-
After reset	1	1	1	1	1	1	1	1
	7	6	5	4	3	2	1	0
bit symbol		RMCDMAX						
After reset	1	1	1	1	1	1	1	1

Bit	Bit Symbol	Туре	Function
31	RMCLIEN	R/W	Leader detection interrupt 0: Not generated 1: Generated
30	RMCEDIEN	R/W	Remote control input falling edge interrupt 0: Not generated 1: Generated
29-26	_	R	Read as 0.
25	RMCLD	R/W	Receiving remote control signal with or without leader 0: Disabled 1: Enabled
24	RMCPHM	R/W	Receiving a remote control signal by a phase modulation 0: Not receiving a remote control signal by a phase modulation. (receive by a cycle modulation) 1: Receive remote control signal by a fixed-frequency pulse modulation. To receive a fixed-frequency remote control signal by a pulse modulation, set this bit to "1".
23-16	-	R	Read as 0.
15-8	RMCLL[7:0]	R/W	Excess low width that triggers reception completion and interrupt generation. 0000_0000 to 1111_1110: Reception completion and interrupt generation at <rmcll> × 1/fs [s]. 1111_1111: not to use as the trigger</rmcll>
7-0	RMCDMAX[7:0]	R/W	Maximum data bit cycle that triggers reception completion and interrupt generation. 0000_0000 to 1111_1110: Reception completion and interrupt generation at <rmcdmax> × 1/fs [s]. 1111_1111: not to use as the trigger</rmcdmax>

13.3.9 RMCRCR3(Receive Control Register 3)

	31	30	29	28	27	26	25	24	
bit symbol	-	-	-	-	-	-	-	-	
After reset	0	0	0	0	0	0	0	0	
	23	22	21	20	19	18	17	16	
bit symbol	-	-	-	-	-	-	-	-	
After reset	0	0	0	0	0	0	0	0	
	15	14	13	12	11	10	9	8	
bit symbol	-		-	-	RMCDATH	-			
After reset	0	0	0	0	0	0	0	0	
	7	6	5	4	3	2	1	0	
bit symbol	-		RMCDATL						
After reset	0	0	0	0	0	0	0	0	

Bit	Bit Symbol	Туре	Function
31-15	-	R	Read as 0.
14-8	RMCDATH[6:0]	R/W	Larger threshold to determine a signal pattern in a phase method Calculating formula of the threshold: <rmcdath> × 1/fs [s] Specifies a larger threshold (within a range of 1.5T and 2T) to determine a pattern of remote control signal in a phase method. If the measured cycle exceeds the threshold, the bit is determined as "10". If not, the bit is determined as "01".</rmcdath>
7	-	R	Read as 0.
6-0	RMCDATL[6:0]	R/W	Threshold to determine 0 or 1 smaller threshold to determine a signal pattern in a phase method. Calculating formula of the threshold: <rmcdatl> × 1/fs [s] Specifies two kinds of thresholds: a threshold to determine whether a data bit is 0 or 1; a smaller threshold (within a range of 1T and 1.5T) to determine a pattern of remote control signal in a phase method. As for the determination of data bit, if the measured cycle exceeds the threshold, the bit is determined as "1". If not, the bit is determined as "0". Calculating formula of the threshold: <rmcdatl> × 1/fs [s]. As for the determination of a remote control signal pattern in a phase method, if the measured cycle exceeds the threshold, the bit is determined as "01". If not, the bit is determined as "00".</rmcdatl></rmcdatl>

Note: If the <RMCPHM> bit of the Receive Control Register 2 is "0", <RMCDATH[6:0]> are not enabled. The bits are enabled when <RMCPHM> is "1".

13.3.10 RMCRCR4(Receive Control Register 4)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	RMCPO	-	-	-		RMCNC		
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7	RMCPO	R/W	Remote control input signal
			0: Not reversed
			1: Reversed
6-4	-	R	Read as 0.
3-0	RMCNC[3:0]	R/W	Specifies noise cancellation time.
			0000: No cancellation
			0001 to 1111: cancellation
			Calculating formula of noise cancellation time: <rmcnc> × 1/fs [s]</rmcnc>

13.3.11 RMCRSTAT (Receive Status Register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	RMCRLIF	RMCLOIF	RMCDMAXIF	RMCEDIF	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	RMCRLDR				RMCRNUM	-	-	
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-16	-	R	Read as 0.
15	RMCRLIF	R	Interrupt source flag 0: No leader detection interrupt generated. 1: Leader detection interrupt generated.
14	RMCLOIF	R	Interrupt source flag 0: No low width detection interrupt generated. 1: Low width detection interrupt generated.
13	RMCDMAXIF	R	Interrupt source flag 0: No maximum data bit cycle interrupt generated. 1: Maximum data bit cycle interrupt generated.
12	RMCEDIF	R	Interrupt source flag 0: No falling edge interrupt generated. 1: Falling edge interrupt generated.
11-8	_	R	Read as 0.
7	RMCRLDR	R	Leader detection. 0: Disable leader detection. 1: Enable leader detection.
6-0	RMCRNUM[6:0]	R	The number of received data bit 000_0000:no data bit (only with leader) 000_0001 to 100_1000: 1 to 72bit 100_1001 to 111_1111: 73bit and more Indicates the number of bits received as remote control signal data. The number cannot be monitored during reception. On completion of reception, the number is stored.

Note 1: This register is updated every time an interrupt is generated. Writing to this register is ignored.

Note 2: RMC keeps receiving 73 bit or more data unless reception is completed by detecting the maximum data bit cycle or the excess low width. If so, the received data in the data buffer may not be correct.

13.4 Operation Description

TMPM332FWUG

13.4 Operation Description

13.4.1 Reception of Remote Control Signal

13.4.1.1 Sampling clock

A remote control signal is sampled by low-speed 32.768kHz clock (fs).

13.4.1.2 Basic operation

RMC set RMCRSTAT<RMCRLDR> bit when a leader is detected.

At this time, if RMCRCR2<RMCLIEN> bit is set, a leader detection interrupt will generate when a leader detecting. When a leader detection interrupt generates, RMCRSTAT<RMCRLIF> bit is set.

After the leader detecting, each data bit is determined as "0" or "1" in sequence. The results are stored in RMCRBUF1, RMCRBUF2 and RMCRBUF3 registers up to 72 bits. By setting RMCRCR2< RMCEDIEN> bit, a remote control signal input falling edge interrupt can be generated in each falling edge of data bit. When a remote control signal input falling edge interrupt is generated, RMCRSTAT< RMCEDIF > bit is set.


Detecting the maximum data bit cycle or the excess low width completes reception and generates an interrupt.

To check the status of RMC if reception is completed, read the remote control receive status register.

On completion of reception, RMC is waiting for the next leader.

By setting RMC to receive a signal without a leader, RMC recognizes the received as data and starts reception without detecting a leader.

If the next data reception is completed before reading the preceding received data, the preceding data is overwritten by the next one.



13.4.1.3 Preparation

Configure reception operation of a remote control signal with the Remote Control Signal Receive Control Registers (RMCRCR1, RMCRCR2 and RMCRCR3,RMCRCR4) before reception.

(1) Settings of Noise Cancelling Time


Configure noise cancelling time with the RMCRCR4 <RMCNC[3:0]> bit.

The signal which is sampled by a sampling clock is cancelled noise.

RMC monitors a sampled remote control signal in each rising edge of a sampling clock. If "High" is monitored, RMC recognizes that the signal was changed to "Low" after monitoring cycles of "Low"s specified in <RMCNC>. If "Low" is monitored, RMC recognizes that the signal was changed to "High" after monitoring cycles of "High" specified in <RMCNC>.

The following figure shows how RMC operates according to the noise cancel setting of <RMCNC [3:0]>="0011" (3 cycles). Subsequent to noise cancellation, the signal is changed from "High" to "Low" upon monitoring 3 cycles of "Low", and the signal is changed from "Low" to "High" upon monitoring 3 cycles of "High".

<RMCNC [3:0]> = 0011 (3 cycle)




(2) Settings of Detecting Leader

To detect a leader, configure cycle and low width of the leader with the RMCRCR1 <RMCLLMIN [7:0]> <RMCLLMAX[7:0]> <RMCLCMIN[7:0]> <RMCLCMAX[7:0]> bits. When you configure the register, you must follow the rule shown below.

Leader	Rules
Low width + High Width	<pre><rmclcmax[7:0]> > <rmclcmin[7:0]> <rmcllmax[7:0]> > <rmcllmin[7:0]> <rmclcmin[7:0]> > <rmcllmax[7:0]></rmcllmax[7:0]></rmclcmin[7:0]></rmcllmin[7:0]></rmcllmax[7:0]></rmclcmin[7:0]></rmclcmax[7:0]></pre>
Only high width	<pre><rmclcmax[7:0]> > <rmclcmin[7:0]> <rmcllmax[7:0]> = 0y00000000 <rmcllmin[7:0]> = don't care</rmcllmin[7:0]></rmcllmax[7:0]></rmclcmin[7:0]></rmclcmax[7:0]></pre>
No leader	<pre><rmclcmax[7:0]> = 0y00000000 <rmclcmin[7:0]> = don't care <rmcllmax[7:0]> = don't care <rmcllmin[7:0]> = don't care</rmcllmin[7:0]></rmcllmax[7:0]></rmclcmin[7:0]></rmclcmax[7:0]></pre>

The following shows a leader waveform and the RMCRCR1 register settings.



If you want to generate an interrupt when detecting a leader, configure the RMCRCR2 < RMCLIEN> bit.

A remote control signal without a leader cannot generate a leader detection interrupt.

(3) Setting of 0/1 determination data bit

Based on a falling edge cycle, the data bit is determined as 0 or 1.

There are two kinds of determinations:

1. Determination by threshold.


Configure a threshold value to RMCRCR3<RMCDATL[6:0]> bit which determines data bit as "0" or "1." If the determination value is equal to threshold value or more, it is determined as "1." If the determination value is less than threshold value, it is determined as "0."

2. Determination by falling edge interrupt inputs.

By setting "1" to the RMCRCR2<RMCEDIEN> bit, a remote control signal input falling edge interrupt can be generated in each falling edge of the data bit. Using this interrupt together with a timer enables the determination to be done by software.

The followings shows the determination model of data bit.

Threshold of 0/1 determination is set to 2.5T with the <RMCDATL[6:0]>bit.



As for data bit determination of a remote control signal in a phase method, see"13.4.1.8 Receiving a Remote Control Signal in a Phase Method".

3.4 Operation Description TMPM332FWUG

(4) Settings of Reception Completion

To complete data reception, settings of detecting the maximum data bit cycle and excess low width are required. If multiple factors are specified, reception is completed by the factor detected first. Make sure to configure the reception completion settings.


1. Completed by a maximum data bit cycle

To complete reception by detecting a maximum data bit cycle, you need to configure the RMCRCR2 <RMCDMAX[7:0]> bits.

If the falling edge of the data bit cycle isn't monitored after time specified as threshold in the <RMCDMAX[7:0]> bits, a maximum data bit cycle is detected.

The detection completes reception and generates an interrupt.

After interrupt inputs generated, RMCRSTAT< RMCDMAXIF > bit is set to "1".




2. Completed by excess low width

To complete reception by detecting the low width, you need to configure the RMCRCR2 <RMCLL[7:0]> bits.

After the falling edge of the data bit is detected, if the signal stays low longer than specified, excess low width is detected. The detection completes reception and generates an interrupt.

After interrupt inputs generated, RMCRSTAT<RMCLOIF> bit is set to "1."



13.4.1.4 Enabling Reception

By enabling the RMCREN <RMCREN> bit after configuring the RMCRCR1, RMCRCR2, RMCRCR3 and RMCRCR4 registers, RMC is ready for reception. Detecting a leader initiates reception.

Note: Changing the configurations of the RMCRCR1, RMCRCR2, RMCRCR3 and RMCRCR4 registers during reception may harm their proper operation. Be careful if you change them during reception.

13.4.1.5 Stopping Reception

RMC stops reception by clearing the RMCREN <RMCREN> bit to "0" (reception disabled).

Clearing this bit during reception stops reception immediately and the received data is discarded.

13.4.1.6 Receiving Remote Control Signal without Leader in Waiting Leader


Setting RMCRCR2 <RMCLD> enables RMC to receive signals with or without a leader.

By setting RMCRCR2 <RMCLD>, RMC starts receiving data if it recognizes a signal of which low width is shorter than a maximum low width of leader detection specified in the RMCRCR1 <RMCLLMAX[7:0]> bits. RMC keeps receiving data until the final data bit is received.

If RMCRCR2 <RMCLD> is enabled, the same settings of error detection, reception completion and data bit determination of 0 or 1 are applied regardless of whether a signal has a leader or not.

Thus receivable remote control signals are limited.

RMCRCR2<RMCLD> = 1



13.4.1.7 A Leader only with Low Width

The figure shown below illustrates a remote control signal that starts with a leader of which waveform only has low width.

This signal starts with a leader that only has low width and a data bit cycle starts from the rising edge. To enable the signal, it must be sent after being reversed by setting the RMCRCR4 <RMCPO> bit to "1".

This is because RMC is configured to detect a data bit cycle from the falling edge

To detect a leader, configure only low-pulse width of the leader with the <RMCLLMAX[7:0]>=0y0000 _ 0000, <RMCLCMAX[7:0]>> <RMCLCMIN[7:0]>.

In this case, the value of <RMCLLMIN[7:0]> is set as "don't care".


To detect whether data "0" or data "1", configure the threshold of 0/1 detection with the RMCRCR3 <RMCDATL[6:0]>.

The maximum data bit cycle is configured with the <RMCDMAX[7:0]> of the RMCRCR2.

To complete data reception, configure the maximum data bit cycle with <RMCDMAX[7:0]> of the RMCRCR2, and configure the low-pulse width detection with <RMCLL[7:0]>.

After detecting the maximum data bit cycle and confirming the low-pulse with which is specified after receiving the last bit, receiving data is completed.

The RMC generates an interrupt and waits for the next leader.



13.4.1.8 Receiving a Remote Control Signal in a Phase Method

RMC is capable of receiving a remote control signal in a phase method of which signal cycle is fixed. A signal in the phase method has three waveform patterns (see the figure shown below).

By setting two thresholds a remote control signal pattern is determined. RMC converts the signal into data "0" or "1". On completion of reception, received data "0" and "1" are stored in the RMCRBUF1, RMCRBUF 2 and RMCRBUF3.


By setting RMCRCR2<RMCPHM> = "1", RMC enables to receive a remote control signal in the phase method. Each threshold can be configured with the RMCRCR3 <RMCDATL[6:0]> bits and <RMCDATH [6:0]> bits.

Two thresholds are used to distinguish three waveform patterns. On condition that a cycle between two falling edges is "T", three patterns show cycles of 1T, 1.5T and 2T. Details of the two thresholds are shown below.


	Determined by	Threshold	Register bits to set
Threshold 1	Pattern 1 & pattern 2	1T to 1.5T	RMCRCR3 <rmcdatl[6:0]></rmcdatl[6:0]>
Threshold 2	Pattern 2 & pattern 3	1.5T to 2T	RMCRCR3 <rmcdath[6:0]></rmcdath[6:0]>

To determine a remote control signal in the phase method, three patterns of data waveform and preceding data are required. In addition, the signal needs to start from data "11".


Waveform pattern in phase method



Remote control signal data in phase method



13.4 Operation Description TMPM332FWUG



TOSHIBA TMPM332FWUG

14. Analog/Digital Converter (ADC)

14.1 Outline

A 10-bit, sequential-conversion analog/digital converter (AD converter) is built into the TMPM332FWUG.

This AD converter is equipped with 8 analog input channels.

These 8 analog input channels (pins AIN4 through AIN11) are also used as input/output ports.

- Note 1: To assure conversion accuracy, the specified value must be set to the ADCBAS register.
- Note 2: If it is necessary to reduce a power current by operating the TMPM332FWUG in IDLE or STOP mode and if either case shown below is applicable, you must first stop the AD converter and then execute the instruction to put the TMPM332FWUG into standby mode.
 - 1. The TMPM332FWUG must be put into IDLE mode when ADMOD1<I2AD> is "0".
 - 2.The TMPM332FWUG must be put into STOP mode.

4.2 Configuration TMPM332FWUG

14.2 Configuration

Figure 14-1 shows the block diagram of this AD converter.




Figure 14-1 AD Converter Block Diagram

14.3 Registers

14.3.1 Register list

The control registers and addresses of the AD converter are as follows.

The AD converter is controlled by the AD mode control registers (ADMOD0 through ADMOD5). The result of AD conversion is stored in the eight AD conversion result registers, ADREG08 through ADREG7F. The highest-priority conversion result is stored in the register ADREGSP.

To assure conversion accuracy, the specified value must be set to the ADCBAS register.

Base Address = 0x4003_0000

Register name		Address (Base+)	
Conversion Clock Setting Register	ADCLK	0x0000	
Mode Control Register 0	ADMOD0	0x0004	
Mode Control Register 1	ADMOD1	0x0008	
Mode Control Register 2	ADMOD2	0x000C	
Mode Control Register 3	ADMOD3	0x0010	
Mode Control Register 4	ADMOD4	0x0014	
Mode Control Register 5	ADMOD5	0x0018	
Conversion Accuracy Setting Register	ADCBAS	0x0020	
Reserved	-	0x0024	
Reserved	-	0x0028	
Conversion Result Register 08	ADREG08	0x0030	
Conversion Result Register 19	ADREG19	0x0034	
Conversion Result Register 2A	ADREG2A	0x0038	
Conversion Result Register 3B	ADREG3B	0x003C	
Conversion Result Register 4C	ADREG4C	0x0040	
Conversion Result Register 5D	ADREG5D	0x0044	
Conversion Result Register 6E	ADREG6E	0x0048	
Conversion Result Register 7F	ADREG7F	0x004C	
Conversion Result Register SP	ADREGSP	0x0050	
Conversion Result Comparison Register 0	ADCMP0	0x0054	
Conversion Result Comparison Register 1	ADCMP1	0x0058	

Note: Access to the "Reserved" address is prohibited.

14.3.2 ADCBAS (Conversion Accuracy Setting Register)

	31	30	29	28	27	26	25	24
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
Bit symbol	1	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
Bit symbol				ADC	BAS			
After reset	0	0	1	1	1	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-0	ADCBAS[7:0]	R/W	Write "0x58".

 $Note: To \ assure \ conversion \ accuracy, \ the \ specified \ value \ (0x0000_0058) \ must \ be \ set \ to \ the \ ADCBAS \ register.$

14.3.3 ADCLK (Conversion Clock Setting Register)

	31	30	29	28	27	26	25	24
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
Bit symbol	-	-	-	-	-	-	-	-
Bit symbol After reset	- 0	- 0	- 0	- 0	- 0	- 0	- 0	- 0
				0 4	0 3	0 2	0 1	
		0	0	-	Ů		0 1 ADCLK	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-4	TSH[3:0]	R/W	Select the AD sample hold time.
			1000: 8 conversion clock
			1001: 16 conversion clock
			1010: 24 conversion clock
			1011: 32 conversion clock
			0011: 64 conversion clock
			1100: 128 conversion clock
			1101: 512 conversion clock
			The setup other than those above: Reserved
3	_	R	Read as 0.
2-0	ADCLK[2:0]	R/W	Select the AD conversion clock.
			000: fc
			001: fc/2
			010: fc/4
			011: fc/8
			100: fc/16
			111: Reserved

A clock count required for conversion is 46 clocks at the minimum.

Examples of sample hold time and conversion time as shown as below.

(Example: If fc = 40MHz)

4TOLU10.035	Sample hold		Conversio	n time(<adclk[2:< th=""><th>0]> setting)</th><th></th></adclk[2:<>	0]> setting)	
<tsh[3:0]></tsh[3:0]>	time	000 (fc)	001 (fc/2)	010 (fc/4)	011 (fc/8)	100 (fc/16)
1000 (8 conversion clock)	0.2 μs	1.15 µs	2.3 µs	4.6 µs	9.2µs	18.4µs
1001 (16 conversion clock)	0.4 μs	1.35 µs	2.7µs	5.4µs	10.8µs	21.6µs
1010 (24 conversion clock)	0.6 μs	1.55 µs	3.1µs	6.2µs	12.4µs	24.8µs
1011 (32 conversion clock)	0.8 µs	1.75 µs	3.5µs	7.0µs	14.0µs	28.0µs
0011 (64 conversion clock)	1.6 µs	2.55 µs	5.1µs	10.2µs	20.4µs	40.8µs
1100 (128 conversion clock)	3.2 µs	4.15 µs	8.3µs	16.6µs	33.2µs	66.4µs
1101 (512 conversion clock)	12.8 µs	13.75 µs	27.5µs	55.0µs	110.0µs	220.0µs

Note: Do not change the setting of the AD conversion clock during AD conversion.

14.3.4 ADMOD0 (Mode Control Register 0)

	31	30	29	28	27	26	25	24
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
Bit symbol	EOCFN	ADBFN	-	IT	M	REPEAT	SCAN	ADS
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function				
31-8	-	R	Read as 0.				
7	EOCFN	R	lormal AD conversion completion flag (note1)				
			0: Before or during conversion				
			1: Completion				
6	ADBFN	R	Normal AD conversion BUSY flag				
			0: Conversion stop				
			1: During conversion				
5	-	R	Read as 0.				
4-3	ITM[1:0]	R/W	Specify interrupt in fixed channel repeat conversion mode (refer to the table below and note 2)				
2	REPEAT	R/W	Specify repeat mode				
			0: Single conversion mode				
			1: Repeat conversion mode				
1	SCAN	R/W	Specify scan mode				
			0: Fixed channel mode				
			1: Channel scan mode				
0	ADS	R/W	Start AD conversion start (note 3)				
			0: Don't care				
			1: Start conversion				
			"0" is always read.				

Specify AD conversion interrupt in fixed channel repeat conversion mode

ITM ())	Fixed channel repeat conversion mode
<itm[1:0]></itm[1:0]>	<scan> = "0", <repeat> = "1"</repeat></scan>
00	Generate in interrupt once every single conversion.
01	Generate interrupt once every 4 conversions.
10	Generate interrupt once every 8 conversions.
11	Setting prohibited.

Note 1: This flag is "0" cleared by reading the ADMOD0 register.

Note 2: It is valid only when it's specified in the fixed channel repeat mode (<REPEAT> ="1", <SCAN> = "0")

Note 3: Conversion must be started after setting the mode.

14.3.5 ADMOD1 (Mode Control Register 1)

	31	30	29	28	27 26		25	24	
Bit symbol	-	-	-	-	-	-	-	-	
After reset	0	0	0	0	0	0	0	0	
	23	22	21	20	19	18	17	16	
Bit symbol	-	-	-	-	-	-	-	-	
After reset	0	0	0	0	0	0	0	0	
	15	14	13	12	11	10	9	8	
Bit symbol	-	-	-	-	-	-	-	-	
After reset	0	0	0	0	0	0	0	0	
	7	6	5	4	3	2	1	0	
Bit symbol	VREFON	I2AD	ADSCN	-		ADCH			
After reset	0	0	0	0	0	0	0	0	

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7	VREFON	R/W	VREF application control(Note1 and Note2) 0: OFF 1: ON
6	I2AD	R/W	Specify operation mode in IDLE mode 0: Stop 1: Operation
5	ADSCN	R/W	Specify operation mode in channel scan mode 0: 4-channel scan 1: 8-channel scan
4	_	R/W	Write "0".
3-0	ADCH[3:0]	R/W	Select analog input channel (Refer to the below table.)

Select Analog Input Channel

ADMOD0 <scan></scan>	0	1	1			
	Fixed channel	Channel scan	Channel scan			
ADMOD1 <adch[3:0]></adch[3:0]>		(<adscn> = 0)</adscn>	(<adscn> = 1)</adscn>			
0000	Setting prohibited	Setting prohibited	Setting prohibited			
0001	Setting prohibited	Setting prohibited	Setting prohibited			
0010	Setting prohibited	Setting prohibited	Setting prohibited			
0011	Setting prohibited	Setting prohibited	Setting prohibited			
0100	AIN4	AIN4	Setting prohibited			
0101	AIN5	AIN4 to AIN5	Setting prohibited			
0110	AIN6	AIN4 to AIN6	Setting prohibited			
0111	AIN7	AIN4 to AIN7	Setting prohibited			
1000	AIN8	AIN8	AIN8			
1001	AIN9	AIN8 to AIN9	AIN8 to AIN9			
1010	AIN10	AIN8 to AIN10	AIN8 to AIN10			
1011	AIN11	AIN8 to AIN11	AIN8 to AIN11			
1100						
1101		Catting and hibited				
1110	Setting prohibited					
1111						

Note 1: Before starting AD conversion, write "1" to the <VREFON> bit, wait for 3µs during which time the internal reference voltage should stabilize, and then write "1" to the ADMOD0<ADS>.

Note 2: Set <VREFON> to "0" to go into standby mode upon completion of AD conversion.

14.3.6 ADMOD2 (Mode Control Register 2)

	31	31 30 29 28 27		27	26	25	24	
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
Bit symbol	EOCFHP	ADBFHP	HPADCE	-		HPADCH		
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	_	R	Read as 0.
7	EOCFHP	R	Top-priority AD conversion completion flag (Note1) 0: Before or during conversion 1: Completion
6	ADBFHP	R	Top-priority AD conversion BUSY flag 0: During conversion halts 1: During conversion
5	HPADCE	R/W	Activate top-priority conversion 0: Don't care 1: Start conversion "0" is always read.
4	-	R/W	Write "0".
3-0	HPADCH[3:0]	R/W	Select analog input channel when activating top-priority conversion. (See the table below)

<hpadch[3:0]></hpadch[3:0]>	Analog input channel whene xecuting top-priority conversion
0000	Setting prohibited
0001	Setting prohibited
0010	Setting prohibited
0011	Setting prohibited
0100	AIN4
0101	AIN5
0110	AIN6
0111	AIN7
1000	AIN8
1001	AIN9
1010	AIN10
1011	AIN11
1100	
1101	Catting muchibited
1110	Setting prohibited
1111	

Analog/Digital Converter (ADC	14.	Analog/Digital	Converter	(ADC
---	-----	----------------	-----------	------

Note 1: This flag is "0" cleared by reading the ADMOD2 register.

14.3.7 ADMOD4 (Mode Control Register 4)

	31	30	29	28	27	26	25	24
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
Bit symbol	HADHS	HADHTG	ADHS	ADHTG	-	-	ADI	RST
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7	HADHS	R/W	H/W source for activating top-priority AD conversion 0: External trigger 1: Match with timer register 0 (TB5RG0)
6	HADHTG	R/W	H/W for activating top-priority AD conversion 0: Disable 1: Enable
5	ADHS	R/W	H/W source for activating normal AD conversion (note1) 0: External trigger 1: Match with timer register 0 (TB6RG0)
4	ADHTG	R/W	HW for activating normal AD conversion 0: Disable 1: Enable
3-2	_	R	Read as 0.
1-0	ADRST[1:0]	W	Overwriting 10 with 01 allows ADC to be software reset.(note 2)

Note 1: The external trigger cannot be used for H/W activation of AD conversion when it is used for H/W activation of top priority AD conversion.

Note 2: A software reset initializes all the registers except for ADCLK<ADCLK>.

Note: The TX03 disables the external trigger used for H/W activation. Therefore "0" cannot be set to <HADHS> and <ADHS>.

14.3.8 ADMOD3 (Mode Control Register 3)

	31	30	29	28	27	26	25	24
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
Bit symbol	-	-	ADOBIC0	ADREGS0		ADOBSV0		
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7	_	R/W	Write "0".
6	_	R	Read as 0.
5	ADOBIC0	R/W	Set the AD monitor function interrupt 0 0: If the value of the conversion result is smaller than the comparison register 0, an interrupt is generated. 1: If the value of the conversion result is bigger than the comparison register 0, an interrupt is generated.
4-1	ADREGS0[3:0]	R/W	Select a target conversion result register when using the AD monitor function 0 (See the below table).
0	ADOBSV0	R/W	AD monitor function 0 0: Disable 1: Enable

<adregs0[3:0]></adregs0[3:0]>	Conversion result register to be compared	<adregs0[3:0]></adregs0[3:0]>	Conversion result register to be compared
0000	ADREG08	0100	ADREG4C
0001	ADREG19	0101	ADREG5D
0010	ADREG2A	0110	ADREG6E
0011	ADREG3B	0111	ADREG7F
-	-	1xxx	ADREGSP

14.3.9 ADMOD5 (Mode Control Register 5)

	31	30	29	28	27	26	25	24
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
Bit symbol	-	-	ADOBIC1	ADREGS1				ADOBSV1
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-6	_	R	Read as 0.
5	ADOBIC1	R/W	Set the AD monitor function interrupt 1. 0: If the value of the conversion result is smaller than the comparison register 1, an interrupt is generated. 1: If the value of the conversion result is bigger than the comparison register 1, an interrupt is generated.
4-1	ADREGS1[3:0]	R/W	Select a target conversion result register when using the AD monitor function 1 (See the below table).
0	ADOBSV1	R/W	AD monitor function 1 0: Disable 1: Enable

<adregs1[3:0]></adregs1[3:0]>	Conversion result register to be compared	<adregs1[3:0]></adregs1[3:0]>	Conversion result register to be compared
0000	ADREG08	0100	ADREG4C
0001	ADREG19	0101	ADREG5D
0010	ADREG2A	0110	ADREG6E
0011	ADREG3B	0111	ADREG7F
-	-	1xxx	ADREGSP

14.3.10 ADREG08 (Conversion Result Register 08)

	31	30	29	28	27	26	25	24
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
Bit symbol				ΑC	PR0			
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
Bit symbol	ADR0		-	-	-	-	OVR0	ADR0RF
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-16	-	R	Read as 0.
15-6	ADR0[9:0]	R	AD conversion result Conversion result is stored. For information about the correlation between the conversion channel and the conversion result register, refer to the Table 14-2, chapter 14.4.5.7.
5-2	-	R	Read as 0.
1	OVR0	R	Overrun flag 0: Not generated 1: Generated If the conversion result is overwritten before reading <adr0>, "1" is set. This bit is "0" cleared when it is read.</adr0>
0	ADR0RF	R	AD conversion result storage flag 0: Conversion result is not stored 1: Conversion result is stored. If a conversion result is stored, "1" is set. This bit is "0" cleared when the conversion result is read.

14.3.11 ADREG19 (AD Conversion Result Register 19)

	31	30	29	28	27	26	25	24
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
Bit symbol				AD	R1			
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
Bit symbol	ADR1		-	-	-	-	OVR1	ADR1RF
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-16	_	R	Read as 0.
15-6	ADR1[9:0]	R	AD conversion result
			Conversion result is stored. For information about the correlation between the conversion channel and the conversion result register, refer to the Table 14-2, chapter 14.4.5.7.
5-2	_	R	Read as 0.
1	OVR1	R	Overrun flag 0: Not generated 1: Generated If the conversion result is overwritten before <adr1>, "1" is set. This bit is "0" cleared when it is read.</adr1>
0	ADR1RF	R	AD conversion result storage flag 0: Conversion result is not stored. 1: Conversion result is stored. If a conversion result is stored, "1" is set. This bit is "0" cleared when the conversion result is read.

14.3.12 ADREG2A (AD Conversion Result Register 2A)

	31	30	29	28	27	26	25	24
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
Bit symbol				ΑC)R2			
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
Bit symbol	ADR2		-	-	-	-	OVR2	ADR2RF
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-16	-	R	Read as 0.
15-6	ADR2[9:0]	R	AD conversion result Conversion result is stored. For information about the correlation between the conversion channel and the conversion result register, refer to the Table 14-2, chapter 14.4.5.7.
5-2	-	R	Read as 0.
1	OVR2	R	Overrun flag 0: Not generated. 1: Generated. If a conversion result is overwritten before reading <adr2>, "1" is set. This bit is "0" cleared when it is read.</adr2>
0	ADR2RF	R	AD conversion result storage flag 0: Conversion result is not stored. 1: Conversion result is stored. If a conversion result is stored, "1" is set. This bit is "0" cleared when the conversion result is read.

14.3.13 ADREG3B (AD Conversion Result Register 3B)

	31	30	29	28	27	26	25	24
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
Bit symbol				AD	R3			
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
Bit symbol	ADR3		-	-	-	-	OVR3	ADR3RF
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-16	_	R	Read as 0.
15-6	ADR3[9:0]	R	AD conversion result.
			Conversion result is stored. For information about the correlation between the conversion channel and the conversion result register, refer to the Table 14-2, chapter 14.4.5.7.
5-2	_	R	Read as 0.
1	OVR3	R	Overrun flag 0: Not generated. 1: Generated. If a conversion result is overwritten before reading <adr3>, "1" is set. This bit is "0" cleared when it is read.</adr3>
0	ADR3RF	R	AD conversion result storage flag 0: Conversion result is not stored. 1: Conversion result is stored. If a conversion result is stored, "1" is set. This bit is "0" cleared when the conversion result is read.

14.3.14 ADREG4C (AD Conversion Result Register 4C)

	31	30	29	28	27	26	25	24
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
Bit symbol				ΑC)R4			
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
Bit symbol	AD	R4	-	-	-	-	OVR4	ADR4RF
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-16	_	R	Read as 0.
15-6	ADR4[9:0]	R	AD conversion result. Conversion result is stored. For information about the correlation between the conversion channel and the conversion result register, refer to the Table 14-2, chapter 14.4.5.7.
5-2	-	R	Read as 0.
1	OVR4	R	Overrun flag 0: Not generated. 1: Generated If a conversion result is overwritten before reading <adr4>, "1" is set. This bit is "0" cleared when it is read.</adr4>
0	ADR4RF	R	AD conversion result storage flag 0: Conversion result is not stored. 1: Conversion result is stored. If a conversion result is stored, "1" is set. This bit is "0" cleared when the conversion result is read.

14.3.15 ADREG5D (AD Conversion Result Register 5D)

	31	30	29	28	27	26	25	24
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
Bit symbol		-	-	AD	R5	-		
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
Bit symbol	AD	R5	-	-	-	-	OVR5	ADR5RF
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-16	-	R	Read as 0.
15-6	ADR5[9:0]	R	AD conversion result. Conversion result is stored. For information about the correlation between the conversion channel and the conversion result register, refer to the Table 14-2, chapter 14.4.5.7.
5-2	-	R	Read as 0.
1	OVR5	R	Overrun flag 0: Not generated. 1: Generated If a conversion result is overwritten before reading <adr5>, "1" is set. This bit is "0" cleared when it is read.</adr5>
0	ADR5RF	R	AD conversion result storage flag 0: Conversion result is not stored. 1: Conversion result is stored. If a conversion result is stored, "1" is set. This bit is "0" cleared when the conversion result is read.

14.3.16 ADREG6E (AD Conversion Result Register 6E)

	31	30	29	28	27	26	25	24
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
Bit symbol		-	-	AD	R6	-		-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
Bit symbol	AD	PR6	-	-	-	-	OVR6	ADR6RF
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-16	-	R	Read as 0.
15-6	ADR6[9:0]	R	AD conversion result. Conversion result is stored. For information about the correlation between the conversion channel and the conversion result register, refer to the Table 14-2, chapter14.4.5.7.
5-2	-	R	Read as 0.
1	OVR6	R	Overrun flag 0: Not generated. 1: Generated. If a conversion result is overwritten before reading <adr6>, "1" is set. This bit is "0" cleared when it is read.</adr6>
0	ADR6RF	R	AD conversion result storage flag 0: Conversion result is not stored. 1: Conversion result is stored. If a conversion result is stored, "1" is set. This bit is "0" cleared when the conversion result is read.

14.3.17 ADREG7F (AD Conversion Result Register 7F)

	31	30	29	28	27	26	25	24
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
Bit symbol				AD)R7			
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
Bit symbol	AD)R7	-	-	-	-	OVR7	ADR7RF
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-16	_	R	Read as 0.
15-6	ADR7[9:0]	R	AD conversion result. Conversion result is stored. For information about the correlation between the conversion channel and
5-2	_	R	the conversion result register, refer to the Table 14-2, chapter 14.4.5.7. Read as 0.
1	OVR7	R	Overrun flag 0: Not generated 1: Generated If a conversion result is overwritten before reading <adr7>, "1" is set. This bit is "0" cleared when it is read.</adr7>
0	ADR7RF	R	AD conversion result storage flag 0: Conversion result is not stored. 1: Conversion result is stored. If a conversion result is stored, "1" is set. This bit is "0" cleared when the conversion result is read.

 $\label{eq:Note:Access} \mbox{ Note:} \mbox{\bf Access to this register must be a half word or a word access.}$

14.3.18 ADREGSP (AD Conversion Result Register SP)

	31	30	29	28	27	26	25	24
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
Bit symbol				ADI	RSP			
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
Bit symbol	AD	RSP	-	-	-	-	OVRSP	ADRSPRF
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-16	-	R	Read as 0.
15-6	ADRSP[9:0]	R	AD conversion result. Top-priority AD conversion result is stored
5-2	-	R	Read as 0
1	OVRSP	R	Overrun flag 0: Not generated 1: Generated If a conversion result is overwritten before reading <adrsp>, "1" is set. This bit is "0" cleared when it is read.</adrsp>
0	ADRSPRF	R	AD conversion result storage flag 0: Conversion result is not stored. 1: Conversion result is stored. If a conversion result is stored, "1" is set. This bit is "0" cleared when the conversion result is read.

14.3.19 ADCMP0 (AD Conversion Result Comparison Register 0)

	31	30	29	28	27	26	25	24
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
Dit access at								
Bit symbol				ADC	OM0			
After reset	0	0	0	ADC	OM0 0	0	0	0
	0 7	0	0 5			0 2	0	0
	7	-	-	0	0		0 1 -	

Bit	Bit Symbol	Туре	Function
31-16	-	R	Read as 0.
15-6	ADCOM0[9:0]	R/W	When AD monitor function 0 is enabled, it sets a value to be compared with the value of the conversion result register specified by ADMOD3 <adregs0>.</adregs0>
5-0	-	R	Read as 0.

Note:To write values into this register, the AD monitor function 0 must be disabled (AD-MOD3<ADBSV0>="0").

14.3.20 ADCMP1 (AD Conversion Result Comparison Register 1)

	31	30	29	28	27	26	25	24
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
Bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
Bit symbol	ADCOM1							
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
Bit symbol	ADC	OM1	1	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0

Bit	Bit Symbol	Туре	Function
31-16	_	R	Read as 0.
15-6	ADCOM1[9:0]	R/W	When AD monitor function 1 is enabled, it sets a value to be compared with the value of the conversion result register specified by ADMODt <adregs1>.</adregs1>
5-0	-	R	Read as 0.

Note:To write values into this register, the AD monitor function 1 must be disabled (AD-MOD5<ADBSV1>="0").

14.4 Description of Operations

14.4.1 Analog Reference Voltage

The "High" level of the analog reference voltage shall be applied to the VRFEH pin, and the "Low" shall be applied to the VREFL pin.

To start AD conversion, make sure that you first write "1" to the <VREFON> bit, wait for 3 µs during which time the internal reference voltage should stabilize, and then write "1" to the ADMOD0<ADS> bit.

By writing "0" to the ADMOD1<VREFON> bit, a switched-on state of VREFH – VREFL can be turned into a switched -off state. To switch to the power-consumption mode, set "0" to the <VREFON> bit after conversion.

Note: VREFL and AVSS are shared by TMPM332FWUG.

14.4.2 AD Conversion Mode

Two types of AD conversion are supported: normal AD conversion and top-priority AD conversion.

For normal AD conversion, the following four operation modes are supported.

14.4.2.1 Normal AD conversion

For normal AD conversion, the following four operation modes are supported and the operation mode is selected with the ADMOD0<REPEAT, SCAN>.

- · Fixed channel single conversion mode
- Channel scan single conversion mode
- · Fixed channel repeat conversion mode
- Channel scan repeat conversion mode

(1) Fixed channel single conversion mode

If ADMOD0<REPEAT, SCAN> is set to "00", "AD conversion is performed in the fixed channel single conversion mode.

In this mode, AD conversion is performed once for one channel selected. After AD conversion is completed, ADMOD0<EOCFN> is set to "1", ADMOD0<ADBFN> is cleared to "0", and the AD conversion completion interrupt request (INTAD) is generated. <EOCFN> is cleared to "0" upon read.

(2) Channel scan single conversion mode

If ADMOD0 <REPEAT, SCAN> is set to "01," AD conversion is performed in the channel scan single conversion mode.

In this mode, AD conversion is performed once for each scan channel selected. After AD scan conversion is completed, ADMOD0<EOCFN> is set to "1", ADMOD0<ADBFN> is cleared to "0", and the conversion completion interrupt request (INTAD) is generated. <EOCFN> is cleared to "0".

(3) Fixed channel repeat conversion mode

If ADMOD0<REPEAT, SCAN> is set to "10", AD conversion is performed in fixed channel repeat conversation mode.

In this mode, AD conversion is performed repeatedly for one channel selected. After AD conversion is completed, ADMOD0<EOCFN> is set to "1". ADMOD0<ADBFN> is not cleared to "0". It remains at "1". The timing with which the conversion completion interrupt request (INTAD) is generated can be selected by setting ADMOD0<ITM> to an appropriate setting. <EOCFN> is set with the same timing as this interrupt INTAD is generated.

By reading <EOCFN>, it is cleared to "0".

(4) Channel scan repeat conversion mode

If ADMOD0<REPEAT, SCAN> is set to "11", AD conversion is performed in the channel scan repeat conversion mode.

In this mode, AD conversion is performed repeatedly for a scan channel selected. Each time one AD scan conversion is completed, ADMOD0<EOCFN> is set to "1", and the conversion completion interrupt request (INTAD) is generated. ADMOD0<ADBFN> is not cleared to "0". It remains at "1". <EOCFN> is cleared to "0" upon read.

14.4.2.2 Top-priority AD conversion

By interrupting ongoing normal AD conversion, top-priority AD conversion can be performed.

The fixed-channel single conversion is automatically selected, irrespective of the ADMOD0<REPEAT, SCAN> setting. When conditions to start operation are met, a conversion is performed just once for a channel designated by ADMOD2<HPADCH>. When conversion is completed, the top-priority AD conversion completion interrupt (INTADHP) is generated, and ADMOD2<EOCFHP> showing the completion of AD conversion is set to "1". <ADBFHP> returns to "0". EOCFHP flag is cleared to "0" upon read.

Top-priority AD conversion activated while top-priority AD conversion is under way is ignored.

14.4.3 AD Monitor Function

There are two channels of AD monitor function.

If ADMOD3<ADOBSV0> and ADMOD5<ADOBSV1> are set to "1", the AD monitor function is enabled. If the value of the conversion result register specified by ADMOD3<ADREGS0> and ADMOD5<ADREGS1> becomes larger or smaller ("Larger" or "Smaller" to be designated by ADMOD3<ADOBIC0> and ADMOD5<ADBIC1>) than the value of a comparison register, the AD monitor function interrupt (INTADM0,INTADM1) is generated. This comparison operation is performed each time a result is stored in a corresponding conversion result register.

If the conversion result register assigned to perform the AD monitor function is continuously used without reading the conversion result, the conversion result is overwritten. The conversion result storage flag <ADRxRF> and the overrun flag <OVRx> remain being set.

14.4 Description of Operations

14.4.4 Selecting the Input Channel

After reset, ADMOD0<REPEAT,SCAN> is initialized to "00" and ADMOD1<ADCH[3:0]> is initialized to "0000".

The channels to be converted are selected according to the operation mode of the AD converter as shown below

1. Normal AD conversion mode

- If the analog input channel is used in a fixed state (ADMOD0<SCAN> = "0")

 One channel is selected from analog input pins AIN4 through AIN11 by setting AD-MOD1<ADCH> to an appropriate setting.
- If the analog input channel is used in a scan state (ADMOD0<SCAN> = "1")
 One scan mode is selected from the scan modes by setting ADMOD1 <ADCH> and ADSCN to an appropriate setting.

2. Top-priority AD conversion mode

One channel is selected from analog input pins from AIN4 through AIN11 by setting AD-MOD2<HPADCH> to an appropriate setting.

14.4.5 AD Conversion Details

14.4.5.1 Starting AD Conversion

Normal AD conversion is activated by setting ADMOD0<ADS> to "1". Top-priority AD conversion is activated by setting ADMOD2<HPADCE> to "1".

Four operation modes are made available to normal AD conversion. In performing normal AD conversion, one of these operation modes must be selected by setting ADMOD0<REPEAT,SCAN> to an appropriate setting. For top-priority AD conversion, only one operation mode can be used: fixed channel single conversion mode.

Normal AD conversion can be activated using the H/W activation source selected by ADMOD4<ADHS>, and top-priority AD conversion can be activated using the HW activation source selected by ADMOD4<HADHS>. If bits of <ADHS> and <HADHS> are "0", normal and top-priority AD conversions are activated in response to the input of a falling edge through the \overline{ADTRG} pin. If these bits are "1", normal AD conversion is activated in response to TB6RG0 generated by the 16-bit timer 6, and top-priority AD conversion is activated in response to TB5RG0 generated by the 16-bit timer 5.

To permit H/W activation, set ADMOD4<ADHTG> to "1" for normal AD conversion and set AD-MOD4<HADHTG> to "1" for top-priority AD conversion.

Software activation is still valid even after H/W activation has been permitted.

Note: When an external trigger is used for the HW activation source of a top-priority AD conversion, an external trigger cannot be set for activating normal AD conversion H/W.

Note: The TMPM332FWUG disables the external trigger used for H/W activation. Therefore "0" cannot be set to <HADHS> and <ADHS>.

14.4.5.2 AD Conversion

When normal AD conversion starts, the AD conversion Busy flag (ADMOD0<ADBFN>) showing that AD conversion is under way is set to "1".

When top-priority AD conversion starts, the top-priority AD conversion Busy flag (AD-MOD2<ADBFHP>) showing that AD conversion is underway is set to "1". At that time, the value of the Busy flag ADMOD0<ADBFN> for normal AD conversion before the start of top-priority AD conversions are retained. The value of the conversion completion flag ADMOD0<EOCFN> for normal AD conversion before the start of top-priority AD conversion is retained.

Note: Normal AD conversion must not be activated when top-priority AD conversion is under way.


14.4.5.3 Top-priority AD conversion during normal AD conversion

If top-priority AD conversion has been activated during normal AD conversion, ongoing normal AD conversion is suspended, and restarts normal AD conversion after top-priority AD conversion is completed.

If ADMOD2<HPADCE> is set to "1" during normal AD conversion, ongoing normal AD conversion is suspended, and the top-priority AD conversion starts; specifically, AD conversion (fixed-channel single conversion) is executed for a channel designated by ADMOD2<HPADCH>. After the result of this top-priority AD conversion is stored in the storage register ADREGSP, normal AD conversion is resumed.

If H/W activation of top-priority AD conversion is authorized during normal AD conversion, ongoing AD conversion is discontinued when requirements for activation using a H/W activation resource are met, and top-priority AD conversion (fixed-channel single conversion) starts for a channel designated by AD-MOD2<HPADCH>. After the result of this top-priority AD conversion is stored in the storage register ADREGSP, normal AD conversion is resumed.

For example, if channel repeat conversion is activated for channels AIN0 through AIN3 and if <HPADCE> is set to "1" during AIN2 conversion, AIN2 conversion is suspended, and conversion is performed for a channel designated by <HPADCH> (AIN11 in the case shown below). After the result of conversion is stored in ADREGSP, channel repeat conversion is resumed, starting from AIN2.



14.4.5.4 Stopping Repeat Conversion Mode

To stop the AD conversion operation in the repeat conversion mode (fixed-channel repeat conversion mode or channel scan conversion mode), write "0" to ADMOD0<REPEAT>. When ongoing AD conversion is completed, the repeat conversion mode terminates, and ADMOD0<ADBFN> is set to "0".

14.4.5.5 Reactivating normal AD conversion

To reactivate normal AD conversion while the conversion is underway, a software reset (AD-MOD3<ADRST>) must be performed before starting AD conversion. The H/W activation method must not be used to reactivate normal AD conversion.

14.4.5.6 Conversion completion

(1) Normal AD conversion completion

When normal AD conversion is completed, the AD conversion completion interrupt (INTAD) is generated. The result of AD conversion is stored in the storage register, and two registers change: the register ADMOD0<EOCFN> which indicates the completion of AD conversion and the register ADMOD0<ADBFN>.

Interrupt request, conversion register storage register and <EOCFN><ADBFN> change with a different timing according to a mode selected.

In mode other than fixed-channel repeat conversion mode, conversion results are stored in AD conversion result registers (ADREG08 through ADRG7F) corresponding to a channel.

In fixed-channel repeat conversion mode, the conversion results are sequentially stored in storage registers ADREG08 through ADREG7F. However, if interrupt setting on <ITM> is set to be generated each time one AD conversion is completed, the conversion result is stored only in ADREG08. If interrupt setting on <ITM> is set to be generated each time four AD conversions are completed, the conversion results are sequentially stored in ADREG08H through ADREG3B.

Interrupt requests, flag changes and conversion result registers in each mode are as shown below.

Fixed-channel single conversion mode

After AD conversion completed, ADMOD0<EOCFN> is set to "1", ADMOD0<ADBFN> is cleared to "0", and the interrupt request is generated.

Conversion results are stored a conversion result register correspond to a channel.

· Channel scan single conversion mode

After the channel scan conversion is completed, ADMOD0<EOCFN> is set to "1", ADMOD0<ADBFN> is set to "0", and the interrupt request INTAD is generated.

Conversion results are stored a conversion result register correspond to a channel.

Fixed-channel repeat conversion mode

ADMOD0<ADBFN> is not cleared to "0". It remains at "1". The timing with which the interrupt request INTAD is generated can be selected by setting ADMOD0<ITM> to an appropriate setting. ADMOD0<EOCFN> is set with the same timing as this interrupt INTAD is generated.

a. One conversion

With <ITM[1:0]> set to "00", an interrupt request is generated each time one AD conversion is completed. In this case, the conversion results are always stored in the storage register ADREG08. After the conversion result is stored, <EOCFN> changes to "1".

b. Four conversions

With <ITM[1:0]> set to "01", an interrupt request is generated each time four AD conversions are completed. In this case, the conversion results are sequentially stored in the storage register ADREG08 through ADREG3B. After the conversion result is stored in ADREG3B, <EOCFN> is set to "1", and the storage of subsequent conversion results starts from ADREG08.

c. 8 conversions

With <ITM[1:0]> set to "10", an interrupt request is generated each time eight AD conversions are completed. In this case, the conversion results are sequentially stored in the storage register ADREG08 through ADREG7F. After the conversion result is stored in ADREG7F, <EOCFN> is set to "1", and the storage of subsequent conversion results starts from ADREG08.

· Channel scan repeat conversion mode

Each time one AD conversion is completed, ADMOD0<EOCF> is set to "1" and interrupt request INTAD is generated. ADMOD0<ADBFN> is not cleared to "0". It remains at "1".

AD conversion results are stored in a AD conversion result register corresponding to a channel.

(2) Top-priority AD conversion completion

After the AD conversion is completed, the top-priority AD conversion completion interrupt (INTADHP) is generated, and ADMOD2<EOCFHP> which indicates the completion of top-priority AD conversion is set to "1".

AD conversion results are stored in the AD conversion result register SP.

(3) Data polling

To confirm the completion of AD conversion without using interrupts, data polling can be used. When AD conversion is completed, ADMOD0<EOCFN> is set to "1". To confirm the completion of AD conversion and to obtain the results, poll this bit.

AD conversion result storage register must be read by half word or word access. If <OVRx> = "0" and <ADRxRF> = "1", a correct conversion result has been obtained.

14.4 Description of Operations

14.4.5.7 Interrupt generation timings and AD conversion result storage register

Table 14-1 shows a relation in the following three items: AD conversion modes, interrupt generation timings and flag operations. Table 14-2 shows a relation between analog channel inputs and AD conversion result registers.

Table 14-1 Relations in conversion modes, interrupt generation timings and flag operations

			peat mode s	setting		<eocfn>/</eocfn>	ADMOD0	ADMOD2
Conversion mode		<repeat></repeat>	<scain></scain>	<itm[1:0]></itm[1:0]>	Interrupt generation timing	<eocfhp> set timing (See note)</eocfhp>	<adbfn> (After the interrupt is generated)</adbfn>	<adbfhp></adbfhp>
	Fixed-channel single conversion	0	0	-	After generation is completed.	After conversion is completed.	0	-
		1 1	0	00	Each time one conversion is completed.	After one conversion is completed.	1	-
Nama	Fixed-channel repeat conversion			01	Each time four conversion is completed.	After four conversions are completed.	1	-
Normal conversion				10	Each time eight conversion is completed.	After eight conversions are completed.	1	-
	Channel scan single conversion	0	1	1	After scan conversion is completed.	After scan conversion is completed.	0	-
	Channel scan repeat conversion	1	1	-	After one scan conversion is completed.	After one scan conversion is completed.	1	-
Top-pri	Top-priority conversion		_	_	After completion is completed.	Conversion com- pletion	-	0

Note: ADMOD0<EOCFN> and ADMOD2<EOCFHP> are cleared upon read.

Table 14-2 Relation between analog channels input and AD conversion result registers

		Normal AD conversion									
Analog input channels	Other conversion mode than those shown on the right side	Fixed channel repeat conversion mode (every one conversion)	Fixed channel repeat conversion mode (every four conver- sions)	Fixed channel repeat conversion mode (every eight conver- sions)	Top-priority AD conversion						
AIN4	ADREG4C	ADREG08 fixed			ADREGSP						
AIN5	ADREG5D		ADREG08 ◀	ADREG08 ◀							
AIN6	ADREG6E		<u> </u>	†							
AIN7	ADREG7F		ADREG3B —	ADREG7F							
AIN8	ADREG08			ABINEOTI							
AIN9	ADREG19										
AIN10	ADREG2A										
AIN11	ADREG3B										

Note: To access the conversion result register, use a half-word or a word access.

Cautions

The result value of AD conversion may vary depending on the fluctuation of the supply voltage, or may be affected by noise.

When using analog input pins and ports alternately, do not read and write ports during conversion because the conversion accuracy may be reduced. Also the conversion accuracy may be reduced if the output ports current fluctuate during AD conversion.

Please take counteractive measures with the program such as averaging the AD conversion results.

Description of Operations	TMPM332FWUG

TOSHIBA TMPM332FWUG

15. Watchdog Timer(WDT)

The watchdog timer (WDT) is for detecting malfunctions (runaways) of the CPU caused by noises or other disturbances and remedying them to return the CPU to normal operation.

If the watchdog timer detects a runaway, it generates a INTWDT interrupt or reset.

Note: INTWDT interrupt is a factor of the non-maskable interrupts (NMI).

Also, the watchdog timer notifies of the detecting malfunction to the external peripheral devices from the watchdog timer pin (WDTOUT) by outputting "Low".

Note: This product does not have the watchdog timer out pin (WDTOUT).

15.1 Configuration

Figure 15-1shows the block diagram of the watchdog timer.




Figure 15-1 Block Diagram of the Watchdog Timer

15.2 Register TMPM332FWUG

15.2 Register

The followings are the watchdog timer control registers and addresses.

Base Address = 0x4004_0000

Register name	Address(Base+)	
Watchdog Timer Mode Register	WDMOD	0x0000
Watchdog Timer Control Register	WDCR	0x0004

15.2.1 WDMOD(Watchdog Timer Mode Register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	WDTE		WDTP		-	I2WDT	RESCR	-
After reset	1	0	0	0	0	0	1	0

Bit	Bit Symbol	Туре		Function				
31-8	-	R	Read as 0.					
7	WDTE	R/W	Enable/Disable control					
			0:Disable					
			1:Enable					
6-4	WDTP[2:0]	R/W	Selects WDT detection time	e(Refer toTable 15-1)				
			000: 2 ¹⁵ /fsys	100: 2 ²³ /fsys				
			001: 2 ¹⁷ /fsys	101: 2 ²⁵ /fsys				
			010: 2 ¹⁹ /fsys	110:Setting prohibited.				
			011: 2 ²¹ /fsys	111:Setting prohibited.				
3	_	R	Read as 0.					
2	I2WDT	R/W	Operation when IDLE mode					
			0: Stop					
			1:In operation					
1	RESCR	R/W	Operation after detecting m	Operation after detecting malfunction				
			0: INTWDT interrupt request generates. (Note)					
			1: Reset					
0	_	R/W	Write 0.					

Note: INTWDT interrupt is a factor of the non-maskable interrupts (NMI).

Table 15-1 Detection time of watchdog timer (fc = 40 MHz)

Clock gear value	WDMOD <wdtp[2:0]></wdtp[2:0]>									
CGSYSCR <gear[2:0]></gear[2:0]>	000	001	010	011	100	101				
000 (fc)	0.82 ms	3.28 ms	13.11 ms	52.43 ms	209.72 ms	838.86 ms				
100 (fc/2)	1.63 ms	6.55 ms	26.21 ms	104.86 ms	419.43 ms	1.68 s				
101 (fc/4)	3.28 ms	13.11 ms	52.43 ms	209.72 ms	838.86 ms	3.36 s				
110 (fc/8)	6.55 ms	26.21 ms	104.86 ms	419.43 ms	1.68 s	6.71 s				

15.2.2 WDCR (Watchdog Timer Control Register)

	31	30	29	28	27	26	25	24	
bit symbol	-	-	-	-	-	-	-	-	
After reset	0	0	0	0	0	0	0	0	
	23	22	21	20	19	18	17	16	
bit symbol	-	-	-	-	-	-	-	-	
After reset	0	0	0	0	0	0	0	0	
	15	14	13	12	11	10	9	8	
bit symbol	-	-	-	-	-	-	-	-	
After reset	0	0	0	0	0	0	0	0	
	7	6	5	4	3	2	1	0	
bit symbol	WDCR								
After reset	1	-	-	-	-	-	-	-	

Bit	Bit Symbol	Туре	Function
31-8	-	R	Read as 0.
7-0	WDCR	W	Disable/Clear code 0xB1:Disable code 0x4E: Clear code Others:Reserved

15.3 Operations TMPM332FWUG

15.3 Operations

15.3.1 Basic Operation

The Watchdog timer is consists of the binary counters that work using the system clock (fsys) as an input. Detecting time can be selected between 2¹⁵, 2¹⁷, 2¹⁹, 2²¹, 2²³ and 2²⁵ by the WDMOD<WDTP[2:0]>. The detecting time as specified is elapsed, the watchdog timer interrupt (INTWDT) generates, and the watchdog timer out pin (WDTOUT) output "Low".

To detect malfunctions (runaways) of the CPU caused by noise or other disturbances, the binary counter of the watchdog timer should be cleared by software instruction before INTWDT interrupt generates. If the binary counter is not cleared, the non-maskable interrupt generates by INTWDT. Thus CPU detects malfunction (runway), malfunction countermeasure program is performed to return to the normal operation.

Additionally, it is possible to resolve the problem of a malfunction (runaway) of the CPU by connecting the watchdog timer out pin to reset pins of peripheral devices.

Note: This product does not include a watchdog timer out pin (WDTOUT).

15.3.2 Operation Mode and Status

The watchdog timer begins operation immediately after a reset is cleared.

If not using the watchdog timer, it should be disabled.

The watchdog timer cannot be used in the STOP mode, SLEEP mode and SLOW mode where high-speed frequency clock is stopped. Before transition to these modes, the watchdog timer should be disabled.

In IDLE mode, its operation depends on the WDMOD <I2WDT> setting.

Also, the binary counter is automatically stopped during debug mode.

TOSHIBA TMPM332FWUG

15.4 Operation when malfunction (runaway) is detected

15.4.1 INTWDT interrupt generation

In the Figure 15-2 shows the case that INTWDT interrupt generates (WDMOD<RESCR>="0").

When an overflow of the binary counter occurs, INTWDT interrupt generates. It is a factor of non-maskable interrupt (NMI). Thus CPU detects non-maskable interrupt and performs the countermeasure program.

The factor of non-maskable interrupt is the plural. CGNMIFLG identifies the factor of non-maskable interrupts. In the case of INTWDT interrupt, CGNMIFLG<NMIFLG0> is set.

When INTWDT interrupt generates, simultaneously the watchdog timer out ($\overline{\text{WDTOUT}}$) output "Low". $\overline{\text{WDTOUT}}$ becomes "High" by the watchdog timer clearing that is writing clear code 0x4E to the WDCR register.

Note: This product does not have the watchdog timer output pin(WDTOUT).




Figure 15-2 INTWDT interrupt generation

15.4.2 Internal reset generation

Figure 15-3 shows the internal reset generation (WDMOD<RESCR>="1").

MCU is reset by the overflow of the binary counter. In this case, reset status continues for 32 states. A clock is initialized so that input clock (fsys) is the same as a high-speed frequency clock (fosc). This means fsys = fosc.




Figure 15-3 Internal reset generation

TMPM332FWUG

15.5 Control register

The watchdog timer (WDT) is controlled by two control registers WDMOD and WDCR.

15.5.1 Watchdog Timer Mode Register (WDMOD)

1. Specifying the detection time of the watchdog timer <WDTP[2:0]>.

Set the watchdog timer detecting time to WDMOD<WDTP[2:0]>. After reset, it is initialized to WDMOD<WDTP[2:0]> = "000".

2. Enabling/disabling the watchdog timer <WDTE>.

When resetting, WDMOD <WDTE> is initialized to "1" and the watchdog timer is enabled.

To disable the watchdog timer to protect from the error writing by the malfunction, first <WDTE> bit is set to "0", and then the disable code (0xB1) must be written to WDCR register.

To change the status of the watchdog timer from "disable" to "enable," set the <WDTE> bit to "1".

3. Watchdog timer out reset connection <RESCR>

This register specifies whether WDTOUT is used for internal reset or interrupt. After reset, WDMOD<RESCR> is initialized to "1", the internal reset is generated by the overflow of binary counter.

15.5.2 Watchdog Timer Control Register(WDCR)

This is a register for disabling the watchdog timer function and controlling the clearing function of the binary counter.

15. Watchdog Timer(WDT)

15.5 Control register TMPM332FWUG

15.5.3 Setting example

15.5.3.1 Disabling control

By writing the disable code (0xB1) to this WDCR register after setting WDMOD <WDTE> to "0," the watchdog timer can be disabled and the binary counter can be cleared.

15.5.3.2 Enabling control

Set WDMOD <WDTE> to "1".

15.5.3.3 Watchdog timer clearing control

Writing the clear code (0x4E) to the WDCR register clears the binary counter and it restarts counting.

15.5.3.4 Detection time of watchdog timer

In the case that 2²¹/fsys is used, set "011" to WDMOD<WDTP[2:0]>.

TOSHIBA TMPM332FWUG

16. Real Time Clock (RTC)

16.1 Function

- 1. Clock (hour, minute and second)
- 2. Calendar (month, week, date and leap year)
- 3. Selectable 12 (am/pm) and 24 hour display
- 4. Time adjustment + or -30 seconds (by software)
- 5. Alarm (alarm output)
- 6. Alarm interrupt

16.2 Block Diagram




Figure 16-1 Block Diagram

- Note 1: Western calendar year column:This product uses only the final two digits of the year. The year following 99 is 00 years. Please take into account the first two digits when handling years in the western calendar.
- Note 2: Leap year: A leap year is divisible by 4 excluding a year divisible by 100; the year divisible by 100 is not considered to be a leap year. Any year divisible by 400 is a leap year. This product is considered the year divisible by 4 to be a leap year and does not take into account the above exceptions. It needs adjustments for the exceptions.

16.3 Detailed Description Register

16.3.1 Register List

The registers and the addresses related to RTC are shown as below.

RTC has two functions, PAGE0 (clock) and PAGE1 (alarm), which share some parts of registers.

The PAGE can be selected by setting RTCPAGER<PAGE >.

Base Address = 0x4004_0100

Register name		Address(Base+)	
Second column register (only PAGE0)	RTCSECR	0x0000	
Minute column register	RTCMINR	0x0001	
Hour column register	RTCHOURR	0x0002	
- (note 1)	-	0x0003	
Day of the week column register	RTCDAYR	0x0004	
Day column register	RTCDATER	0x0005	
Month column register (PAGE0)	RTCMONTHR	00000	
Selection register of 24-hour,12-hour (PAGE1)	RICMONTHR	0x0006	
Year column register (PAGE0)	RTCYEARR	0x0007	
Leap year register (PAGE1)	RICIEARK	0x0007	
PAGE register	RTCPAGER	0x0008	
- (note 1)	-	0x0009	
- (note 1)	-	0x000A	
- (note 1)	-	0x000B	
Reset register	RTCRESTR	0x000C	
Reserved	-	0x000D	
- (note 1)	-	0x000E	
- (note 1)	-	0x000F	

Note 1: "0" is read by reading the address. Writing is disregarded.

Note 2: Access to the "Reserved" areas is prohibited.

16.3.2 Control Register

Reset operation initializes the following registers.

- RTCPAGER<PAGE>, <ADJUST>, <INTENA>
- $\bullet \quad \mathsf{RTCRESTR} < \mathsf{RSTALM} >, < \mathsf{RSTTMR} >, < \mathsf{DIS16HZ} >, < \mathsf{DIS1HZ} >$

Other clock-related registers are not initialized by reset operation.

Before starting the RTC, set the time, month, day, day of the week, year and leap year in the relevant registers.

Caution is required in setting clock data, adjusting seconds or resetting the clock.

Refer to "16.4.3 Entering the Low Power Consumption Mode" for more information.

Table 16-1 PAGE0 (clock function) register

Symbol	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0	Function
RTCSECR	-	40sec.	20sec.	10sec.	8sec.	4sec.	2sec.	1sec.	Second column
RTCMINR	1	40min.	20min.	10min.	8min.	4min.	2min.	1min.	Minute column
RTCHOURR	ı	ı	20hours PM/AM	10hour	8hour	4hour	2hour	1hours	Hour column
RTCDAYR	ı	ı	ı	-	-	D	ay of the wee	ek	Day of the week column
RTCDATER	ı	ı	Day20	Day10	Day8	Day4	Day2	Day1	Day column
RTCMONTHR	-	1	ı	Oct.	Aug.	Apr.	Feb.	Jan.	Month column
RTCYEARR	year 80	year 40	year20	year 10	year 8	year 4	year 2	year 1	Year column (lower two columns)
RTCPAGER	Interrupt enable	-	-	Adjustment function	Clock ena- ble	Alarm en- able	-	PAGE setting	PAGE register
RTCRESTR	1 Hz enable	16 Hz enable	Clock reset	Alarm reset	_	Always write "1"		Reset register	

Note: Reading RTCSECR, RTCMINR, RTCHOURR, RTCDAYR, RTCMONTHR, RTCYEARR of PAGE0 captures the current state.

Table 16-2 PAGE1 (alarm function) registers

Symbol	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0	Function
RTCSECR	-	-	-	-	-	-	-	-	-
RTCMINR	-	40min.	20min.	10min.	8min.	4min.	2min.	1min.	Minute column
RTCHOURR	-	-	20hours PM/AM	10hour	8hour	4hour	2hour	1hour	Hour column
RTCDAYR	-	-	-	-	-	D	Day of the week		Day of the week column
RTCDATER	-	-	Day20	Day10	Day8	Day4	Day2	Day1	Day column
RTCMONTHR	-	-	-	-	-	-	-	24/12	24-hour clock mode
RTCYEARR	-	-	-	-	-	-	Leap-yea	ar setting	Leap-year mode
RTCPAGER	Interrupt enable	-	-	Adjustment function	Clock ena- ble	Alarm en- able	-	PAGE setting	PAGE register
RTCRESTR	1 Hz Enable	16 Hz Enable	Clock reset	Alarm reset	-	Always write "1"		Reset register	

Note 1: Reading RTCMINR, RTCHOURR, RTCDAYR, RTCMONTHR, RTCYEARR of PAGE1 captures the current state.

Note 2: RTCSECR, RTCMINR, RTCHOURR, RTCDAYR, RTCDATER, RTCMONTHR, RTCYEARR of PAGE0 and RTCYEARR of PAGE1 (for leap year) must be read twice and compare the data captured.

16.3.3 Detailed Description of Control Register

16.3.3.1 RTCSECR (Second column register (for PAGE0 only))

	7	6	5	4	3	2	1	0
bit symbol	-		SE					
After reset	0	Undefined						

Bit	Bit Symbol	Туре		Functon					
7	-	R	Read as 0.						
6-0	SE	R/W	Setting digit register of s	econd					
			000_0000 : 00sec.	001_0000 : 10sec.	010_0000 : 20sec.				
			000_0001 : 01sec.	001_0001 : 11sec.	•				
			000_0010 : 02sec.	001_0010 : 12sec.	011_0000 : 30sec.				
			000_0011 : 03sec.	001_0011 : 13sec.	•				
			000_0100 : 04sec.	001_0100 : 14sec.	100_0000 : 40sec.				
			000_0101 : 05sec.	001_0101 : 15sec.	•				
			000_0110 : 06sec.	001_0110 : 16sec.	101_0000 : 50sec.				
			000_0111 : 07sec.	001_0111 : 17sec.	•				
			000_1000 : 08sec.	001_1000 : 18sec.	•				
			000_1001 : 09sec.	001_1001 : 19sec.	101_1001 : 59sec.				

Note: The setting other than listed above is prohibited.

16.3.3.2 RTCMINR (Minute column register (PAGE0/1))

	7	6	5	4	3	2	1	0
Bit symbol	-		MI					
After reset	0	Undefined						

Bit	Bit Symbol	Туре		ı	Functon			
7	-	R	Read as 0.					
6-0	МІ	R/W	Setting digit register of Minutes.					
			000_0000 : 00min.	001_0000 : 10min.	010_0000 : 20min.			
			000_0001 : 01min.	001_0001 : 11min.				
			000_0010 : 02min.	001_0010 : 12min.	011_0000 : 30min.			
			000_0011 : 03min.	001_0011 : 13min.	•			
			000_0100 : 04min.	001_0100 : 14min.	100_0000 : 40min.			
			000_0101 : 05min.	001_0101 : 15min.	•			
			000_0110 : 06min.	001_0110 : 16min.	101_0000 : 50min.			
			000_0111 : 07min.	001_0111 : 17min.	•			
			000_1000 : 08min.	001_1000 : 18min.				
			000_1001 : 09min.	001_1001 : 19min.	101_1001 : 59min.			

Note: The setting other than listed above is prohibited.

16.3.3.3 RTCHOURR (Hour column register(PAGE0/1))

(1) 24-hour clock mode (RTCMONTHR<MO0>= "1")

	7	6	5	4	3	2	1	0
Bit symbol	-	-	но					
After reset	0	0	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined

Bit	Bit Symbol	Туре		Fund	cton
7-6	-	R	Read as 0.		
5-0	НО	R/W	Setting digit register of Ho	our.	
			00_0000 : 0 o'clock	01_0000 : 10 o'clock	10_0000 : 20 o'clock
			00_0001 : 1 o'clock	01_0001 : 11 o'clock	10_0001 : 21 o'clock
			00_0010 : 2 o'clock	01_0010 : 12 o'clock	10_0010 : 22 o'clock
			00_0011 : 3 o'clock	01_0011 : 13 o'clock	10_0011 : 23 o'clock
			00_0100 : 4 o'clock	01_0100 : 14 o'clock	
			00_0101 : 5 o'clock	01_0101 : 15 o'clock	
			00_0110 : 6 o'clock	01_0110 : 16 o'clock	
			00_0111 : 7 o'clock	01_0111 : 17 o'clock	
			00_1000 : 8 o'clock	01_1000 : 18 o'clock	
			00_1001 : 9 o'clock	01_1001 : 19 o'clock	

Note: The setting other than listed above is prohibited.

(2) 12-hour clock mode (RTCMONTHR<MO0> = "0")

	7	6	5	4	3	2	1	0
Bit symbol	-	-	но					
After reset	0	0	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined

Bit	Bit Symbol	Туре		Functon
7-6	-	R	Read as 0.	
5-0	НО	R/W	Setting digit register of Ho	our.
			(AM)	(PM)
			00_0000 : 0 o'clock	10_0000 : 0 o'clock
			00_0001 : 1 o'clock	10_0001 : 1 o'clock
			00_0010 : 2 o'clock	10_0010 : 2 o'clock
			00_0011 : 3 o'clock	10_0011 : 3 o'clock
			00_0100 : 4 o'clock	10_0100 : 4 o'clock
			00_0101 : 5 o'clock	10_0101 : 5 o'clock
			00_0110 : 6 o'clock	10_0110 : 6 o'clock
			00_0111 : 7 o'clock	10_0111 : 7 o'clock
			00_1000 : 8 o'clock	10_1000 : 8 o'clock
			00_1001 : 9 o'clock	10_1001 : 9 o'clock
			01_0000 : 10 o'clock	11_0000 : 10 o'clock
			01_0001 : 11 o'clock	11_0001 : 11 o'clock

Note: The setting other than listed above is prohibited.

16.3.3.4 RTCDAYR (Day of the week column register(PAGE0/1))

	7	6	5	4	3	2	1	0
Bit symbol	-	-	-	-	-	WE		
After reset	0	0	0	0	0	Undefined Undefined Undefine		Undefined

Bit	Bit Symbol	Туре	Function
7-3	-	R	Read as 0.
2-0	WE	R/W	Setting digit register of day of the week. 000: Sunday
			001: Monday 010: Tuesday 011: Wednesday
			100: Thursday 101: Friday 110: Saturday

Note: The setting other than listed above is prohibited.

16.3.3.5 RTCDATER (Day column register (for PAGE0/1 only))

	7	6	5	4	3	2	1	0
Bit symbol	-	-	DA					
After reset	0	0	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined

Bit	Bit Symbol	Туре		Fund	ton	
7-6	-	R	Read as 0.			
5-0	DA	R/W	Setting digit register of day.			
				01_0000 : 10th day	10_0000 : 20th day	11_0000 : 30th day
			00_0001 : 1st day	01_0001 : 11th day	10_0001 : 21th day	11_0001 : 31th day
			00_0010 : 2nd day	01_0010 : 12th day	10_0010 : 22th day	
			00_0011 : 3rd day	01_0011 : 13th day	10_0011 : 23th day	
			00_0100 : 4th day	01_0100 : 14th day	10_0100 : 24th day	
			00_0101 : 5th day	01_0101 : 15th day	10_0101 : 25th day	
			00_0110 : 6th day	01_0110 : 16th day	10_0110 : 26th day	
			00_0111 : 7th day	01_0111 : 17th day	10_0111 : 27th day	
			00_1000 : 8th day	01_1000 : 18th day	10_1000 : 28th day	
1			00_1001 : 9th day	01_1001 : 19th day	10_1001 : 29th day	

Note 1: The setting other than listed above is prohibited.

Note 2: Do not set for non-existent days (e.g.: 30th Feb.).

16.3.3.6 RTCMONTHR (Month column register (for PAGE0 only))

	7	6	5	4	3	2	1	0
Bit symbol	-	-	-			MO		
After reset	0	0	0	Undefined	Undefined	Undefined	Undefined	Undefined

Bit	Bit Symbol	Туре		Functon					
7-5	-	R	Read as 0.						
4-0	МО	R/W	Setting digi	letting digit register of Month.					
			0_0001 :	January	0_0111 :	July			
			0_0010 :	February	0_1000 :	August			
			0_0011 :	March	0_1001:	September			
			0_0100 :	April	1_0000 :	October			
			0_0101 :	May	1_0001 :	November			
			0_0110 :	June	1_0010 :	December			

Note: The setting other than listed above is prohibited.

16.3.3.7 RTCMONTHR (Selection of 24-hour clock or 12-hour clock24(for PAGE1 only))

	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	-	MO0
After reset	0	0	0	0	0	0	0	Undefined

Bit	Bit Symbol	Туре	Function
7-1	-	R	Read as 0.
0	MO0	R/W	0: 12-hour 1: 24-hour

Note: Do not change the RTCMONTHR<MO0> while the RTC is in operation.

16.3.3.8 RTCYEARR (Year column register (for PAGE0 only))

	7	6	5	4	3	2	1	0
bit symbol		YE						
After reset	Undefined							

Bit	Bit Symbol	Туре	Function						
7-0	YE	R/W	Setting digit register of Year.						
			0000_0000 : 00 years	0001_0000 : 10 years	0110_0000 : 60 years				
			0000_0001 : 01 years	•	•				
			0000_0010 : 02 years	0010_0000 : 20 years	0111_0000 : 70 years				
			0000_0011 : 03 years	•	•				
			0000_0100 : 04 years	0011_0000 : 30 years	1000_0000 : 80 years				
			0000_0101 : 05 years	•	•				
			0000_0110 : 06 years	0100_0000 : 40 years	1001_0000 : 90 years				
			0000_0111 : 07 years	•	•				
			0000_1000 : 08 years	01001_0000 : 50 years	•				
			0000_1001 : 09 years	•	1001_1001 : 99 years				

Note: The setting other than listed above is prohibited.

16.3.3.9 RTCYEARR (Leap year register (for PAGE1 only))

	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	LE	AP
After reset	0	0	0	0	0	0	Undefined	Undefined

Bit	Bit Symbol	Туре	Functon
7-2	-	R	Read as 0.
1-0	LEAP	R/W	00 : leap year
			01 : one year after leap year
			10 : two years after leap year
			11 : three years after leap year

16.3.3.10 RTCPAGER(PAGE register(PAGE0/1))

	7	6	5	4	3	2	1	0
Bit symbol	INTENA	-	-	ADJUST	ENATMR	ENAALM	-	PAGE
After reset	0	0	0	0	Undefined	Undefined	0	0

Bit	Bit Symbol	Туре	Function
7	INTENA	R/W	INTRTC
			0:Disable
			1:Enable
6-5	_	R	Read as 0.
4	ADJUST	R/W	[Write]
			0: Don't care
			1: Sets ADJUST request
			Adjusts seconds. The request is sampled when the sec. counter counts up.
			If the time elapsed is between 0 and 29 seconds, the sec. counter is cleared to "0".
			If the time elapsed is between 30 and 59 seconds, the min. counter is carried and sec. counter is cleared
			to "0".
			[Read]
			0: ADJUST no request
			1: ADJUST requested
			If "1" is read, it indicates that ADJUST is being executed. If "0" is read, it indicates that the execution
			is finished.
3	ENATMR	R/W	Clock
			0: Disable
			1: Enable
2	ENAALM	R/W	ALARM
			0: Disable
			1: Enable
1	-	R	Read as 0.
0	PAGE	R/W	PAGE selection
			0:Selects Page0
			1:Selects Page1

Note 1: A read-modify-write operation cannot be porfomed.

Note 2: To set interrupt enable bits to <ENATMR>, <ENAALM> and <INTENA>, you must follow the order specified here.

Make sure not to set them at the same time (make sure that there is time lag between interrupt enable and clock/
alarm enable).To change the setting of <ENATMR> and <ENAALM>, <INTENA> must be disabled first.

Example: Clock setting/Alarm setting

16.3.3.11 RTCRESTR (Reset register (for PAGE0/1))

	7	6	5	4	3	2	1	0
Bit symbol	DIS1HZ	DIS16HZ	RSTTMR	RSTALM	-	-	-	-
After reset	1	1	0	0	0	1	1	1

Bit	Bit Symbol	Туре	Function
7	DIS1HZ	R/W	1 Hz
			0:Enable
			1: Disable
6	DIS16HZ	R/W	16 Hz
			0: Enable
			1: Disable
5	RSTTMR	R/W	[Write]
			0: Don't care
			1: Sec.counter reset
			Resets the sec counter. The equest is sampled using low-speed clock.
			[Read]
			0: No reset request
			1: RESET requested
			If "1" is read, it indicates that RESET is being executed. If "0" is read, it indicates that the execution is
			finished.
4	RSTALM	R/W	0:Don't care
			1: Alarm reset
			Initializes alarm registers (Minute column, hour column, day column and day of the week column) as
			follows.
			MInute:00, Hour:00, Day:01, Day of the week:Sunday
3	_	R	Read as 0.
2-0	_	R/W	Write "1".

Note 1: A read-modify-write operation cannot be performed.

The setting of <DIS1HZ> and <DIS16MHZ>,RTCPAGER<ENAALM> used for alarm, 1Hz interrupt and 16Hz interrupt is shown as below.

<dis1hz></dis1hz>	<dis16hz></dis16hz>	RTCPAGER <enaalm></enaalm>	Interrupt source signal
1	1	1	Alarm
0	1	0	1 Hz
1	0	0	16 Hz
	Interrupt not generated.		

16.4 Operational Description

The RTC incorporates a second counter that generates a 1Hz signal from a 32.768 kHz signal.

The second counter operation must be taken into account when using the RTC.

16.4.1 Reading clock data

1. Using 1Hz interrupt

The 1Hz interrupt is generated being synchronized with counting up of the second counter.

Data can be read correctly if reading data after 1Hz interrupt occurred.

2. Using pair reading

There is a possibility that the clock data may be read incorrectly if the internal counter operates carry during reading. To ensure correct data reading, read the clock data twice as shown below. A pair of data read successively needs to match.




Figure 16-2 Flowchart of the clock data reading

16.4.2 Writing clock data

A carry during writing ruins correct data writing. The following procedure ensures the correct data writing.

1. Using 1 Hz interrupt

The 1Hz interrupt is generated by being synchronized with counting up of the second counter. If data is written in the time between 1Hz interrupt and subsequent one second count, it completes correctly.

2. Resetting counter

Write data after resetting the second counter.

The 1Hz-interrupt is generated one second after enabling the interrupt subsequent to counter reset.

The time must be set within one second after the interrupt.

Figure 16-3 Flowchart of the clock data writing

Timer setting

End

3. Disabling the clock

Writing "0" to RTCPAGER<ENATMR> disables clock operation including a carry.

Stop the clock after the 1Hz-interrupt. The second counter keeps counting.

Set the clock again and enable the clock within one second before next 1Hz-interrupt




Figure 16-4 Flowchart of the disabling clock

16.4.3 Entering the Low Power Consumption Mode

To enter SLEEP mode, in which the system clock stops, after changing clock data, adjusting seconds or resetting the clock, be sure to observe one of the following procedures

- 1. After changing the clock setting registers, setting the RTCPAGER<ADJUST> bit or setting the RTCRESTR<RSTTMR> bit, wait for one second for an interrupt to be generated.
- 2. After changing the clock setting registers, setting the RTCPAGER<ADJUST> bit or setting the RTCRESTR<RSTTMR> bit, read the corresponding clock register values, <ADJUST> or <RSTTMR> to make sure that the setting you have made is reflected.

16.5 Alarm function TMPM332FWUG

16.5 Alarm function

By writing "1" to RTCPAGER<PAGE>, the alarm function of the PAGE1 registers is enabled. One of the following three signals is output to the ALARM pin.

- 1. "Low" pulse (when the alarm register corresponds with the clock)
- 2. 1Hz cycle "Low" pulse
- 3. 16Hz cycle "Low" pulse

In any cases shown above, the INTRTC outputs one cycle pulse of low-speed clock. It outputs the INTRTC interrupt request simultaneously.

The INTRTC interrupt signal is falling edge triggered. Specify the falling edge as the active state in the CG Interrupt Mode Control Register

16.5.1 "Low" pulse (when the alarm register corresponds with the clock)

"Low" pulse is output to the ALARM pin when the values of the PAGE0 clock register and the PAGE1 alarm register correspond. The INTRTC interrupt is generated and the alarm is triggered.

The alarm settings

Initialize the alarm with alarm prohibited. Write "1" to RTCRESTR<RSTALM>.

It makes the alarm setting to be 00 minute, 00 hour, 01 day and Sunday.

Setting alarm for min., hour, date and day is done by writing data to the relevant PAGE1 register.

Enable the alarm with the RTCPAGER <ENAALM> bit. Enable the interrupt with the RTCPAGER <INTENA> bit.

The following is an example program for outputting an alarm from the ALARM pin at noon (12:00) on Monday 5th

		7	6	5	4	3	2	1	0	
RTCPAGER	←	0	0	0	0	1	0	0	1	Disables alarm, sets PAGE1
RTCRESTR	←	1	1	0	1	0	0	0	0	Initializes alarm
RTCDAYR	←	0	0	0	0	0	0	0	1	Monday
RTCDATER	←	0	0	0	0	0	1	0	1	5th day
RTCHOURR	←	0	0	0	1	0	0	1	0	Sets 12 o'clock
RTCMINR	←	0	0	0	0	0	0	0	0	Sets 00 min
RTCPAGER	←	0	0	0	0	1	1	0	0	Enables alarm
RTCPAGER	←	1	0	0	0	1	1	0	0	Enables interrupts

The above alarm works in synchronization with the low-speed clock. When the CPU is operating at high frequency oscillation, a maximum of one clock delay at fs (about 30µs) may occur for the time register setting to become valid.

Note: To make the alarm work repeatedly (e.g. every Wednesday at 12:00), next alarm must be set during the INTRTC interrupt routine that is generated when the time set for the alarm matches the RTC count.

16.5.2 1Hz cycle "Low" pulse1 Hz

The RTC outputs a "Low" pulse cycle of low-speed 1Hz clock to the \overline{ALARM} pin by setting RTCPAGER<INTENA>="1" after setting RTCPAGER<ENAALM>= "0", RTCRESTR<DIS1HZ>= "0" and <DIS16HZ>= "1". It generates an INTRTC interrupt simultaneously.

16.5.3 16Hz cycle "Low" pulse16 Hz

The RTC outputs a "Low" pulse cycle of low-speed 16Hz clock to the \overline{ALARM} pin by setting RTCPAGER<INTENA>="1" after setting RTCPAGER<ENAALM>= "0", RTCRESTR<DIS1HZ>= "1" and <DIS16HZ>= "0". It generates an INTRTC interrupt simultaneously.

16.	Real	Time Clock (RTC)	

16.5 Alarm function TMPM332FWUG

TOSHIBA TMPM332FWUG

17. Flash Memory Operation

This section describes the hardware configuration and operation of the flash memory.

17.1 Flash Memory

17.1.1 Features

1. Memory capacity

The TMPM332FWUG devices contain flash memory. The memory sizes and configurations of each device are shown in the table below.

Independent write access to each block is available. When the CPU is to access the internal flash memory, 32-bit data bus width is used.

2. Write/erase time

Writing is executed per page. The contain 128 words and the TMPM332FWUG contains 64 words in a page.

Page writing requires 1.25ms (typical) regardless of number of words.

A block erase requires 0.1 sec. (typical).

The following table shows write and erase time per chip.

Product Name	Memory Size		Block Cor	nfiguration	# = \$ \ \ \ = = = 1 = 1	Maita Tima	Erase	
		128 KB	64 KB	32 KB	16 KB	# of Words	Write Time	Time
TMPM332FWUG	128 KB	-	1	1	2	64	0.64 sec	0.2 sec

Note: The above values are theoretical values not including data transfer time.

The write time per chip depends on the write method to be used by the user.

3. Programming method

There are two types of the onboard programming mode for the user to program (rewrite) the device while it is mounted on the user's board:

- The onboard programming mode
- a. User boot mode

The user's original rewriting method can be supported.

b. Single boot mode

The rewriting method to use serial data transfer (Toshiba's unique method) can be supported.

4. Rewriting method

The flash memory included in this device is generally compliant with the applicable JEDEC standards except for some specific functions. Therefore, if the user is currently using an external flash memory device, it is easy to implement the functions into this device. Furthermore, the user is not required to build his/her own programs to realize complicated write and erase functions because such functions are automatically performed using the circuits already built-in the flash memory chip.

JEDEC compliant functions	Modified, added, or deleted functions
Automatic programming	
Automatic chip erase	<modified> Block protect (only software protection is supported)</modified>
Automatic block erase	<deleted> Erase resume - suspend function</deleted>
Data polling/toggle bit	

17.1 Flash Memory TMPM332FWUG

5. Protect/ Security Function

This device is also implemented with a read-protect function to inhibit reading flash memory data from any external writer device. On the other hand, rewrite protection is available only through command-based software programming; any hardware setting method to apply +12VDC is not supported. See the chapter "ROM protection" for details of ROM protection and security function.

Note: If a password is set to 0xFF (erased data), it is difficult to protect data securely due to an easy-to-guess password. Even if Single Boot mode is not used, it is recommended to set a unique value as a password.

17.1.2 Block Diagram of the Flash Memory Section




Figure 17-1 Block Diagram of the Flash Memory Section

17.2 Operation Mode

This device has three operation modes including the mode not to use the internal flash memory.

Table 17-1 Operation Modes

	Operation mode	Operation details
Single chip mode		After reset is cleared, it starts up from the internal flash memory.
	Normal mode	In this operation mode, two different modes, i.e., the mode to execute user application programs and the mode to rewrite the flash memory onboard the user's card, are defined. The former is referred to as "normal mode" and the latter "user boot mode.
	User boot mode	The user can uniquely configure the system to switch between these two modes. For example, the user can freely design the system such that the normal mode is selected when the port "A0" is set to "1" and the user boot mode is selected when it is set to "0." The user should prepare a routine as part of the application program to make the decision on the selection of the modes.
Sir	ngle boot mode	After reset is cleared, it starts up from the internal Boot ROM (Mask ROM). In the Boot ROM, an algorithm to enable flash memory rewriting on the user's set through the serial port of this device is programmed. By connecting to an external host computer through the serial port, the internal flash memory can be programmed by transferring data in accordance with predefined protocols.

Among the flash memory operation modes listed in the above table, the User Boot mode and the Single Boot mode are the programmable modes. These two modes, the User Boot mode and the Single Boot mode, are referred to as "Onboard Programming" modes where onboard rewriting of internal flash memory can be made on the user's card.

Either the Single Chip or Single Boot operation mode can be selected by externally setting the level of the \overline{BOOT} (PH0) pin while the device is in reset status.

Table 17-2 Operation Mode Setting

On another manda	Pin				
Operation mode	RESET	BOOT (PH0)			
Single chip mode	0 → 1	1			
Single boot mode	0 → 1	0			




Figure 17-2 Mode Transition Diagram

17.2.1 Reset Operation

To reset the device, ensure that the power supply voltage is within the operating voltage range, that the internal oscillator has been stabilized, and that the \overline{RESET} input is held at "0" for a minimum duration of 12 system clocks (0.3 µs with 40MHz operation; the "1/1" clock gear mode is applied after reset).

- Note 1: Regarding power-on reset of devices with internal flash memory; for devices with internal flash memory, it is necessary to apply "0" to the RESET inputs upon power on for a minimum duration of 700 microseconds regardless of the operating frequency.
- Note 2: While flash auto programming or deletion is in progress, at least 0.5 microseconds of reset period is required regardless of the system clock frequency. In this condition, it takes approx. 2 ms to enable reading after reset.

17.2 Operation Mode TMPM332FWUG

17.2.2 User Boot Mode (Single chip mode)

User Boot mode is to use flash memory programming routine defined by users. It is used when the data transfer buses for flash memory program code on the old application and for serial I/O are different. It operates at the single chip mode; therefore, a switch from normal mode in which user application is activated at the single chip mode to User Boot Mode for programming flash is required. Specifically, add a mode judgment routine to a reset program in the old application.

The condition to switch the modes needs to be set by using the I/O of TMPM332FWUG in conformity with the user's system setup condition. Also, flash memory programming routine that the user uniquely makes up needs to be set in the new application. This routine is used for programming after being switched to User Boot Mode. The execution of the programming routine must take place while it is stored in the area other than the flash memory since the data in the internal flash memory cannot be read out during delete/ writing mode. Once reprogramming is complete, it is recommended to protect relevant flash blocks from accidental corruption during subsequent Single-Chip (Normal mode) operations. Be sure not to cause any exceptions including a non-maskable while User Boot Mode.

(1-A) and (1-B) are the examples of programming with routines in the internal flash memory and in the external memory. For a detailed description of the erase and program sequence, refer to "17.3 On-board Programming of Flash Memory (Rewrite/Erase)".

17.2.2.1 (1-A) Method 1: Storing a Programming Routine in the Flash Memory

(1) Step-1

Determine the conditions (e.g., pin states) required for the flash memory to enter User Boot mode and the I/O bus to be used to transfer new program code. Create hardware and software accordingly. Before installing the TMPM332FWUG on a printed circuit board, write the following program routines into an arbitrary flash block using programming equipment.


(a) Mode judgment routine: Code to determine whether or not to switch to User Boot mode
(b) Programming routine: Code to download new program code from a host controller and

re-program the flash memory

(c) Copy routine: Code to copy the data described in (b) from the


TMPM332FWUG flash memory to either the TMPM332FWUG

on-chip RAM or external memory device.




(2) Step-2

After $\overline{\text{RESET}}$ is released, the reset procedure determines whether to put the TMPM332FWUG flash memory in User Boot mode. If mode switching conditions are met, the flash memory enters User Boot mode. (All interrupts including NMI must be disabled while in User Boot mode.)




(3) Step-3

Once transition to User Boot mode is occurred, execute the copy routine (c) to copy the flash programming routine (b) to the TMPM332FWUG on-chip RAM.




(4) Step-4

Jump program execution to the flash programming routine in the on-chip RAM to erase a flash block containing the old application program code.




(5) Step-5

Continue executing the flash programming routine to download new program code from the host controller and program it into the erased flash block. When the programming is completed, the writing or erase protection of that flash block in the user's program area must be set.



(6) Step-6

Set \overline{RESET} to "0" to reset the TMPM332FWUG. Upon reset, the on-chip flash memory is put in Normal mode. After \overline{RESET} is released, the CPU will start executing the new application program code.



17.2.2.2 (1-B) Method 2: Transferring a Programming Routine from an External Host


(1) Step-1

Determine the conditions (e.g., pin states) required for the flash memory to enter User Boot mode and the I/O bus to be used to transfer new program code. Create hardware and software accordingly. Before installing the TMPM332FWUG on a printed circuit board, write the following program routines into an arbitrary flash block using programming equipment.

(a) Mode judgment routine: Code to determine whether or not to switch to User Boot mode
(b) Transfer routine: Code to download new program code from a host controller


Also, prepare a programming routine shown below on the host controller:

(c) Programming routine: Code to download new program code from an external host controller and re-program the flash memory




(2) Step-2

After $\overline{\text{RESET}}$ is released, the reset procedure determines whether to put the TMPM332FWUG flash memory in User Boot mode. If mode switching conditions are met, the flash memory enters User Boot mode. (All interrupts including NMI must be disabled while in User Boot mode).




(3) Step-3

Once User Boot mode is entered, execute the transfer routine (b) to download the flash programming routine (c) from the host controller to the TMPM332FWUG on-chip RAM.




(4) Step-4

Jump program execution to the flash programming routine in the on-chip RAM to erase a flash block containing the old application program code.




(5) Step-5

Continue executing the flash programming routine to download new program code from the host controller and program it into the erased flash block. When the programming is completed, the writing or erase protection of that flash block in the user program area must be set.



(6) Step-6

Set \overline{RESET} to "0" low to reset the TMPM332FWUG. Upon reset, the on-chip flash memory is put in Normal mode. After \overline{RESET} is released, the CPU will start executing the new application program code.



17.2.3 Single Boot Mode

In Single Boot mode, the flash memory can be re-programmed by using a program contained in the TMPM332FWUG on-chip boot ROM. This boot ROM is a masked ROM. When Single Boot mode is selected upon reset, the boot ROM is mapped to the address region including the interrupt vector table while the flash memory is mapped to an address region different from it.


Single Boot mode allows for serial programming of the flash memory. Channel 0 of the SIO (SIO0) of the TMPM332FWUG is connected to an external host controller. Via this serial link, a programming routine is downloaded from the host controller to the TMPM332FWUG on-chip RAM. Then, the flash memory is reprogrammed by executing the programming routine. The host sends out both commands and programming data to re-program the flash memory. Communications between the SIO0 and the host must follow the protocol described later. To secure the contents of the flash memory, the validity of the application's password is verified before a programming routine is downloaded into the on-chip RAM. If password matching fails, the transfer of a programming routine itself is aborted. As in the case of User Boot mode, all interrupts including the non-maskable interrupt (NMI) must be disabled in Single Boot mode while the flash memory is being erased or programmed. In Single Boot mode, the boot-ROM programs are executed in Normal mode.

Once re-programming is complete, it is recommended to protect relevant flash blocks from accidental corruption during subsequent Single-Chip (Normal mode) operations.

17.2.3.1 (2-A) Using the Program in the On-Chip Boot ROM


(1) Step-1

The flash block containing the older version of the program code need not be erased before executing the programming routine. Since a programming routine and programming data are transferred via the SIO (SIO0), the SIO0 must be connected to a host controller. Prepare a programming routine (a) on the host controller.




(2) Step-2

Set the \overline{RESET} pin to "1" to cancel the reset of the TMPM332FWUG when the \overline{BOOT} pin has already been set to "0". After reset, CPU reboots from the on-chip boot ROM. The 12-byte password transferred from the host controller via SIO0 is first compared to the contents of the special flash memory locations. (If the flash block has already been erased, the password is 0xFF).




(3) Step-3

If the password was correct, the boot program downloads, via the SIO0, the programming routine (a) from the host controller into the on-chip RAM of the TMPM332FWUG. The programming routine must be stored in the range from 0x2000_0400 to the end address of RAM.



(4) Step-4


The CPU jumps to the programming routine (a) in the on-chip RAM to erase the flash block containing the old application program code. The Block Erase or Chip Erase command may be used.



(5) Step-5


Next, the programming routine (a) downloads new application program code from the host controller and programs it into the erased flash block. When the programming is completed, the writing or erase protection of that flash block in the user's program area must be set.

In the example below, new program code comes from the same host controller via the same SIO0 channel as for the programming routine. However, once the programming routine has begun to execute, it is free to change the transfer path and the source of the transfer. Create board hardware and a programming routine to suit your particular needs.



(6) Step-6

When programming of the flash memory is complete, power off the board and disconnect the cable leading from the host to the target board. Turn on the power again so that the TMPM332FWUG reboots in Single-Chip (Normal) mode to execute the new program.



17.2.4 Configuration for Single Boot Mode

To execute the on-board programming, boot the TMPM332FWUG with Single Boot mode following the configuration shown below.

$$\overline{\text{BOOT}}(\text{PH0}) = 0$$

 $\overline{\text{RESET}} = 0 \rightarrow 1$

Set the \overline{RESET} input to "0", and set the each \overline{BOOT} (PH0) pins to values shown above, and then release RESET (high).

17.2.5 Memory Map

Figure 17-3 shows a comparison of the memory maps in Normal and Single Boot modes. In Single Boot mode, the internal flash memory is mapped to 0x3F80_0000 and later addresses, and the Internal boot ROM (Mask ROM) is mapped to 0x0000_0000 through 0x0000_1FFF.

The internal flash memory and RAM addresses of each device are shown below.

Product Name	Flash Size	RAM Size	Flash Address (Single Chip/ Single Boot Mode)	RAM Address
TMPM332FWUG	128 KB	8 KB	0x0000_0000 to 0x0001_FFFF 0x3F80_0000 to 0x3F81_FFFF	0x2000_0000 to 0x2000_1FFF




Figure 17-3 Memory Maps for TMPM332FWUG

17.2.6 Interface specification

In Single Boot mode, an SIO channel is used for communications with a programming controller. The same configuration is applied to a communication format on a programming controller to execute the on-board programming. Both UART (asynchronous) and I/O Interface (synchronous) modes are supported. The communication formats are shown below.

· UART communication

Communication channel: SIO channel 0

Serial transfer mode: UART (asynchronous), half-duplex, LSB fast

Data length: 8 bit Parity bits: None STOP bits: 1 bit

Baud rate: Arbitrary baud rate

· I/O interface mode

Communication channel: SIO channel 0

Serial transfer mode: I/O interface mode, full -duplex, LSB fast

Synchronization clock (SCLK0): Input mode

Handshaking signal: PE4 configured as an output mode

Baud rate: Arbitrary baud rate

Table 17-3 Required Pin Connections

Pins		Interface	
Pin	S	UART	I/O Interface Mode
	RVDD3	0	0
	AVDD	0	0
Danier annah saire	DVDD3	0	0
Power supply pins	RVSS	0	0
	AVSS	0	0
	DVSS3	0	0
Mode-setting pin	BOOT (PH0)	0	0
Reset pin	RESET	0	0
	TXD0 (PE0)	0	0
Communication	RXD0 (PE1)	0	0
pins	SCLK0 (PE2)	×	o (Input mode)
	PE4	×	o(Output mode)

17.2.7 Data Transfer Format

Table 17-4 and Table 17-6 to Table 17-9 illustrate the operation commands and data transfer formats at each operation mode. In conjunction with this section, refer to "17.2.10 Operation of Boot Program".

Table 17-4 Single Boot Mode Commands

On do	Command
Code	Command
0x10	RAM transfer
0x20	Show Flash Memory SUM
0x30	Show Product Information
0x40	Chip and protection bit erase

17.2.8 Restrictions on internal memories

Single Boot Mode places restrictions on the internal RAM and ROM as shown in Table 17-5.

Table 17-5 Restrictions in Single Boot Mode

Memory	Details
Internal RAM	A program contained in the BOOT ROM uses the area, through 0x2000_0000 to 0x2000_03FF as a work area. Store the RAM transfer program from 0x2000_0400 through the end address of RAM.
Internal ROM	The following addresses are assigned for storing software ID information and passwords. Storing program in these addresses is not recommendable. 0x3F81_FF00 to 0x3F81_FF0F

17.2.9 Transfer Format for Single Boot Mode commands

The following tables shows the transfer format for each Single Boot Mode command. Use this section in conjunction with Chapter "17.2.10 Operation of Boot Program".

17.2.9.1 RAM Transfer

Table 17-6 Transfer Format for the RAM Transfer Command

	Byte	Data Transferred from the Controller to the TMPM332FWUG	Baud rate	Data Transferred from the TMPM332FWUG to the Controller
Boot ROM	1 byte	Serial operation mode and baud rate For UART mode : 0x86 For I/O Interface mode : 0x30	Desired baud rate (Note 1)	-
	2 byte	-		ACK for the serial operation mode byte For UART mode -Normal acknowledge: 0x86 (The boot program aborts if the baud rate can not be set correctly.) For I/O Interface mode -Normal acknowledge: 0x30
	3 byte	Command code (0x10)		-
	4 byte	-		ACK for the command code byte (Note 2) -Normal acknowledge : 0x10 -Negative acknowledge : 0xX1 -Communication error : 0xX8
	5 byte to 16 byte	Password sequence (12 bytes) 0x3F81_FF04 to 0x3F81_FF0F		-
	17 byte	Check SUM value for bytes 5 - 16		-
	18 byte	-		ACK for the checksum byte (Note 2) -Normal acknowledge : 0x10 -Negative acknowledge : 0xX1 -Communication error : 0xX8
	19 byte	RAM storage start address 31 to 24		-
	20 byte	RAM storage start address 23 to 16		-
	21 byte	RAM storage start address 15 to 8		-
	22 byte	RAM storage start address 7 to 0		-
	23 byte	RAM storage byte count 15 to 8		-
	24 byte	RAM storage byte count 7 to 0		-
	25 byte	Check SUM value for bytes 19 to 24		-
	26 byte	-		ACK for the checksum byte (Note 2) -Normal acknowledge : 0x10 -Negative acknowledge : 0xX1 -Communication error : 0xX8
	27 byte to m byte	RAM storage data		-
	m + 1 byte	Checksum value for bytes 27 ~ m		-
	m + 2 byte	-		ACK for the checksum byte (Note 2) -Normal acknowledge : 0x10 -Negative acknowledge : 0xX1 -Communication error : 0xX8
RAM	m + 3 byte	-		Jump to RAM storage start address

Note 1: In I/O Interface mode, the baud rate for the transfers of the first and second bytes must be 1/16 of the desired baud rate.

Note 2: In case of any negative acknowledge, the boot program returns to a state in which it waits for a command code (3rd byte). In I/O Interface mode, if a communication error occurs, a negative acknowledge does not occur.

Note 3: The 19th to 25th bytes must be within the RAM address range from 0x2000_0400 through the end address of RAM.

17.2.9.2 Show Flash Memory SUM

Table 17-7 Transfer Format for the Show Flash Memory SUM Command

	Byte	Data Transferred from the Controller to the TMPM332FWUG	Baud rate	Data Transferred from the TMPM332FWUG to the Controller
Boot ROM	1 byte	Serial operation mode and baud rate For UART mode : 0x86 For I/O Interface mode: 0x30	Desired baud rate (Note 1)	-
	2 byte	-		ACK for the serial operation mode byte For UART mode -Normal acknowledge: 0x86 (The boot program aborts if the baud rate can not be set correctly.) For I/O Interface mode -Normal acknowledge: 0x30
	3 byte	Command code (0x20)]	-
	4 byte	-		ACK for the command code byte (Note 2) -Normal acknowledge : 0x20 -Negative acknowledge : 0xX1 -Communication error : 0xX8
	5 byte	-		SUM (upper byte)
	6 byte	-]	SUM (lower byte)
	7 byte	-]	Checksum value for bytes 5 and 6
	8 byte	(Wait for the next command code.)		-

Note 1: In I/O Interface mode, the baud rate for the transfers of the first and second bytes must be 1/16 of the desired baud rate.

Note 2: In case of any negative acknowledge, the boot program returns to a state in which it waits for a command code (3rd byte). In I/O Interface mode, if a communication error occurs, a negative acknowledge does not occur.

17.2.9.3 Transfer Format for the Show Product Information

Table 17-8 Transfer Format for the Show Product Information Command

	Byte	Data Transferred from the Controller to the TMPM332FWUG	Baud rate	Data Transferred from the TMPM332FWUG to the Controller
Boot ROM	1 byte	Serial operation mode and baud rate For UART mode : 0x86 For I/O Interface mode: 0x30	Desired baud rate (Note 1)	-
	2 byte	-		ACK for the serial operation mode byte For UART mode Normal acknowledge: 0x86 (The boot program aborts if the baud rate can not be set correctly.) For I/O Interface mode Normal acknowledge: 0x30
	3 byte	Command code (0x30)		-
	4 byte	-		ACK for the command code byte (Note 2) -Normal acknowledge : 0x30 -Negative acknowledge : 0xX1 -Communication error : 0xX8
	5 byte	-		Flash memory data at address 0x3F81_FF00
	6 byte	-		Flash memory data at address 0x3F81_FF01
	7 byte	-		Flash memory data at address 0x3F81_FF02
	8 byte	-		Flash memory data at address 0x3F81_FF03
	9 byte to 20 byte	-		Product name (12-byte ASCII code) From the 9th byte: TMPM330FW'
	21 byte to 24 byte	-		Password comparison start address (4 bytes) From the 21st byte: 0x04, 0xFF, 0x81, 0x3F
	25 byte to 28 byte	-		RAM start address (4 bytes) From the 25th byte: 0x00, 0x00, 0x00, 0x20
	29 byte to 32 byte	-		Dummy data (4 bytes) From the 29th byte: 0x00, 0x00, 0x00, 0x00
	33 byte to 36 byte	-		RAM end address (4 bytes) From the 33rd byte: 0xFF, 0x1F, 0x00, 0x20
	37 byte to 40 byte	-		Dummy data (4 bytes) From the 37th byte: 0x00, 0x00, 0x00, 0x00
	41 byte to 44 byte	-		Dummy data (4 bytes) From the 41st byte: 0x00, 0x00, 0x00, 0x00

Table 17-8 Transfer Format for the Show Product Information Command

Byte	Data Transferred from the Controller to the TMPM332FWUG	Baud rate	Data Transferred from the TMPM332FWUG to the Controller
45 byte to 46 byte	-		Dummy data or Fuse information (2 bytes) From the 45th byte: 0x00, 0x00
47 byte to 50 byte	-		Flash memory start address (4 bytes) From the 47th byte: 0x00, 0x00, 0x80, 0x3F
51 byte to 54 byte	-		Flash memory end address (4 bytes) From the 51st byte: 0xFF, 0xFF, 0x81, 0x3F
55 byte to 56 byte	-		Flash memory block count (2 bytes) From the 55th byte: 0x04, 0x00
57 byte to 60 byte	-		Start address of a group of the same-size (16K) flash blocks (4 bytes) From 57th byte: 0x00, 0x00, 0x80, 0x3F
61 byte to 64 byte	-		Size (in halfwords) of the same-size (16K) flash blocks (4 bytes) From 61st byte: 0x00, 0x20, 0x00, 0x00
65 byte	-		Number of flash blocks of the same size (16K) (1 byte) 0x02
66 byte to 69 byte	-		Start address of a group of the same-size (32K) flash blocks (4 bytes) From 66th byte: 0x00, 0x80, 0x80, 0x3F
70 byte to 73 byte	-		Size (in halfwords) of the same-size (32K) flash blocks (4 bytes) From 70th byte: 0x00, 0x40, 0x00, 0x00
74 byte	-		Number of flash blocks of the same size (32K) (1 byte) 0x01
75 byte to 78 byte	-		Start address of a group of the same-size (64K) flash blocks (4 bytes) From 75th byte: 0x00, 0x00, 0x81, 0x3F
79 byte to 82 byte	-		Size (in halfwords) of the same-size (64K) flash blocks (4 bytes) From 79th byte: 0x00, 0x80, 0x00, 0x00

Table 17-8 Transfer Format for the Show Product Information Command

Byte	Data Transferred from the Controller to the TMPM332FWUG	Baud rate	Data Transferred from the TMPM332FWUG to the Controller
83 byte	-		Number of flash blocks of the same size (64K) (1 byte) 0x01
84 byte to 87 byte	-		Start address of a group of the same-size (128K) flash blocks (4 bytes) From 84th byte: 0x00, 0x00, 0x00, 0x00
88 byte to 91 byte	-		Size (in halfwords) of the same-size (128K) flash blocks (4 bytes) From 88th byte: 0x00, 0x00, 0x01, 0x00
92 byte	-		Number of flash blocks of the same size (128K) (1 byte) 0x00
93 byte	-		Checksum value for bytes 5 ~ 92
94 byte	(Wait for the next command code.)		-

Note 1: In I/O Interface mode, the baud rate for the transfers of the first and second bytes must be 1/16 of the desired baud rate.

Note 2: In case of any negative acknowledge, the boot program returns to a state in which it waits for a command code (3rd byte). In I/O Interface mode, if a communication error occurs, a negative acknowledge does not occur.

17.2.9.4 Chip Erase and Protect Bit Erase

Table 17-9 Transfer Format for the Chip and Protection Bit Erase Command

	Byte	Data Transferred from the Controller to the TMPM332FWUG	Baud rate	Data Transferred from the TMPM332FWUG to the Controller
Boot ROM	1 byte	Serial operation mode and baud rate For UART mode : 0x86 For I/O Interface mode : 0x30	Desired baud rate (Note 1)	-
	2 byte	-		ACK for the serial operation mode byte For UART mode -Normal acknowledge: 0x86 For I/O Interface mode -Normal acknowledge: 0x30 (The boot program aborts if the baud rate can not be set correctly.)
	3 byte	Command code (0x40)	7	-
	4 byte	-		ACK for the command code byte (Note 2) -Normal acknowledge : 0x40 -Negative acknowledge : 0xX1 -Communication error : 0xX8
	5 byte	Chip erase command code (0x54)		-
	6 byte	-		ACK for the command code byte (Note 2) -Normal acknowledge : 0x54 -Negative acknowledge : 0xX1 -Communication error : 0xX8
	7 byte	-		ACK for the chip erase command code byte -Normal acknowledge : 0x4F -Negative acknowledge : 0x4C
	8 byte	(Wait for the next command code.)		-

17. Flash Memory Operation

17.2 Operation Mode TMPM332FWUG

Note 1: In I/O Interface mode, the baud rate for the transfers of the first and second bytes must be 1/16 of the desired baud rate.

Note 2: In case of any negative acknowledge, the boot program returns to a state in which it waits for a command code (3rd byte). In I/O Interface mode, if a communication error occurs, a negative acknowledge does not occur.

17.2.10 Operation of Boot Program

When Single Boot mode is selected, the boot program is automatically executed on startup. The boot program offers these four commands, of which the details are provided on the following subsections.

1. RAM Transfer command

The RAM Transfer command stores program code transferred from a host controller to the on-chip RAM and executes the program once the transfer is successfully completed. The user program RAM space can be assigned to the range from $0x2000_0400$ to the end address of RAM, whereas the boot program area $(0x2000_0000 \sim 0x2000_03FF)$ is unavailable. The user program starts at the assigned RAM address.

The RAM Transfer command can be used to download a flash programming routine of your own; this provides the ability to control on-board programming of the flash memory in a unique manner. The programming routine must utilize the flash memory command sequences described in Section 17.3. Before initiating a transfer, the RAM Transfer command verifies a password sequence coming from the controller against that stored in the flash memory.

Note: If a password is set to 0xFF (erased data), it is difficult to protect data securely due to an easy-to-guess password. Even if Single Boot mode is not used, it is recommended to set a unique value as a password.

2. Show Flash Memory SUM command

The Show Flash Memory SUM command adds the entire contents of the flash memory together. The boot program does not provide a command to read out the contents of the flash memory. Instead, the Flash Memory SUM command can be used for software revision management.

3. Show Product Information command

The Show Product Information command provides the product name, on-chip memory configuration and the like. This command also reads out the contents of the flash memory locations at addresses shown below. In addition to the Show Flash Memory Sum command, these locations can be used for software revision management.

Product name	Area
TMPM332FWUG	0x3F81_FF00 to 0x3F81_FF03

4. Chip and Protection Bit Erase command

This command erases the entire area of the flash memory automatically without verifying a password. All the blocks in the memory cell and their protection conditions are erased even when any of the blocks are prohibited from writing and erasing. When the command is completed, the FCSECBIT <SECBIT> bit is set to "1". This command serves to recover boot programming operation when a user forgets the password. Therefore password verification is not executed.

17.2.10.1 RAM Transfer Command

See Table 17-6 for the transfer format of this command.

The 1st byte specifies which one of the two serial operation modes is used. For a detailed description of how the serial operation mode is determined, see "17.2.10.6 Determination of a Serial Operation Mode" described later. If it is determined as UART mode, the boot program then checks if the SIO0 is programmable to the baud rate at which the 1st byte was transferred. During the first-byte interval, the RXE bit in the SC0MOD register is cleared.

· To communicate in UART mode

Send, from the controller to the target board, 0x86 in UART data format at the desired baud rate. If the serial operation mode is determined as UART, then the boot program checks if the SIO0 can be programmed to the baud rate at which the first byte was transferred. If that baud rate is not possible, the boot program aborts, disabling any subsequent communications

To communicate in I/O Interface mode

Send, from the controller to the target board, 0x30 in I/O Interface data format at 1/16 of the desired baud rate. Also send the 2nd byte at the same baud rate. Then send all subsequent bytes at a rate equal to the desired baud rate.

In I/O Interface mode, the CPU sees the serial receive pin as if it were a general input port in monitoring its logic transitions. If the baud rate of the incoming data is high or the chip's operating frequency is high, the CPU may not be able to keep up with the speed of logic transitions. To prevent such situations, the 1st and 2nd bytes must be transferred at 1/16 of the desired baud rate; then the boot program calculates 16 times that as the desired baud rate. When the serial operation mode is determined as I/O Interface mode, the SIO0 is configured for SCLK Input mode. Beginning with the third byte, the controller must ensure that its AC timing restrictions are satisfied at the selected baud rate. In the case of I/O Interface mode, the boot program does not check the receive error flag; thus there is no such thing as error acknowledge (bit 3, 0x08).

- 2. The 2nd byte, transmitted from the target board to the controller, is an acknowledge response to the 1st byte. The boot program echoes back the first byte: 0x86 for UART mode and 0x30 for I/O Interface mode.
 - · UART mode

If the SIO0 can be programmed to the baud rate at which the 1st byte was transferred, the boot program programs the SC0BRCR and sends back 0x86 to the controller as an acknowledge. If the SIO0 is not programmable at that baud rate, the boot program simply aborts with no error indication. Following the 1st byte, the controller should allow for a time-out period of five seconds. If it does not receive 0x86 within the allowed time-out period, the controller should give up the communication. The boot program sets the RXE bit in the SC0MOD0 register to enable reception ("1") before loading the SIO transmit buffer with 0x86.

· I/O Interface mode

The boot program programs the SC0MOD0 and SC0CR registers to configure the SIO0 in I/O Interface mode (clocked by the rising edge of SCLK0), writes 0x30 to the SC0BUF. Then, the SIO0 waits for the SCLK0 signal to come from the controller. Following the transmission of the 1st byte, the controller should send the SCLK clock to the target board after a certain idle time (several microseconds). This must be done at 1/16 the desire baud rate. If the 2nd byte, which is from the target board to the controller, is 0x30, then the controller should take it as a go-ahead. The controller must then deliver the 3rd byte to the target board at a rate equal to the desired baud rate. The boot program sets the RXE bit in the SC0MOD register to enable reception before loading the SIO transmit buffer with 0x30.

- 3. The 3rd byte transmitted from the controller to the target board is a command. The code for the RAM Transfer command is 0x10.
- 4. The 4th byte, transmitted from the target board to the controller, is an acknowledge response to the 3rd byte. Before sending back the acknowledge response, the boot program checks for a receive error. If there was a receive error, the boot program transmits 0xX8 (bit 3) and returns to the state

in which it waits for a command (the third byte) again. In this case, the upper four bits of the acknowledge response are undefined - they hold the same values as the upper four bits of the previously issued command. When the SIO0 is configured for I/O Interface mode, the boot program does not check for a receive error.

If the 3rd byte is equal to any of the command codes listed in Table 17-4, the boot program echoes it back to the controller. When the RAM Transfer command was received, the boot program echoes back a value of 0x10 and then branches to the RAM Transfer routine. Once this branch is taken, password verification is done. Password verification is detailed in a later section "Password". If the 3rd byte is not a valid command, the boot program sends back 0xX1 (bit 0) to the controller and returns to the state in which it waits for a command (the third byte) again. In this case, the upper four bits of the acknowledge response are undefined - they hold the same values as the upper four bits of the previously issued command.

5. The 5th to 16th bytes transmitted from the controller to the target board, are a 12-byte password. Each byte is compared to the contents of following addresses in the flash memory. The verification is started with the 5th byte and the smallest address in the designated area. If the password verification fails, the RAM Transfer routine sets the password error flag.

Product name	Area
TMPM332FWUG	0x3F81_FF04 to 0x3F81_FF0F

- 6. The 17th byte is a checksum value for the password sequence (5th to 16th bytes). To calculate the checksum value for the 12-byte password, add the 12 bytes together, drop the carries and take the two's complement of the total sum. Transmit this checksum value from the controller to the target board. The checksum calculation is described in details in a later section "Checksum Calculation".
- 7. The 18th byte, transmitted from the target board to the controller, is an acknowledge response to the 5th to 17th bytes. First, the RAM Transfer routine checks for a receive error in the 5th to 17th bytes. If there was a receive error, the boot program sends back 0x18 (bit 3) and returns to the state in which it waits for a command (i.e., the 3rd byte) again. In this case, the upper four bits of the acknowledge response are the same as those of the previously issued command (i.e., 1). When the SIO0 is configured for I/O Interface mode, the RAM Transfer routine does not check for a receive error.

Next, the RAM Transfer routine performs the checksum operation to ensure data integrity. Adding the series of the 5th to 16th bytes must result in 0x00 (with the carry dropped). If it is not 0x00, one or more bytes of data has been corrupted. In case of a checksum error, the RAM Transfer routine sends back 0x11 to the controller and returns to the state in which it waits for a command (i.e., the 3rd byte) again.

Finally, the RAM Transfer routine examines the result of the password verification. The following two cases are treated as a password error. In these cases, the RAM Transfer routine sends back 0x11 (bit 0) to the controller and returns to the state in which it waits for a command (i.e., the 3rd byte) again.

- Irrespective of the result of the password comparison, all the 12 bytes of a password in the flash memory are the same value other than 0xFF.
- Not the entire password bytes transmitted from the controller matched those contained in the flash memory.

When all the above verification has been successful, the RAM Transfer routine returns a normal acknowledge response (0x10) to the controller.

- 8. The 19th to 22nd bytes, transmitted from the controller the target board, indicate the start address of the RAM region where subsequent data (e.g., a flash programming routine) should be stored. The 19th byte corresponds to bits 31.24 of the address and the 22nd byte corresponds to bits 7.0 of the address.
- 9. The 23rd and 24th bytes, transmitted from the controller to the target board, indicate the number of bytes that will be transferred from the controller to be stored in the RAM. The 23rd byte corresponds to bits 15.8 of the number of bytes to be transferred, and the 24th byte corresponds to bits 7.0 of the number of bytes.

10. The 25th byte is a checksum value for the 19th to 24th bytes. To calculate the checksum value, add all these bytes together, drop the carries and take the two's complement of the total sum. Transmit this checksum value from the controller to the target board. The checksum calculation is described in details in a later section "Checksum Calculation".

11. The 26th byte, transmitted from the target board to the controller, is an acknowledge response to the 19th to 25th bytes of data. First, the RAM Transfer routine checks for a receive error in the 19th to 25th bytes. If there was a receive error, the RAM Transfer routine sends back 0x18 and returns to the command wait state (i.e., the 3rd byte) again. In this case, the upper four bits of the acknowledge response are the same as those of the previously issued command (i.e., 1). When the SIO0 is configured for I/O Interface mode, the RAM Transfer routine does not check for a receive error.

Next, the RAM Transfer routine performs the checksum operation to ensure data integrity. Adding the series of the 19th to 25th bytes must result in 0x00 (with the carry dropped). If it is not 0x00, one or more bytes of data has been corrupted. In case of a checksum error, the RAM Transfer routine sends back 0x11 to the controller and returns to the state in which it waits for a command (i.e., the 3rd byte) again.

 The RAM storage start address must be within the range of 0x2000_0400 to the end address of RAM.

When the above checks have been successful, the RAM Transfer routine returns a normal acknowledge response (0x10) to the controller.

- 12. The 27th to mth bytes from the controller are stored in the on-chip RAM of the TMPM332FWUG. Storage begins at the address specified by the 19th.22nd bytes and continues for the number of bytes specified by the 23rd.24th bytes.
- 13. The (m+1) th byte is a checksum value. To calculate the checksum value, add the 27th to mth bytes together, drop the carries and take the two's complement of the total sum. Transmit this checksum value from the controller to the target board. The checksum calculation is described in details in a later section "Checksum Calculation".
- 14. The (m+2) th byte is a acknowledge response to the 27th to (m+1) th bytes. First, the RAM Transfer routine checks for a receive error in the 27th to (m+1) th bytes. If there was a receive error, the RAM Transfer routine sends back 0x18 (bit 3) and returns to the state in which it waits for a command (i.e., the 3rd byte) again. In this case, the upper four bits of the acknowledge response are the same as those of the previously issued command (i.e., 1). When the SIO0 is configured for I/O Interface mode, the RAM Transfer routine does not check for a receive error.

Next, the RAM Transfer routine performs the checksum operation to ensure data integrity. Adding the series of the 27th to (m+1) th bytes must result in 0x00 (with the carry dropped). If it is not 0x00, one or more bytes of data has been corrupted. In case of a checksum error, the RAM Transfer routine sends back 0x11 (bit 0) to the controller and returns to the command wait state (i.e., the 3rd byte) again. When the above checks have been successful, the RAM Transfer routine returns a normal acknowledge response (0x10) to the controller.

15. If the (m+2) th byte was a normal acknowledge response, a branch is made to the address specified by the 19th to 22nd bytes.

17.2.10.2 Show Flash Memory SUM Command

See Table 17-7 for the transfer format of this command.

- 1. The processing of the 1st and 2nd bytes are the same as for the RAM Transfer command.
- 2. The 3rd byte, which the target board receives from the controller, is a command. The code for the Show Flash Memory Sum command is 0x20.
- 3. The 4th byte, transmitted from the target board to the controller, is an acknowledge response to the 3rd byte. Before sending back the acknowledge response, the boot program checks for a receive

error. If there was a receive error, the boot program transmits 0xX8 (bit 3) and returns to the command wait state again. In this case, the upper four bits of the acknowledge response are undefined - they hold the same values as the upper four bits of the previously issued command. When the SIO0 is configured for I/O Interface mode, the boot program does not check for a receive error.

If the 3rd byte is equal to any of the command codes listed in Table 17-4, the boot program echoes it back to the controller. When the Show Flash Memory Sum command was received, the boot program echoes back a value of 0x20 and then branches to the Show Flash Memory Sum routine. If the 3rd byte is not a valid command, the boot program sends back 0xX1 (bit 0) to the controller and returns to the command wait state (the third byte) again. In this case, the upper four bits of the acknowledge response are undefined - they hold the same values as the upper four bits of the previously issued command.

- 4. The Show Flash Memory Sum routine adds all the bytes of the flash memory together. The 5th and 6th bytes, transmitted from the target board to the controller, indicate the upper and lower bytes of this total sum, respectively. For details on sum calculation, see a later section "17.2.10.8 Calculation of the Show Flash Memory Sum Command".
- 5. The 7th byte is a checksum value for the 5th and 6th bytes. To calculate the checksum value, add the 5th and 6th bytes together, drop the carry and take the two's complement of the sum. Transmit this checksum value from the controller to the target board.
- 6. The 8th byte is the next command code.

17.2.10.3 Show Product Information Command

See Table 17-8 for the transfer format of this command.

- 1. The processing of the 1st and 2nd bytes are the same as for the RAM Transfer command.
- 2. The 3rd byte, which the target board receives from the controller, is a command. The code for the Show Product Information command is 0x30.
- 3. The 4th byte, transmitted from the target board to the controller, is an acknowledge response to the 3rd byte. Before sending back the acknowledge response, the boot program checks for a receive error. If there was a receive error, the boot program transmits 0xX8 (bit 3) and returns to the command wait state again. In this case, the upper four bits of the acknowledge response are undefined they hold the same values as the upper four bits of the previously issued command. When the SIO0 is configured for I/O Interface mode, the boot program does not check for a receive error.

If the 3rd byte is equal to any of the command codes listed in Table 17-4, the boot program echoes it back to the controller. When the Show Flash Memory Sum command was received, the boot program echoes back a value of 0x30 and then branches to the Show Flash Memory Sum routine. If the 3rd byte is not a valid command, the boot program sends back 0xX1 (bit 0) to the controller and returns to the state in which it waits for a command (the third byte) again. In this case, the upper four bits of the acknowledge response are undefined - they hold the same values as the upper four bits of the previously issued command.

4. The 5th to 8th bytes, transmitted from the target board to the controller, are the data read from addresses shown below in the flash memory. Software version management is possible by storing a software ID in these locations.

Product name	Area
TMPM332FWUG	0x3F81_FF00 to 0x3F81_FF03

5. The 9th to 20th bytes, transmitted from the target board to the controller, indicate the product name as shown below (where [] is a space) in ASCII code.

Product name	Code
TMPM332FWUG	T, M, P, M, 3, 3, 0, F, W, _, [], _

6. The 21st to 24th bytes, transmitted from the target board to the controller, indicate the start address of the flash memory area containing the password. Each product has own start address shown below.

Product name	Address
TMPM332FWUG	0x04, 0xFF,0x 81, 0x3F

- 7. The 25th to 28th bytes, transmitted from the target board to the controller, indicate the start address of the on-chip RAM, i.e., 0x00, 0x00, 0x00, 0x20.
- 8. The 29th to 32nd bytes, transmitted from the target board to the controller, are dummy data (0x00, 0x00, 0x00 and 0x00).
- 9. The 33rd to 36th bytes, transmitted from the target board to the controller, indicate the end address of the on-chip RAM. Each product has own end address shown below.

Product name	Address
TMPM332FWUG	0xFF, 0x1F, 0x00, 0x20

- 10. The 37th to 40th bytes, transmitted from the target board to the controller, are 0x00, 0x00, 0x00 and 0x00. The 41st to 44th bytes, transmitted from the target board to the controller, are 0x00, 0x00, 0x00 and 0x00.
- 11. The 45th and 46th bytes transmitted are 0x00, 0x00.
- 12. The 47th to 50th bytes, transmitted from the target board to the controller, indicate the start address of the on-chip flash memory, are 0x00, 0x00, 0x80, and 0x3F.
- 13. The 51st to 54th bytes, transmitted from the target board to the controller, indicate the end address of the on-chip flash memory. Each product has own end address shown below.

Product name	Address
TMPM332FWUG	0xFF, 0xFF, 0x81, 0x3F

14. The 55th to 56th bytes, transmitted from the target board to the controller, indicate the number of flash blocks available. Each product transmits own number shown below.

Product name	Number of flash blocks
TMPM332FWUG	0x04, 0x00

- 15. The 57th to 83rd bytes, transmitted from the target board to the controller, contain information about the flash blocks. Flash blocks of the same size are treated as a group. Information about the flash blocks indicate the start address of a group, the size of the blocks in that group (in halfwords) and the number of the blocks in that group. The 57th to 65th bytes are the information about the 16-kbyte blocks. The 66th to 74th bytes are the information about the 32-kbyte blocks. The 75th to 83rd bytes are the information about the 64-kbyte blocks. The 84th to 92nd bytes are the information about the 128-kbyte blocks. See Table 17-8 for the values of bytes transmitted.
- 16. The 66th byte, transmitted from the target board to the controller, is a checksum value for the 5th to 92nd bytes. The checksum value is calculated by adding all these bytes together, dropping the carry and taking the two's complement of the total sum.
- 17. The 94th byte is the next command code.

17.2.10.4 Chip and Protection Bit Erase Command

See Table 17-9 for the transfer format of this command.

1. The processing of the 1st and 2nd bytes are the same as for the RAM Transfer command.

2. From the Controller to the TMPM332FWUG

The 3rd byte, which the target board receives from the controller, is a command. The code for the Show Product Information command is 0x40.

3. From the TMPM332FWUG to the Controller

The 4th byte, transmitted from the target board to the controller, is an acknowledge response to the 3rd byte.

Before sending back the acknowledge response, the boot program checks for a receive error. If there was a receive error, the boot program transmits 0xX8 (bit 3) and returns to the command wait state again. In this case, the upper four bits of the acknowledge response are undefined - they hold the same values as the upper four bits of the previously issued command.

If the 3rd byte is equal to any of the command codes listed in Table 17-4, the boot program echoes it back to the controller. When the Show Flash Memory Sum command was received, the boot program echoes back a value of 0x40. If the 3rd byte is not a valid command, the boot program sends back 0xX1 (bit 0) to the controller and returns to the state in which it waits for a command (the third byte) again. In this case, the upper four bits of the acknowledge response are undefined - they hold the same values as the upper four bits of the previously issued command.

4. From the Controller to the TMPM332FWUG

The 5th byte, transmitted from the target board to the controller, is the Chip Erase Enable command code (0x54).

5. From the TMPM332FWUG to the Controller

The 6th byte, transmitted from the target board to the controller, is an acknowledge response to the 5th byte.

Before sending back the acknowledge response, the boot program checks for a receive error. If there was a receive error, the boot program transmits 0xX8 (bit 3) and returns to the command wait state again. In this case, the upper four bits of the acknowledge response are undefined - they hold the same values as the upper four bits of the previously issued command.

If the 5th byte is equal to any of the command codes to enable erasing, the boot program echoes it back to the controller. When the Chip and Protection Erase command was received, the boot program echoes back a value of 0x54 and then branches to the Chip Erase routine. If the 5th byte is not a valid command, the boot program sends back 0xX1 (bit 0) to the controller and returns to the state in which it waits for a command (the third byte) again. In this case, the upper four bits of the acknowledge response are undefined - they hold the same values as the upper four bits of the previously issued command.

6. From the TMPM332FWUG to the Controller

The 7th byte indicates whether the Chip Erase command is normally completed or not.

At normal completion, completion code (0x4F) is sent.

When an error was detected, error code (0x4C) is sent.

7. The 9th byte is the next command code.

17.2.10.5 Acknowledge Responses

The boot program represents processing states with specific codes. Table 17-10 to Table 17-13 show the values of possible acknowledge responses to the received data. The upper four bits of the acknowledge response are equal to those of the command being executed. Bit 3 of the code indicates a receive error. Bit 0 indicates an invalid command error, a checksum error or a password error. Bit 1 and bit 2 are always "0". Receive error checking is not done in I/O Interface mode.

Table 17-10 ACK Response to the Serial Operation Mode Byte

Return Value	Meaning
0x86	The SIO can be configured to operate in UART mode. (See Note)
0x30	The SIO can be configured to operate in I/O Interface mode.

Note: If the serial operation mode is determined as UART, the boot program checks if the SIO can be programmed to the baud rate at which the operation mode byte was transferred. If that baud rate is not possible, the boot program aborts, without sending back any response.

Table 17-11 ACK Response to the Command Byte

Return Value	Meaning
0x?8 (See Note)	A receive error occurred while getting a command code.
0x?1 (See Note)	An undefined command code was received. (Reception was completed normally.)
0x10	The RAM Transfer command was received.
0x20	The Show Flash Memory Sum command was received.
0x30	The Show Product Information command was received.
0x40	The Chip Erase command was received.

Note: The upper four bits of the ACK response are the same as those of the previous command code.

Table 17-12 ACK Response to the Checksum Byte

Return Value	Meaning	
0xN8 (See Note)	A receive error occurred.	
0xN1 (See Note)	A checksum or password error occurred.	
0xN0 (See Note)	The checksum was correct.	

Note: The upper four bits of the ACK response are the same as those of the operation command code. It is 1 (N; RAM transfer command data [7:4]) when password error occurs.

Table 17-13 ACK Response to Chip and Protection Bit Erase Byte

Return Value	Meaning
0x54	The Chip Erase enabling command was received.
0x4F	The Chip Erase command was completed.
0x4C	The Chip Erase command was abnormally completed.

17.2.10.6 Determination of a Serial Operation Mode

The first byte from the controller determines the serial operation mode. To use UART mode for communications between the controller and the target board, the controller must first send a value of 0x86 at a desired baud rate to the target board. To use I/O Interface mode, the controller must send a value of 0x30 at 1/16 the desired baud rate. Figure 17-4 shows the waveforms for the first byte.




Figure 17-4 Serial Operation Mode Byte

After RESET is released, the boot program monitors the first serial byte from the controller, with the SIO reception disabled, and calculates the intervals of tAB, tAC and tAD. Figure 17-5 shows a flowchart describing the steps to determine the intervals of tAB, tAC and tAD. As shown in the flowchart, the boot program captures timer counts each time a logic transition occurs in the first serial byte. Consequently, the calculated tAB, tAC and tAD intervals are bound to have slight errors. If the transfer goes at a high baud rate, the CPU might not be able to keep up with the speed of logic transitions at the serial receive pin. In particular, I/O Interface mode is more prone to this problem since its baud rate is generally much higher than that for UART mode. To avoid such a situation, the controller should send the first serial byte at 1/16 the desired baud rate.

The flowchart in Figure 17-5 shows how the boot program distinguishes between UART and I/O Interface modes. If the length of tAB is equal to or less than the length of tCD, the serial operation mode is determined as UART mode. If the length of tAB is greater than the length of tCD, the serial operation mode is determined as I/O Interface mode. Bear in mind that if the baud rate is too high or the timer operating frequency is too low, the timer resolution will be coarse, relative to the intervals between logic transitions. This becomes a problem due to inherent errors caused by the way in which timer counts are captured by software; consequently the boot program might not be able to determine the serial operation mode correctly. To prevent this problem, reset UART mode within the programming routine.

For example, the serial operation mode may be determined to be I/O Interface mode when the intended mode is UART mode. To avoid such a situation, when UART mode is utilized, the controller should allow for a time-out period within which it expects to receive an echo-back (0x86) from the target board. The controller should give up the communication if it fails to get that echo-back within the allowed time. When I/O Interface mode is utilized, once the first serial byte has been transmitted, the controller should send the SCLK clock after a certain idle time to get an acknowledge response. If the received acknowledge response is not 0x30, the controller should give up further communications.

When the intended mode is I/O interface mode, the first byte does not have to be 0x30 as long as tAB is greater than tCD as shown above. 0x91, 0xA1 or 0xB1 can be sent as the first byte code to determine the falling edges of Point A and Point C and the rising edges of Point B and Point D. If tAB is greater than tCD and SIO is selected by the resolution of the operation mode determination, the second byte code is 0x30 even though the transmitted code on the first byte is not 0x30 (The first byte code to determine I/O interface mode is described as 0x30).




Figure 17-5 Serial Operation Mode Byte Reception Flowchart




Figure 17-6 Serial Operation Mode Determination Flowchart

17.2.10.7 Password

The RAM Transfer command (0x10) causes the boot program to perform password verification. Following an echo-back of the command code, the boot program verifies the contents of the 12-byte password area within the flash memory. The following table shows the password area of each product.

Product name	Area
TMPM332FWUG	0x3F81_FF04 to 0x3F81_FF0F

Note: If a password is set to 0xFF (erased data area), it is difficult to protect data securely due to an easy-to-guess password. Even if Single Boot mode is not used, it is recommended to set a unique value as a password.

If all these address locations contain the same bytes of data other than 0xFF, a password area error occurs as shown in Figure 17-7. In this case, the boot program returns an error acknowledge (0x11) in response to the checksum byte (the 17th byte), regardless of whether the password sequence sent from the controller is all 0xFFs.

The password sequence received from the controller (5th to 16th bytes) is compared to the password stored in the flash memory. All of the 12 bytes must match to pass the password verification. Otherwise, a password error occurs, which causes the boot program to reply an error acknowledge in response to the checksum byte (the 17th byte).

The password verification is performed even if the security function is enabled.




Figure 17-7 Password Area Verification Flowchart

17.2.10.8 Calculation of the Show Flash Memory Sum Command

The result of the sum calculation "byte + byte + byte + \cdot • • " is responded by a word quantity. The Show Flash Memory Sum command adds all 512 Kbytes of the flash memory together and provides the total sum as a halfword quantity. The sum is sent to the controller, with the upper eight bits first, followed by the lower eight bits.

Example)

0xA1	
0xB2	
0xC3	
0xD4	
	\neg

For the interest of simplicity, assume the depth of the flash memory is four locations. Then the sum of the four bytes is calculated as:

0xA1 + 0xB2 + 0xC3 + 0xD4 = 0x02EA

Hence, 0x02 is first sent to the controller, followed by 0xEA.

17.2.10.9 Checksum Calculation

The checksum byte for a series of bytes of data is calculated by adding the bytes together, dropping the carries, and taking the two's complement of the total sum. The Show Flash Memory Sum command and the Show Product Information command perform the checksum calculation. The controller must perform the same checksum operation in transmitting checksum bytes.

Example) Assume the Show Flash Memory Sum command provides the upper and lower bytes of the sum as 0xE5 and 0xF6. To calculate the checksum for a series of 0xE5 and 0xF6:

Add the bytes together

0xE5 + 0xF6 = 0x1DB

Take the two's complement of the sum, and that is the checksum byte.

0 - 0xDB = 0x25

17.2.11 General Boot Program Flowchart

Figure 17-8 shows an overall flowchart of the boot program.




Figure 17-8 Overall Boot Program Flowchart

On-board Programming of Flash Memory (Rewrite/Erase) 17.3

In on-board programming, the CPU is to execute software commands for rewriting or erasing the flash memory. The rewrite/erase control program should be prepared by the user beforehand. Because the flash memory content cannot be read while it is being written or erased, it is necessary to run the rewrite/erase program from the internal RAM after shifting to the user boot mode.

17.3.1 Flash Memory

Except for some functions, writing and erasing flash memory data are in accordance with the standard JEDEC commands. In writing or erasing, use 32-bit data transfer command of the CPU to enter commands to the flash memory. Once the command is entered, the actual write or erase operation is automatically performed internally.

Table 17-14 Flash Memory Functions

Major functions	Description
Automatic page program	Writes data automatically per page.
Automatic chip erase	Erases the entire area of the flash memory automatically.
Automatic block erase	Erases a selected block automatically.
Protect function	The write or erase operation can be individually inhibited for each block.

17.3.1.1 **Block Configuration**

TMPM332FWUG (1)




Figure 17-9 Block Configuration of Flash Memory (TMPM332FWUG)

17.3.1.2 Basic operation

This flash memory device has the following two operation modes:

- The mode to read memory data (Read mode)
- The mode to automatically erase or rewrite memory data (Automatic operation)

Transition to the automatic mode is made by executing a command sequence while it is in the memory read mode. In the automatic operation mode, flash memory data cannot be read and any commands stored in the flash memory cannot be executed. In the automatic operation mode, any interrupt or exception generation cannot set the device to the read mode except when a hardware reset is generated. During automatic operation, be sure not to cause any exceptions other than reset and debug exceptions while a debug port is connected. Any exception generation cannot set the device to the read mode except when a hardware reset is generated.

(1) Read

When data is to be read, the flash memory must be set to the read mode. The flash memory will be set to the read mode immediately after power is applied, when CPU reset is removed, or when an automatic operation is normally terminated. In order to return to the read mode from other modes or after an automatic operation has been abnormally terminated, either the Read/reset command (a software command to be described later) or a hardware reset is used. The device must also be in the read mode when any command written on the flash memory is to be executed.

· Read/reset command and Read command (software reset)

When ID-Read command is used, the reading operation is terminated instead of automatically returning to the read mode. In this case, the Read/reset command can be used to return the flash memory to the read mode. Also, when a command that has not been completely written has to be canceled, the Read/reset command must be used. The Read command is used to return to the read mode after executing 32-bit data transfer command to write the data "0x0000_00F0" to an arbitrary address of the flash memory.

• With the Read/reset command, the device is returned to the read mode after completing the third bus write cycle.

(2) Command write

This flash memory uses the command control method. Commands are executed by executing a command sequence to the flash memory. The flash memory executes automatic operation commands according to the address and data combinations applied (refer to Command Sequence).

If it is desired to cancel a command write operation already in progress or when any incorrect command sequence has been entered, the Read/reset command is to be executed. Then, the flash memory will terminate the command execution and return to the read.

While commands are generally comprised of several bus cycles, the operation to apply 32-bit data transmit command to the flash memory is called "bus write cycle." The bus write cycles are to be in a specific sequential order and the flash memory will perform an automatic operation when the sequence of the bus write cycle data and address of a command write operation is in accordance with a predefined specific sequence. If any bus write cycle does not follow a predefined command write sequence, the flash memory will terminate the command execution and return to the read mode.

Note 1: Command sequences are executed from outside the flash memory area.

Note 2: Each bus write cycle must be sequentially executed by 32-bit data transmit command. While a command sequence is being executed, access to the flash memory is prohibited. Also, don't generate any interrupt (except debug exceptions when a debug port is connected). If such an operation is made, it can result in an unexpected read access to the flash memory and the command sequencer may not be able to correctly recognize the command. While it could cause an abnormal termination of the command sequence, it is also possible that the written command is incorrectly recognized.

- Note 3: For the command sequencer to recognize a command, the device must be in the read mode prior to executing the command. Be sure to check before the first bus write cycle that FCFLCS <RDY/BSY> is set to "1." It is recommended to subsequently execute a Read com-
- Note 4: Upon issuing a command, if any address or data is incorrectly written, be sure to perform a software reset to return to the read mode again.

17.3.1.3 Reset(Hardware reset)

A hardware reset is used to cancel the operational mode set by the command write operation when forcibly termination during auto programming/ erasing or abnormal termination during automatic operation.

The flash memory has a reset input as the memory block and it is connected to the CPU reset signal. Therefore, when the RESET input pin of this device is set to VIL or when the CPU is reset due to any overflow of the watch dog timer, the flash memory will return to the read mode terminating any automatic operation that may be in progress. It should also be noted that applying a hardware reset during an automatic operation can result in incorrect rewriting of data. In such a case, be sure to perform the rewriting again.

Refer to Section "17.2.1 Reset Operation" for CPU reset operations. After a given reset input, the CPU will read the reset vector data from the flash memory and starts operation after the reset is removed.

17.3.1.4 Commands

(1) Automatic Page Programming

Writing to a flash memory device is to make "1" data cells to "0" data cells. Any "0" data cell cannot be changed to a "1" data cell. For making "0" data cells to "1" data cells, it is necessary to perform an erase operation.

The automatic page programming function of this device writes data of each page. The TMPM332FWUG contains 64 words in a page. A 64 word block is defined by a same [31:8] address and it starts from the address [7:0] = 0x00 and ends at the address [7:0] = 0xFF. This programming unit is hereafter referred to as a "page".

Writing to data cells is automatically performed by an internal sequencer and no external control by the CPU is required. The state of automatic page programming (whether it is in writing operation or not) can be checked by FCFLCS [0] <RDY/BSY>.

Also, any new command sequence is not accepted while it is in the automatic page programming mode. If it is desired to interrupt the automatic page programming, use the hardware reset function. If the operation is stopped by a hardware reset operation, it is necessary to once erase the page and then perform the automatic page programming again because writing to the page has not been normally terminated.

The automatic page programming operation is allowed only once for a page already erased. No programming can be performed twice or more times irrespective of the data cell value whether it is "1" or "0." Note that rewriting to a page that has been once written requires execution of the automatic block erase or automatic chip erase command before executing the automatic page programming command again. Note that an attempt to rewrite a page two or more times without erasing the content can cause damages to the device.

No automatic verify operation is performed internally to the device. So, be sure to read the data programmed to confirm that it has been correctly written.

The automatic page programming operation starts when the third bus write cycle of the command cycle is completed. On and after the fifth bus write cycle, data will be written sequentially starting from the next address of the address specified in the fourth bus write cycle (in the fourth bus write cycle, the page top address will be command written) (32 bits of data is input at a time). Be sure to use the 32-bit data transfer command in writing commands on and after the fourth bus cycle. In this, any 32-bit data transfer commands shall not be placed across word boundary. On and after the fifth bus write cycle, data is command written to the same page area. Even if it is desired to write the page only partially, it is required to perform the automatic page programming for the entire page. In this case, the address input for the fourth bus write cycle shall be set to the top address of the page. Be sure to perform command write operation with the input data set to "1" for the data cells not to be set to "0." For example, if the top address of a page is not to be written, set the input data of the fourth bus write cycle to 0xFFFFFFFF to command write the data.

Once the third bus cycle is executed, the automatic page programming is in operation. This condition can be checked by monitoring FCFLCS<RDY/BSY>. Any new command sequence is not accepted while it is in automatic page programming mode. If it is desired to stop operation, use the hardware reset function. Be careful in doing so because data cannot be written normally if the operation is interrupted. When a single page has been command written normally terminating the automatic page writing process, FCFLCS<RDY/BSY> is set to "1" and it returns to the read mode.

When multiple pages are to be written, it is necessary to execute the page programming command for each page because the number of pages to be written by a single execution of the automatic page program command is limited to only one page. It is not allowed for automatic page programming to process input data across pages.

Data cannot be written to a protected block. When automatic programming is finished, it automatically returns to the read mode. This condition can be checked by monitoring FCFLCS<RDY/BSY>. If automatic programming has failed, the flash memory is locked in the mode and will not return to the read mode. For returning to the read mode, it is necessary to execute hardware reset to reset the flash memory or the device. In this case, while writing to the address has failed, it is recommended not to use the device or not to use the block that includes the failed address.

Note: Software reset becomes ineffective in bus write cycles on and after the fourth bus write cycle of the automatic page programming command.

(2) Automatic chip erase

The automatic chip erase operation starts when the sixth bus write cycle of the command cycle is completed.

This condition can be checked by monitoring FCFLCS<RDY/BSY>. While no automatic verify operation is performed internally to the device, be sure to read the data to confirm that data has been correctly erased. Any new command sequence is not accepted while it is in an automatic chip erase operation. If it is desired to stop operation, use the hardware reset function. If the operation is forced to stop, it is necessary to perform the automatic chip erase operation again because the data erasing operation has not been normally terminated.

Also, any protected blocks cannot be erased. If all the blocks are protected, the automatic chip erase operation will not be performed and it returns to the read mode after completing the sixth bus read cycle of the command sequence. When an automatic chip erase operation is normally terminated, it automatically returns to the read mode. If an automatic chip erase operation has failed, the flash memory is locked in the mode and will not return to the read mode.

For returning to the read mode, it is necessary to execute hardware reset to reset the device. In this case, the failed block cannot be detected. It is recommended not to use the device anymore or to identify the failed block by using the block erase function for not to use the identified block anymore.

(3)Automatic block erase (for each block)

The automatic block erase operation starts when the sixth bus write cycle of the command cycle is completed.

This status of the automatic block erase operation can be checked by monitoring FCFLCS <RDY/ BSY>. While no automatic verify operation is performed internally to the device, be sure to read the data to confirm that data has been correctly erased. Any new command sequence is not accepted while it is in an automatic block erase operation. If it is desired to stop operation, use the hardware reset function. In this case, it is necessary to perform the automatic block erase operation again because the data erasing operation has not been normally terminated.

Also, any protected blocks cannot be erased. If an automatic block erase operation has failed, the flash memory is locked in the mode and will not return to the read mode. In this case, execute hardware reset to reset the device.

Automatic programming of protection bits (for each block)

This device is implemented with protection bits. This protection can be set for each block. See Table 17-18 for table of protection bit addresses. This device assigns 1 bit to 1 block as a protection bit. The applicable protection bit is specified by PBA in the seventh bus write cycle. By automatically programming the protection bits, write and/or erase functions can be inhibited (for protection) individually for each block. The protection status of each block can be checked by FCFLCS <BLPRO> to be described later. This status of the automatic programming operation to set protection bits can be checked by monitoring FCFLCS <RDY/BSY> . Any new command sequence is not accepted while automatic programming is in progress to program the protection bits. If it is desired to stop the programming operation, use the hardware reset function. In this case, it is necessary to perform the programming operation again because the protection bits may not have been correctly programmed. If all the protection bits have been programmed, all FCFLCS <BLPRO> are set to "1" indicating that it is in the protected state. This disables subsequent writing and erasing of all blocks.

Note: Software reset is ineffective in the seventh bus write cycle of the automatic protection bit programming command. FCFLCS <RDY/BSY> turns to "0" after entering the seventh bus write cycle.

(5) Automatic erasing of protection bits

Different results will be obtained when the automatic protection bit erase command is executed depending on the status of the protection bits and the security bits. It depends on the status of FCFLCS <BLPRO> whether all <BLPRO> are set to "1" or not if FCSECBIT<FCSECBIT> is 0x1. Be sure to check the value of FCFLCS <BLPRO> before executing the automatic protection bit erase command. See the chapter "ROM protection" for details.

• When all the FCFLCS <BLPRO> are set to "1" (all the protection bits are programmed):

When the automatic protection bit erase command is command written, the flash memory is automatically initialized within the device. When the seventh bus write cycle is completed, the entire area of the flash memory data cells is erased and then the protection bits are erased. This operation can be checked by monitoring FCFLCS <RDY/BSY>. If the automatic operation to erase protection bits is normally terminated, FCFLCS will be set to "0x00000001". While no automatic verify operation is performed internally to the device, be sure to read the data to confirm that it has been correctly erased. For returning to the read mode while the automatic operation after the seventh bus cycle is in progress, it is necessary to use the hardware reset to reset the device. If this is done, it is necessary to check the status of protection bits by FCFLCS <BLPRO> after retuning to the read mode and perform either the automatic protection bit erase, automatic chip erase, or automatic block erase operation, as appropriate.

When FCFLCS <BLPRO> include "0" (not all the protection bits are programmed):

If the automatic protection bit is cleared to "0", the protection condition is canceled. With this device, protection bits can be programmed to an individual block and performed bit-erase operation in the four bits unit as shown in Table 17-19. The target bits are specified in the seventh bus write cycle. The protection status of each block can be checked by FCFLCS <BLPRO> to be described later. This status of the programming operation for automatic protection bits can be checked by monitoring FCFLCS <RDY/BSY>. When the automatic operation to erase protection bits is normally terminated, the protection bits of FCFLCS <BLPRO> selected for erasure are set to "0".

In any case, any new command sequence is not accepted while it is in an automatic operation to erase protection bits. If it is desired to stop the operation, use the hardware reset function. When the automatic operation to erase protection bits is normally terminated, it returns to the read mode.

Note: The FCFLCS <RDY/BSY> bit is "0" while in automatic operation and it turns to "1" when the automatic operation is terminated.

(6) ID-Read

Using the ID-Read command, you can obtain the type and other information on the flash memory contained in the device. The data to be loaded will be different depending on the address [15:14] of the fourth and subsequent bus write cycles (recommended input data is 0x00). On and after the fourth bus write cycle, when an arbitrary flash memory area is read, the ID value will be loaded. Once the fourth bus write cycle of an ID-Read command has passed, the device will not automatically return to the read mode. In this condition, the set of the fourth bus write cycle and ID-Read commands can be repetitively executed. For returning to the read mode, use the Read/reset command or hardware reset command.

17.3.1.5 Flash control/ status register

Base Address = 0x4004_0500

Register name	Address(Base+)	
Security bit register	FCSECBIT	0x0000
Reserved	-	0x0004
Flash control register	FCFLCS	0x0020
Reserved	-	0x0024
Reserved	-	0x0028

Note: Access to the "Reserved" areas is prohibited.

(1) FCFLCS (Flash control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	BLPRO3	BLPRO2	BLPRO1	BLPRO0
After reset	0	0	0	0	(Note2)	(Note2)	(Note2)	(Note2)
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	-	RDY/BSY
After reset	0	0	0	0	0	0	0	1

Bit	Bit Symbol	Туре	Function
31-20	-	R	Read as 0.
19-16	BLPRO3 to BLPRO0	R	Protection for Block3 to 0 0: disabled 1: enabled Protection status bits Each of the protection bits represents the protection status of the corresponding block. When a bit is set to "1," it indicates that the block corresponding to the bit is protected. When the block is protected, data cannot be written to it.
15-1	-	R	Read as 0.
0	RDY/BSY	R	Ready/Busy (Note 1) 0: Auto operating 1:Auto operation terminated Ready/Busy flag bit The RDY/BSY output is provided as a means to monitor the status of automatic operation. This bit is a function bit for the CPU to monitor the function. When the flash memory is in automatic operation, it outputs "0" to indicate that it is busy. When the automatic operation is terminated, it returns to the ready state and outputs "1" to accept the next command. If the automatic operation has failed, this bit maintains the "0" output. By applying a hardware reset, it returns to "1."

Note 1: This command must be issued in the ready state. Issuing the command in the busy state may disable both correct command transmission and further command input. To exit from the condition, execute system reset. System reset requires at least 0.5 µs regardless of the system clock frequency. In this condition, it takes approx. 2 ms to enable reading after reset.

Note 2: The value varies depending on protection applied.

(2) FCSECBIT (Security bit register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	-	SECBIT
After reset	0	0	0	0	0	0	0	1

Bit	Bit Symbol	Туре	Function
31-1	-	R	Read as 0.
0	SECBIT	R/W	Security bits
			0:disabled
			1:enabled

Note: This register is initialized by cold reset.

17.3.1.6 List of Command Sequences

Table 17-15 shows the addresses and the data of each command of flash memory.

Bus cycles are "bus write cycles" except for the second bus cycle of the Read command, the fourth bus cycle of the Read/reset command, and the fifth bus cycle of the ID-Read command. Bus write cycles are executed by 32-bit (word) data transfer commands. (In the following table, only lower 8 bits data are shown.)

See Table 17-16 for the detail of the address bit configuration. Use a value of "Addr." in the Table 17-15 for the address [15:8] of the normal command in the Table 17-16.

Note: Always set "0" to the address bits [1:0] in the entire bus cycle.

Table 17-15 Flash Memory Access from the Internal CPU

	First bus cy- cle	Second bus cycle	Third bus cy- cle	Fourth bus cycle	Fifth bus cy- cle	Sixth bus cy- cle	Seventh bus cycle
Command sequence	Addr.	Addr.	Addr.	Addr.	Addr.	Addr.	Addr.
	Data	Data	Data	Data	Data	Data	Data
Dead	0xXX	-	-	-	-	-	-
Read	0xF0	-	-	-	-	-	-
Read/Reset	0x54XX	0xAAXX	0x54XX	RA	-	-	ı
Read/Reset	0xAA	0x55	0xF0	RD	-	-	-
ID-Read	0x54XX	0xAAXX	0x54XX	IA	0xXX	-	-
ID-Read	0xAA	0x55	0x90	0x00	ID	-	-
Automatic page program-	0x54XX	0xAAXX	0x54XX	PA	PA	PA	PA
ming	0xAA	0x55	0xA0	PD0	PD1	PD2	PD3
A	0x54XX	0xAAXX	0x54XX	0x54XX	0xAAXX	0x54XX	ı
Automatic chip erase	0xAA	0x55	0x80	0xAA	0x55	0x10	-
Auto Block erase	0x54XX	0xAAXX	0x54XX	0x54XX	0xAAXX	BA	-
Auto Block erase	0xAA	0x55	0x80	0xAA	0x55	0x30	-
Protection bit program-	0x54XX	0xAAXX	0x54XX	0x54XX	0xAAXX	0x54XX	PBA
ming	0xAA	0x55	0x9A	0xAA	0x55	0x9A	0x9A
Protection bit erase	0x54XX	0xAAXX	0x54XX	0x54XX	0xAAXX	0x54XX	PBA
Frotection bit erase	0xAA	0x55	0x6A	0xAA	0x55	0x6A	0x6A

Supplementary explanation

- · RA: Read address
- RD: Read data
- IA: ID address
- · ID: ID data
- PA: Program page address
 - PD: Program data (32 bit data)
 - After the fourth bus cycle, enter data in the order of the address for a page.
- BA: Block address
- PBA: Protection bit address

17.3.1.7 Address bit configuration for bus write cycles

Table 17-16 is used in conjunction with Table 17-15 "Flash Memory Access from the Internal CPU." Address setting can be performed according to the normal bus write cycle address configuration from the first bus cycle. "0" is recommended" in the Table 17-16 Address Bit Configuration for Bus Write Cycles can be changed as necessary.

Table 17-16 Address Bit Configuration for Bus Write Cycles

A -l -l	Addr	Addr	Addr	Addr	Addr	Addr	Addr	Addr	Addr	Addr	Addr
Address	[31:19]	[18]	[17]	[16]	[15]	[14]	[13:11]	[10]	[9]	[8]	[7:0]

			Normal bus write	cycle address configuration		
Normal com- mands	Flash area	"0" is recommended.			Addr[1:0]="0" (fixed) Others:0 (recommended)	
ID DEAD		IA: ID address	(Set the fourth bus	s write cycle address for ID-Read	operation)	
ID-READ	Flash area	"0" is recommended.	ID address	Addr[1:0]="0" (fixed	d) , Others:0 (recor	nmended)
		BA: Block addres	s (Set the sixth bus	write cycle address for block eras	se operation)	
Block erase		Block selection (Table 17-17)		Addr[1:0]="0" (fixed	d) , Others:0 (recor	mmended)
		PA: Program page addres	s (Set the fourth bu	us write cycle address for page pro	ogramming operati	on)
Auto page program- ming			Page selection	1		Addr[1:0]="0" (fixed) Others:0 (recommended)
		PBA: Protection bit addres	ss (Set the seventh	bus write cycle address for protec	ction bit programm	ing
Protection bit brogram-ming	Flash area	Flash area Protection bit selection (Table 17-18) Protection bit selection (Table 17-18)				Addr[1:0]="0" (fixed) Others:0 (recommended)
	PBA: Protection bit address (Set the seventh bus write cycle address for protection bit programming					
Protection bit erase	Flash area	Protection bit selection (Table 17-19)	Fixed to "0".			:0]="0" (fixed) (recommended)

As block address, specify any address in the block to be erased.

Table 17-17 Block Address Table

Block	Address (User boot mode)	Address (Single boot mode)	Size (Kbyte)
2	0x0000_0000 ~ 0x0000_3FFF	0x3F80_0000 ~ 0x3F80_3FFF	16
3	0x0000_4000 ~ 0x0000_7FFF	0x3F80_4000 ~ 0x3F80_7FFF	16
1	0x0000_8000 ~ 0x0000_FFFF	0x3F80_8000 ~ 0x3F80_FFFF	32
0	0x0001_0000 ~ 0x0001_FFFF	0x3F81_0000 ~ 0x3F81_FFFF	64

Note: As for the addresses from the first to the fifth bus cycles, specify the upper addresses of the blocks to be erased.

Table 17-18 Protection Bit Programming Address Table

				The sevent	h bus write cy	cle address		
Block	Protection bit	Address [18]	Address [17]	Address [16]	Address [15:11]	Address [10]	Address [9]	Address [8]
Block0	<blpro[0]></blpro[0]>	0	0				0	0
Block1	<blpro[1]></blpro[1]>	0	0		F:		0	1
Block2	<blpro[2]></blpro[2]>	0	0		Fixed to "0".		1	0
Block3	<blpro[3]></blpro[3]>	0	0				1	1


Table 17-19 Protection Bit Erase Address Table

Dlask	Drataction hit	The seventh bus write cycle address [18:17]		
Block	Protection bit	Address[18]	Address[17]	
Block0 to 3	<blpro[0:3]></blpro[0:3]>	0	0	

Note: The protection bit erase command cannot erase by individual block.

Table 17-20 The ID-Read command's fourth bus write cycle ID address (IA) and the data to be read by the following 32-bit data transfer command (ID)

IA[15:14]	ID[7:0]	Code
00b	0x98	Manufacturer code
01b	0x5A	Device code
10b	Reserved	-
11b	0x11	Macro code



Automatic Page Programming Command Sequence (Address/ Command)





Figure 17-10 Automatic Programming

Note: Command sequence is executed by 0x54xx or 0x55xx.



Automatic chip erase command sequence Automatic block/ multi-block erase command sequence (address/ command) (address/ command) 0x54xx/0xAA 0x54xx/0xAA 0xAAxx/0x55 0xAAxx/0x55 0x54xx/0x80 0x54xx/0x80 0x54xx/0xAA 0x54xx/0xAA 0xAAxx/0x55 0xAAxx/0x55 0x54xx/0x10 Block address/0x30

Figure 17-11 Automatic Erase

Note: Command sequence is executed by 0x54xx or 0x55xx.

Flash Memory Operation On-board Programming of Flash Memory (Rewrite/Erase)	TMPM332FWUG

TOSHIBA TMPM332FWUG

18. ROM protection

18.1 Outline

The TMPM332FWUG offers two kinds of ROM protection/ security functions.

One is a write/ erase-protection function for the internal flash ROM data.

The other is a security function that restricts internal flash ROM data readout and debugging.

18.2 Future

18.2.1 Write/ erase-protection function

The write/ erase-protection function enables the internal flash to prohibit the writing and erasing operation for each block.

To activate the function, write "1" to the corresponding bits to a block to protect. Writing "0" to the bits cancels the protection.

The protection settings of the bits can be monitored by the FCFLCS <BLPRO[5:0]> bit. See the chapter "Flash" for programming details.

18.2.2 Security function

The security function restricts flash ROM data readout and debugging.

This function is available under the conditions shown below.

- 1. The FCSECBIT <SECBIT> bit is set to"1".
- 2. All the protection bits (the FCFLCS<BLPRO> bits) used for the write/erase-protection function are set to "1".

Note: The FCSECBIT <SECBIT> bit is set to "1" at a power-on reset right after power-on.

Table 18-1 shows details of the restrictions by the security function.

Table 18-1 Restrictions by the security function

Item	Details
1) ROM data readout	Data can be read from CPU.
2) Debug port	Communication of JTAG/SW and trace are prohibited
3) Command for flash memory	Writing a command to the flash memory is prohibited. An attempt to erase the contents in the bits used for the write/erase-protection erases all the protection bits.

18.3 Register TMPM332FWUG

18.3 Register

Base Address = 0x4004_0500

Register name		Address(Base+)
Security bit register	FCSECBIT	0x0000
Reserved	-	0x0004
Flash control register	FCFLCS	0x0020
Reserved	-	0x0024
Reserved	-	0x0028

 $\label{eq:Note:Access} \mbox{ to the "Reserved" areas is prohibited.}$

18.3.1 FCFLCS (Flash control register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	BLPRO3	BLPRO2	BLPRO1	BLPRO0
After reset	0	0	0	0	(Note2)	(Note2)	(Note2)	(Note2)
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	-	RDY/BSY
After reset	0	0	0	0	0	0	0	1

Bit	Bit Symbol	Туре	Function
31-20	-	R	Read as 0.
19-16	BLPRO3 to BLPRO0	R	Protection for Block3 to 0 0: disabled 1: enabled Protection status bits Each of the protection bits represents the protection status of the corresponding block. When a bit is set to "1," it indicates that the block corresponding to the bit is protected. When the block is protected, data cannot be written to it.
15-1	-	R	Read as 0.
0	RDY/BSY	R	Ready/Busy (Note 1) 0: Auto operating 1:Auto operation terminated Ready/Busy flag bit The RDY/BSY output is provided as a means to monitor the status of automatic operation. This bit is a function bit for the CPU to monitor the function. When the flash memory is in automatic operation, it outputs "0" to indicate that it is busy. When the automatic operation is terminated, it returns to the ready state and outputs "1" to accept the next command. If the automatic operation has failed, this bit maintains the "0" output. By applying a hardware reset, it returns to "1."

Note 1: This command must be issued in the ready state. Issuing the command in the busy state may disable both correct command transmission and further command input. To exit from the condition, execute system reset. System reset requires at least 0.5 ms regardless of the system clock frequency. In this condition, it takes approx. 2 ms to enable reading after reset.

Note 2: The value varies depending on protection applied.

18.3 Register TMPM332FWUG

18.3.2 FCSECBIT(Security bit register)

	31	30	29	28	27	26	25	24
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	23	22	21	20	19	18	17	16
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	15	14	13	12	11	10	9	8
bit symbol	-	-	-	-	-	-	-	-
After reset	0	0	0	0	0	0	0	0
	7	6	5	4	3	2	1	0
bit symbol	-	-	-	-	-	-	-	SECBIT
After reset	0	0	0	0	0	0	0	1

Bit	Bit Symbol	Туре	ã@î\
31-1	_	R	Read as 0.
0	SECBIT	R/W	Security bit
			0: Disabled
			1: Enabled

Note: This register is initialized only by power-on reset.

TOSHIBA TMPM332FWUG

18.4 Writing and erasing

18.4.1 Protection bits

Writing and erasing protection bits are available with a single chip mode, single boot mode and writer mode.

Writing to the protection bits is done on block-by-block basis.

Erasing of the protection bits is done by two groups of the blocks: block 0 through 3 and block 4 through 5. When the settings for all the blocks are "1", erasing must be done after setting the FCSECBIT <SECBIT> bit to "0". Setting "1" at that situation erases all the protection bits. To write and erase the protection bits, command sequence is used.

See the capter "Flash" for details

18.4.2 Security bit

The FCSECBIT <SECBIT> bit that activates security function is set to "1" at a power-on reset right after power-on.

The bit is rewritten by the following procedure.

- 1. Write the code 0xa74a9d23 to FCSECBIT register.
- 2. Write data within 16 clocks from the above.1.

Note: The above procedure is enabled only when using 32-bit data transfer command.

18. ROM protection

18.4 Writing and erasing TMPM332FWUG

TMPM332FWUG

19. Electrical Characteristics

19.1 Absolute Maximum Ratings

Para	meter	Symbol	Rating	Unit
		DVDD3	-0.3 to 3.9	
Supply voltage		AVDD3	-0.3 to 3.9	V
		RVDD3	-0.3 to 3.9	
Input voltage		V _{IN}	-0.3 to VDD + 0.3	V
Low-level	Per pin	I _{OL}	5	
output current	Total	ΣI _{OL}	50	
High-level	Per pin	Іон	-5	mA
output current	Total	ΣΙΟΗ	-50	
Power consumption (Ta = 85 °C)	PD	600	mW
Soldering temperatur	re(10 s)	T _{SOLDER}	260	°C
Storage temperature		T _{STG}	-40 to 125	°C
Operating Tempera-	Except during Flash W/E	T _{OPR}	−20 to 85	°C
ture	During Flash W/E	2	0 to 70	

Note: Absolute maximum ratings are limiting values of operating and environmental conditions which should not be exceeded under the worst possible conditions. The equipment manufacturer should design so that no Absolute maximum rating value is exceeded with respect to current, voltage, power consumption, temperature, etc. Exposure to conditions beyond those listed above may cause permanent damage to the device or affect device reliability, which could increase potential risks of personal injury due to IC blowup and/or burning.

DC Electrical Characteristics (1/3) 19.2

Ta = −20 to 85 °C

	Parameter	Symbol	Cor	ndition	Min	Typ. (Note 1)	Max	Unit
Supply volt- age	DVDD3 = AVDD3 = RVDD3 (Note2) DVSS = AVSS = 0V	DVDD3 AVDD3 RVDD3	f _{OSC} = 8 to 10 N fsys = 1 to 40 N fs = 30 to 34 kH	1Hz	2.7	-	3.6	٧
	PD4 to 7	V _{IL1}	2.7 V ≤ AVDD3	<26V			0.3 AVDD3	
PD0 to 3 PA2 to 3, PB0, PE0, PI0 to 5, PJ4,PK1	PD0 to 3	V _{IL2}	2.7 V 3 AVDD3	3 3.0 V			0.2 AVDD3	
	PA2 to 3, PB0, PE0, PE4, PI0 to 5, PJ4,PK1	V_{IL3}					0.3 DVDD3	
Low-level input volt- age	PA0 to 1, PE1 to 3, PE5 to 6, PF4 to 6, PG0 to 3, PH0 to 3, PJ0 to 3 RESET, NMI, MODE	V_IL4	2.7 V ≤ DVDD3	≤ 3.6 V	-0.3	-	0.2 DVDD3	V
	PK0	V _{IL5}	5					
	X1	V _{IL6}					0.1 DVDD3	
	PD4 to 7	V _{IH1}	271/< 11/003	< 3.6 V	0.7 AVDD3		DD3 AVDD3 + 0.3	
	PD0 to 3	V_{IH2}	2.7 V ≤ AVDD3 ≤ 3.6 V		0.8 AVDD3		AVDD3 + 0.3	
	PA2 to 3, PB0, PE0, PE4, PI0 to 5, PJ4,PK1	V _{IH3}			0.7 DVDD3			
High-level input volt- age	PA0 to 1, PE1 to 3, PE5 to 6, PF4 to 6, PG0 to 3, PH0 to 3, PJ0 to 3 RESET, NMI, MODE	V _{IH4}	2.7 V ≤ DVDD3 ≤ 3.6 V		0.8 DVDD3	-	DVDD3 + 0.3	V
	PK0	V _{IH5}	1				3.6	
	X1	V _{IH6}	1		0.9 DVDD3		DVDD3 + 0.3	
Low-level out	put voltage	V _{OL}	I _{OL} = 2 mA	DVDD3 ≥ 2.7 V	-	-	0.4	٧
High-level ou	tput voltage	V _{OH}	I _{OH} = −2 mA	DVDD3 ≥ 2.7 V	2.4	-	-	V
Input leak- age current	Except PK0	I _{LI1}	$0.0 \le V_{IN} \le DV_{IN}$ $0.0 \le V_{IN} \le AV_{IN}$		-	0.02	±5	
age current	PK0	I _{LI2}	0.0 V ≤ V _{IN} ≤ 3.	6 V				
Output leakage	Except PK0	I _{LO1}	$0.2 \le V_{IN} \le DVI$ $0.2 \le V_{IN} \le AVI$		-	0.05	±10	μΑ
current PK0 I _{LO2}		I _{LO2}	0.2 V ≤ V _{IN} ≤ 3.4 V					
Pull-up resister at Reset		RRST	DVDD3 = 2.7 V	to 3.6 V	30	50	150	kΩ
Hysteresis vo	oltage	VTH	2.7 V ≤ DVDD3	≤ 3.6 V	0.3	0.6	-	V
Programmab	le pull-up/pull-down resistor	PKH	DVDD3 = 2.7 V	to 3.6 V	-	50	150	kΩ
Pin capacitan	nce (Except power supply pins)	C _{IO}	fc = 1 MHz		-	-	10	pF

Note 1: Ta = 25 °C, DVDD3 = RVDD3 = AVDD3 = 3.3 V, unless otherwise noted.

Note 2: The same voltage must be supplied to DVDD3, AVDD3, and RVDD3.

19.3 DC Electrical Characteristics (2/3)

DVDD3 = AVDD3 = RVDD3 = 2.7 V to 3.6 V, Ta = -20 to 85 °C

Parameter	Symbol	Condition	Min	Тур.	Max	Unit
	I _{OL}	Per pin	-	-	2	mA
Low-level output current	Σl _{OL1}	Per group GrL1 = 6, 58pin <pe3 pg3=""> GrL2 = 11 to 23pin <pe0 2="" 2,4="" 3="" 6="" pg0="" ph0="" to=""> GrL3 = 24 to 38pin <pa0,1 5="" 6="" pb0="" pf4="" pi0="" pj1="" pk0,1="" to=""> GrL4 = 41 to 57pin <pa2 2="" 3="" 4="" pj0,="" to=""></pa2></pa0,1></pe0></pe3>	-	-	_	mA
	Σl _{OL2}	Total	1	-	35	mA
	I _{OH}	Per pin	-	-	-2	mA
High-level output current	ΣI _{OH1}	Per group GrL1 = 6, 58pin <pe3 pg3=""> GrL2 = 11 to 23pin <pe0 2="" 2,4="" 3="" 6="" pg0="" ph0="" to=""> GrL3 = 24 to 38pin <pa0,1 5="" 6="" pb0="" pf4="" pi0="" pj1="" pk0,1="" to=""> GrL4 = 41 to 57pin <pa2 2="" 3="" 4="" pj0,="" to=""></pa2></pa0,1></pe0></pe3>	-	-	-18	mA
	ΣI _{OH2}	Total	18 PI0 to 5 / PJ1 352 2 / PH0 to 3>18 PI0 to 5 / PJ1	mA		

Note: The same voltage must be supplied to DVDD3, AVDD3, and RVDD3.

19.4 DC Electrical Characteristics (3/3)

DVDD3 = AVDD3 = RVDD3 = 2.7 V to 3.6 V, Ta = -20 to 85 °C

Parameter	Symbol	Condition	Min	Typ. (Note1)	Max	Unit
NORMAL (Note2) Gear 1/1		fsys = 40 MHz	-	26	32	
IDLE (Note3)		(f _{OSC} = 10 MHz)	-	8	12.5	mA
SLOW	I _{DD}	f 00 700 H.L.	-	2.5	5.5	
SLEEP		fs = 32.768 kHz	-	55	900	
STOP		-	-	45	850	μA

Note 1: Ta = 25 °C, DVDD3 = AVDD3 = RVDD3 = 3.3 V, unless otherwise noted.

Note 2: I_{DD} NORMAL: Measured with the dhrystone ver. 2.1 operated in FLASH. All functions operates excluding A/D.

Note 3: I_{DD} IDLE: Measured with all functions stopped.The currents flow through DVDD3, AVDD3 and RVDD3 are included.

19.5 10-bit ADC Electrical Characteristics

DVDD3 = AVDD3 = RVDD3 = VREFH = 2.7 V to 3.6 VAVSS = DVSS, Ta = -20 to 85 °C

					AVOC	S = DVSS, Ta =	-20 to 65 C
Para	meter	Symbol	Condition	Min	Тур.	Max	Unit
Analog reference	e voltage(+)	VREFH	-	2.7	3.3	3.6	V
Analog input vol	tage	VAIN	-	AVSS	-	VREFH	V
Power supply	AD conversion			-	2.5	5.5	mA
current of ana- log reference voltage	Non-AD con- version	IREF	DVSS = AVSS	-	±0.02	±5	μΑ
Supply current	AD conversion	-	Except IREF	-	-	3	mA
INL error	!			-	±2	±3	
DNL error			AIN resistance ≤ 600 Ω - AIN load capacitance ≤ 30 pF Conversion time ≥ 1.15 μs	-	±1	±2	
Offset error		_		-	±2	±4	
Full-scale error			30.170.010 timio = 1110 po	-	±2	±4	
INL error				-	±2	±3	
DNL error			AIN resistance ≤ 600 Ω	-	±1	±2	
Offset error		_	AIN load capacitance ≤ 0.1 μF Conversion time ≥ 1.15 μs	-	±2	±4	LSB
Full-scale error			30.170.010 timio = 1110 po	-	±2	±4	
INL error				ı	±2	±3	
DNL error Offset error			AIN resistance ≤ 10 kΩ	-	±1	±2	
		_	AIN load capacitance ≥ 0.1 μF Conversion time ≥ 2.30 μs	-	±2	±4	
Full-scale error			25	-	±2	±4	

Note 1: 1LSB = (VREFH - AVSS)/1024 [V]

Note 2: Peripheral functions are disable.

TMPM332FWUG

19.6 AC Electrical Characteristics

19.6.1 AC measurement condition

The AC characteristics data of this chapter is measured under the following conditions unless otherwise noted

- Output levels: High = $0.8 \times DVDD3$, Low = $0.2 \times DVDD3$
- Input levels: Refer to low-level input voltage and high-level input voltage in "DC Electrical Characteristics".
- Load capacity: CL = 30pF

19.6.2 Serial Channel (SIO/ UART)

19.6.2.1 I/O Interface mode

In the table below, the letter x represents the SIO operation clock cycle time which is identical to the fsys cycle time. It varies depending on the programming of the clock gear function.

(1) SCLK input mode

Davanastas	O:hl	Equation		40 1	MHz	l lait
Parameter	Symbol	Min	Max	Min	Max	Unit
SCLK Clock High width (input)	t _{SCH}	3x	-	75	-	
SCLK Clock Low width (input)	t _{SCL}	3x	-	75	-	
SCLK cycle	t _{SCY}	t _{SCH} + t _{SCL}	-	150	-	
Output Data ← SCLK rise or fall (Note 1)	toss	t _{SCY} /2 - 3x- 45	-	-45 (Note2)	-	
SCLK rise → Output Data hold or fall(Note1)	tons	t _{SCY} /2	_	75	_	ns
Valid Data input ← SCLK rise or fall(Note1)	t _{SRD}	30	_	30	_	
SCLK rise → Input Data hold or fall(Note1)	t _{HSR}	x + 30	-	55	_	


 $\label{eq:note-lattice} \mbox{Note 1: } \mbox{SCLK rise or fall } \mbox{\dots Measured relative to the programmed active edge of SCLK.}$

Note 2: Keep this value positive by adjusting SCLK cycle.

19.6 AC Electrical Characteristics

(2) SCLK output mode

Descriptor	Equation			40 1	11:4	
Parameter	Symbol	Min	Max	Min	Max	Unit
SCLK cycle (programmable)	t _{SCY}	4x	-	100	-	
Output Data ← SCLK rise	toss	t _{SCY} /2 - 20	-	30	-	
SCLK rise → Output hold Data hold	t _{OHS}	t _{SCY} /2 - 20	-	30	-	ns
Valid Data Input ← SCLK rise	t _{SRD}	45	-	45	-	
SCLK rise → Input Data hold	t _{HSR}	0	-	0	-	



19.6.3 Serial Bus Interface(I2C / SIO)

19.6.3.1 I2C Mode

In the table below, the letter x represents the I2C operation clock cycle time which is identical to the fsys cycle time. It varies depending on the programming of the clock gear function.

n denotes the value of n programmed into the SCK (SCL output frequency select) field in the SBIxCR.

Danamatan	O. mah al	Equ	ation	Standa	rd Mode	Fast	Mode	l lait
Parameter	Symbol	Min	Max	Min	Max	Min	Max	Unit
SCL clock frequency	t _{SCL}	0	-	0	100	0	400	kHz
Hold time for START condition	t _{HD; STA}	-	-	4.0	-	0.6	-	μs
SCL Low width (Input) (Note 1)	t _{LOW}	-	-	4.7	-	1.3	-	μs
SCL High width (Input) (Note 2)	t _{HIGH}	-	-	4.0	-	0.6	-	μs
Setup time for a repeated START condition	t _{SU; STA}	(Note5)	-	4.7	-	0.6	-	μs
Data hold time (Input) (Note 3, 4)	t _{HD; DAT}	-	-	0.0	-	0.0	-	μs
Data setup time	t _{SU; DAT}	-	-	250	-	100	-	ns
Setup time for a STOP condition	t _{SU; STO}	_	_	4.0	_	0.6	_	μs
Bus free time between stop condition and start condition	t _{BUF}	(Note5)	-	4.7	-	1.3	-	μs

Note 1: SCL clock Low width (output) = $(2^{n-1} + 58)/x$


Note 2: SCL clock High width (output) = (2ⁿ⁻¹ + 12)/x On I2C-bus specification, Maximum Speed of Standard Mode is 100kHz, Fast mode is 400khz. Internal SCL Frequency setting should comply with Note1 & Note2 shown above.

Note 3: The output data hold time is equal to 12x of internal SCL.

Note 4: The Philips I2C-bus specification states that a device must internally provide a hold time of at least 300 ns for the SDA signal to bridge the undefined region of the falling edge of SCL. However, this SBI does not satisfy this requirement. Also, the output buffer for SCL does not incorporate slope control of the falling edges; therefore, the equipment manufacturer should design so that the input data hold time shown in the table is satisfied, including tr/tf of the SCL and SDA lines.

Note 5: Software -dependent

Note 6: The Philips I2C-bus specification instructs that if the power supply to a Fast-mode device is switched off, the SDA and SCL I/O pins must be floating so that they don't obstruct the bus lines. However, this SBI does not satisfy this requirement.



S: Start condition

Sr: Repeated start condition

P: Stop condition

19.6.3.2 Clock-Synchronous 8-Bit SIO mode

In the table below, the letter x represents the I2C operation clock cycle time which is identical to the fsys cycle time. It varies depending on the programming of the clock gear function.


(1) SCK Input Mode (The electrical specifications below are for an SCK signal with a 50% duty cycle.)

Descriptor	O. mah al	Equation	_	40 I	MHz	l lmit
Parameter	Symbol	Min	Max	Min	Max	Unit
SCK Clock High width (input)	t _{SCH}	4x	-	100	-	
SCK Clock Low width (input)	t _{SCL}	4x	-	100	-	
SCK cycle	t _{SCY}	t _{SCH} + t _{SCL}	-	200	-	
Output Data ← SCK rise	toss	t _{SCY} /2 - 3x - 45	-	-20 (Note)	-	ns
SCK rise → Output Data hold	t _{OHS}	t _{SCY} /2 + x	-	125	-	
Valid Data input ← SCK rise	t _{SRD}	30 - x	_	5	_	
SCK rise → Input Data hold	t _{HSR}	30	-	30	-	

Note: Keep this value positive by adjusting SCK cycle.

(2) SCK Output Mode (The electrical specifications below are for an SCK signal with a 50% duty cycle.)

Denomotor	O. mah ad	Equation		40 [MHz	l lmit	
Parameter	Symbol	Min. Max		Min.	Max	Unit	
SCK cycle (programmable)	t _{SCY}	16x	-	400	-		
Output Data ← SCK rise	toss	t _{SCY} /2 - 20	-	180	-		
SCK rise → Output Data hold	t _{OHS}	t _{SCY} /2 - 20	-	180	-	ns	
Valid Data input ← SCK rise	t _{SRD}	45	-	45	-		
SCK rise → Input Data hold	t _{HSR}	0	-	0	-		



19.6.4 Event Counter

In the table below, the letter x represents the TMRB operation clock cycle time which is identical to the fsys cycle time. It varies depending on the programming of the clock gear function.

Parameter	O. make al	Equation		40 [40 MHz	
	Symbol	Min	Max	Min	Max	Unit
Clock Low pulse width	t _{VCKL}	2x + 100	-	150	-	ns
Clock High pulse width	tvckh	2x + 100	-	150	-	ns

19.6.5 Capture

In the table below, the letter x represents the TMRB operation clock cycle time which is identical to the fsys cycle time. It varies depending on the programming of the clock gear function.

Parameter	O. make al	Equation		40	ИНz	1.1
	Symbol	Min	Max	Min	Max	Unit
Low pulse width	t _{CPL}	2x + 100	-	150	-	ns
High pulse width	t _{CPH}	2x + 100	-	150	-	ns

19.6.6 External Interrupt

In the table below, the letter x represents the fsys cycle time.

1. Except STOP release interrupts

Deservator	O. mak al	Equation	!	40 I	MHz	l lait
Parameter Syn	Symbol	Min	Max	Min	Max	Unit
INT0 to 4 low level pulse width	t _{INTAL}	x + 100	-	125	-	ns
INT0 to 4 high level pulse width	t _{INTAH}	x + 100	-	125	-	ns

2. STOP release interrupts

Parameter	Symbol	Min	Max	Unit
INT0 to 4 low level pulse width	t _{INTBL}	125	-	ns
INT0 to 4 high level pulse width	t _{INTBH}	125	-	ns

19.6.7 NMI


Parameter	Symbol	Min	Max	Unit
NIM low level pulse width	t _{INTCL}	100	-	ns

19.6 AC Electrical Characteristics

19.6.8 SCOUT Pin AC Characteristic


Parameter	Equation		40 1	l lait		
Parameter	Symbol	Min	Max	Min	Max	Unit
High pulse width	t _{SCH}	0.5T - 5	-	7.5	-	ns
Low pulse width	t _{SCL}	0.5T - 5	-	7.5	-	ns

Note: In the above table, the letter T represents the cycle time of the SCOUT output clock.




19.6.9 Debug Communication

	1	1		
Parameter	Symbol	Min	Max	Unit
CLK cycle	T _{dck}	83.33	-	ns
CLK rise → Output data hold	T _{d1}	4	1	ns
CLK rise → Output data valid	T _{d2}	-	30	ns
Input data valid ←CLK rise	T _{ds}	20	-	ns
CLK rise → Input data hold	T _{dh}	15	-	ns



19.6.10 ETM Trace

Parameter	Symbol	Min	Max	Unit
TRACECLK cycle	t _{tclk}	50	-	ns
TRACEDATA valid ← TRACECLK rise	t _{setupr}	2	-	ns
TRACECLK rise → TRACEDATA hold	t _{holdr}	1	-	ns
TRACEDATA valid ← TRACECLK fall	t _{setupf}	2	-	ns
TRACECLK fall → TRACEDATA hold	t _{holdf}	1	-	ns



19.7 Flash Characteristics

19.7.1 Rewriting

Parameter	Condition	Min	Тур.	Max	Unit
Guarantee on	DVDD3 = AVDD3 = RVDD3 = 2.7 V to 3.6 V			400	Ti
Flash-memory rewriting	Ta = 0 to 70 °C	_	_	100	Times

19.8 Recommended Oscillation Circuit




Figure 19-1 High-frequency oscillation connection

Note: To obtain a stable oscillation, load capacity and the position of the oscillator must be configured properly. Since these factors are strongly affected by substratepatterns, please evaluate oscillation stability using the substrate you use.

The TX03 has been evaluated by the oscillator vender below. Please refer this information when selecting external parts

19.8.1 Ceramic oscillator

The TX03 recommends the high-frequency oscillator by Murata Manufacturing Co., Ltd.

Please refer to the following URL for details.

http://www.murata.co.jp

19.8.2 Crystal oscillator

The TX03 recommends the high-frequency oscillator by KYOCERA KINSEKI Corporation.

Please refer to the following URL for details.

http://www.kinseki.co.jp

19.9 Handling Precaution

19.9.1 Solderability

Test parameter	Test condition	Note	
Solderability	Use of Sn-37Pb solder Bath Solder bath temperature = 230°C, Dipping time = 5 seconds The number of times = one, Use of R-type flux	Pass:	
	Use of Sn-3.0Ag-0.5Cu solder bath Solder bath temperature = 245°C, Dipping time = 5 seconds The number of times = one, Use of R-type flux	solderability rate until forming ≥ 95%	

19.9.2 Power-on sequence

The power supply must be raised (from 0V to 2.7V) at a speed of 0.37ms/V or slower. The power-on sequence must consider the time for the internal regulator and oscillator to be stable. In the TX03, the internal regulator requires at least 700 μ s to be stable.

The time required to achieve stable oscillation varies with system. At cold reset, the external reset pin must be kept "Low" for a duration of time sufficiently long enough for the internal regulator and oscillator to be stable.

Figure 19-2 shows the power-on sequence.




Figure 19-2 Power-on sequence

19. Electrical Characteristics


19.9 Handling Precaution TMPM332FWUG

20. Port Section Equivalent Circuit Schematic


Basically, the gate symbols written are the same as those used for the standard CMOS logic IC [74HCXX] series.

The input protection resistance ranges from several tens of Ω to several hundreds of Ω . Damping resistors X2 and XT2 are shown with a typical value.


20.1 PA0, PE1 to 3, PE5 to 6, PF4 to 6, PG0 to 3, PH0 to 3, PJ0 to 3




20.2 PA1




20.3 PA2 to 3, PB0, PE0, PE4, PI0 to 5, PJ4, PK1



20.4 PD4 to 7




20.5 PD0 to 3



TOSHIBA


20.6 PK0



20.7 NMI, MODE




20.8 RESET




20.9 X1, X2 TMPM332FWUG


20.9 X1, X2



20.10 XT1, XT2



20.11 VREFH, AVSS




TOSHIBA TMPM332FWUG


21. Package Dimensions

Type:LQFP64-P-1010-0.50E


Dimensions







Pin detail



RESTRICTIONS ON PRODUCT USE

- Toshiba Corporation, and its subsidiaries and affiliates (collectively "TOSHIBA"), reserve the right to make changes to the information in this document, and related hardware, software and systems (collectively "Product") without notice.
- This document and any information herein may not be reproduced without prior written permission from TOSHIBA. Even with TOSHIBA's written permission, reproduction is permissible only if reproduction is without alteration/omission.
- Though TOSHIBA works continually to improve Product's quality and reliability, Product can malfunction or fail. Customers are responsible for complying with safety standards and for providing adequate designs and safeguards for their hardware, software and systems which minimize risk and avoid situations in which a malfunction or failure of Product could cause loss of human life, bodily injury or damage to property, including data loss or corruption. Before customers use the Product, create designs including the Product, or incorporate the Product into their own applications, customers must also refer to and comply with (a) the latest versions of all relevant TOSHIBA information, including without limitation, this document, the specifications, the data sheets and application notes for Product and the precautions and conditions set forth in the "TOSHIBA Semiconductor Reliability Handbook" and (b) the instructions for the application with which the Product will be used with or for. Customers are solely responsible for all aspects of their own product design or applications, including but not limited to (a) determining the appropriateness of the use of this Product in such design or applications; (b) evaluating and determining the applicability of any information contained in this document, or in charts, diagrams, programs, algorithms, sample application circuits, or any other referenced documents; and (c) validating all operating parameters for such designs and applications. TOSHIBA ASSUMES NO LIABILITY FOR CUSTOMERS' PRODUCT DESIGN OR APPLICATIONS.
- Product is intended for use in general electronics applications (e.g., computers, personal equipment, office equipment, measuring equipment, industrial robots and home electronics appliances) or for specific applications as expressly stated in this document.
 Product is neither intended nor warranted for use in equipment or systems that require extraordinarily high levels of quality and/or reliability and/or a malfunction or failure of which may cause loss of human life, bodily injury, serious property damage or serious public impact ("Unintended Use"). Unintended Use includes, without limitation, equipment used in nuclear facilities, equipment used in the aerospace industry, medical equipment, equipment used for automobiles, trains, ships and other transportation, traffic signaling equipment, equipment used to control combustions or explosions, safety devices, elevators and escalators, devices related to electric power, and equipment used in finance-related fields.
 Do not use Product for Unintended Use unless specifically permitted in this document.
- Do not disassemble, analyze, reverse-engineer, alter, modify, translate or copy Product, whether in whole or in part.
- Product shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable laws or regulations.
- The information contained herein is presented only as guidance for Product use. No responsibility is assumed by TOSHIBA for any infringement of patents or any other intellectual property rights of third parties that may result from the use of Product. No license to any intellectual property right is granted by this document, whether express or implied, by estoppel or otherwise.
- ABSENT A WRITTEN SIGNED AGREEMENT, EXCEPT AS PROVIDED IN THE RELEVANT TERMS AND CONDITIONS
 OF SALE FOR PRODUCT, AND TO THE MAXIMUM EXTENT ALLOWABLE BY LAW, TOSHIBA (1) ASSUMES NO
 LIABILITY WHATSOEVER, INCLUDING WITHOUT LIMITATION, INDIRECT, CONSEQUENTIAL, SPECIAL, OR
 INCIDENTAL DAMAGES OR LOSS, INCLUDING WITHOUT LIMITATION, LOSS OF PROFITS, LOSS OF
 OPPORTUNITIES, BUSINESS INTERRUPTION AND LOSS OF DATA, AND (2) DISCLAIMS ANY AND ALL EXPRESS
 OR IMPLIED WARRANTIES AND CONDITIONS RELATED TO SALE, USE OF PRODUCT, OR INFORMATION,
 INCLUDING WARRANTIES OR CONDITIONS OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE,
 ACCURACY OF INFORMATION, OR NONINFRINGEMENT.
- Do not use or otherwise make available Product or related software or technology for any military purposes, including
 without limitation, for the design, development, use, stockpiling or manufacturing of nuclear, chemical, or biological
 weapons or missile technology products (mass destruction weapons). Product and related software and technology
 may be controlled under the Japanese Foreign Exchange and Foreign Trade Law and the U.S. Export Administration
 Regulations. Export and re-export of Product or related software or technology are strictly prohibited except in compliance
 with all applicable export laws and regulations.
- Please contact your TOSHIBA sales representative for details as to environmental matters such as the RoHS compatibility of Product. Please use Product in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. TOSHIBA assumes no liability for damages or losses occurring as a result of noncompliance with applicable laws and regulations.

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for ARM Microcontrollers - MCU category:

Click to view products by Toshiba manufacturer:

Other Similar products are found below:

R7FS3A77C2A01CLK#AC1 CP8363AT MB96F119RBPMC-GSE1 MB9BF122LPMC1-G-JNE2 MB9BF122LPMC-G-JNE2 MB9BF128SAPMC-GE2 MB9BF218TBGL-GE1 MB9BF529TBGL-GE1 26-21/R6C-AT1V2B/CT 5962-8506403MQA MB9AF342MAPMC-G-JNE2 MB96F001YBPMC1-GSE1 MB9BF121KPMC-G-JNE2 VA10800-D000003PCA CP8547AT CY9AF156NPMC-G-JNE2 MB9BF104NAPMC-G-JNE1 CY8C4724FNI-S402T ADUCM410BCBZ-RL7 ADUCM410BBCZ-RL7 GD32f303RGT6 NHS3152UK/A1Z MK26FN2M0CAC18R EFM32TG230F32-D-QFN64 EFM32TG232F32-D-QFP64 EFM32TG825F32-D-BGA48 MB9AFB44NBBGL-GE1 MB9BF304RBPMC-G-JNE2 MB9BF416RPMC-G-JNE2 MB9AF155MABGL-GE1 MB9BF306RBPMC-G-JNE2 MB9BF618TBGL-GE1 MK20DX64VFT5 MK50DX128CMC7 MK51DN256CMD10 MK51DX128CMC7 MK53DX256CMD10 MKL25Z32VFT4 MKL25Z64VFT4 LPC1754FBD80 STM32F030K6T6TR STM32L073VBT6 AT91M42800A-33AU AT91SAM7L64-CU ATSAM3N0AA-MU ATSAM3N0CA-CU ATSAM3SD8BA-MU ATSAM4LC2BA-UUR ATSAM4LC4BA-MU ATSAM4LS2AA-MU