


KitchenAid® COOKTOP PARTS

For Models: KESA907PBL00, KESA907PWW00, KESA907PBB00, KESA907PSS00
(Black) (Pure White) (Pure Biscuit) (S.Steel)

30" SLIDE-IN
ELECTRIC OVEN
CONVECTION



Illus. No.	Part No.	DESCRIPTION
1	9757446	Literature Parts Installation Instructions
	9757451	Use & Care Guide
	9757662	Tech Sheet
	9757680	Anti-Tip Instruct.
	3191638	Safe Cooking Tips
2	8523739	Light, Indicator
3	4454023	Bracket, Mounting
	3179776	Screw
4		Cooktop
	9759748BT	Biscuit
	9759748WH	White
	9759748BL	Black
	9759748SS	S.Steel
	9756450	Gasket
5	4453764	Clip, Ceran (2)
	3179776	Screw


Illus. No.	Part No.	DESCRIPTION
6		Trim-CkTop, SI
	4453875WH	White LH
	4453875BT	Biscuit LH
	4453875BL	Black LH
	4453875SS	S.Steel LH
	4453870WH	White RH
	4453870BT	Biscuit RH
	4453870BL	Black RH
	4453870SS	S.Steel RH
	3179776	Screw
8	9756929	Light, Indicator
9		Support
	9757686	L.Hand
	9757687	R.Hand
10	9756821	Support, Wiring
	4449809	Screw (2)
12		Element, Surface
	8203525	1800/1000W LR
	8523696	1800W RF
	4453909	2500/1000W (2) LF and RR

Illus. No.	Part No.	DESCRIPTION
13	9757800	Bracket, Front Support
	3179776	Screw (4)
16	9751984	Bi-Metal
	3196160	Screw (2)
17	9758799	Bracket, Ind. Lamp
	3196160	Screw (2)
18		Trim. Cooktop Rear
	4453865BL	Black
	4453865WH	White
	4453865BT	Biscuit
	4453865SS	S.Steel
	3196160	Screw
19	3191791	Spring, Locator
20	9757802	Bracket, Rear Sprt
	3179776	Screw (4)
21	9756813	Rail, Element (2)
	3179776	Screw (4)
22	3179776	Screw
23	9759626	Cover, Cktp Rear
	3179776	Screw (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: KESA907PBL00, KESA907PWW00, KESA907PBB00, KESA907PSS00
 (Black) (Pure White) (Pure Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1	4453826WH	Control Panel White
	4453826BT	Biscuit
	4453826BL	Black
	4453826SS	S.Steel
2	9756595WH	Membrane Switch White
	9756595BT	Biscuit
	9756595BL	Black
	9756595ES	Etched Stainless
	3400832	Screw
3	9759565	Control, Interface
	9780271	Screw
4	9757119	Bracket, Console
	3179776	Screw (3)
5	3196068	Lens, Ind. (2)


Illus. No.	Part No.	DESCRIPTION
6	9757787	Bracket, User Interface
7	9759781	Switch, Infinite RF
	9759782	LF,RR,LR
8	4453726BT	Endcap Biscuit LH
	4453726WH	White LH
	4453726BL	Black LH
	4453726CM	S.Steel
	4453727BT	Biscuit RH
	4453727WH	White RH
	4453727BL	Black RH
	4453727CM	S.Steel
	3196172	Screw

Illus. No.	Part No.	DESCRIPTION
9	9756943	Knob Black
	9756941	White
	9756942	Biscuit
	9756944	Cashmere Metal
10	9757730BL	Nameplate Black
	9757730BT	Biscuit
	9757730WH	White
	4453107	Nut

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: KESA907PBL00, KESA907PWW00, KESA907PBB00, KESA907PSS00
(Black) (Pure White) (Pure Biscuit) (S.Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS


For Models: KESA907PBL00, KESA907PWW00, KESA907PBB00, KESA907PSS00
 (Black) (Pure White) (Pure Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Trim, Side (Right Hand)	15	4455382	Gasket, Door	32	9759561	Central, Appliance
	9756619WH	White	16	4453951	Deflector, Vent Bottom	37	4452223	Thermostat (TOD) Manager
	9756619BT	Biscuit	17	4452152	Bracket, Mounting		3179776	Screw (Temp.) SPST
	9756619BL	Black	19	4451478	Support, Insulation	43	9759713	Base, Chassis
	9756619SS	S.Steel (Left Hand)		4449809	Screw	49	4448933	Retainer, Gasket
	9756620WH	White	20		Body, Side		4449154	Screw
	9756620BT	Biscuit		9781907PB	Black	50	4451747	Cover, Back
	9756620BL	Black		9781907PC	Biscuit		4449809	Screw
	9756620SS	S.Steel		9781907PW	White	54		Vent, Bottom Upper
	3400832	Screw	22	8302474	Latch, Motorized		9756481WH	White
3		Hinge Receiver		4449154	Screw		9756481BT	Biscuit
	4455605	Left Hand	23	341196	Thermostat SPST (205)		9756481BL	Black
	4455606	Right Hand	25	4455641	Side, Chassis (R.H. & L.H.)		9756481SS	S.Steel
4	4448520	Bumper, Door		4449809	Screw	55		Trim, Btm Vent
7	4455865	Top Chassis	26	9759761	Back, Chassis		9756485WH	White
	4449809	Screw		4449809	Screw		9756485BT	Biscuit
9	4452158	Tube, Vent	27		Liner, Oven (Not serviceable)		9756485BL	Black
	3196176	Screw	29	4455636	Sensor		9756485SS	S.Steel
10	4452165	Lens, Light		4449154	Screw	FOLLOWING PARTS NOT ILLUSTRATED		
11	4452368	Oven Light Assy	30	9756454	Bracket, GOC	INSULATION		
12	4452166	Bulb, Light		4449809	Screw		9756817	Insulation, Wrap
13	9757732	Shield, Heat	31	9756452	Slide. GOC		9756470	Insulation, Back
	4449743	Screw (4)		3179776	Screw			
14	4455612	Frame, Front						
	4449040	Screw						
	4450118	Nut						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS

For Models: KESA907PBL00, KESA907PWW00, KESA907PBB00, KESA907PSS00
(Black) (Pure White) (Pure Biscuit) (S.Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS


For Models: KESA907PBL00, KESA907PWW00, KESA907PBB00, KESA907PSS00
 (Black) (Pure White) (Pure Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION
5		Glass, Door Front
	9757102BL	Black
	9757102WH	White
	9757102BT	Biscuit
	9757102SS	S.Steel
8		Handle, Door
	9756833BL	Black
	9756833WH	White
	9756833BT	Biscuit
	9756833OG	S.Steel
9	8302094	Bracket, Central
10		Hinge, Door
	8300579	Orange
	8300580	Orange
	4449743	Screw
11	312701	Foot, Rear
12	8302092	Bracket, Side
13	8274149	Sensor
	3196537	Screw
14	8054056	Element, Warming
	4449809	Screw
15	9757706	Glass, Inner
16	4457114	Shield, Heat Btm
17	4449263	Glass, Inner (2)
18	4451722	Insulation, Door
19	4455618	Liner, Door
20	9757805	Drawer & Roller
21	3196037	Foot, Front
	4449743	Screw
22	9757796	Panel, Drawer
23	9759743	Retainer, Door
24		Front, Drawer
	4453799WH	White
	4453799BL	Black
	4453799BT	Biscuit
	4453799SS	S.Steel
	3196168	Screw
25		Bracket, Handle
	8301837	R.Hand
	8301838	L.Hand
	8533988	Screw
26		Handle, Drawer
	9756952WH	White
	9756952BT	Biscuit
	9756952BL	Black
	9756952CM	S.Steel
32		Guide, Roller
	4453719	R.Hand
	4453718	L.Hand
33	9757707	Shield, Heat Top

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: KESA907PBL00, KESA907PWW00, KESA907PBB00, KESA907PSS00
(Black) (Pure White) (Pure Biscuit) (S.Steel)




Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

1	4451583	Motor, Convection
2	8301514	Element, Broil
	4449154	Screw
3	4457277	Grill, Broiler
4	4457276	Pan, Broiler
5	3181534	Rack, Roasting
6	4448717	Rack, Oven
7	4452155	Element, Bake
	4449154	Screw
8	4451355	Probe, Meat
9	4452157	Element, Convect.
	4449154	Screw
10	9756690	Cover, Fan
	4449154	Screw
11	4455037	Tray, Hidden Bake
12	4450039	Cover, Bake Tray
13	4448948	Probe, Meat
14	4445552	Washer, Lock
15	4448881	Nut, Hex

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: KESA907PBL00, KESA907PWW00, KESA907PBB00, KESA907PSS00
 (Black) (Pure White) (Pure Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust	7	9759883	Bracket, Term.Box	12	9757405	Cover, Term Box
	4449040	Screw, 8-18 x 3/8		4449809	Screw (2)		3196160	Screw (2)
2	4455178	Elbow, Vent Top	8	9757404	Box, Terminal	13	9757118BL	Vent, (Control Panel)
3	8300223	Blower		4449809	Screw (3)		4450038	Screw
	4455352	Bracket	9	9759721	Insulator, Term Box	14	9757829	Bracket, Transfrm
	4449809	Screw (4)	10	9757136	Block, Terminal		4449809	Screw
4	4451758	Block, Foam	11	4449868	Block, Terminal	15	9756551	Transformer
5	4455177	Elbow, Vent Bottom		3400080	Screw		4449809	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: KESA907PBL00, KESA907PWW00, KESA907PBB00, KESA907PSS00
 (Black) (Pure White) (Pure Biscuit) (S.Steel)

Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION
<p><u>PAINT, TOUCH-UP (1/2oz.)</u></p> <p>72017 White 261869 Cord Brown 72032 Black</p> <p><u>PAINT, SPRAY</u></p> <p>350930 White 261900 Citrine White 830864 Black</p> <p><u>ADHESIVE</u></p> <p>591014 Adhesive Loctite (1/3 oz.) 482338 Sealer, Silastic (3 oz.)</p>	<p><u>SPLICING WIRES--25FT.</u></p> <p><u>LENGTH</u></p> <p>242828 Wire (12 Ga. 150 c Black) 242820 Wire (14 Ga. 150 c Black) 242821 Wire (14 Ga. 150 c Blue) 242822 Wire (14 Ga. 150 c Brown) 242830 Wire (14 Ga. 200 c Brown) 242823 Wire (14 Ga. 150 c Green) 242824 Wire (14 Ga. 150 c Orange) 242829 Wire (12 Ga. 150 c Red) 242825 Wire (14 Ga. 150 c Red) 242831 Wire (14 Ga. 200 c Red) 242826 Wire (14 Ga. 150 c White) 242827 Wire (14 Ga. 150 c Yellow) 242832 Wire (14 Ga. 200 c Yellow)</p>	<p><u>WIRING HARNESS PARTS</u></p> <p>9759791 Harness, Wire (Main) 9759793 Harness, Wire (Switch, Elec) 9759795 Harness, Main Smart, Knob 9759796 Harness, Wire (Left) 9759797 Harness, Wire (Right) 9759855 Harness, APSSC Smart Knob 9756554 Harness, Comm. 9759715 Conduit 313660 Clip, Ground Wire 4448664 Clamp 4449809 Screw 112432 Nut 4450800 Screw, Ground 4452222 Spacer, Harness 3400015 Screw, Ground</p> <p><u>Miscellaneous</u></p> <p>814381 Hinge Pin Kit 4448950 Screw, Install (4) 9782676 Anit-Tip Assy Filler,Counter Top 9757785WH White 9757785BL Black 9757785BT Biscuit</p>

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for [WHIRLPOOL](#) manufacturer:

Other Similar products are found below :

[W10859086](#) [W10920627](#) [WPW10006355](#) [W10837029](#) [WP12918704](#) [13042603](#) [WPW10558463](#) [WPW10306546](#) [WPW10446920](#)
[WH17X20599](#) [WP9761694](#) [W10830982](#) [W11050487](#) [WP3149400](#) [WP8312709](#) [WPW10475495](#) [WP67006315](#) [WPW11097831](#) [W11117429](#)
[WP67001721](#) [WP90016](#) [WPW10279615](#) [WB07X24882](#) [WPW10318952](#) [WPW10318953](#) [WP2309758](#) [W11230488](#) [WR32X27438](#)
[WR71X27933](#) [WPW10254672](#) [WPW10183368](#) [W10854969](#) [279816](#) [131658800](#) [WPW11109500](#) [WP67001722](#) [W10465771](#) [WH16X24095](#)
[WH16X26912](#) [WH16X26913](#) [WB07X24881](#) [WPW10208250](#) [W11243996](#) [W11050804](#) [WR02X27445](#) [814399](#) [WP3390631](#) [WP3392519](#)
[W10823692](#) [WZ4X241D](#)