



Out of Liquid Evaluation Kit Thermal Mass Flow Evaluation Kit Only for evaluation purposes










Benefits & Characteristics

- Single supply 5 $V_{\rm DC}$
- Suitable for aggressive liquids

- No contact between sensor and liquid
- Adjustable by customer

Illustration¹⁾



1) For actual size, see dimensions

Technical Data

Tube dimensions (L x $\varnothing_{\text{OUTER}}$ x ($\varnothing_{\text{INNER}}$) in mm):	40 x 4 x (3.8)
PCB dimensions (L x W x H in mm):	25 x 58 x 12
Operating measuring range:	0 ml/min to 3000 ml/min (4 m/s)
Response time (t_{90}) :	< 300 ms (at step from 0 to 1000 ml/min)
Warm up time:	< 30 s
Connection (PCB to tube):	Cu/Ag-wire, PTFE insulated, AWG 30/19, 50 mm
Heater:	$R_{H}(0 \text{ °C}) = 50 \Omega \pm 1 \%$
Temperature sensor:	$R_s(0 ^{\circ}C) = 1000 \Omega \pm 1 \%$
Connection (module):	Screw terminal
Supply voltage:	5 V _{DC} ±5 %
Current consumption:	1.5 A (maximal)
Analogue output, non linear	$0 V_{DC}$ to $< 5.0 V_{DC}$
Tube material:	Stainless steel






Out of Liquid Evaluation Kit Thermal Mass Flow Evaluation Kit Only for evaluation purposes





Adjustement Procedure (if necessary)





J1		
Pin 1	Pin 2	
$V_{DD} = 5.0 V_{DC}$ (regulated) minimum 1.5 A	GND	

J2			
Pin 1	Pin 2	Pin 3	Pin 4
GND	analog out (non-linear flow signal 0 to $< 5 V_{DC}$)	W	

- 1. power up the module
- 2. start pump to fill up the system (tube) with liquid
- 3. wait until output signal is stable (about 30 s)
- 4. adjust potentiometer R1 to a heater voltage of about 8 to 10 V_{DC} at TP1
- 5. apply a known flow (for example 200 ml/min)
- 6. measure analog output voltage at J2 Pin2 (should be in the range of 2.0 to 2.5 V_{DC} at 200 ml/min)
- 7. adjust R1 for desired output voltage
- 8. stop flow
- 9. check if analog output voltage at J2 Pin2 is $< 0.1 V_{DC}$
- 10. if not, push the offset buttons repeatedly to adjust output voltage and LED's so only the green LED is ON and voltage is below 0.1 V_{DC}
- 11. apply flow again and check output voltage
- 12. this output signal is the non-linearized flow signal






Out of Liquid Evaluation Kit Thermal Mass Flow Evaluation Kit Only for evaluation purposes





Typical Flow Curve (water)





Order Information

	OOL Demo Unit V2.0	
Order code	160.00005	
	P1K0/050.232.2K.C.050.M.U.S	
Order code	310.00819	

Additional Documents

Datasheet: DFOOL_E





INNOVATIVE SENSOR TECHNOLOGY

Innovative Sensor Technology IST AG, Stegrütistrasse 14, CH-9642 Ebnat-Kappel, Switzerland, Phone: +41 (0) 71 992 01 00 | Fax: +41 (0) 71 992 01 99 | E-mail: info@ist-ag.com | Web: www.ist-ag.com

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for ist innovative sensor manufacturer:

Other Similar products are found below:

TSIC 301 TO92 P0K1.202.3K.A.010 P14 FEMTOCAP-G P0K1.281.6W.B.007 P0K1.520.6W.Y.010 P0K1.161.1E.B.200 TSIC 306 SOP-8 P1K0.308.7W.B.007 P0K1.516.7W.B.010 TSIC 306 TO92 P1K0.232.6W.B.010 P0K1.232.3FW.A.010.M.U P1K0.520.6W.B.010 P0K1.161.6W.B.010 P1K0.161.6W.A.010 HYT 221 P1K0.1206.2P.B P0K1.232.6W.A.010 P10K.520.6W.B.010.D P1K0.0805.2P.B P1K0.1206.2P.A P0K1.0805.2P.B P0K1.1206.2P.B