

# **CRC CRICK 120**

## Penetrant for non-destructive testing

Ref.: 10878

### 1. GENERAL DESCRIPTION

A red-colored liquid penetrant for the non-destructive testing of surfaces and structures. Many cracks in engineering materials can be deep in spite of having a very small opening width on the surface and can cause very serious defects. By normal visual inspection such cracks may be very difficult to detect, but penetrant flaw detection is an extension of the visual inspection method. The control is carried out using 3 products: CRC Crick 110 (cleaner), CRC Crick 120 (penetrant) and CRC Crick 130 (developer). CRC Crick 120 is a water washable liquid penetrant visible with natural white light. Based on special hydrocarbons, with high boiling point, surfactants, corrosion inhibitors and dyes.

#### 2. FEATURES

- The check can be carried out with ready-to-use aerosols.
- It produces results in a speedy and easy way.
- An economical technology with no need for expensive and advanced equipment.
- A sensitive and reliable test method.
- Widely applicable, regardless the nature of the materials and shape of the objects.
- The aerosol uses a hydrocarbon propellant for controlled application.
- Certifications: ASME Section V, art 6.

#### 3. APPLICATIONS

Non-destructive inspection of materials, parts, assemblies, equipment, surfaces or structures:

- Cracks, lack of fusion and open cavities in welded parts.
- Cracks and cavities caused by metal fatigue and cutting operations.
- Check of porosity or leaks in pipes, tanks, boilers, heat exchangers.
- Discontinuities, laps, folds and cracks in castings, forgings and ceramics.

#### 4. DIRECTIONS

Do not use at ambient temperatures below 10°C.

- In liquid penetrant inspections, the test object or material is coated with a visible dye solution. The excess dye is removed from the surface and a developer is then applied. The developer acts like a blotter and draws penetrant out of the imperfections of the surface. With visible dyes, the vivid color contrast between the penetrant and the developer makes the 'bleed-out' easy to see.
- Cleaning of the surface

The surface to be checked must be clean, degreased and dry. All soil, like rust, oil, grease, paint etc, which can mask the imperfections, must be removed. Finish the cleaning by spraying CRC Crick 110 generously. If possible wipe with an absorbent cloth and allow drying thoroughly.









## **CRC CRICK 120**

# Penetrant for non-destructive testing

Ref.: 10878

# • Penetrant application

Shake the can of CRC Crick 120 prior to use. Spray the penetrant in a light, even film on the surface, wetting all areas to be controlled. Allow to drain for 10 to 20 minutes.

## Excess penetrant removal

Remove excess of penetrant by wiping the surface using a lint-free cloth. Apply water (CRC Crick 120 is water washable) until all visible, coloured traces are removed. Care must be taken that only disturbing penetrant on the surface is removed. Dry properly.

## Development

Shake the can of CRC Crick 130 thoroughly prior to use. Spray a light, homogeneous coat of developer from a distance of about 20 cm. Avoid any excess developer to avoid masking the finest flaws. Allow to develop for at least 7 minutes so that imperfections are visible.

# Visual inspection of defects

As time passes, the defects will appear as red spots or lines on a white background. The speed of appearance, the shape and dimensions can give information about the nature of the defects. Post-clean the controlled surface and protect against corrosion with one of CRC's corrosion protection products.

A safety data sheet (MSDS) according to EC Regulation N° 1907/2006 Art.31 and amendments is available for all CRC products.

# 5. TYPICAL PRODUCT DATA (without propellant)

Appearance : red liquid
Odor : solvent
Specific gravity (@ 20°C) : 0,816
Boiling range (solvent) : 180 - 250°C
Flash point liquid : > 70°C
Auto-ignition temperature : > 200°C
Solubility in water : water washable

6. PACKAGING

aerosol: 12 x 500 ml

All statements in this publication are based on service experience and/or laboratory testing. Because of the wide variety of equipment and conditions and the unpredictable human factors involved, we recommend that our products be tested on-the-job prior to use. When used on certain magnesium alloys, light discoloration might occur after extremely prolonged contact time with CRICK 120. All information is given in good faith but without warranty neither expressed nor implied.

This Technical Data Sheet may already have been revised at this moment for reason such as legislation, availability of components and newly acquired experiences. The latest and only valid version of this Technical Data Sheet will be sent to you upon simple request or can be found on our website: <a href="www.crcind.com">www.crcind.com</a>. We recommend you to register on this website for this product so you will be able to receive any future updated version automatically.

Version : 10878 03 0702 08 Date : 24 December 2008



Manufactured by:





# **X-ON Electronics**

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Chemicals category:

Click to view products by CRC manufacturer:

Other Similar products are found below:

HANDPAD 1624-10S 3045-QT 3065-15S 3125-9S 5200-WHITE-3OZ 70008073302 1398159-1 S1255-04-34X100FT 3748-Q-58"x8" FO25DT 13844 S1009-KIT-A-CS8606 8361-P 2216-GRAY-2OZ DP100-200ML 1743-2FP 2310-10 VERSIL406 826-450G SS4120-1P
3789-Q 9729 9223 9176 600-0510 3748PG 04952-00531-00 04952-00533-00 10-50L 3748-Q-5/8"X8" 3764-TC 3M 9087 3M 9088
AS1700 120-320 BLR-15ML HYBRICX 35C 7552 7558 3748-V-O-Q-5/8"X8" 3764-Q 3779-TC 3797TC 3M 9086 100500F00000G
101800F00000G 1610-5G 1610-G4 1621-5G