


1544 Soldering Flux Activated Rosin Liquid Flux

Product Description

Kester 1544 Activated Rosin Liquid Flux is a homogeneous solution of high quality, purified Grade WW rosin blended into an alcohol solvent system. A very effective activating agent has been added to provide superior fluxing ability. 1544 is a liquid equivalent of Kester 44 Activated Rosin Core Solder. The desired flux activity and the amount of rosin residue are determined by the concentration (solids percentage) of the flux.1544 has been developed for fluxing applications where non-activated and mildly activated rosin fluxes are too inactive to remove metal oxides, where proper and complete residue removal of potentially corrosive water-soluble organic acid flux is not possible, and where soldering of electronic assemblies requires instant wetting and excellent capillary flow. 1544 can be used for solder coating or tinning bare leads.

Performance Characteristics:

High thermal stability



This product meets the requirements of the Restriction of Hazardous Substances (RoHS) Directive, 2015/863 for the stated banned substances.

Improves soldering performance

Physical Properties

Specific Gravity: 0.917-0.928 Anton Paar DMA @ 25°C Percent Solids (typical): 50% Tested to J-STD-004, IPC-TM-650, Method 2.3.34 Flash Point: 18°C (64°F)



Copper Mirror Corrosion: Moderate Tested to J-STD-004, IPC-TM-650, Method 2.3.32

Corrosion Test: Low Tested to J-STD-004, IPC-TM-650, Method 2.6.15 Silver Chromate: Fail Tested to J-STD-004, IPC-TM-650, Method 2.3.33

Chloride and Bromides: 0.44% Tested to J-STD-004, IPC-TM-650, Method 2.3.35 Fluorides by Spot Test: Pass Tested to J-STD-004, IPC-TM-650, Method 2.3.35.1

Classified as ROM1 per J-STD-004

Application Notes



✓Flux Application

1544 can be applied by brush, dip or wave processes.

OProcess Considerations

The optimum preheat temperature for most circuit assemblies is 90-105°C (194-221°F) as measured on the top or component side of the printed circuit board. Dwell time in the wave is typically 2-4 seconds for leaded soldering process and 4-8 seconds for a lead-free process. The wave soldering speed should be adjusted to accomplish the proper solder contact range. The next step will be to adjust the temperature settings for the preheat section to achieve the proper preheat temperatures range as measured on the topside of the circuit board.

IFlux Control

Specific gravity is normally the most reliable method to control the flux concentration of high solids rosin-based fluxes. To check concentration, a hydrometer should be used. Kester 104 Thinner is an appropriate solvent for diluting this activated rosin flux to the desired solids content and viscosity, and for restoring solvent loss through evaporation. The correct specific gravity range for 1544 is 0.917-0.928 (Anton Paar DMA @ 25°C).

Cleaning

1544 residues are non-conducive, non-corrosive and do not require removal in most applications. If residue removal is required, call Kester Technical Support.

Storage, Handling and Shelf Life

1544 is flammable. Store away from sources of ignition. Shelf life is 2 years from the date of manufacture when handled properly and held at 10-25°C (50-77°F).

\otimes Health and Safety

This product, during handling or use, may be hazardous to your health or the environment. Read the Safety Data Sheet and warning label before using this product.

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Soldering Flux category:

Click to view products by Kester manufacturer:

Other Similar products are found below :

24-6337-9727 8351-1L 051-0002 051-0007 051-0008 053-1000 053-1001 053-1002 053-1003 CW8700 CW8300 SMD4300TF10 SMD291/30CC CQ2LF CQ4LF 8342-50G 270WR ART.AGT-094 CW8100 CW8400 CW8500 CQ4LF-0.5 CQ4LF-1.0 SMD291 SMD291150G SMD29175G SMD291AX SMD291AX10 SMD291AX250T3 SMD291AX250T5 SMD291ST2CC6 SMD291ST8CC SMD4300TF CW8100 CW8200 CW8500 63-0000-0951 63-0000-0977 63-0000-1544 83-1000-0186 83-1097-2331 NF372-TB 760089 8341-10ML 8341-10ML 835-100ML 837-P SF-01 SF-02 2506-N