



HANDLING INSTRUCTION

opticalCON | FOPS-SINGLE Pulling Sock



- Ⓐ Open metal zipper and attach the strain relief on the cable as illustrated on pic A.

Attention: Make sure that the strain relief is between the two velcro straps.



- Ⓑ Due to the strain relief is the center element for the pulling force, it's important to tighten the cable tie.



- Ⓒ With tighten the velcro straps, fix the attached strain relief and cable on the opticalCON pulling sock.



- Ⓓ Close metal zipper and tighten velcro strap to enhance cable retention of the entire pulling sock.

FINISH





STORAGE

- A** 
- B** 
- A** Reel cable with attached pulling sock flat on the used cable drum.
- B** Secure opticalCON pulling sock with the black hook on the metal grommet.

NOTE:



The proper length of the elastic cord can be individual adjusted according the oute diameter of the used drum.

FINISH



X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for [Neutrik](#) manufacturer:

Other Similar products are found below :

[103F](#) [103M](#) [103P](#) [104L](#) [108E](#) [203F](#) [203FM](#) [203M](#) [203P](#) [3FD-H-I](#) [3FD-H-I-\(0\)](#) [3FD-H-I-B](#) [3FD-L-I-\(O\)](#) [3FD-V-I](#) [3FD-V-I-0](#) [3FD-V-I-\(0\)](#)
[3FD-V-I-B](#) [3MC-I](#) [3MD-H-I](#) [3MD-H-I-B](#) [3MD-V-I](#) [3MD-V-I-B](#) [8800235](#) [8MX6-T](#) [91101181024](#) [91201231](#) [91210071096](#) [91214571](#)
[91303761006](#) [ACRF-1](#) [ACRF-2](#) [ACRF-3](#) [ACRF-4](#) [ACRF-5](#) [ACRF-6](#) [ACRF-7](#) [ACRF-8](#) [ACRF-9](#) [ACRM-1](#) [ACRM-2](#) [ACRM-3](#) [ACRM-4](#)
[ACRM-5](#) [ACRM-6](#) [ACRM-7](#) [ACRM-9](#) [A-SCREW-1-8](#) [B220-0X-33](#) [B220-8X-33](#) [BP1](#)