There are also various probe points to facilitate simple waveform measurement and efficiency calculation. A complete block diagram of the circuit is given in Figure 1. For more information on the EPC2015 eGaN FETs or LMS113 driver, please refer to the data-sheet available from EPC at www.epc-co.com and www.Tl.com. These datasheets, as well that of the LT3833 controller should be read in conjunction with this quick start guide.

The EPC9107 demonstration board is 3" square and contains a fully closed loop buck converter with optimized control loop.

The EPC9107 board contains the complete power stage (including eGaN FETs, driver, inductor and input/output caps) in a compact ½" x ½" layout to showcase the performance that can be achieved using the eGaN FETs and eGaN driver together.

Table 1: Performance Summary (TA = $25 \, \text{C}$)

The EPC9107 demonstration board is a 3.3 V output, 1 MHz buck converter with an 15 A maximum output current and 9 V to 28 V input voltage range. The demonstration board features the EPC2015 enhancement mode (eGaN®) field effect transistor (FET), as well as the Texas Instruments LM5113 gate driver.

DESCRIPTION WWW.epc-co.com





Quick Start Procedure

Demonstration board EPC9107 is easy to set up to evaluate the performance of the EPC2015 eGaN FETs and LM5113 driver. Refer to Figure 2 for proper connect and measurement setup and follow the procedure below:

- 1. With power off, connect the input power supply bus between V_{IN} and GND banana jacks as shown.
- 2. With power off, connect the active (constant current) load as desired between V_{OUT} and GND banana jacks as shown.
- 3. Turn on the supply voltage to the required value (more than 9V, but do not exceed the absolute maximum voltage of 28 V on V_{IN}).
- 4. Measure the output voltage to make sure the board is fully functional and operating no-load.
- 5. Turn on active load to the desired load current while staying below the maximum current (15 A)
- 6. Once operational, adjust the bus voltage and load current within the allowed operating range and observe the output switching behavior, efficiency and other parameters.
- 7. For shutdown, please follow steps in reverse.

NOTE. When measuring the high frequency content switch node of gate voltage, care must be taken to avoid long ground leads. Measure these by placing the oscilloscope probe tip on the top pad of D3 and grounding the probe directly across D3 on the bottom pad provided for switch node and using the right hand pad of R24 and the GND pad below it for gate voltage. See Figure 3 for proper scope probe technique. Measuring the switch node with a high bandwidth (\geq 500MHz) probe and high bandwidth scope (\geq 1GHz) is recommended.

NOTE. The dead-times for both the leading and trailing edges have been set for optimum full load efficiency. Adjustment is not recommended, but can be done at own risk by replacing R21 and R22 with potentiometers P1 and P2. This should be done while monitoring both the input current and switch-node voltage to determine the effect of these adjustments. Under no circumstance should the input pins to the LM5113 be probed during operation as the added probe capacitance will change the device timing.

CIRCUIT PERFORMANCE




Figure 1: Block Diagram of EPC9107 Demonstration Board




Figure 2: Proper Connection and Measurement Setup




Figure 3: Proper Measurement of Switch Node or Gate Voltage




Figure 4: Typical waveforms for 28 V to 3.3 V / 15 A (1 MHz) CH1: Switch node voltage

There are also various probe points to facilitate simple waveform measurement and efficiency calculation. A complete block diagram of the circuit is given in Figure 1. For more information on the EPC2015 eGaN FETs or LMS113 driver, please refer to the data-sheet available from EPC at www.epc-co.com and www.Tl.com. These datasheets, as well that of the LT3833 controller should be read in conjunction with this quick start guide.

The EPC9107 demonstration board is 3" square and contains a fully closed loop buck converter with optimized control loop.

The EPC9107 board contains the complete power stage (including eGaN FETs, driver, inductor and input/output caps) in a compact ½" x ½" layout to showcase the performance that can be achieved using the eGaN FETs and eGaN driver together.

Table 1: Performance Summary (TA = $25 \, \text{C}$)

The EPC9107 demonstration board is a 3.3 V output, 1 MHz buck converter with an 15 A maximum output current and 9 V to 28 V input voltage range. The demonstration board features the EPC2015 enhancement mode (eGaN®) field effect transistor (FET), as well as the Texas Instruments LM5113 gate driver.

DESCRIPTION WWW.epc-co.com





Quick Start Procedure

Demonstration board EPC9107 is easy to set up to evaluate the performance of the EPC2015 eGaN FETs and LM5113 driver. Refer to Figure 2 for proper connect and measurement setup and follow the procedure below:

- 1. With power off, connect the input power supply bus between V_{IN} and GND banana jacks as shown.
- 2. With power off, connect the active (constant current) load as desired between V_{OUT} and GND banana jacks as shown.
- 3. Turn on the supply voltage to the required value (more than 9V, but do not exceed the absolute maximum voltage of 28 V on V_{IN}).
- 4. Measure the output voltage to make sure the board is fully functional and operating no-load.
- 5. Turn on active load to the desired load current while staying below the maximum current (15 A)
- 6. Once operational, adjust the bus voltage and load current within the allowed operating range and observe the output switching behavior, efficiency and other parameters.
- 7. For shutdown, please follow steps in reverse.

NOTE. When measuring the high frequency content switch node of gate voltage, care must be taken to avoid long ground leads. Measure these by placing the oscilloscope probe tip on the top pad of D3 and grounding the probe directly across D3 on the bottom pad provided for switch node and using the right hand pad of R24 and the GND pad below it for gate voltage. See Figure 3 for proper scope probe technique. Measuring the switch node with a high bandwidth (\geq 500MHz) probe and high bandwidth scope (\geq 1GHz) is recommended.

NOTE. The dead-times for both the leading and trailing edges have been set for optimum full load efficiency. Adjustment is not recommended, but can be done at own risk by replacing R21 and R22 with potentiometers P1 and P2. This should be done while monitoring both the input current and switch-node voltage to determine the effect of these adjustments. Under no circumstance should the input pins to the LM5113 be probed during operation as the added probe capacitance will change the device timing.

CIRCUIT PERFORMANCE




Figure 1: Block Diagram of EPC9107 Demonstration Board




Figure 2: Proper Connection and Measurement Setup




Figure 3: Proper Measurement of Switch Node or Gate Voltage




Figure 4: Typical waveforms for 28 V to 3.3 V / 15 A (1 MHz) CH1: Switch node voltage

There are also various probe points to facilitate simple waveform measurement and efficiency calculation. A complete block diagram of the circuit is given in Figure 1. For more information on the EPC2015 eGaN FETs or LMS113 driver, please refer to the data-sheet available from EPC at www.epc-co.com and www.Tl.com. These datasheets, as well that of the LT3833 controller should be read in conjunction with this quick start guide.

The EPC9107 demonstration board is 3" square and contains a fully closed loop buck converter with optimized control loop.

The EPC9107 board contains the complete power stage (including eGaN FETs, driver, inductor and input/output caps) in a compact ½" x ½" layout to showcase the performance that can be achieved using the eGaN FETs and eGaN driver together.

Table 1: Performance Summary (TA = $25 \, \text{C}$)

The EPC9107 demonstration board is a 3.3 V output, 1 MHz buck converter with an 15 A maximum output current and 9 V to 28 V input voltage range. The demonstration board features the EPC2015 enhancement mode (eGaN®) field effect transistor (FET), as well as the Texas Instruments LM5113 gate driver.

DESCRIPTION WWW.epc-co.com





Quick Start Procedure

Demonstration board EPC9107 is easy to set up to evaluate the performance of the EPC2015 eGaN FETs and LM5113 driver. Refer to Figure 2 for proper connect and measurement setup and follow the procedure below:

- 1. With power off, connect the input power supply bus between V_{IN} and GND banana jacks as shown.
- 2. With power off, connect the active (constant current) load as desired between V_{OUT} and GND banana jacks as shown.
- 3. Turn on the supply voltage to the required value (more than 9V, but do not exceed the absolute maximum voltage of 28 V on V_{IN}).
- 4. Measure the output voltage to make sure the board is fully functional and operating no-load.
- 5. Turn on active load to the desired load current while staying below the maximum current (15 A)
- 6. Once operational, adjust the bus voltage and load current within the allowed operating range and observe the output switching behavior, efficiency and other parameters.
- 7. For shutdown, please follow steps in reverse.

NOTE. When measuring the high frequency content switch node of gate voltage, care must be taken to avoid long ground leads. Measure these by placing the oscilloscope probe tip on the top pad of D3 and grounding the probe directly across D3 on the bottom pad provided for switch node and using the right hand pad of R24 and the GND pad below it for gate voltage. See Figure 3 for proper scope probe technique. Measuring the switch node with a high bandwidth (\geq 500MHz) probe and high bandwidth scope (\geq 1GHz) is recommended.

NOTE. The dead-times for both the leading and trailing edges have been set for optimum full load efficiency. Adjustment is not recommended, but can be done at own risk by replacing R21 and R22 with potentiometers P1 and P2. This should be done while monitoring both the input current and switch-node voltage to determine the effect of these adjustments. Under no circumstance should the input pins to the LM5113 be probed during operation as the added probe capacitance will change the device timing.

CIRCUIT PERFORMANCE




Figure 1: Block Diagram of EPC9107 Demonstration Board




Figure 2: Proper Connection and Measurement Setup




Figure 3: Proper Measurement of Switch Node or Gate Voltage




Figure 4: Typical waveforms for 28 V to 3.3 V / 15 A (1 MHz) CH1: Switch node voltage

There are also various probe points to facilitate simple waveform measurement and efficiency calculation. A complete block diagram of the circuit is given in Figure 1. For more information on the EPC2015 eGaN FETs or LMS113 driver, please refer to the data-sheet available from EPC at www.epc-co.com and www.Tl.com. These datasheets, as well that of the LT3833 controller should be read in conjunction with this quick start guide.

The EPC9107 demonstration board is 3" square and contains a fully closed loop buck converter with optimized control loop.

The EPC9107 board contains the complete power stage (including eGaN FETs, driver, inductor and input/output caps) in a compact ½" x ½" layout to showcase the performance that can be achieved using the eGaN FETs and eGaN driver together.

Table 1: Performance Summary (TA = $25 \, \text{C}$)

The EPC9107 demonstration board is a 3.3 V output, 1 MHz buck converter with an 15 A maximum output current and 9 V to 28 V input voltage range. The demonstration board features the EPC2015 enhancement mode (eGaN®) field effect transistor (FET), as well as the Texas Instruments LM5113 gate driver.

DESCRIPTION WWW.epc-co.com





Quick Start Procedure

Demonstration board EPC9107 is easy to set up to evaluate the performance of the EPC2015 eGaN FETs and LM5113 driver. Refer to Figure 2 for proper connect and measurement setup and follow the procedure below:

- 1. With power off, connect the input power supply bus between V_{IN} and GND banana jacks as shown.
- 2. With power off, connect the active (constant current) load as desired between V_{OUT} and GND banana jacks as shown.
- 3. Turn on the supply voltage to the required value (more than 9V, but do not exceed the absolute maximum voltage of 28 V on V_{IN}).
- 4. Measure the output voltage to make sure the board is fully functional and operating no-load.
- 5. Turn on active load to the desired load current while staying below the maximum current (15 A)
- 6. Once operational, adjust the bus voltage and load current within the allowed operating range and observe the output switching behavior, efficiency and other parameters.
- 7. For shutdown, please follow steps in reverse.

NOTE. When measuring the high frequency content switch node of gate voltage, care must be taken to avoid long ground leads. Measure these by placing the oscilloscope probe tip on the top pad of D3 and grounding the probe directly across D3 on the bottom pad provided for switch node and using the right hand pad of R24 and the GND pad below it for gate voltage. See Figure 3 for proper scope probe technique. Measuring the switch node with a high bandwidth (\geq 500MHz) probe and high bandwidth scope (\geq 1GHz) is recommended.

NOTE. The dead-times for both the leading and trailing edges have been set for optimum full load efficiency. Adjustment is not recommended, but can be done at own risk by replacing R21 and R22 with potentiometers P1 and P2. This should be done while monitoring both the input current and switch-node voltage to determine the effect of these adjustments. Under no circumstance should the input pins to the LM5113 be probed during operation as the added probe capacitance will change the device timing.

CIRCUIT PERFORMANCE




Figure 1: Block Diagram of EPC9107 Demonstration Board




Figure 2: Proper Connection and Measurement Setup




Figure 3: Proper Measurement of Switch Node or Gate Voltage




Figure 4: Typical waveforms for 28 V to 3.3 V / 15 A (1 MHz) CH1: Switch node voltage





Figure 5: Typical efficiency and power loss curves for 12V, 19V, 24V and 28V input

THERMAL CONSIDERATIONS

The EPC9107 demonstration board thermal image for steady state full load operation is shown in Figure 6. The EPC9107 is intended for bench evaluation with low ambient temperature and convection cooling. The addition of heat-sinking and forced air cooling could increase the current capability of the demonstration circuit, but care must be taken to not exceed the absolute maximum die temperature of 125°C and stay within the constraints of the other components within the circuit, most notably the saturation of the output inductor.

NOTE. The EPC9107 demonstration board does not have any thermal protection on board.







Figure 6: Thermal image of EPC9107 under full load condition: 28 V_{IN} , 15 A_{OUT} with convection cooling

	Α.	D.C.	D (D) ()	M () (D) "
tem	Qty	Reference	Part Description	Manufacturer / Part #
1	1	C1	Capacitor, 150pF, 5%, 50V, NP0	Murata, GRM1885C1H151JA01D
2	1	C3	Capacitor, 22pF, 5%, 50V, NP0	Murata, GRM1885C1H220JA01D
3	1	C12	Capacitor, 47pF, 5%, 50V, NP0	TDK, C1608C0G1H470J
4	6	C2, C4, C7, C9, C15, C19	Capacitor, 0.1uF, 10%, 25V, X5R	TDK, C1005X5R1E104K
5	2	C5, C8	Capacitor, 4.7uF, 10%, 10V, X5R	TDK, C1608X5R1A475K
6	1	C10	Capacitor, 10uF, 20%, 35V, X5R	Taiyo Yuden, GMK325BJ106KN
7	2	C11, C22, C23	Capacitor, 4.7uF, 10%, 35V, X7R	TDK, C2012X6S1V475K125AB
8	4	C13, C14, C20, C21	Capacitor, 47uF, 20%, 10V, X5R	TDK, C2012X5R1A476M
9	2	C16, C17	Capacitor, 100pF, 5%, 50V, NP0	Kemet, C0402C101K5GACTU
10	1	C24	Capacitor, 100uF, 20%, 6.3V, X5R	Kemet, C1206C107M9PACTU
11	2	C30, C31	Capacitor, 1uF, 20%, 10V, X5R	TDK, C1005X5R1A105K050BB
12	2	D1, D2, D4	Schottky Diode, 30V	Diodes Inc., SDM03U40-7
13	4	J1, J2, J3, J4	Banana Jack	Keystone, 575-4
14	1	L1	Inductor, 1.0uH, 22A	Cooper Bussman, HCF1305-1R0-R
15	2	Q1, Q2	eGaN® FET	EPC, EPC2015
16	1	R3	Resistor, 45.0k, 1%, 1/8W	Stackpole, RMCF0603FT45K3
17	2	R4, R10	Resistor, 10.0k, 1%, 1/10W	Panasonic, ERJ-2RKF1002X
18	6	R5, R19, R20, R23, R24, R30	Resistor, 0 Ohm, 1/16W	Stackpole, RMCF0402ZT0R00
19	1	R31	Resistor, 39 Ohm, 1%, 1/16W	Stackpole, RMCF0402FT39R0
20	1	R8	Resistor, 39.2k, 1%, 1/8W	Stackpole, RMCF0603FT39K2
21	1	R2	Resistor, 18.0k, 1%, 1/8W	Stackpole, RMCF0603FT18K0
22	1	R9	Resistor, 2.2 Ohm, 5%, 1/16W	Yageo, RC0402FR-072R2L
23	1	R11	Resistor, 560K, 1%, 1/8W	Stackpole, RMCF0603FT560K
24	1	R12	Resistor, 100k, 1%, 1/8W	Stackpole, RMCF0603FT100K
25	2	R13, R14	Resistor, 1.00k, 5%, 1/10W	Rohm, MCR03EZPJ102
26	1	R15	Resistor, 3.3k, 5%, 1/8W	Stackpole, RMCF0603JT3K30
27	1	R21	Resistor, 7.5 Ohm, 5%, 1/16W	Stackpole, RMCF0603JT7R50
28	1	R22	Resistor, 47 Ohm, 5%, 1/16W	Stackpole, RMCF0603JT47R0
29	9	TP1, TP2, TP3, TP4, TP5, TP6, TP7, TP8, TP9	Measurement Point	Keystone Elect, 5015
30	1	U1	I.C., Buck Regulator	Linear Technology, LTC3833EUDC#PBF
31	1	U2	I.C., Gate Driver	Texas Instruments, LM5113
32	1	U3	I.C., Logic	Fairchild, NC7SZ00L6X
33	1	U4	I.C., Charge Pump	Texas Instruments, LM2766M6
34	4		Nylon Stand-offs	Keystone, 8834
35	0	P1, P2	Optional Potentiometer, 500 Ohm, 0.25W	
36	0	R7, R16	Optional Resistors	
37	0	C6, C18	Optional Capacitors	
38	0	SJ5	Optional Scope Jack	
39	0	D3	Optional Diode	
40	0	SJ1, SJ2, SJ3, SJ4	Optional SMA connectors	







Figure 5: Typical efficiency and power loss curves for 12V, 19V, 24V and 28V input

THERMAL CONSIDERATIONS

The EPC9107 demonstration board thermal image for steady state full load operation is shown in Figure 6. The EPC9107 is intended for bench evaluation with low ambient temperature and convection cooling. The addition of heat-sinking and forced air cooling could increase the current capability of the demonstration circuit, but care must be taken to not exceed the absolute maximum die temperature of 125°C and stay within the constraints of the other components within the circuit, most notably the saturation of the output inductor.

NOTE. The EPC9107 demonstration board does not have any thermal protection on board.








Figure 6: Thermal image of EPC9107 under full load condition: 28 V_{IN} , 15 A_{OUT} with convection cooling

	Α.	D.C.	D (D) ()	M () (D) "
tem	Qty	Reference	Part Description	Manufacturer / Part #
1	1	C1	Capacitor, 150pF, 5%, 50V, NP0	Murata, GRM1885C1H151JA01D
2	1	C3	Capacitor, 22pF, 5%, 50V, NP0	Murata, GRM1885C1H220JA01D
3	1	C12	Capacitor, 47pF, 5%, 50V, NP0	TDK, C1608C0G1H470J
4	6	C2, C4, C7, C9, C15, C19	Capacitor, 0.1uF, 10%, 25V, X5R	TDK, C1005X5R1E104K
5	2	C5, C8	Capacitor, 4.7uF, 10%, 10V, X5R	TDK, C1608X5R1A475K
6	1	C10	Capacitor, 10uF, 20%, 35V, X5R	Taiyo Yuden, GMK325BJ106KN
7	2	C11, C22, C23	Capacitor, 4.7uF, 10%, 35V, X7R	TDK, C2012X6S1V475K125AB
8	4	C13, C14, C20, C21	Capacitor, 47uF, 20%, 10V, X5R	TDK, C2012X5R1A476M
9	2	C16, C17	Capacitor, 100pF, 5%, 50V, NP0	Kemet, C0402C101K5GACTU
10	1	C24	Capacitor, 100uF, 20%, 6.3V, X5R	Kemet, C1206C107M9PACTU
11	2	C30, C31	Capacitor, 1uF, 20%, 10V, X5R	TDK, C1005X5R1A105K050BB
12	2	D1, D2, D4	Schottky Diode, 30V	Diodes Inc., SDM03U40-7
13	4	J1, J2, J3, J4	Banana Jack	Keystone, 575-4
14	1	L1	Inductor, 1.0uH, 22A	Cooper Bussman, HCF1305-1R0-R
15	2	Q1, Q2	eGaN® FET	EPC, EPC2015
16	1	R3	Resistor, 45.0k, 1%, 1/8W	Stackpole, RMCF0603FT45K3
17	2	R4, R10	Resistor, 10.0k, 1%, 1/10W	Panasonic, ERJ-2RKF1002X
18	6	R5, R19, R20, R23, R24, R30	Resistor, 0 Ohm, 1/16W	Stackpole, RMCF0402ZT0R00
19	1	R31	Resistor, 39 Ohm, 1%, 1/16W	Stackpole, RMCF0402FT39R0
20	1	R8	Resistor, 39.2k, 1%, 1/8W	Stackpole, RMCF0603FT39K2
21	1	R2	Resistor, 18.0k, 1%, 1/8W	Stackpole, RMCF0603FT18K0
22	1	R9	Resistor, 2.2 Ohm, 5%, 1/16W	Yageo, RC0402FR-072R2L
23	1	R11	Resistor, 560K, 1%, 1/8W	Stackpole, RMCF0603FT560K
24	1	R12	Resistor, 100k, 1%, 1/8W	Stackpole, RMCF0603FT100K
25	2	R13, R14	Resistor, 1.00k, 5%, 1/10W	Rohm, MCR03EZPJ102
26	1	R15	Resistor, 3.3k, 5%, 1/8W	Stackpole, RMCF0603JT3K30
27	1	R21	Resistor, 7.5 Ohm, 5%, 1/16W	Stackpole, RMCF0603JT7R50
28	1	R22	Resistor, 47 Ohm, 5%, 1/16W	Stackpole, RMCF0603JT47R0
29	9	TP1, TP2, TP3, TP4, TP5, TP6, TP7, TP8, TP9	Measurement Point	Keystone Elect, 5015
30	1	U1	I.C., Buck Regulator	Linear Technology, LTC3833EUDC#PBF
31	1	U2	I.C., Gate Driver	Texas Instruments, LM5113
32	1	U3	I.C., Logic	Fairchild, NC7SZ00L6X
33	1	U4	I.C., Charge Pump	Texas Instruments, LM2766M6
34	4		Nylon Stand-offs	Keystone, 8834
35	0	P1, P2	Optional Potentiometer, 500 Ohm, 0.25W	
36	0	R7, R16	Optional Resistors	
37	0	C6, C18	Optional Capacitors	
38	0	SJ5	Optional Scope Jack	
39	0	D3	Optional Diode	
40	0	SJ1, SJ2, SJ3, SJ4	Optional SMA connectors	





There are also various probe points to facilitate simple waveform measurement and efficiency calculation. A complete block diagram of the circuit is given in Figure 1. For more information on the EPC2015 eGaN FETs or LMS113 driver, please refer to the data-sheet available from EPC at www.epc-co.com and www.Tl.com. These datasheets, as well that of the LT3833 controller should be read in conjunction with this quick start guide.

The EPC9107 demonstration board is 3" square and contains a fully closed loop buck converter with optimized control loop.

The EPC9107 board contains the complete power stage (including eGaN FETs, driver, inductor and input/output caps) in a compact ½" x ½" layout to showcase the performance that can be achieved using the eGaN FETs and eGaN driver together.

Table 1: Performance Summary (TA = $25 \, \text{C}$)

The EPC9107 demonstration board is a 3.3 V output, 1 MHz buck converter with an 15 A maximum output current and 9 V to 28 V input voltage range. The demonstration board features the EPC2015 enhancement mode (eGaN®) field effect transistor (FET), as well as the Texas Instruments LM5113 gate driver.

DESCRIPTION WWW.epc-co.com





Quick Start Procedure

Demonstration board EPC9107 is easy to set up to evaluate the performance of the EPC2015 eGaN FETs and LM5113 driver. Refer to Figure 2 for proper connect and measurement setup and follow the procedure below:

- 1. With power off, connect the input power supply bus between V_{IN} and GND banana jacks as shown.
- 2. With power off, connect the active (constant current) load as desired between V_{OUT} and GND banana jacks as shown.
- 3. Turn on the supply voltage to the required value (more than 9V, but do not exceed the absolute maximum voltage of 28 V on V_{IN}).
- 4. Measure the output voltage to make sure the board is fully functional and operating no-load.
- 5. Turn on active load to the desired load current while staying below the maximum current (15 A)
- 6. Once operational, adjust the bus voltage and load current within the allowed operating range and observe the output switching behavior, efficiency and other parameters.
- 7. For shutdown, please follow steps in reverse.

NOTE. When measuring the high frequency content switch node of gate voltage, care must be taken to avoid long ground leads. Measure these by placing the oscilloscope probe tip on the top pad of D3 and grounding the probe directly across D3 on the bottom pad provided for switch node and using the right hand pad of R24 and the GND pad below it for gate voltage. See Figure 3 for proper scope probe technique. Measuring the switch node with a high bandwidth (\geq 500MHz) probe and high bandwidth scope (\geq 1GHz) is recommended.

NOTE. The dead-times for both the leading and trailing edges have been set for optimum full load efficiency. Adjustment is not recommended, but can be done at own risk by replacing R21 and R22 with potentiometers P1 and P2. This should be done while monitoring both the input current and switch-node voltage to determine the effect of these adjustments. Under no circumstance should the input pins to the LM5113 be probed during operation as the added probe capacitance will change the device timing.

CIRCUIT PERFORMANCE




Figure 1: Block Diagram of EPC9107 Demonstration Board




Figure 2: Proper Connection and Measurement Setup




Figure 3: Proper Measurement of Switch Node or Gate Voltage




Figure 4: Typical waveforms for 28 V to 3.3 V / 15 A (1 MHz) CH1: Switch node voltage

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for epcos manufacturer:

Other Similar products are found below:

B82432X001 B82731H2501A30 B25673A4302A080 B32529C0104K000 B43501B3337M7 B44066R6012E230 B57235S0100M
B57236S0200M B57236S0259M B57236S0800M B57237S0100M B57237S0109M B57237S0229M B57237S0259M B57237S0330M
B72520T0250K062 B82422A1102K100 B82422A1333K100 B82422A1472K100 B82721A2202N001 B84142A50R B84143B600S20
B84144A0120R000 B84144A90R120 B84243A8008W B88069X0270S102 BR6000-R6 B25631A1506K200 B32656S0105K561
B32656T684K B32686A7104K B32913A5154M B41550E7229Q000 B43252A5476M B57236S0509M B57237S0150M B57237S0479M
B57237S0509M B59955C0120A070 B59995C0120A070 B64290A0045X038 B72240B321K1 B72530T0400K062 B72530T250K62
B82422A1473K100 B84144A50R B323332I6755J080 B32521C1105J B32673P6474K000 B43504B2108M000