

SMART ARM-based Motor Control Kit

ATSAMD21BLDC24V-STK

USER GUIDE

Table of Contents

1. Atmel Low Voltage Motor Control Starter Kit			3	
	1.1.	ATSAMD21BLDC24V-STK Features	3	
	1.2.	ATSAMD21BLDC24V-STK Kit Content		
	1.3.	Design Documentation and Relevant Links	5	
2.	Getti	ing Started with ATSAMD21BLDC24V-STK	6	
3.	ATS	AMD21BLDC24V-STK Hardware	12	
	3.1.	ATSAMD21BLDC24V-STK MCU Board	12	
	3.2.	ATSAMD21BLDC24V-STK Driver Board		
	3.3.	ATSAMD21BLDC24V-STK MCU-driver Interface	23	
4.	Hard	lware Revision History and Known Issues	26	
	4.1.	Identifying Product ID and Revision		
	4.2.	Revision	26	
5.	Product Compliance			
6.	Revision History			



1. Atmel Low Voltage Motor Control Starter Kit

The Atmel[®] ATSAMD21BLDC24V-STK is a low voltage BLDC, PMSM motor control starter kit. The kit contains a driver board hardware with half-bridge power MOSFET drivers, current and voltage sensing circuit, Hall and Encoder interface, fault protection circuits, etc. The ATSAMD21MOTOR MCU card is plugged into the driver board and has an on-board debugger. Supported by the Atmel studio integrated development platform, the kit provides easy access to the features of ATSAMD21J18A MCU and explains how to integrate the device in a custom motor control application. Pluggable MCU cards are available from Atmel, supporting other SMART ARM[®] MCUs.



1.1. ATSAMD21BLDC24V-STK Features

ATSAMD21BLDC24V-STK has the following features:

- Pluggable MCU card interface
- Debug support using on-board Atmel EDBG device
- Three half-bridge MOSFET driver
- Motor BEMF sensing
- Motor individual phase current sensing
- DC-bus voltage sensing

Atmel

- Hall sensor interface
- Encoder sensor interface
- Over-current protection support
- Over-voltage protection at 30VDC
- 5V and 3.3V MCU card support
- Selectable MCU supply voltage
- Reverse power supply voltage protection
- Atmel Xplained Pro compatible header interface
- On board Temperature sensor
- On board serial flash
- LED fault indications
- Atmel studio plug-and-use support using unique ID device

1.2. ATSAMD21BLDC24V-STK Kit Content

ATSAMD21BLDC24V-STK Kit contains the PCBs, BLDC motor, power adaptor and USB cable to get started and running the motor in the kit.

Power Adaptor

The kit contains the following items:

- 1. AT24VBLDC driver board.
- 2. ATSAMD21MOTOR MCU card.
- 3. LDO brush-less DC motor (LDO: 42BL02402-0026B-002).
- 4. Fully assembled chassis plate.
- 5. 24V, 4A AC adapter (EDAC: EA11011E-240).
- 6. Micro-USB cable.

Figure 1-1. ATSAMD21BLDC24V-STK Kit Content

Assembled Chassis



USB Cable



1.3. Design Documentation and Relevant Links

The following list contains links to the most relevant documents and software for ATSAMD21BLDC24V-STK:

- Xplained Pro products Atmel Xplained Pro is a series of small-sized and easy-to-use evaluation kits for Atmel microcontrollers and other Atmel products. It consists of a series of low-cost MCU boards for evaluation and demonstration of features and capabilities of different MCU families.
- ATSAMD21BLDC24V-STK User Guide PDF version of this User Guide.
- ATSAMD21BLDC24V-STK Design Documentation Package containing schematics, BOM, assembly drawings, 3D plots, layer plots, etc.
- Atmel Studio Free Atmel IDE for development of C/C++ and assembler code for Atmel microcontrollers.
- **EDBG User Guide** User guide containing more information about the on-board Embedded Debugger.
- Atmel Data Visualizer Atmel Data Visualizer is a program used for processing and visualizing data. Data Visualizer can receive data from various sources such as the Embedded Debugger Data Gateway Interface found on Xplained Pro boards and COM ports.
- ATSAMD21BLDC24V-STK Product page.
- ATSAMD21J18A MCU datasheet.



2. Getting Started with ATSAMD21BLDC24V-STK

This chapetr is a step-by-step guide to get started with the SAMD21BLDC24V-STK.

- 1. SAMD21BLDC24V-STK kit contains a fully assembled chassis and 24VDC power adaptor.
- 2. Connect the power adaptor to the "SUPPLY-IN connector". Connect white color cable to + PIN. Figure 2-1. Kit with Power and USB Ports Connected



- 3. Switch ON the power adaptor.
- 4. Connect the Micro-USB cable to the "EDBG-USB connector" and PC USB port.
- 5. The power LED indications on the MCU board are now ON.
- 6. Open "Data Visualizer".
- 7. In the "Data Visualizer Connect Window" Choose the kit from the DGI control panel's drop down list.



ta Visualizer DGI Control Panel	
ATSAMD21MOTOR ATML224100200000226	- Conn
Interfaces:	ADP Logging Autodetect ADP Reset

Figure 2-2. Data Visualizer Connect Window

- 8. Click "Connect". The orange LED in the MCU board shall now blink.
- 9. The Data Visualizer default window will pop up once the connection is made. All the fields shall show default values.






Figure 2-3. Data Visualizer Start Window

10. Click on "Start" to turn the motor ON with default values.






Figure 2-4. Data Visualizer "Start Motor" Window

11. Change the value in a field and press "Enter". For instance, to change the motor speed, type in the desired speed within the motor's rating and press "Enter".






Figure 2-5. Data Visualizer "Change Parameter"

- 12. Stop the Motor by clicking the "Stop" button.
- 13. To change direction of rotation after "Stop", choose "CCW" in radio button and click "Start".






Figure 2-6. Data Visualizer "Change Direction"

14. Adjust the graph by checking "Automatically fit Y".

3. ATSAMD21BLDC24V-STK Hardware

The ATSAMD21BLDC24V-STK has a two-board architecture. The driver base board contains drive circuits, sensor circuits, protection circuits, power supply, etc., and the MCU board (MCU card) contains the MCU, clock circuit, and debug circuit. The MCU card is inserted into the 67-pin NGFF standard interface on the driver board. The ATSAMD21BLDC24V-STK comes with an ATSAMD21J18A MCU card.

3.1. ATSAMD21BLDC24V-STK MCU Board

The main components in the ATSAMD21MOTOR MCU card are highlighted in the PCB and block diagram given below.

Figure 3-1. MCU Board PCB







Figure 3-2. MCU Board Block Diagram



3.1.1. Power Supply

The ATSAMD21MOTOR MCU card takes 3.3VDC supply from the 67-pin edge connector. Both the EDBG device and the Main MCU operates from 3.3VDC. The power supply selection jumper on the Driver board should be connected to 3V3 (silk screen text) selection.

3.1.2. Main MCU Circuit

The ATSAMD21MOTOR has an ATSAMD21J18A device. The device is intended to work with MCU internal clock source. A 32.768kHz crystal is connected externally to the MCU.

3.1.3. Embedded Debugger

The ATSAMD21J18A MCU is interfaced to the EDBG debug device. The EDBG uses SWD interface for programming and debugging the main MCU. A debug header is also provided on the MCU board with ARM Cortex[®] debug pinout. An external debugger can be connected to this debug port.

The DGI is a proprietary communication interface used by the Atmel Data Visualizer software to communicate with the development kits through the EDBG. SERCOM4 of the ATSAMD21J18A connected to the EDBG device support DGI SPI interface and uses Atmel ADP protocol. The MCU SERCOM4 is also connected to the UART channel of the EDBG through a pair of "normally open" jumpers, the J200 and J201. Shorting these jumpers will enable the CDC UART interface for the main MCU.

High Speed USB port of the EDBG is accessible at the driver board. EDBG USB enumerates as a composite device supporting debug, DGI SPI, and CDC interfaces.

The USB port of the ATSAMD21J18A is connected to the Micro-USB connecter on the driver board.

3.2. ATSAMD21BLDC24V-STK Driver Board

The driver board contains half-bridge MOSFET driver circuits for three-phase BLDC, PMSM motor drive and supports 12-24VDC recommended bus drive voltage. Individual phase current sense, bus voltage sense, and back-EMF sense circuits supports development of sensor-less motor drive algorithms. Hall and Encoder sensor interfaces enables the user to develop sensor-based motor control applications. The



driver board has over-voltage protection in hardware and over-current shutdown through the MCU input. Reverse voltage protection is available at 12-24VDC and EXT1-header external supply inputs. USB interface headers are interfaced to the main MCU and EDBG device in the MCU board. Temperature sensor, serial flash, XPRO interface header, and UID chip circuits are the other features included in the driver board hardware. The figure below shows the main components and block diagram of driver board.





Figure 3-3. ATSAMD21BLDC24V-STK Driver Board PCB





Figure 3-4. ATSAMD21BLDC24V-STK Block Diagram



3.2.1. Half-bridge FET Driver

The half-bridge circuit is based on the NTMFS5C646NL N-channel Power MOSFET. Each half-bridge is driven by the NCP5106A gate driver. The gate driver takes two independent PWM inputs from the MCU and uses bootstrap technique to drive the high side Power MOSFET in the half-bridge. The bootstrap capacitor is tied between PIN5 and PIN8 of the NCP5106 through a resistor. C5 is the bootstrap capacitor and D1 is the bootstrap diode for phase-U half-bridge, as shown in the figure below. The bootstrap capacitor value is chosen based on the total charge to be supplied by the capacitor and maximum allowable voltage drop on the bootstrap capacitor.






3.2.2. Power Supply

The driver board has multiple power supply selection options. Automatic supply input selection is similar to the Atmel Xplained Pro hardware. The block diagram shows how to use the SW1 user switch and the jumper available on the PCB to select the MCU voltage supply.

Figure 3-6. Driver Board Power Supply



3.2.3. Phase Current Sense

The current sense resistor and the differential amplifier circuit enables measurement of individual phase currents using the ADC channel of the MCU. The figure below shows the sense circuit for the U-phase and reference generator. R30 is the current shunt and op-amp U8 is configured in inverting differential amplifier configuration. Voltage offset is added to the sense output, which is the reference voltage output generated from the MCU supply voltage (MCU supply divided by 2). Solving the circuit,

Vout = Vr-(Is.Rs)(R52/R16)

Vout = U_I_sense at TP13 Vr = reference voltage (= 1.65V) Is = phase current Rs = shunt resistor

Atmel

R52 = feedback resistor

R16 = input side resistor





Figure 3-7. Current Sense and Reference Generation Circuit

3.2.4. BEMF, DC Bus Sense

Back-EMF generated in the phase windings can be determined from the voltage read at the individual phase terminals. A schematic drawing for the voltage scaling and the filter circuit is shown in the figure below. BEMF output is connected to the ADC and analog comparator of the MCU. Motor DC supply is divided by network R79, R80 and connected to ADC reference and analog comparator.


Figure 3-8. Back-EMF, DC Bus Voltage Sense Circuit




3.2.5. Over-voltage Protection (OVP)

DC bus voltage is monitored by the voltage sense circuit. If the voltage gets higher than 30VDC, the overvoltage protection will shut down the FET driver. The OVP circuit is shown in the figure below. Sense voltage is determined by the zener diode (D7) voltage (28V) and R-network R117 and R118. Vgs (threshold) of Q8A is typically 2V.









3.2.6. Over-current Protection

Over-current protection (OCP OFF) is signaled from the MCU when the total individual phase shunt current value exceeds the limit. Shutdown circuit is shown in the image below. Q8B will be OFF in normal operation and switches ON and shuts off U5 when OCP OFF triggers. Shutting down U5 will cut off the MOSFET driver and can be switched back to active condition by pressing the SW2 push button.





3.2.7. Hall Sensor Interface

The Hall sensor interface uses NTS0104 level translator. The interface is tested with motors with open drain and push pull type Hall sensor output. The LDO motor supplied with ATSAMD21BLDC24V-STK has open drain Hall sensor output type.



3.2.8. Encoder Sensor Interface

The encoder sensor interface uses a NTS0104 level translator. The interface is tested with motors with open drain and push pull type encoder sensor output. The LDO motor supplied with ATSAMD21BLDC24V-STK has open drain output type.

3.2.9. Atmel Xplained PRO Interface

The Xplained PRO compatible header has a 20-pin EXT1 connector and a 4-pin power connector. All the lines of the 20-pin header are routed to the 67-pin NGFF interface. Some pins of the header are not connected to the MCU ports, also some pins are connected to other features on the driver board. This is based on the availability of pins on the MCU card. The table below shows the pinout for both the connectors in the case of ATSAMD21MOTOR MCU card supplied with the kit.

Pin	Pin name	67-pin interface	Driver board connections	SAMD21J18A port
1	ID_2	4	EDBG_ID2/EXT1_1	EDBG_PB01
2	GND	67	-	GND
3	ADC(+)	20	EXT_3	NC
4	ADC(-)	35	EXT1_4(GPIO10)	NC
5	GPIO5	22	EXT1_5(GPIO5)	PB31
6	GPIO6	23	EXT1_6(GPIO6)	PA17
7	PWM(+)	18	EXT1_7(GPIO1)	PA19
8	PWM(-)	19	EXT1_8(GPIO2)	PB08
9	IRQ/GPIO	37	EXT1_9(GPIO12)	NC
10	SPI_SS_B/GPIO	36	EXT1_10(GPIO11)	NC
11	TWI_SDA	12	TEMP_SDA, EXT1_11	PA22
12	TWI_SCL	13	TEMP_SCL, EXT_12	PA23
13	UART_RX	26	RXD_EXT1_13	PA13
14	UART_TX	27	TXD_EXT1_14	PA12
15	SPI_SS_A	34	EXT_15	PA02
16	SPI_MOSI	17	SPI_MOSI, EXT1_16	PB16
17	SPI_MISO	15	SPI_MISO, EXT1_17	PA20
18	SPI_SCK	16	SPI_SCK, EXT1_18	PB17
19	GND	67	-	-
20	VCC_P	63	VCC_P	VCC_TARGET_P3V3

Table 3-1. EXT1- Xplained PRO Extension Header

Table 3-2. Xplained PRO Power Header

Pin	Signal name	Description
1	VCC_EXT_P5V0	External 5VDC input
2	GND	Ground



3	VCC_P5V0	5V
4	VCC_P	MCU Voltage

3.2.10. Temperature Sensor

The temperature sensor is placed adjacent to the MOSFET drive circuit to sense the board temperature. The AT30TSE758 temperature sensor is connected to the MCU through I²C and SMBus compatible 2-wire interface and has 7-bit I²C address 1001111.

Table 3-3. I²C Pin Connection

Signal	67Pin #	SAMD21J18A MCU pin	Indented MUX function
TEMP SDA	12	PA22	SERCOM3(PAD0)
TEMP SCL	13	PA23	SERCOM3(PAD1)
TEMP alert	24	PB30	Ю

3.2.11. Serial Flash

The AT25DF0181A 8Mb serial flash is connected to the MCU through SPI interface. Some of the pins are routed to the EXT1 header as given in the table below.

Signal	67Pin #	SAMD21J18A MCU pin	Indented MUX function	Other connection
FLASH SS	14	PA21	SERCOM5(PAD3)	
FLASH MISO	15	PA20	SERCOM5(PAD2)	EXT1_17
FLASH SCK	16	PB17	SERCOM5(PAD1)	EXT1_18
FLASH MOSI	17	PB16	SERCOM5(PAD0)	EXT1_16

Table 3-4. Flash Pin Connection

3.2.12. UID Identification Chip

The UID chip is a unique ID chip used by the EDBG interface to enable automatic board identification in Atmel Studio. When the motor control evaluation board is connected to the USB port the Atmel studio recognizes it and load the necessary software and documentation.

3.2.13. USB Communication Interface

The driver board has EDBG and MCU Micro-USB headers. EDBG USB is connected to the HS USB port of the EDBG device in the MCU card. MCU USB is connected to the USB port of the MCU in the MCU card plugged in.

3.2.14. Debug Test Points

Test points are available on the driver board for probing debug signals. Proper silk screen text is provided on the PCB to identify the test points. Some of the most useful test points are highlighted in the image below.







Figure 3-11. Debug Test Points on the Driver Board

3.2.15. Motor Specification

Specification and wiring for the motor are given in the figure below.



Figure 3-12. Motor Specification





Х

Х

3.3. ATSAMD21BLDC24V-STK MCU-driver Interface

Atmel low voltage motor control solution support plugable MCU cards. The MCU card and driver interface is a standard 67-pin interface as given in table below.

PIN	INTERFACE NAME	DRIVER BOARD	SAMD21J18A PIN	SAMD21 FUNCTION
1	EDBG USB HSP	EDBG_USB_HS_P	EDBG_USB_HS_P	EDBG_USB_HS_N
2	NC	NC	NC	NC
3	EDBG USB HSN	EDBG_USB_HS_N	EDBG_USB_HS_N	EDBG_USB_HS_N
4	EDBG ID2	EDBG_ID2/EXT1_1	EDBG_PB01	EDBG
5	NC	NC	NC	NC
6	EDBG ID1	EDBG_ID1	EDBG_PA28	EDBG
7	MCU USB DP	TARGET_USB_HS_P	PA25	USB_DN
8	TARGET USB VBUS	VCC_TARGET_USB_ P5V0	NC	NC
9	MCU USB DN	TARGET_USB_HS_N	PA24	USB_DP
10	EDBG USB VBUS	VCC_EDBG_USB_P5 V0	VCC_EDBG_USB_P5 V0	VCC_EDBG_USB_P5 V0
11	TARGET_USB_ID	TARGET_USB_ID	NC	NC
12	TEMP SDA	TEMP_SDA, EXT1_11	PA22	SERCOM3(PAD0)
13	TEMP SCL	TEMP_SCL, EXT_12	PA23	SERCOM3(PAD1)
14	FLASH SS	SPI_SS	PA21	SERCOM5(PAD3)
15	FLASH MISO	SPI_MISO, EXT1_17	PA20	SERCOM5(PAD2)
16	FLASH SCK	SPI_SCK, EXT1_18	PB17	SERCOM5(PAD1)
17	FLASH MOSI	SPI_MOSI, EXT1_16	PB16	SERCOM5(PAD0)
18	MCU GPIO1	EXT1_7(GPIO1)	PA19 (0)	I/O, EXTINT8 (Encoder)
19	MCU GPIO2	EXT1_8(GPIO2)	PB08	I/O
20	MCU GPIO3	EXT_3	NC	I/O
21	MCU GPIO4	NC(GPIO4)	NC	I/O
22	MCU GPIO5	EXT1_5(GPIO5)	PB31	I/O
23	MCU GPIO6	EXT1_6(GPIO6)	PA17	I/O
24	MCU GPIO7	Temp_Alert(GPIO7)	PB30	I/O
25	OCP	OCP(GPIO8)	PB03	I/O
26	EXT1 RXD	RXD_EXT1_13	PA13	SERCOM2(PAD1)
27	EXT1 TXD	TXD_EXT1_14	PA12	SERCOM2(PAD0)



29PWM ULPWM_ULPA14VV04(TCC0)30PWM VHPWM_VHPA09VV01(TCC0)31PWM VLPWM_VLPA15VV05(TCC0)32PWM WHPWM_WLPA16VV02(TCC0)33PWM WLPWM_WLPA16VV06(TCC0)34MCU_GPI08EXT_15PA02AIN0 (ADC)35ATA RESETEXT1_4(GPI010)NCI/O36ATA WDEXT1_10(GPI011)NCI/O37ATA SLEEPEXT1_9(GPI012)NCI/O38USHUNT_ADCUSHUNT_ADCPB04AIN12(ADC)39VSHUNT_ADCVSHUNT_ADCPB05AIN13(ADC)40WSHUNT_ADCVSHUNT_ADCPB02AIN10(ADC)41MOTOR VDCMOTOR_ADCPB02AIN10(ADC)42BEMF U_ADCBEMF_UADCPB06AIN14(ADC)43BEMF V_ADCBEMF_VADCPB06AIN14(ADC)44BEMF_WABEMF_UPPA04AIN0 (AC)45BEMF UNBEMF_UPPA06AIN2 (AC)48BEMF VNBEMF_VNPA07AIN3(AC)49BEMF VNBEMF_VNPB07AIN0(AC1)50BEMF WNBEMF_WPPB07AIN1(AC1)51HALL1HALL2PA18EXTINT352HALL2HAIL2PA18EXTINT354HALL1HALL3PA28EXTINT355ENCODER_AENCODER_BPB10EXTINT1056ENCODER					
30PWM VHPWM_VHPA09W01(TCC0)31PWM VLPWM_VLPA15W05(TCC0)32PWM WHPWM_WHPA10W02(TCC0)33PWM WLPWM_WLPA16W06(TCC0)34MCU_GPI08EXT_15PA02AIN0 (ADC)35ATA RESETEXT1_4(GPI010)NCI/O36ATA WDEXT1_10(GPI011)NCI/O37ATA SLEEPEXT1_9(GPI012)NCI/O38USHUNT_ADCUSHUNT_ADCPB04AIN12(ADC)39VSHUNT_ADCVSHUNT_ADCPB05AIN13(ADC)40WSHUNT_ADCWSHUNT_ADCPB02AIN10(ADC)41MOTOR VDCMOTOR_ADCPB02AIN10(ADC)42BEMF U_ADCBEMF_UADCPB00AIN8(ADC)43BEMF V_ADCBEMF_VADCPB06AIN14(ADC)44BEMF V_ADCBEMF_UPPA04AIN0 (AC)45BEMF UPBEMF_UPPA06AIN2 (AC)48BEMF VNBEMF_VPPA06AIN2 (AC)48BEMF VNBEMF_VPPB07AIN0(AC1)50BEMF WNBEMF_WNPB07AIN0(AC1)51HALL1HALL3PA28EXTINT352HALL2HA18EXTINT354HALL3HA28EXTINT955ENCODER_APB09EXTINT956ENCODER_BENCODER_APB09EXTINT1057ENCODER_LZENCODER_APB22I	28	PWM UH	PWM_UH	PA08	W00(TCC0)
31PWM VLPWM_VLPA15W05(TCC0)32PWM WHPWM_WHPA10W02(TCC0)33PWM WLPWM_WLPA16W06(TCC0)34MCU_GPI08EXT_15PA02AIN0 (ADC)35ATA RESETEXT1_4(GPI010)NCI/O36ATA WDEXT1_10(GPI011)NCI/O37ATA SLEEPEXT1_9(GPI012)NCI/O38USHUNT_ADCUSHUNT_ADCPB04AIN12(ADC)39VSHUNT_ADCVSHUNT_ADCPB05AIN13(ADC)40WSHUNT_ADCWSHUNT_ADCPB05AIN13(ADC)41MOTOR VDCMOTOR_ADCPB02AIN10(ADC)42BEMF U_ADCBEMF_UADCPB00AIN8(ADC)43BEMF V_ADCBEMF_VADCPB06AIN14(ADC)44BEMF_WADCBEMF_UPPA04AIN0 (AC)45BEMF UPBEMF_UPPA04AIN0 (AC)48BEMF VNBEMF_VPPA06AIN2 (AC)48BEMF VNBEMF_WPPB07AIN0(AC1)50BEMF WNBEMF_WPPB07AIN0(AC1)51HALL1HALL2PA18EXTINT352HALL2HA18PA28EXTINT354HALL1PA05PB11I/O55ENCODER_APB09EXTINT656ENCODER_BENCODER_APB09EXTINT657ENCODER_BENCODER_APB09EXTINT658ENCODER_APB09	29	PWM UL	PWM_UL	PA14	W04(TCC0)
32PWM WHPWM_WHPA10W02(TCC0)33PWM WLPWM_WLPA16W06(TCC0)34MCU_GPI08EXT_15PA02AIN0 (ADC)35ATA RESETEXT1_4(GPI010)NCI/O36ATA WDEXT1_10(GPI011)NCI/O37ATA SLEEPEXT1_9(GPI012)NCI/O38USHUNT_ADCUSHUNT_ADCPB04AIN12(ADC)39VSHUNT_ADCVSHUNT_ADCPB05AIN13(ADC)40WSHUNT_ADCWSHUNT_ADCPB02AIN10(ADC)41MOTOR VDCMOTOR_ADCPB02AIN10(ADC)42BEMF U_ADCBEMF_UADCPB00AIN8(ADC)43BEMF V_ADCBEMF_VADCPB01AIN9(ADC)44BEMF_WADCBEMF_UPPA04AIN0 (AC)45BEMF UPBEMF_UPPA06AIN2 (AC)46BEMF VNBEMF_VPPA06AIN2 (AC)47BEMF VNBEMF_VPPA07AIN3 (AC)48BEMF VNBEMF_WPPB07AIN0(AC1)50BEMF WNBEMF_WNPB07AIN1(AC1)51HALL1HALL2PA18EXTINT352HALL2HAIL2PA18EXTINT354HALL1 TRX OEHALL_TRX_OEPB11I/O55ENCODER_AENCODER_APB09EXTINT656ENCODER_BENCODER_APB03EXTINT657ENCODER_LZENCODER_APB23EXTINT658<	30	PWM VH	PWM_VH	PA09	W01(TCC0)
33PVM WLPVM_WLPA16W06(TCC0)34MCU_GPI08EXT_15PA02AIN0 (ADC)35ATA RESETEXT1_4(GPI010)NCI/O36ATA WDEXT1_10(GPI011)NCI/O37ATA SLEEPEXT1_9(GPI012)NCI/O38USHUNT_ADCUSHUNT_ADCPB04AIN12(ADC)39VSHUNT_ADCVSHUNT_ADCPB05AIN13(ADC)40WSHUNT_ADCVSHUNT_ADCPB02AIN10(ADC)41MOTOR VDCMOTOR_ADCPB02AIN10(ADC)42BEMF U_ADCBEMF_UADCPB00AIN8(ADC)43BEMF V_ADCBEMF_UADCPB06AIN14(ADC)44BEMF_WADCBEMF_UADCPB06AIN14(ADC)45BEMF UPBEMF_UPPA04AIN0 (AC)46BEMF UNBEMF_UPPA06AIN2 (AC)48BEMF VNBEMF_VNPA07AIN3 (AC)49BEMF WPBEMF_WPPB07AIN0(AC1)50BEMF WNBEMF_WPPB07AIN0(AC1)51HALL2HALL2PA18EXTINT352HALL2HALL3PA28EXTINT354HALL1 TRX OEHALL1_TRX_OEPB11I/O55ENCODER_AENCODER_BPB10EXTINT956ENCODER_BENCODER_APB22I/O57ENCODER_ENFR20FB23EXTINT7	31	PWM VL	PWM_VL	PA15	W05(TCC0)
34MCU_GPIO8EXT_15PA02AIN0 (ADC)35ATA RESETEXT1_4(GPIO10)NCI/O36ATA WDEXT1_10(GPIO11)NCI/O37ATA SLEEPEXT1_9(GPIO12)NCI/O38USHUNT_ADCUSHUNT_ADCPB04AIN12(ADC)39VSHUNT_ADCVSHUNT_ADCPB05AIN13(ADC)40WSHUNT_ADCVSHUNT_ADCPB02AIN10(ADC)41MOTOR VDCMOTOR_ADCPB02AIN10(ADC)42BEMF U_ADCBEMF_UADCPB00AIN8(ADC)43BEMF V_ADCBEMF_UADCPB06AIN14(ADC)44BEMF_WADCBEMF_UADCPB06AIN14(ADC)45BEMF UPBEMF_UPPA04AIN0 (AC)46BEMF UNBEMF_UPPA05AIN1 (AC)47BEMF VPBEMF_VNPA07AIN3 (AC)48BEMF VNBEMF_VNPA07AIN0(AC1)50BEMF WNBEMF_WNPB07AIN1(AC1)51HALL2HALL2PA18EXTINT352HALL2HALL3PA28EXTINT354HALL1 TRX OEHALL1 TRX_OEPB11I/O55ENCODER_AENCODER_BPB10EXTINT956ENCODER_BENCODER_APB22I/O57ENCODER_ENFR20FR23EXTINT758ENCODER_ENFR20FR23EXTINT7	32	PWM WH	PWM_WH	PA10	W02(TCC0)
35ATA RESETEXT1_4(GPI010)NCI/O36ATA WDEXT1_10(GPI011)NCI/O37ATA SLEEPEXT1_9(GPI012)NCI/O38USHUNT_ADCUSHUNT_ADCPB04AIN12(ADC)39VSHUNT_ADCVSHUNT_ADCPB05AIN13(ADC)40WSHUNT_ADCVSHUNT_ADCPA11AIN19(ADC)41MOTOR VDCMOTOR_ADCPB02AIN10(ADC)42BEMF U_ADCBEMF_UADCPB00AIN8(ADC)43BEMF V_ADCBEMF_VADCPB06AIN14(ADC)44BEMF_W_ADCBEMF_UPPA04AIN0 (AC)45BEMF UNBEMF_UPPA06AIN2 (AC)46BEMF VNBEMF_VPPA06AIN2 (AC)47BEMF VNBEMF_VPPA07AIN3 (AC)48BEMF VNBEMF_VPPB07AIN0(AC1)50BEMF WNBEMF_WPPB07AIN1(AC1)51HALL1HALL1PA03EXTINT352HALL2HALL2PA18EXTINT354HALL3HALL3PA28EXTINT854HALL1TRX OEHALL_TRX_OEPB10EXTINT1056ENCODER_BENCODER_BPB10EXTINT1057ENCODER_ENENCODER_ENPB22I/O	33	PWM WL	PWM_WL	PA16	W06(TCC0)
36ATA WDEXT1_10(GPI011)NCIO37ATA SLEEPEXT1_9(GPI012)NCIO38USHUNT_ADCUSHUNT_ADCPB04AIN12(ADC)39VSHUNT_ADCVSHUNT_ADCPB05AIN13(ADC)40WSHUNT_ADCVSHUNT_ADCPA11AIN19(ADC)41MOTOR VDCMOTOR_ADCPB02AIN10(ADC)42BEMF U_ADCBEMF_UADCPB00AIN8(ADC)43BEMF V_ADCBEMF_VADCPB06AIN14(ADC)44BEMF_W_ADCBEMF_UPPA04AIN0 (AC)45BEMF UNBEMF_UPPA05AIN1 (AC)46BEMF VNBEMF_VPPA06AIN2 (AC)48BEMF VNBEMF_VPPA06AIN2 (AC)49BEMF WPBEMF_WPPB07AIN0(AC1)50BEMF WNBEMF_WNPB07AIN1(AC1)51HALL1HALL1PA03EXTINT352HALL2HALL2PA18EXTINT354HALL3HALL3PA28EXTINT854HALL1TRX OEHALL_TRX_OEPB10EXTINT956ENCODER_AENCODER_BPB10EXTINT1057ENCODER_ENENCODER_ENPB22IO	34	MCU_GPIO8	EXT_15	PA02	AIN0 (ADC)
37ATA SLEEPEXT1_9(GPI012)NCI/O38USHUNT_ADCUSHUNT_ADCPB04AIN12(ADC)39VSHUNT_ADCVSHUNT_ADCPB05AIN13(ADC)40WSHUNT_ADCWSHUNT_ADCPA11AIN19(ADC)41MOTOR VDCMOTOR_ADCPB02AIN10(ADC)42BEMF U_ADCBEMF_UADCPB00AIN8(ADC)43BEMF V_ADCBEMF_VADCPB01AIN9(ADC)44BEMF_W_ADCBEMF_WADCPB06AIN14(ADC)45BEMF UPBEMF_UPPA04AIN0 (AC)46BEMF UNBEMF_VPPA05AIN1 (AC)47BEMF VPBEMF_VPPA06AIN2 (AC)48BEMF VNBEMF_VNPA07AIN3 (AC)49BEMF WPBEMF_WPPB07AIN1(AC1)50BEMF WNBEMF_WNPB07AIN1(AC1)51HALL1HALL1PA28EXTINT352HALL2HALL2PA18EXTINT354HALL3HALL3PA28EXTINT955ENCODER_AENCODER_BPB10EXTINT056ENCODER_BENCODER_ZPB23EXTINT758ENCODER_ENENCODER_ENPB22I/O	35	ATA RESET	EXT1_4(GPIO10)	NC	I/O
38USHUNT_ADCUSHUNT_ADCPB04AIN12(ADC)39VSHUNT_ADCVSHUNT_ADCPB05AIN13(ADC)40WSHUNT_ADCWSHUNT_ADCPA11AIN19(ADC)41MOTOR VDCMOTOR_ADCPB02AIN10(ADC)42BEMF U_ADCBEMF_UADCPB00AIN8(ADC)43BEMF V_ADCBEMF_VADCPB01AIN9(ADC)44BEMF_W_ADCBEMF_WADCPB06AIN14(ADC)45BEMF UPBEMF_UPPA04AIN0 (AC)46BEMF UNBEMF_VPPA05AIN1 (AC)47BEMF VPBEMF_VPPA06AIN2 (AC)48BEMF VNBEMF_VNPA07AIN3 (AC)49BEMF WPBEMF_WPPB07AIN1(AC1)50BEMF WNBEMF_WNPB07AIN1(AC1)51HALL1HALL1PA03EXTINT352HALL2PA18EXTINT354HALL3HALL3PA28EXTINT854HALL1 TRX OEHALL_TRX_OEPB11I/O55ENCODER_AENCODER_BPB10EXTINT1056ENCODER_BENCODER_ZPB23EXTINT758ENCODER_ENENCODER_ENPB22I/O	36	ATA WD	EXT1_10(GPIO11)	NC	I/O
39VSHUNT_ADCVSHUNT_ADCPB05AIN13(ADC)40WSHUNT_ADCWSHUNT_ADCPA11AIN19(ADC)41MOTOR VDCMOTOR_ADCPB02AIN10(ADC)42BEMF U_ADCBEMF_UADCPB00AIN8(ADC)43BEMF V_ADCBEMF_VADCPB06AIN14(ADC)44BEMF_WADCBEMF_WADCPB06AIN14(ADC)45BEMF_UPBEMF_UPPA04AIN0 (AC)46BEMF UNBEMF_UNPA05AIN1 (AC)47BEMF VPBEMF_VPPA06AIN2 (AC)48BEMF VNBEMF_VNPA07AIN3 (AC)49BEMF WPBEMF_WNPB07AIN0(AC1)50BEMF WNBEMF_WNPB07AIN1(AC1)51HALL1HALL2PA18EXTINT352HALL2HALL2PA18EXTINT354HALL3PA28EXTINT854HALL3RX_OEPB10EXTINT956ENCODER_AENCODER_APB09EXTINT1057ENCODER_ZENCODER_ENPB22I/O	37	ATA SLEEP	EXT1_9(GPIO12)	NC	I/O
40WSHUNT_ADCWSHUNT_ADCPA11AIN19(ADC)41MOTOR VDCMOTOR_ADCPB02AIN10(ADC)42BEMF U_ADCBEMF_UADCPB00AIN8(ADC)43BEMF V_ADCBEMF_VADCPB01AIN9(ADC)44BEMF_W_ADCBEMF_WADCPB06AIN14(ADC)45BEMF UPBEMF_UPPA04AIN0 (AC)46BEMF VNBEMF_UPPA05AIN1 (AC)47BEMF VPBEMF_VPPA06AIN2 (AC)48BEMF VNBEMF_VPPB07AIN0(AC1)50BEMF WPBEMF_WPPB07AIN0(AC1)51HALL1HALL1PA03EXTINT352HALL2HALL2PA18EXTINT253HALL3HALL3PA28EXTINT954HALL TRX OEHALL_TRX_OEPB10EXTINT955ENCODER_AENCODER_BPB10EXTINT1057ENCODER_ENENCODER_ENPB22I/O	38	USHUNT_ADC	USHUNT_ADC	PB04	AIN12(ADC)
41MOTOR VDCMOTOR_ADCPB02AIN10(ADC)42BEMF U_ADCBEMF_UADCPB00AIN8(ADC)43BEMF V_ADCBEMF_VADCPB01AIN9(ADC)44BEMF_W_ADCBEMF_WADCPB06AIN14(ADC)45BEMF UPBEMF_UPPA04AIN0 (AC)46BEMF UNBEMF_UPPA05AIN1 (AC)47BEMF VPBEMF_VPPA06AIN2 (AC)48BEMF VNBEMF_VPPA07AIN3 (AC)49BEMF WPBEMF_WPPB07AIN0(AC1)50BEMF WNBEMF_WNPB07AIN1(AC1)51HALL1HALL1PA03EXTINT352HALL2HALL2PA18EXTINT354HALL3PA28EXTINT854HALL TRX OEHALL_TRX_OEPB11I/O55ENCODER_AENCODER_APB09EXTINT1056ENCODER_BENCODER_APB22I/O	39	VSHUNT_ADC	VSHUNT_ADC	PB05	AIN13(ADC)
42BEMF U_ADCBEMF_UADCPB00AIN8(ADC)43BEMF V_ADCBEMF_VADCPB01AIN9(ADC)44BEMF_W_ADCBEMF_WADCPB06AIN14(ADC)45BEMF UPBEMF_UPPA04AIN0 (AC)46BEMF UNBEMF_UNPA05AIN1 (AC)47BEMF VPBEMF_VPPA06AIN2 (AC)48BEMF VPBEMF_VNPA07AIN3 (AC)49BEMF WPBEMF_WPPB07AIN0(AC1)50BEMF WNBEMF_WNPB07AIN1(AC1)51HALL1HALL1PA03EXTINT352HALL2HALL2PA18EXTINT353HALL3HALL3PA28EXTINT854HALLTRX OEHALL_TRX_OEPB11/O55ENCODER_AENCODER_APB09EXTINT1056ENCODER_BENCODER_BPB10EXTINT1057ENCODER_ENENCODER_ENPB22I/O	40	WSHUNT_ADC	WSHUNT_ADC	PA11	AIN19(ADC)
43BEMF V_ADCBEMF_VADCPB01AIN9(ADC)44BEMF_W_ADCBEMF_WADCPB06AIN14(ADC)45BEMF_UPBEMF_UPPA04AIN0 (AC)46BEMF UNBEMF_UNPA05AIN1 (AC)47BEMF VPBEMF_VPPA06AIN2 (AC)48BEMF VNBEMF_VPPA07AIN3 (AC)49BEMF WPBEMF_WPPB07AIN0(AC1)50BEMF WNBEMF_WNPB07AIN1(AC1)51HALL1HALL1PA03EXTINT352HALL2HALL2PA18EXTINT353HALL3HALL3PA28EXTINT954HALL TRX OEHALL_TRX_OEPB11I/O55ENCODER_AENCODER_BPB10EXTINT1057ENCODER_BENCODER_BPB10EXTINT758ENCODER_ENPB22I/OI/O	41	MOTOR VDC	MOTOR_ADC	PB02	AIN10(ADC)
44BEMF_W_ADCBEMF_WADCPB06AIN14(ADC)45BEMF UPBEMF_UPPA04AIN0 (AC)46BEMF UNBEMF_UNPA05AIN1 (AC)47BEMF VPBEMF_VPPA06AIN2 (AC)48BEMF VNBEMF_VNPA07AIN3 (AC)49BEMF WPBEMF_WPPB07AIN0(AC1)50BEMF WNBEMF_WNPB07AIN1(AC1)51HALL1HALL1PA03EXTINT352HALL2HALL2PA18EXTINT253HALL3HALL3PA28EXTINT854HALL TRX OEHALL_TRX_OEPB11I/O55ENCODER_AENCODER_BPB10EXTINT956ENCODER_BENCODER_BPB10EXTINT1057ENCODER_ENENCODER_ENPB22I/O	42	BEMF U_ADC	BEMF_UADC	PB00	AIN8(ADC)
45BEMF UPBEMF_UPPA04AIN0 (AC)46BEMF UNBEMF_UNPA05AIN1 (AC)47BEMF VPBEMF_VPPA06AIN2 (AC)48BEMF VNBEMF_VNPA07AIN3 (AC)49BEMF WPBEMF_WPPB07AIN0(AC1)50BEMF WNBEMF_WNPB07AIN1(AC1)51HALL1HALL1PA03EXTINT352HALL2HALL2PA18EXTINT253HALL3PA28EXTINT854HALL TRX OEHALL_TRX_OEPB11I/O55ENCODER_AENCODER_APB09EXTINT956ENCODER_BENCODER_ZPB23EXTINT758ENCODER_ENPB22I/O	43	BEMF V_ADC	BEMF_VADC	PB01	AIN9(ADC)
46BEMF UNBEMF_UNPA05AIN1 (AC)47BEMF VPBEMF_VPPA06AIN2 (AC)48BEMF VNBEMF_VNPA07AIN3 (AC)49BEMF WPBEMF_WPPB07AIN0(AC1)50BEMF WNBEMF_WNPB07AIN1(AC1)51HALL1HALL1PA03EXTINT352HALL2HALL2PA18EXTINT253HALL3HALL3PA28EXTINT854HALL TRX OEHALL_TRX_OEPB11/O55ENCODER_AENCODER_APB09EXTINT956ENCODER_BENCODER_BPB23EXTINT758ENCODER_ENPB22I/OI/O	44	BEMF_W_ADC	BEMF_WADC	PB06	AIN14(ADC)
47BEMF VPBEMF_VPPA06AIN2 (AC)48BEMF VNBEMF_VNPA07AIN3 (AC)49BEMF WPBEMF_WPPB07AIN0(AC1)50BEMF WNBEMF_WNPB07AIN1(AC1)51HALL1HALL1PA03EXTINT352HALL2HALL2PA18EXTINT253HALL3HALL3PA28EXTINT854HALL TRX OEHALL_TRX_OEPB11I/O55ENCODER_AENCODER_APB09EXTINT956ENCODER_BENCODER_ZPB23EXTINT758ENCODER_ENPB22I/O	45	BEMF UP	BEMF_UP	PA04	AIN0 (AC)
48BEMF VNBEMF_VNPA07AIN3 (AC)49BEMF WPBEMF_WPPB07AIN0(AC1)50BEMF WNBEMF_WNPB07AIN1(AC1)51HALL1HALL1PA03EXTINT352HALL2HALL2PA18EXTINT253HALL3HALL3PA28EXTINT854HALL TRX OEHALL_TRX_OEPB11/O55ENCODER_AENCODER_APB09EXTINT956ENCODER_BENCODER_BPB10EXTINT1057ENCODER_ZENCODER_ZPB23EXTINT758ENCODER_ENENCODER_ENPB22//O	46	BEMF UN	BEMF_UN	PA05	AIN1 (AC)
49BEMF WPBEMF_WPPB07AIN0(AC1)50BEMF WNBEMF_WNPB07AIN1(AC1)51HALL1HALL1PA03EXTINT352HALL2HALL2PA18EXTINT253HALL3HALL3PA28EXTINT854HALL TRX OEHALL_TRX_OEPB11I/O55ENCODER_AENCODER_APB09EXTINT956ENCODER_BENCODER_BPB10EXTINT1057ENCODER_ZENCODER_ZPB23EXTINT758ENCODER_ENPB22I/OI/O	47	BEMF VP	BEMF_VP	PA06	AIN2 (AC)
50BEMF WNBEMF_WNPB07AIN1(AC1)51HALL1HALL1PA03EXTINT352HALL2HALL2PA18EXTINT253HALL3HALL3PA28EXTINT854HALL TRX OEHALL_TRX_OEPB11I/O55ENCODER_AENCODER_APB09EXTINT956ENCODER_BENCODER_BPB10EXTINT1057ENCODER_ZENCODER_ZPB23EXTINT758ENCODER_ENPB22I/OI/O	48	BEMF VN	BEMF_VN	PA07	AIN3 (AC)
51HALL1PA03EXTINT352HALL2HALL2PA18EXTINT253HALL3HALL3PA28EXTINT854HALL TRX OEHALL_TRX_OEPB11//O55ENCODER_AENCODER_APB09EXTINT956ENCODER_BENCODER_BPB10EXTINT1057ENCODER_ZENCODER_ZPB23EXTINT758ENCODER_ENENCODER_ENPB22//O	49	BEMF WP	BEMF_WP	PB07	AIN0(AC1)
52HALL2HALL2PA18EXTINT253HALL3HALL3PA28EXTINT854HALL TRX OEHALL_TRX_OEPB11//O55ENCODER_AENCODER_APB09EXTINT956ENCODER_BENCODER_BPB10EXTINT1057ENCODER_ZENCODER_ZPB23EXTINT758ENCODER_ENENCODER_ENPB22//O	50	BEMF WN	BEMF_WN	PB07	AIN1(AC1)
53HALL3PA28EXTINT854HALL TRX OEHALL_TRX_OEPB11//O55ENCODER_AENCODER_APB09EXTINT956ENCODER_BENCODER_BPB10EXTINT1057ENCODER_ZENCODER_ZPB23EXTINT758ENCODER_ENPB22//O	51	HALL1	HALL1	PA03	EXTINT3
54HALL TRX OEHALL_TRX_OEPB11I/O55ENCODER_AENCODER_APB09EXTINT956ENCODER_BENCODER_BPB10EXTINT1057ENCODER_ZENCODER_ZPB23EXTINT758ENCODER_ENPB22I/O	52	HALL2	HALL2	PA18	EXTINT2
55ENCODER_AENCODER_APB09EXTINT956ENCODER_BENCODER_BPB10EXTINT1057ENCODER_ZENCODER_ZPB23EXTINT758ENCODER_ENENCODER_ENPB22I/O	53	HALL3	HALL3	PA28	EXTINT8
56ENCODER_BENCODER_BPB10EXTINT1057ENCODER_ZENCODER_ZPB23EXTINT758ENCODER_ENENCODER_ENPB22I/O	54	HALL TRX OE	HALL_TRX_OE	PB11	I/O
57ENCODER_ZENCODER_ZPB23EXTINT758ENCODER_ENENCODER_ENI/O	55	ENCODER_A	ENCODER_A	PB09	EXTINT9
58ENCODER_ENPB22I/O	56	ENCODER_B	ENCODER_B	PB10	EXTINT10
	57	ENCODER_Z	ENCODER_Z	PB23	EXTINT7
	58	ENCODER_EN	ENCODER_EN	PB22	I/O
	59	NC	NC	NC	NC
60 NC NC NC NC	60	NC	NC	NC	NC
61 NC NC NC NC	61	NC	NC	NC	NC



62	3V3 SUPPLY for MCU	VCC_P	VCC_TARGET_P3V3	NC
63	3V3 SUPPLY for MCU	VCC_P	VCC_TARGET_P3V3	NC
64	GND	GND	GND	NC
65	GND	GND	GND	NC
66	GND	GND	GND	NC
67	GND	GND	GND	NC



4. Hardware Revision History and Known Issues

4.1. Identifying Product ID and Revision

The revision and product identifier of ATSAMD21BLDC24V-STK can be found by looking at the sticker on the bottom side of the PCB. The identifier and revision are printed in plain text as A09-nnnn\rr, where nnnn is the identifier and rr is the revision. Also the label contains a 10-digit serial number unique to each kit assembly that contains the PCBs, motor and chassis.

The product identifier for ATSAMD21BLDC24V-STK is A09-2671.

4.2. Revision

Kit assembly revision for initial version is A09-2671/03. Known issues in this revision are:

 The driver board should be powered OFF when the user is changing the power supply selection switch or power supply selection jumper. Overall power consumption of the board seems to be increasing otherwise.



5. Product Compliance

RoHS and WEEE

The Atmel ATSAMD21BLDC24V-STK and its accessories are manufactured in accordance to both the RoHS Directive (2002/95/EC) and the WEEE Directive (2002/96/EC).

CE and FCC

The Atmel ATSAMD21BLDC24V-STK unit has been tested in accordance to the essential requirements and other relevant provisions of Directives:

- Directive 2004/108/EC (class B)
- FCC rules part 15 subpart B

The following standards are used for evaluation:

- EN 61326-1 (2013)
- FCC CFR 47 Part 15 (2013)

The Technical Construction File is located at:

```
Atmel Norway
Vestre Rosten 79
7075 Tiller
Norway
```

Every effort has been made to minimize electromagnetic emissions from this product. However, under certain conditions, the system (this product connected to a target application circuit) may emit individual electromagnetic component frequencies which exceed the maximum values allowed by the above-mentioned standards. The frequency and magnitude of the emissions will be determined by several factors, including layout and routing of the target application with which the product is used.



6. Revision History

Doc. Rev.	Date	Description
42681A	02/2016	Initial document release.





f 🔰 in 8 🖸 W

Т

Atmel Enabling Unlimited Possibilities

Atmel Corporation

1600 Technology Drive, San Jose, CA 95110 USA

T: (+1)(408) 441.0311

F: (+1)(408) 436.4200

www.atmel.com

© 2016 Atmel Corporation. / Rev.: Atmel-42681A-SMART-ARM-based-Motor-Control-Kit_User Guide-02/2016

Atmel[®], Atmel logo and combinations thereof, Enabling Unlimited Possibilities[®], and others are registered trademarks or trademarks of Atmel Corporation in U.S. and other countries. ARM[®], ARM Connected[®] logo, Cortex[®], and others are the registered trademarks or trademarks of ARM Ltd. Other terms and product names may be trademarks of others.

DISCLAIMER: The information in this document is provided in connection with Atmel products. No license, express or implied, by estoppel or otherwise, to any intellectual property right is granted by this document or in connection with the sale of Atmel products. EXCEPT AS SET FORTH IN THE ATMEL TERMS AND CONDITIONS OF SALES LOCATED ON THE ATMEL WEBSITE, ATMEL ASSUMES NO LIABILITY WHATSOEVER AND DISCLAIMS ANY EXPRESS, IMPLIED OR STATUTORY WARRANTY RELATING TO ITS PRODUCTS INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT. IN NO EVENT SHALL ATMEL BE LIABLE FOR ANY DIRECT, INDIRECT, CONSEQUENTIAL, PUNITIVE, SPECIAL OR INCIDENTAL DAMAGES (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS AND PROFITS, BUSINESS INTERRUPTION, OR LOSS OF INFORMATION) ARISING OUT OF THE USE OR INABILITY TO USE THIS DOCUMENT, EVEN IF ATMEL HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Atmel makes no representations or warranties with respect to the accuracy or completeness of the contents of this document and reserves the right to make changes to specifications and products descriptions at any time without notice. Atmel does not make any commitment to update the information contained herein. Unless specifically provided otherwise, Atmel products are not suitable for, and shall not be used in, automotive applications. Atmel products are not intended, authorized, or warranted for use as components in applications intended to support or sustain life.

SAFETY-CRITICAL, MILITARY, AND AUTOMOTIVE APPLICATIONS DISCLAIMER: Atmel products are not designed for and will not be used in connection with any applications where the failure of such products would reasonably be expected to result in significant personal injury or death ("Safety-Critical Applications") without an Atmel officer's specific written consent. Safety-Critical Applications include, without limitation, life support devices and systems, equipment or systems for the operation of nuclear facilities and weapons systems. Atmel products are not designed nor intended for use in military or aerospace applications unless specifically designated by Atmel as military-grade. Atmel products are not designed nor intended for use in automotive applications unless specifically designated by Atmel as automotive-grade.

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Power Management IC Development Tools category:

Click to view products by Microchip manufacturer:

Other Similar products are found below :

EVB-EP5348UI MIC23451-AAAYFL EV MIC5281YMME EV 124352-HMC860LP3E DA9063-EVAL ADP122-3.3-EVALZ ADP130-0.8-EVALZ ADP130-1.8-EVALZ ADP1740-1.5-EVALZ ADP1870-0.3-EVALZ ADP1874-0.3-EVALZ ADP199CB-EVALZ ADP2102-1.25-EVALZ ADP2102-1.875EVALZ ADP2102-1.8-EVALZ ADP2102-2-EVALZ ADP2102-3-EVALZ ADP2102-4-EVALZ AS3606-DB BQ25010EVM BQ3055EVM ISLUSBI2CKIT1Z LP38512TS-1.8EV EVAL-ADM1186-1MBZ EVAL-ADM1186-2MBZ ADP122UJZ-REDYKIT ADP166Z-REDYKIT ADP170-1.8-EVALZ ADP171-EVALZ ADP1853-EVALZ ADP1873-0.3-EVALZ ADP198CP-EVALZ ADP2102-1.0-EVALZ ADP2102-1-EVALZ ADP2107-1.8-EVALZ ADP5020CP-EVALZ CC-ACC-DBMX-51 ATPL230A-EK MIC23250-S4YMT EV MIC26603YJL EV MIC33050-SYHL EV TPS60100EVM-131 TPS65010EVM-230 TPS71933-28EVM-213 TPS72728YFFEVM-407 TPS79318YEQEVM UCC28810EVM-002 XILINXPWR-083 LMR22007YMINI-EVM LP38501ATJ-EV