


## GNSS expansion board based on Teseo-LIV3F module for STM32 Nucleo



### Features

- Operating supply voltage: 3.3 - 5 V
- Ambient temperature: -40/+85 °C
- Sensitivity: -162 dBm indoor (tracking mode)
- Interfaces:
  - a UART port
  - an I<sup>2</sup>C port
  - Configurable digital I/O timepulse
  - EXTINT input for wakeup
- NMEA protocol
- Assisted GNSS:
  - Predictive autonomous
  - Predictive server-based
  - Real-time server-based
- Compatible with [STM32 Nucleo](#) boards
- Compatible with the [Arduino™ UNO R3](#) connector
- LNA and SAW filter on the RF path
- SMA female antenna connector
- Battery holder
- RoHS and WEEE compliant

### Product summary

GNSS expansion board based on Teseo-LIV3F module for STM32 Nucleo	<a href="#">X-NUCLEO-GNSS1A1</a>
Tiny GNSS module	<a href="#">Teseo-LIV3F</a>
Global navigation satellite system software expansion for STM32Cube	<a href="#">X-CUBE-GNSS1</a>

### Description

The [X-NUCLEO-GNSS1A1](#) expansion board is based on the [Teseo-LIV3F](#) tiny GNSS module.


It represents an affordable, easy-to-use, global navigation satellite system (GNSS) module, embedding a TeseoIII single die standalone positioning receiver IC, usable in different configurations in your [STM32 Nucleo](#) project.




The Teseo-LIV3F is a compact (9.7x10.1 mm) module that provides superior accuracy thanks to the on-board 26 MHz temperature compensated crystal oscillator (TCXO) and a reduced time-to-first fix (TTFF) with its dedicated 32 KHz real-time clock (RTC) oscillator.

The Teseo-LIV3F module runs the GNSS firmware ([X-CUBE-GNSS1](#)) to perform all GNSS operations including acquisition, tracking, navigation and data output without external memory support.

The [X-NUCLEO-GNSS1A1](#) expansion board is compatible with the [Arduino™ UNO R3](#) connector and the ST morpho connector, so it can be plugged to the [STM32 Nucleo](#) development board and stacked with additional [STM32 Nucleo](#) expansion boards.

# 1 Schematic diagram

**Figure 1. X-NUCLEO-GNSS1A1 circuit schematic (1 of 3)**


**Figure 2. X-NUCLEO-GNSS1A1 circuit schematic (2 of 3)**

**Figure 3. X-NUCLEO-GNSS1A1 circuit schematic (3 of 3)**


## Revision history

**Table 1. Document revision history**

Date	Version	Changes
05-Dec-2017	1	Initial release.
12-Oct-2018	2	Updated cover page image and <a href="#">Section 1 Schematic diagram</a> .

**IMPORTANT NOTICE – PLEASE READ CAREFULLY**

STMicroelectronics NV and its subsidiaries (“ST”) reserve the right to make changes, corrections, enhancements, modifications, and improvements to ST products and/or to this document at any time without notice. Purchasers should obtain the latest relevant information on ST products before placing orders. ST products are sold pursuant to ST’s terms and conditions of sale in place at the time of order acknowledgement.

Purchasers are solely responsible for the choice, selection, and use of ST products and ST assumes no liability for application assistance or the design of Purchasers’ products.

No license, express or implied, to any intellectual property right is granted by ST herein.

Resale of ST products with provisions different from the information set forth herein shall void any warranty granted by ST for such product.

ST and the ST logo are trademarks of ST. All other product or service names are the property of their respective owners.

Information in this document supersedes and replaces information previously supplied in any prior versions of this document.

© 2018 STMicroelectronics – All rights reserved

## X-ON Electronics

Largest Supplier of Electrical and Electronic Components

*Click to view similar products for [GPS Development Tools](#) category:*

*Click to view products by [STMicroelectronics](#) manufacturer:*

Other Similar products are found below :

[MAX2769EVKIT](#) [A9G](#) [SKY65725-11EK1](#) [SKY65728-11EK1](#) [TAU1201-EVK-A00](#) [1059](#) [1090](#) [MIKROE-2045](#) [1272](#) [MDEV-GNSS-TM](#)  
[TEL0051](#) [M20050-EVB-1](#) [GPS-14414](#) [SIM808](#) [EVK-M8BZOE-0](#) [EVK-M8N-0](#) [EVK-M8U](#) [SIM868](#) [746](#) [2324](#) [4279](#) [4415](#) [M10578-A2-U1](#)  
[ASX00017](#) [AS-RTK2B-F9P-L1L2-NH-02](#) [AS-RTK2B-LIT-L1L2-SMA-00](#) [AS-STARTKIT-BASIC-L1L2-NH-02](#) [AS-STARTKIT-LITE-](#)  
[L1L2-HS-00](#) [AS-STARTKIT-LR-L1L2-EUNH-00](#) [AS-STARTKIT-LR-L1L2-NANH-00](#) [AS-STARTKIT-MCPIE-L1L2-0-00](#) [AS-](#)  
[STARTKIT-MR-L1L2-NH-00](#) [A2235HB04](#) [M5310A-MBR](#) [M5312](#) [EVA2035-H](#) [EVA2100-A](#) [EVA2200-A](#) [MAX2659EVKIT+](#)  
[MAX2669EVKIT+](#) [MIKROE-4673](#) [MIKROE-1032](#) [MIKROE-1714](#) [MIKROE-1850](#) [MIKROE-1887](#) [MIKROE-1895](#) [MIKROE-1912](#)  
[MIKROE-2382](#) [ML302](#) [MOD-GPS](#)