

# **ADSP-BF527 EZ-KIT Lite® Evaluation System Manual**

Revision 1.7, July 2012

Part Number  
82-000208-01

Analog Devices, Inc.  
One Technology Way  
Norwood, Mass. 02062-9106



## **Copyright Information**

© 2012 Analog Devices, Inc., ALL RIGHTS RESERVED. This document may not be reproduced in any form without prior, express written consent from Analog Devices, Inc.

Printed in the USA.

## **Disclaimer**

Analog Devices, Inc. reserves the right to change this product without prior notice. Information furnished by Analog Devices is believed to be accurate and reliable. However, no responsibility is assumed by Analog Devices for its use; nor for any infringement of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under the patent rights of Analog Devices, Inc.

## **Trademark and Service Mark Notice**

The Analog Devices logo, Blackfin, CrossCore, EngineerZone, EZ-Extender, EZ-KIT Lite, Lockbox, and VisualDSP++ are registered trademarks of Analog Devices, Inc.

All other brand and product names are trademarks or service marks of their respective owners.

## Regulatory Compliance

The ADSP-BF527 EZ-KIT Lite is designed to be used solely in a laboratory environment. The board is not intended for use as a consumer end product or as a portion of a consumer end product. The board is an open system design which does not include a shielded enclosure and therefore may cause interference to other electrical devices in close proximity. This board should not be used in or near any medical equipment or RF devices.

The ADSP-BF527 EZ-KIT Lite has been certified to comply with the essential requirements of the European EMC directive 2004/108/EC and therefore carries the “CE” mark.

The ADSP-BF527 EZ-KIT Lite has been appended to Analog Devices, Inc. EMC Technical File (EMC TF) referenced **DSPTOOLS1**, issue 2 dated June 4, 2008 and was declared CE compliant by an appointed Notified Body (No.0673) as listed below.

Notified Body Statement of Compliance: Z600ANA2.030 dated June 4, 2008.



Issued by: Technology International (Europe) Limited  
60 Shrivenham Hundred Business Park  
Shrivenham, Swindon, SN6 8TY, UK

The EZ-KIT Lite evaluation system contains ESD (electrostatic discharge) sensitive devices. Electrostatic charges readily accumulate on the human body and equipment and can discharge without detection. Permanent damage may occur on devices subjected to high-energy discharges. Proper ESD precautions are recommended to avoid performance degradation or loss of functionality. Store unused EZ-KIT Lite boards in the protective shipping package.





# CONTENTS

## PREFACE

|                                 |       |
|---------------------------------|-------|
| Product Overview .....          | xiii  |
| Purpose of This Manual .....    | xv    |
| Intended Audience .....         | xvi   |
| Manual Contents .....           | xvi   |
| What's New in This Manual ..... | xvii  |
| Technical Support .....         | xvii  |
| Supported Processors .....      | xviii |
| Product Information .....       | xviii |
| Analog Devices Web Site .....   | xviii |
| EngineerZone .....              | xx    |
| Related Documents .....         | xx    |
| Notation Conventions .....      | xxi   |

## USING THE ADSP-BF527 EZ-KIT LITE

|  |     |
|--|-----|
| Package Contents .....                 | 1-3 |
| Default Configuration .....            | 1-3 |
| CCES Install and Session Startup ..... | 1-4 |
| Session Startup .....                  | 1-6 |

# Contents

|   |      |
|---|------|
| VisualDSP++ Install and Session Startup ..... | 1-8  |
| CCES Evaluation License .....                 | 1-10 |
| VisualDSP++ Evaluation License .....          | 1-11 |
| Lockbox Key Security Features .....           | 1-11 |
| Memory Map .....                              | 1-12 |
| SDRAM Interface .....                         | 1-15 |
| Parallel Flash Memory Interface .....         | 1-17 |
| NAND Flash Interface .....                    | 1-17 |
| SPI Interface .....                           | 1-18 |
| PPI Interface .....                           | 1-19 |
| LCD Module Interface .....                    | 1-19 |
| Touchscreen Interface .....                   | 1-21 |
| Keypad Interface .....                        | 1-21 |
| Rotary Encoder Interface .....                | 1-22 |
| Ethernet Interface .....                      | 1-22 |
| Audio Interface .....                         | 1-23 |
| USB OTG Interface .....                       | 1-25 |
| UART Interface .....                          | 1-26 |
| RTC Interface .....                           | 1-27 |
| LEDs and Push Buttons .....                   | 1-27 |
| JTAG Interface .....                          | 1-28 |
| Expansion Interface .....                     | 1-29 |
| Power Measurements .....                      | 1-29 |
| Power-On-Self Test .....                      | 1-30 |

|                             |      |
|-----------------------------|------|
| Example Programs .....      | 1-31 |
| Board Design Database ..... | 1-31 |

## ADSP-BF527 EZ-KIT LITE HARDWARE REFERENCE

|  |      |
|--|------|
| System Architecture .....                        | 2-2  |
| Programmable Flags .....                         | 2-3  |
| Push Buttons and Switches .....                  | 2-10 |
| ETH Enable Switch (SW1) .....                    | 2-10 |
| Boot Mode Select Switch (SW2) .....              | 2-11 |
| Rotary Encoder With Momentary Switch (SW3) ..... | 2-12 |
| MIC Gain Switch (SW4) .....                      | 2-12 |
| LCD Reset Switch (SW5) .....                     | 2-13 |
| Flash Enable Switch (SW7) .....                  | 2-13 |
| Mic/HP LPBK Audio Mode Switch (SW8) .....        | 2-14 |
| ETH Mode Flash CS Switch (SW9) .....             | 2-14 |
| UART Enable Switch (SW10) .....                  | 2-15 |
| Rotary NAND Enable Switch (SW11) .....           | 2-16 |
| GPIO Enable Switch (SW13) .....                  | 2-17 |
| Programmable Flag Push Buttons (SW14–15) .....   | 2-18 |
| Reset Push Button (SW16) .....                   | 2-18 |
| SPI/TWI Switch (SW19) .....                      | 2-19 |
| SPORT0A ENBL Switches (SW20 and SW27) .....      | 2-19 |
| TFS0A/HOSTCE Enable Switch (SW21) .....          | 2-19 |
| Touch ADD Switch (SW22) .....                    | 2-19 |
| Touchpad INT Switch (SW24) .....                 | 2-20 |

# Contents

|   |      |
|---|------|
| LCD/KPAD CTL Switch (SW25) .....            | 2-20 |
| Mode Switch (SW26) .....                    | 2-21 |
| Line In-Out LPBK Switch (SW28) .....        | 2-22 |
| CPLD D8–13 Switch (SW29) .....              | 2-22 |
| CPLD 14–15/DCE ENB Switch (SW30) .....      | 2-22 |
| Jumpers .....                               | 2-23 |
| MIC Select Jumper (JP6) .....               | 2-23 |
| STAMP Enable Jumper (JP7) .....             | 2-23 |
| Flash WP Jumper (JP10) .....                | 2-24 |
| STP ENB Enable Jumper (JP14) .....          | 2-24 |
| LED0 OFF Jumper (JP15) .....                | 2-24 |
| VDDINT Power Jumper (P14) .....             | 2-25 |
| VDDEXT Power Jumper (P15) .....             | 2-25 |
| VDDMEM Power Jumper (P16) .....             | 2-25 |
| LEDs .....                                  | 2-26 |
| User LEDs (LED1–3) .....                    | 2-26 |
| Power LED (LED4) .....                      | 2-27 |
| Reset LED (LED5) .....                      | 2-27 |
| Ethernet LEDs (LED6–7) .....                | 2-27 |
| Keypad Current Sink LED (LED8) .....        | 2-27 |
| Connectors .....                            | 2-28 |
| Expansion Interface Connectors (J1–3) ..... | 2-28 |
| DCE (RS-232) Connector (J4) .....           | 2-29 |
| Battery Holder (J5) .....                   | 2-29 |



|                                       |      |
|---------------------------------------|------|
| Power Connector (J6) .....            | 2-30 |
| Dual Audio Connectors (J7–8) .....    | 2-30 |
| Ethernet Connector (J9) .....         | 2-30 |
| USB OTG Connector (P1) .....          | 2-31 |
| Keypad Connector (P2) .....           | 2-31 |
| UART0 Connector (P5) .....            | 2-31 |
| SPORT0 Connector (P6) .....           | 2-32 |
| SPORT1 Connector (P7) .....           | 2-32 |
| PPI Connector (P8) .....              | 2-32 |
| SPI Connector (P9) .....              | 2-33 |
| TWI Connector (P10) .....             | 2-33 |
| TIMERS Connector (P11) .....          | 2-33 |
| Host Interface Connector (P13) .....  | 2-34 |
| CPLD JTAG Connector (P17) .....       | 2-34 |
| LCD Data Connector (P18) .....        | 2-34 |
| USB Debug Agent Connector (ZJ1) ..... | 2-35 |
| JTAG Connector (ZP4) .....            | 2-35 |

## **ADSP-BF527 EZ-KIT LITE BILL OF MATERIALS**

## **ADSP-BF527 EZ-KIT LITE SCHEMATIC**

## **INDEX**

# Contents

# PREFACE

Thank you for purchasing the ADSP-BF527 EZ-KIT Lite<sup>®</sup>, Analog Devices, Inc. evaluation system for Blackfin<sup>®</sup> processors.

Blackfin processors embody a type of embedded processor designed specifically to meet the computational demands and power constraints of today's embedded audio, video, and communications applications. They deliver breakthrough signal-processing performance and power efficiency within a reduced instruction set computing (RISC) programming model.

Blackfin processors support a media instruction set computing (MISC) architecture. This architecture is the natural merging of RISC, media functions, and digital signal processing (DSP) characteristics. Blackfin processors deliver signal-processing performance in a microprocessor-like environment.

Based on the Micro Signal Architecture (MSA), Blackfin processors combine a 32-bit RISC instruction set, dual 16-bit multiply accumulate (MAC) DSP functionality, and eight-bit video processing performance that had previously been the exclusive domain of very-long instruction word (VLIW) media processors.

The evaluation board is designed to be used in conjunction with the CrossCore<sup>®</sup> Embedded Studio (CCES) and VisualDSP++<sup>®</sup> development environments to test capabilities of the ADSP-BF523/BF525/BF527 Blackfin processors. The development environment facilitates advanced application code development and debug, such as:

- Create, compile, assemble, and link application programs written in C++, C, and ADSP-BF527 assembly
- Load, run, step, halt, and set breakpoints in application programs
- Read and write data and program memory
- Read and write core and peripheral registers
- Plot memory

Access to the processor from a personal computer (PC) is achieved through a USB port or an external JTAG emulator. The USB interface provides unrestricted access to the ADSP-BF527 processor and evaluation board peripherals. Analog Devices JTAG emulators offer faster communication between the host PC and target hardware. Analog Devices carries a wide range of in-circuit emulation products. To learn more about Analog Devices emulators and processor development tools, go to <http://www.analog.com/dsp/tools>.

The ADSP-BF527 EZ-KIT Lite provides example programs to demonstrate the evaluation board capabilities.

# Product Overview

The board features:

- Analog Devices ADSP-BF527 Blackfin processor
  - Core performance up to 600 MHz
  - External bus performance up to 133 MHz
  - 289-pin 0.5 mm pitch mini-BGA package
  - 25 MHz oscillator
- Synchronous dynamic random access memory (SDRAM)
  - Micron MT48LC32M16A2TG – 64 MB (8M x 16 bits x 4 banks)
- Parallel flash memory
  - ST Micro M29W320EB – 32 Mb (2M x 16 bits)
- NAND flash memory
  - Numonyx NAND04 – 4 Gb
- SPI flash memory
  - ST Micro M25P16 – 16 Mb
- Internal audio codec
  - Low-power audio codec
  - One stereo LINE OUT jack
  - One input MIC jack
  - One input stereo LINE IN jack

## Product Overview

- TFT LCD display with touchscreen
  - Sharp LQ035Q1DH02 320 x 240 3.5” touchscreen LCD
  - Analog Devices AD7879-1 four-wire touchscreen controller
- Ethernet interface
  - SMSC LAN8700 PHY device
  - 10-BaseT and 100-BaseTX Ethernet controller
  - Auto-MDIX
- Keypad
  - Analog Devices ADP5520 keypad controller
  - ACT components – 4 x 4 keypad assembly
- Thumbwheel
  - CTS Corp rotary encoder
- Universal asynchronous receiver/transmitter (UART)
  - ADM3202 RS-232 line driver/receiver
  - DB9 female connector
- LEDs
  - Ten LEDs: one power (green), one board reset (red), three general-purpose (yellow), one USB monitor (amber), PHY link (yellow), PHY activity (green), keypad controller (red), and FPGA done (yellow)

- Push buttons
  - Three push buttons: one reset, two programmable flags with debounce logic
- Expansion interface
  - Provides access to all ADSP-BF527 processor signals
- Other features
  - JTAG ICE 14-pin header
  - USB OTG connector
  - HOST interface connector
  - Power measurement jumpers
  - PPI IDC connector
  - SPORT0 and SPORT1 IDC connectors
  - TWI, SPI, timers, and UART0 IDC connectors

For information about the hardware components of the EZ-KIT Lite, refer to [“ADSP-BF527 EZ-KIT Lite Hardware Reference”](#) on page 2-1.

## Purpose of This Manual

The *ADSP-BF527 EZ-KIT Lite Evaluation System Manual* provides instructions for installing the product hardware (board). The text describes operation and configuration of the board components and provides guidelines for running your own code on the ADSP-BF527 EZ-KIT Lite. Finally, a schematic and a bill of materials are provided as a reference guide for future designs.

# Intended Audience

The primary audience for this manual is a programmer who is familiar with Analog Devices processors. This manual assumes that the audience has a working knowledge of the appropriate processor architecture and instruction set.

Programmers who are unfamiliar with Analog Devices processors can use this manual but should supplement it with other texts that describe your target architecture. For the locations of these documents, see [“Related Documents”](#).

Programmers who are unfamiliar with CCES or VisualDSP++ should refer to the online help and user’s manuals.

# Manual Contents

The manual consists of:

- Chapter 1, [“Using the ADSP-BF527 EZ-KIT Lite” on page 1-1](#)  
Describes EZ-KIT Lite operation from a programmer’s perspective and provides a simplified memory map.
- Chapter 2, [“ADSP-BF527 EZ-KIT Lite Hardware Reference” on page 2-1](#)  
Provides information on the EZ-KIT Lite hardware components.
- Appendix A, [“ADSP-BF527 EZ-KIT Lite Bill Of Materials” on page A-1](#)  
Provides a list of components used to manufacture the EZ-KIT Lite board.
- Appendix B, [“ADSP-BF527 EZ-KIT Lite Schematic” on page B-1](#)  
Provides the resources for board-level debugging, can be used as a reference guide. Appendix B is part of the online help.



## What's New in This Manual

This is revision 1.7 of the *ADSP-BF527 EZ-KIT Lite Evaluation System Manual*. The manual has been updated to include CCES information. In addition, modifications and corrections based on errata reports against the previous manual revision have been made.

For the latest version of this manual, please refer to the Analog Devices Web site.

## Technical Support

You can reach Analog Devices processors and DSP technical support in the following ways:

- Post your questions in the processors and DSP support community at EngineerZone<sup>®</sup>:

<http://ez.analog.com/community/dsp>

- Submit your questions to technical support directly at:

<http://www.analog.com/support>

- E-mail your questions about processors, DSPs, and tools development software from **CrossCore Embedded Studio** or **VisualDSP++**:

Choose **Help > Email Support**. This creates an e-mail to [processor.tools.support@analog.com](mailto:processor.tools.support@analog.com) and automatically attaches your **CrossCore Embedded Studio** or **VisualDSP++** version information and `license.dat` file.

- E-mail your questions about processors and processor applications to:

[processor.support@analog.com](mailto:processor.support@analog.com) or

[processor.china@analog.com](mailto:processor.china@analog.com) (Greater China support)

## Supported Processors

- In the **USA only**, call **1-800-ANALOGD** (1-800-262-5643)
- Contact your Analog Devices sales office or authorized distributor.  
Locate one at:  
[www.analog.com/adi-sales](http://www.analog.com/adi-sales)
- Send questions by mail to:  
Processors and DSP Technical Support  
Analog Devices, Inc.  
Three Technology Way  
P.O. Box 9106  
Norwood, MA 02062-9106  
USA

## Supported Processors

This evaluation system supports Analog Devices ADSP-BF527 Blackfin embedded processors. Functionality of the ADSP-BF523 and ADSP-BF525 processors can be evaluated using the same product because the processors have many similarities.

## Product Information

Product information can be obtained from the Analog Devices Web site and the online help system.

## Analog Devices Web Site

The Analog Devices Web site, [www.analog.com](http://www.analog.com), provides information about a broad range of products—*analog integrated circuits, amplifiers, converters, and digital signal processors.*

To access a complete technical library for each processor family, go to [http://www.analog.com/processors/technical\\_library](http://www.analog.com/processors/technical_library). The manuals selection opens a list of current manuals related to the product as well as a link to the previous revisions of the manuals. When locating your manual title, note a possible errata check mark next to the title that leads to the current correction report against the manual.

Also note, [myAnalog](#) is a free feature of the Analog Devices Web site that allows customization of a Web page to display only the latest information about products you are interested in. You can choose to receive weekly e-mail notifications containing updates to the Web pages that meet your interests, including documentation errata against all manuals. [myAnalog](#) provides access to books, application notes, data sheets, code examples, and more.

Visit [myAnalog](#) (found on the Analog Devices home page) to sign up. If you are a registered user, just log on. Your user name is your e-mail address.

## Related Documents

### EngineerZone

EngineerZone is a technical support forum from Analog Devices. It allows you direct access to ADI technical support engineers. You can search FAQs and technical information to get quick answers to your embedded processing and DSP design questions.

Use EngineerZone to connect with other DSP developers who face similar design challenges. You can also use this open forum to share knowledge and collaborate with the ADI support team and your peers. Visit <http://ez.analog.com> to sign up.

## Related Documents




For additional information about the product, refer to the following publications.

Table 1. Related Processor Publications

| Title  | Description   |
|--|---|
| <i>ADSP-BF522/ADSP-BF523/ADSP-BF524/<br/>ADSP-BF525/ADSP-BF526/ADSP-BF527<br/>Blackfin Embedded Processor Data Sheet</i> | General functional description, pinout, and timing of the processor           |
| <i>ADSP-BF2x Blackfin Processor Hardware Reference</i>   | Description of the internal processor architecture and all register functions |
| <i>Blackfin Processor Programming Reference</i>  | Description of all allowed processor assembly instructions                    |

## Notation Conventions

Text conventions used in this manual are identified and described as follows.

| Example   | Description  |
|---|--|
| Close command<br>(File menu)  | Titles in reference sections indicate the location of an item within the development environment's menu system (for example, the <b>Close</b> command appears on the <b>File</b> menu).  |
| {this   that}   | Alternative required items in syntax descriptions appear within curly brackets and separated by vertical bars; read the example as <i>this</i> or <i>that</i> . One or the other is required.  |
| [this   that]   | Optional items in syntax descriptions appear within brackets and separated by vertical bars; read the example as an optional <i>this</i> or <i>that</i> .  |
| [this,...]  | Optional item lists in syntax descriptions appear within brackets delimited by commas and terminated with an ellipsis; read the example as an optional comma-separated list of <i>this</i> .   |
| .SECTION  | Commands, directives, keywords, and feature names are in text with letter gothic font.   |
| <i>filename</i>   | Non-keyword placeholders appear in text with italic style format.  |
|  | <b>Note:</b> For correct operation, ...<br>A Note provides supplementary information on a related topic. In the online version of this book, the word <b>Note</b> appears instead of this symbol.  |
|  | <b>Caution:</b> Incorrect device operation may result if ...<br><b>Caution:</b> Device damage may result if ...<br>A Caution identifies conditions or inappropriate usage of the product that could lead to undesirable results or product damage. In the online version of this book, the word <b>Caution</b> appears instead of this symbol. |
|  | <b>Warning:</b> Injury to device users may result if ...<br>A Warning identifies conditions or inappropriate usage of the product that could lead to conditions that are potentially hazardous for the devices users. In the online version of this book, the word <b>Warning</b> appears instead of this symbol.                              |

## Notation Conventions

# 1 USING THE ADSP-BF527 EZ-KIT LITE

This chapter provides information to assist you with development of programs for the ADSP-BF527 EZ-KIT Lite evaluation system.

The following topics are covered.

- “Package Contents” on page 1-3
- “Default Configuration” on page 1-3
- “CCES Install and Session Startup” on page 1-4
- “VisualDSP++ Install and Session Startup” on page 1-8
- “CCES Evaluation License” on page 1-10
- “VisualDSP++ Evaluation License” on page 1-11
- “Lockbox Key Security Features” on page 1-11
- “Memory Map” on page 1-12
- “SDRAM Interface” on page 1-15
- “Parallel Flash Memory Interface” on page 1-17
- “NAND Flash Interface” on page 1-17
- “SPI Interface” on page 1-18
- “PPI Interface” on page 1-19
- “LCD Module Interface” on page 1-19

- “Touchscreen Interface” on page 1-21
- “Keypad Interface” on page 1-21
- “Rotary Encoder Interface” on page 1-22
- “Ethernet Interface” on page 1-22
- “Audio Interface” on page 1-23
- “USB OTG Interface” on page 1-25
- “UART Interface” on page 1-26
- “RTC Interface” on page 1-27
- “LEDs and Push Buttons” on page 1-27
- “JTAG Interface” on page 1-28
- “Expansion Interface” on page 1-29
- “Power Measurements” on page 1-29
- “Power-On-Self Test” on page 1-30
- “Example Programs” on page 1-31
- “Board Design Database” on page 1-31

For information about the graphical user interface, including the boot loading, target options, and other facilities of the EZ-KIT Lite system, refer to the online help.

For more detailed information about the ADSP-BF527 Blackfin processor, see documents referred to at [“Related Documents”](#).



## Package Contents

Your ADSP-BF527 EZ-KIT Lite evaluation system package contains the following items.

- ADSP-BF527 EZ-KIT Lite board
- Universal 7.0V DC power supply
- Ethernet patch cable
- Three 3.5 mm male-to-male audio cables
- 3.5 mm headphones
- USB A-B male cable for USB debug agent
- 5-in-1 cable and connectors for USB on-the-go (OTG) applications
- Ethernet loopback connector

If any item is missing, contact the vendor where you purchased your EZ-KIT Lite or contact Analog Devices, Inc.

## Default Configuration

The EZ-KIT Lite evaluation system contains ESD (electrostatic discharge) sensitive devices. Electrostatic charges readily accumulate on the human body and equipment and can discharge without detection. Permanent damage may occur on devices subjected to high-energy discharges. Proper ESD precautions are recommended to avoid performance degradation or loss of functionality. Store unused EZ-KIT Lite boards in the protective shipping package.



The ADSP-BF527 EZ-KIT Lite board is designed to run outside your personal computer as a standalone unit. You do not have to open your computer case.

## CCES Install and Session Startup

When removing the EZ-KIT Lite board from the package, handle the board carefully to avoid the discharge of static electricity, which can damage some components. [Figure 1-1](#) shows the default jumper settings, switches, connector locations, and LEDs used in installation. Confirm that your board is in the default configuration before using the board.




Figure 1-1. EZ-KIT Lite Hardware Setup

## CCES Install and Session Startup

For information about CCES and to download the software, go to [www.analog.com/CCES](http://www.analog.com/CCES). A link for the ADSP-BF527 EZ-KIT Lite Board Support Package (BSP) for CCES can be found at <http://www.analog.com/Blackfin/EZKits>.

Follow these instructions to ensure correct operation of the product software and hardware.

**Step 1:** Connect the EZ-KIT Lite board to a personal computer (PC) running CCES using one of two options: an Analog Devices emulator or via the debug agent.

### Using an Emulator:

1. Plug one side of the USB cable into the USB connector of the emulator. Plug the other side into a USB port of the PC running CCES.
2. Attach the emulator to the header connector ZP4 (labeled JTAG) on the EZ-KIT Lite board.

### Using the on-board Debug Agent:

1. Plug one side of the USB cable into the USB connector of the debug agent ZJ1 (labeled USB).
2. Plug the other side of the cable into a USB port of the PC running CCES.

**Step 2:** Attach the provided cord and appropriate plug to the power adaptor.


1. Plug the jack-end of the power adaptor into the power connector J6 (labeled 7.0V) on the EZ-KIT Lite board.
2. Plug the other side of the power adaptor into a power outlet. The power LED (labeled LED4) is lit green when power is applied to the board.
3. Power the emulator (if used). Plug the jack-end of the assembled power adaptor into the emulator and plug the other side of the power adaptor into a power outlet. The enable/power is lit green when power is applied.

## CCES Install and Session Startup

**Step 3 (if connected through the debug agent):** Verify that the yellow USB monitor LED (labeled ZLED3) on the debug agent is on. This signifies that the board is communicating properly with the host PC and ready to run CCES.

### Session Startup

It is assumed that the CrossCore Embedded Studio software is installed and running on your PC.

 Note: If you connect the board or emulator first (before installing CCES) to the PC, the Windows driver wizard may not find the board drivers.

1. Navigate to the CCES environment via the **Start** menu.

Note that CCES is not connected to the target board.


2. Use the system configuration utility to connect to the EZ-KIT Lite board.

If a debug configuration exists already, select the appropriate configuration and click **Apply and Debug** or **Debug**. Go to step 8.

To create a debug configuration, do one of the following:

- Click the down arrow next to the little bug icon, select **Debug Configurations**
- Choose **Run > Debug Configurations**.

The **Debug Configuration** dialog box appears.

3. Select **CrossCore Embedded Studio Application** and click  (New launch configuration).

The **Select Processor** page of the **Session Wizard** appears.

4. Ensure **Blackfin** is selected in **Processor family**. In **Processor type**, select **ADSP-BF527**. Click **Next**.

The **Select Connection Type** page of the **Session Wizard** appears.

5. Select one of the following:
  - For standalone debug agent connections, **EZ-KIT Lite** and click **Next**.
  - For emulator connections, **Emulator** and click **Next**.

The **Select Platform** page of the **Session Wizard** appears.

6. Do one of the following:
  - For standalone debug agent connections, ensure that the selected platform is **ADSP-BF527 EZ-KIT Lite via Debug Agent**.
  - For emulator connections, choose the type of emulator that is connected to the board.




7. Click **Finish** to close the wizard.

The new debug configuration is created and added to the program(s) to load list.

8. In the **Program(s) to load** section, choose the program to load when connecting to the board. If not loading any program upon connection to the target, do not make any changes.

## VisualDSP++ Install and Session Startup


Note that while connected to the target, there is no way to choose a program to download. To load a program once connected, terminate the session.

-  To delete a configuration, go to the **Debug Configurations** dialog box and select the configuration to delete. Click  and choose **Yes** when asked if you wish to delete the selected launch configuration. Then **Close** the dialog box.
-  To disconnect from the target board, click the terminate button (red box) or choose **Run > Terminate**.

To delete a session, choose **Target > Session > Session List**. Select the session name from the list and click **Delete**. Click **OK**.

## VisualDSP++ Install and Session Startup

For information about VisualDSP++ and to download the software, go to [www.analog.com/VisualDSP](http://www.analog.com/VisualDSP).

-  There are two USB interfaces on the ADSP-BF527 EZ-KIT Lite. Be sure to use the debugger's interface (ZJ1) when connecting your computer to the board with provided USB cable. The other USB interface (labelled USB-OTG, P1) is for applications use.
1. Verify that the yellow USB monitor LED (ZLED3, located near the USB connector) is lit. This signifies that the board is communicating properly with the host PC and is ready to run VisualDSP++.
  2. If you are running VisualDSP++ for the first time, navigate to the VisualDSP++ environment via the **Start > Programs** menu. The main window appears. Note that VisualDSP++ does not connect to any session. Skip the rest of this step to step 3.

If you have run VisualDSP++ previously, the last opened session appears on the screen. You can override the default behavior and force VisualDSP++ to start a new session by pressing and holding down the **Ctrl** key while starting VisualDSP++. Do not release the **Ctrl** key until the **Session Wizard** appears on the screen. Go to step 4.


3. To connect to a new EZ-KIT Lite session, start **Session Wizard** by selecting one of the following.
  - From the **Session** menu, **New Session**.
  - From the **Session** menu, **Session List**. Then click **New Session** from the **Session List** dialog box.
  - From the **Session** menu, **Connect to Target**.
4. The **Select Processor** page of the wizard appears on the screen. Ensure **Blackfin** is selected in **Processor family**. In **Choose a target processor**, select **ADSP-BF527**. Click **Next**.
5. The **Select Connection Type** page of the wizard appears on the screen. Select **EZ-KIT Lite** and click **Next**.
6. The **Select Platform** page of the wizard appears on the screen. Ensure that the selected platform is **ADSP-BF527 EZ-KIT Lite via Debug Agent**. Specify your own **Session name** for the session or accept the default name.

The session name can be a string of any length; although, the box displays approximately 32 characters. The session name can include space characters. If you do not specify a session name, VisualDSP++ creates a session name by combining the name of the selected platform with the selected processor. The only way to change a session name later is to delete the session and open a new session and click **Next**.

## CCES Evaluation License

7. The **Finish** page of the wizard appears on the screen. The page displays your selections. Check the selections. If you are not satisfied, click **Back** to make changes; otherwise, click **Finish**. VisualDSP++ creates the new session and connects to the EZ-KIT Lite. Once connected, the main window's title is changed to include the session name set in step 6.



To disconnect from a session, click the disconnect button  or select **Session > Disconnect from Target**.

To delete a session, select **Session > Session List**. Select the session name from the list and click **Delete**. Click **OK**.


## CCES Evaluation License

The ADSP-BF527 EZ-KIT Lite software is part of the Board Support Package (BSP) for the Blackfin ADSP-BF52x family. The EZ-KIT Lite is a licensed product that offers an unrestricted evaluation license for 90 days after activation. Once the evaluation period ends, the evaluation license becomes permanently disabled. If the evaluation license is installed but not activated, it allows 10 days of unrestricted use and then becomes disabled. The license can be re-enabled by activation.

An evaluation license can be upgraded to a full license. Licenses can be purchased from:

- Analog Devices directly. Call (800) 262-5645 or 781-937-2384 or go to:  
<http://www.analog.com/buyonline>.
- Analog Devices, Inc. local sales office or authorized distributor. To locate one, go to:  
<http://www.analog.com/salesdir/continent.asp>.




-  The EZ-KIT Lite hardware must be connected and powered up to use CCES with a valid evaluation or full license.

## VisualDSP++ Evaluation License

The ADSP-BF527 EZ-KIT Lite installation is part of the VisualDSP++ installation. The EZ-KIT Lite is a licensed product that offers an unrestricted evaluation license for the first 90 days. Once the initial unrestricted 90-day evaluation license expires:

- VisualDSP++ restricts a connection to the ADSP-BF527 EZ-KIT Lite via the USB debug agent interface only. Connections to simulators and emulation products are no longer allowed.
- The linker restricts a user program to 20 KB of memory for code space with no restrictions for data space.

-  To avoid errors when opening VisualDSP++, the EZ-KIT Lite hardware must be connected and powered up. This is true for using VisualDSP++ with a valid evaluation or full license.

## Lockbox Key Security Features


Blackfin processors feature Lockbox<sup>®</sup> secure technology: hardware-enabled code security and content protection for one-time programmable (OTP) memory. Customers purchasing Blackfin processors can program their own customer public key in OTP.

The ADSP-BF527 EZ-KIT Lites are evaluation boards with the Lockbox key pre-programmed and publicly documented—the burden of key generation and OTP programming of public keys is removed from the customer. Customers can still program other areas of OTP memory on the ADSP-BF527 EZ-KIT Lite. Analog Devices publicly document the EZ-KIT Lite's public and private key pair for customer evaluation and

## Memory Map

support of the Lockbox feature, all while avoiding any keys information exchange. As a result, there is no confidentiality associated with the Lockbox key on EZ-KIT Lites.

To demonstrate Lockbox features using an EZ-KIT Lite, you must use the keys that are provided pre-programmed on your EZ-KIT Lite.

-  Use the EZ-KIT Lite key pair to generate a demo and then provide the keys to the demo users. Note that the EZ-KIT Lite cannot be used to secure any confidential information. If you wish to create a demo with confidential keys, you must build your own Blackfin board and personalize it with your own keys.

## Memory Map

The ADSP-BF527 processor has internal static random access memory (SRAM) used for instructions or data storage. See [Table 1-1](#). The internal memory details can be found in the *ADSP-BF2x Blackfin Processor Hardware Reference*.

The ADSP-BF527 EZ-KIT Lite board includes four types of external memory: synchronous dynamic random access memory (SDRAM), serial peripheral interconnect (SPI), parallel flash, and NAND flash. See [Table 1-2](#). For more information about a specific memory type, go the respective section in this chapter.

Table 1-1. EZ-KIT Lite Internal Memory Map

| Start Address   | Content                                    |
|---|--|
| 0xEF00 0000   | BOOT ROM (32K BYTE)                        |
| 0xEF00 8000<br>0xFE80 0000<br>0xFE82 0000<br>0xFF40 0000<br>0xFF40 4000<br>0xFF40 8000<br>0xFF50 0000<br>0xFF50 4000<br>0xFF50 8000<br>0xFF60 0000<br>0xFF60 4000<br>0xFF60 8000<br>0xFF60 C000<br>0xFF61 0000<br>0xFF61 4000<br>0xFF70 0000<br>0xFF70 1000 | Reserved                                   |
| 0xFF80 0000   | L1 DATA BANKA SRAM (16K BYTE)              |
| 0xFF80 4000   | L1 DATA BANKA SRAM/CACHE (16K BYTE)        |
| 0xFF80 8000   | Reserved                                   |
| 0xFF90 0000   | L1 DATA BANKB SRAM (16K BYTE)              |
| 0xFF90 4000   | L1 DATA BANKB SRAM/CACHE (16K BYTE)        |
| 0xFF90 8000   | Reserved                                   |
| 0xFFA0 0000   | L1 INSTRUCTION BANKA LOWER SRAM (16K BYTE) |
| 0xFFA0 4000   | L1 INSTRUCTION BANKA UPPER SRAM (16K BYTE) |
| 0xFFA0 8000   | L1 INSTRUCTION BANKB LOWER SRAM (16K BYTE) |
| 0xFFA0 C000   | Reserved                                   |
| 0xFFA1 0000   | L1 INSTRUCTION SRAM/CACHE (16K BYTE)       |

# Memory Map

Table 1-1. EZ-KIT Lite Internal Memory Map (Cont'd)

| Start Address   | Content                      |
|---|------------------------------|
| 0xFFA1 4000<br>0xFFA1 8000<br>0xFFA1 C000<br>0xFFA2 0000<br>0xFFA2 4000 | Reserved                     |
| 0xFFB0 0000   | L1 SCRATCHPAD SRAM (4K BYTE) |
| 0xFFB0 1000   | Reserved                     |
| 0xFFC0 0000   | SYSTEM MMR REGISTERS         |
| 0xFFE0 0000   | CORE MMR REGISTERS           |

Table 1-2. EZ-KIT Lite External Memory Map

| Start Address | End Address | Content                     |
|---------------|-------------|-----------------------------|
| 0x0000 0000   | 0x03FF FFFF | SDRAM bank 0 (SDRAM)        |
| 0x2000 0000   | 0x200F FFFF | ASYNC memory bank 0 (flash) |
| 0x2010 0000   | 0x201F FFFF | ASYNC memory bank 1 (flash) |
| 0x2020 0000   | 0x202F FFFF | ASYNC memory bank 2 (flash) |
| 0x2030 0000   | 0x203F FFFF | ASYNC memory bank 3 (flash) |
| 0x2040 0000   | 0xEEFF FFFF | Reserved                    |

## SDRAM Interface

The ADSP-BF527 processor connects to a 64 MB Micron MT48LC32M16A2TG-75 chip through the external bus interface unit (EBIU). The SDRAM chip can operate at a maximum clock frequency of 133 MHz.

With a CCES or VisualDSP++ session running and connected to the EZ-KIT Lite board via the USB debug agent, SDRAM registers are configured automatically with values listed in [Table 1-3](#) each time the processor is reset. The values are used whenever SDRAM is accessed through the debugger (for example, when viewing memory windows or loading a program).

To disable the automatic setting of the SDRAM registers, do one of the following:

- CCES users, choose **Target > Settings > Target Options** and clear the **Use XML reset values** check box.
- VisualDSP++ users, choose **Settings > Target Options** and clear the **Use XML reset values** check box.

Table 1-3. SDRAM Default Settings With a 133 MHz SCLK

| Register    | Value  | Function   |
|-------------|--------|--|
| pEBIU_SDRRC | 0x0407 | Calculated with SCLK = 133 MHz<br>fSCLK = 133 MHz<br>tREF = 64 ms<br>NRA = 8192 row addresses<br>tRAS = 6 clock cycles<br>tRP = 2 clock cycles<br>RDIV = 0x407 |

## SDRAM Interface

Table 1-3. SDRAM Default Settings With a 133 MHz SCLK (Cont'd)

| Register     | Value      | Function  |
|--------------|------------|---|
| pEBIU_SDBCTL | 0x0025     | EBCAW = 10 bits<br>EBSZ = 64M byte<br>EBE = enabled   |
| pEBIU_SDGCTL | 0x0091998d | TSCSR = 45 degrees C<br>EMREN = disabled<br>FBBRW = disabled<br>PSSE = enables SDRAM powerup sequence on next SDRAM access<br>PSM = precharge, 8 BCBR refresh cycles, mode register set<br>PUPSD = no extra delay added before first precharge command<br>TWR = 2 cycles<br>TRCD = 3 cycles<br>TRP = 3 cycles<br>TRAS = 6 cycles<br>PASR = all 4 banks refreshed<br>CL = CAS latency 3 cycles<br>SCTLE = CLOUT disabled |

Table 1-4 shows the PLL register settings using a 400 MHz CCLK and 133 MHz SCLK. The PLL\_CTL and PLL\_DIV registers are initialized in the user code to achieve maximum performance.

Table 1-4. PLL Register Settings

| Register | SCLK = 133 MHz<br>CCLK = 400 MHz |
|----------|----------------------------------|
| PLL_CTL  | 16                               |
| PLL_DIV  | 3                                |

An example program is included in the EZ-KIT Lite installation directory to demonstrate how to setup and access the SDRAM interface. For more information on how to initialize the registers after a reset, search the online help for “reset values”.

## Parallel Flash Memory Interface

The parallel flash memory interface of the ADSP-BF527 EZ-KIT Lite contains a 4 MB (2M x 16 bits) ST Micro M29W320EB chip. Flash memory is connected to the 16-bit data bus and address lines 1 through 19. Chip enable is decoded by using  $AMS0-3$  select lines through NAND and AND gates. The address range for flash memory is  $0x2000\ 0000$  to  $0x203F\ FFFF$ .

Flash memory is pre-loaded with boot code for the blink, LCD images, and power-on-self test (POST) programs. For more information, refer to [“Power-On-Self Test” on page 1-30](#).

By default, the EZ-KIT Lite boots from the 16-bit parallel flash memory. The processor boots from flash memory if the boot mode select switch (SW2) is set to a position of 1; see [“Boot Mode Select Switch \(SW2\)” on page 2-11](#).

Flash memory code can be modified. For instructions, refer to the online help and example program included in the EZ-KIT Lite installation directory.

## NAND Flash Interface

The ADSP-BF527 processor is equipped with an internal NAND flash controller, which allows the 4 Gbit ST Micro’s NAND04 device to be attached gluelessly to the processor. NAND flash is attached via the processor’s specific NAND flash control and data lines. NAND flash shares pins with the Ethernet PHY, host connector, and expansion interface.

The NAND chip enable signal (NDCE#\_HOSTD10) can be disconnected from NAND flash by turning SW11.4 (switch 11 position 4) OFF. This ensures that the NAND will not be driving data when HOSTD10 changes state. See [“Rotary NAND Enable Switch \(SW11\)” on page 2-16](#) for more information.

## SPI Interface

The Ethernet PHY (U14) must be disabled in order for NAND flash to function properly. This is accomplished by setting SW1 to OFF, OFF, ON, OFF.

For more information about the NAND04 device, refer to the Numonyx Web site at <http://www.numonyx.com>.

An example program is included in the EZ-KIT Lite installation directory to demonstrate how to setup and access the NAND flash interface.

## SPI Interface

The ADSP-BF527 processor has one serial peripheral interface (SPI) port with multiple chip select lines. The SPI port connects directly to serial flash memory, LCD, audio codec, and expansion interface.

Serial flash memory is a 16 Mb ST Micro M25P16 device, which is selected using the SPISEL1 line of the processor. SPI flash memory is pre-loaded with boot code for the blink and POST programs. For more information, refer to “[Power-On-Self Test](#)” on page 1-30. By default, the EZ-KIT Lite boots from the 16-bit flash parallel memory. SPI flash can be selected as the boot source by setting the boot mode select switch (SW2) to position 3; see “[Boot Mode Select Switch \(SW2\)](#)” on page 2-11.

SPI flash code can be modified. For instructions, refer to the online help and example program included in the EZ-KIT Lite installation directory.

By default, the audio codec is set up to use the SPISEL5 signal as the SPI chip select when configuring the codec. The chip select is shared with the HOSTD9 signal. For more information, refer to “[Audio Interface](#)” on page 1-23.

By default, the LCD is setup to use SPISEL7. The LCD optionally can use SPISEL1 or SPISEL5 by setting SW25 appropriately. For more information, refer to “[LCD/KPAD CTL Switch \(SW25\)](#)” on page 2-20.



## PPI Interface

The ADSP-BF527 processor provides a parallel peripheral interface (PPI), supporting data widths up to 16 bits. The PPI interface provides three multiplexed frame syncs, a dedicated clock input, and 16 data lines. The EZ-KIT Lite uses an eight-bit data connection to the TFT LCD module. The full PPI port is accessible on the PPI connector P8 and expansion interface.

The PPI signals are connected to multi-function pins; the upper eight data bit signals are configured for the rotary, SPI, UART1, and LED0 interfaces.

The PPI interface is set up to drive the LCD through a complex programmable logic device (CPLD). The CPLD has a 15 MHz oscillator input and drives PPICLK at 5 MHz, 10 MHz or 15 MHz, depending on the LCD display mode chosen. For more information, refer to the [“LCD Module Interface” on page 1-19](#).

The source of the PPI clock can be configured by software via the PPI\_SEL signal. The signal connects to the processor’s flag pin PG12 by setting SW13 position 4 ON. Flag pin PG12 is shared with the HOSTACK\_LED2 signal. When the clock select line is used, HOSTACK and LED2 are not available. The PPISEL signal does not need to be driven if the default CPLD clock is used; PPISEL is driven when the expansion interface is used as the clocking source. Refer to [“GPIO Enable Switch \(SW13\)” on page 2-17](#) for more information.

## LCD Module Interface

The EZ-KIT Lite features a Sharp LQ035Q1DH02 TFT LCD module with touchscreen overlay. This is a 3.5” landscape display with a resolution of 320 x 240 pixels and a color depth of 16 bits. By default, the interface is an RGB-888 serial parallel interface, eight bits of red, followed by eight bits of green, and then eight bits of blue.

## LCD Module Interface

To configure the PPI interface, refer to the LCD software example found in the `Examples` folder of the installation.

The configuration values are obtained from the timing characteristics section of the Sharp LQ035Q1DH02 data sheet.

The LCD interface setup is flexible and allows three data formats: RGB888 (24 bits per pixel), RGB565 (16 bits per pixel), and 16-bit pass through mode. All LCD signals are input from the processor into a Xilinx CPLD (XC95144XL), and the CPLD drives the LCD inputs. By default, switch `SW26` is used to interface the LCD module in RGB888 mode.

The other two LCD modes are RGB565, where each pixel is represented by two bytes, and 16-bit pass through, where all 16 bits of the PPI data bus are connected to the CPLD and passed to the LCD. To run RGB565 or 16-bit pass through mode, configure the processor's PPI appropriately. For more information about setting up the LCD interface mode, see [“Mode Switch \(SW26\)” on page 2-21](#).

When setting up the LCD module in 16-bit pass through mode, ensure PPI data signals `PPID15–8` are not used elsewhere on the board because these processor pins are multiplexed with other functionality. Switches `SW29` and `SW30` disconnect the PPI data lines from the CPLD: turn `SW29` all ON and `SW30` positions 1 and 2 ON to disconnect `PPID15–8` from the CPLD. See [“CPLD D8–13 Switch \(SW29\)” on page 2-22](#) and [“CPLD 14–15/DCE ENB Switch \(SW30\)” on page 2-22](#) for more information.

The LCD reset is selectable between the board's `RESET` signal and GPIO controllable signal `HOSTWR#_LED1` (PG11). By default, the LCD reset is connected to the board's `RESET` signal. See [“LCD Reset Switch \(SW5\)” on page 2-13](#) for more information.

The verilog source code for the CPLD can be found in the reference resource zip file in the `Examples` folder of the installation.

The LCD module can be disconnected from PPI by setting `Enable2` to high. Refer to [“Mode Switch \(SW26\)” on page 2-21](#) for more information.

## Touchscreen Interface

The AD7879-1 touchscreen controller (U37) is connected to the 2-wire interface (TWI) of the processor. Switch SW22 sets the default I<sup>2</sup>C address to 0101111. The  $\overline{\text{AD7879\_1\_PENIRQ}}$  interrupt signal comes from one of the three signals connected to the SW24 switch. The default is LED0. To use two other signals for the touch pad interrupt, set SW24 appropriately. Refer to [“Touchpad INT Switch \(SW24\)” on page 2-20](#) for more information.

An example program is included in the EZ-KIT Lite installation directory to demonstrate how to set up and access the touchscreen interface.

## Keypad Interface

The ADP5520 keypad controller is used for keypad functions and connected to the TWI interface of the processor. By default, the keypad interrupt ( $\overline{\text{NINT}}$ ) is set up to the  $\overline{\text{KEYIRQ}}$  signal on the PF9 port pin. To use two other signals for the keypad interrupt, set SW25 accordingly. Refer to [“LCD/KPAD CTL Switch \(SW25\)” on page 2-20](#) for more information.

The I<sup>2</sup>C address of the keypad controller is 0110101. A red LED (LED8) can be used as a general-purpose status LED. LED8 is connected to the ILED pin of the ADP5520 controller (U35).

An example program is included in the EZ-KIT Lite installation directory to demonstrate how to setup and access the keypad interface.

# Rotary Encoder Interface

The ADSP-BF527 processor has a built-in, up-down counter interface with support for a rotary encoder. The three-wire rotary encoder interface connects to the rotary switch (SW3) and expansion interface connector. The rotary encoder can be turned clockwise for the up function, counter clockwise for the down function, or can be used as a push button for clearing the counter.

The rotary switch is a two-bit quadrature (Gray code) counter with detent, meaning that both the down signal (CDG) and up signal (CUD) will toggle when the count register increases on a rotation to the right. Upon rotating to the left, both CDG and CUD will toggle, and the overall count decreases.

If the processor pins are needed for the expansion interface, disconnect the rotary encoder switch via the four-position rotary NAND enable switch (SW11). [For more information, see “Rotary NAND Enable Switch \(SW11\)” on page 2-16.](#)

An example program is included in the EZ-KIT Lite installation directory to demonstrate how to setup and access the rotary encoder interface.

## Ethernet Interface

The ADSP-BF527 processor has an integrated Ethernet MAC with media independent interface (MII) and reduced media independent interface (RMII), which connects to an external PHY. The EZ-KIT Lite provides a SMSC LAN8700 RMII Ethernet PHY with Auto-MDIX, fully compliant with IEEE 802.2/802.2u standards. The SMSC LAN8700 chip supports 10BASE-T and 100BASE-TX operations. The part is attached gluelessly to the processor.

The Ethernet signals are shared with NAND flash. By default, Ethernet is turned off (SW1 OFF, OFF, ON, OFF). See [“ETH Enable Switch \(SW1\)” on](#)

[page 2-10](#) for more information. It is important not to run code that accesses the NAND while using the Ethernet interface.

The Ethernet mode is set by the SW9 switch and defaults to all capable, auto negotiation with settings OFF, OFF, OFF, ON. See “[ETH Mode Flash CS Switch \(SW9\)](#)” on [page 2-14](#) for more information.

The Ethernet chip is pre-loaded with a MAC address for the EZ-KIT Lite. The MAC address is stored in the public one-time programmable (OTP) memory of the processor and can be found on a sticker on the bottom side of the EZ-KIT Lite.

The PHY portion of the Ethernet chip is connected to a Pulse HX1188 (U26) magnetics, then to a standard RJ-45 Ethernet connector (J9). [For more information, see “Ethernet Connector \(J9\)” on page 2-30.](#)

Example programs are included in the EZ-KIT Lite installation directory to demonstrate how to use the Ethernet interface.

## Audio Interface

The audio interface of the EZ-KIT Lite consists of an internal low-power stereo codec with an integrated headphone driver and its associated passive components. There are two inputs, stereo line in, and mono microphone as well as two outputs, headphone, and stereo line out. The codec has integrated stereo analog-to-digital converters (ADCs) and digital-to-analog converters (DACs) and requires minimal external circuitry.

The codec is connected to the ADSP-BF527 processor via the processor’s serial port 0A (alternate). The SPORT0A port is disconnected from the codec by turning SW20 all OFF and SW27 positions 1 and 2 OFF. This allows SPORT0A to be used on the expansion interface.

The TFS0A signal is shared with the Ethernet and host connectors, as well as the RMIIMDINT# and HOSTCE# signals. SW21 allows this signal to be disconnected from the host connector by setting position 1 OFF, and STAMP

## Audio Interface

connectors position 2 OFF. To connect signal `TFS0A_RMIIMDINT#_HOSTCE#` to either interface, turn the corresponding switch position ON. Refer to [“TFS0A/HOSTCE Enable Switch \(SW21\)” on page 2-19](#) for more information.

The control interface for the codec is selectable by the SW8 and SW19 switches between the TWI and SPI. By default, the board is in SPI mode, which is set up by the SW19 switch (ON, OFF, ON, OFF) and SW8 switch (positions 3 ON and 4 OFF). To select TWI mode, turn SW8 positions 3 OFF and 4 ON, as well as SW19 OFF, ON, OFF, ON. Refer to [“Mic/HP LPBK Audio Mode Switch \(SW8\)” on page 2-14](#) and [“SPI/TWI Switch \(SW19\)” on page 2-19](#) for more information.

Switch SW28 can be used to tie the `LEFT_IN` channel to `LEFT_OUT` and the `RIGHT_IN` channel to `RIGHT_OUT`, respectively. See [“Line In-Out LPBK Switch \(SW28\)” on page 2-22](#) for more information.

Mic gain is selectable through the SW4 switch, with values of 14 dB, 0 dB, or -6 dB, by turning ON position 1, 2, or 3 respectively. All other positions must be OFF to achieve the desired gain. Refer to [“MIC Gain Switch \(SW4\)” on page 2-12](#) for more information.

Microphone bias is provided through a low-noise reference voltage. A jumper on position 2 and 3 of JP6 connects the `MICBIAS` signal to the audio jack. Placing the jumper on positions 1 and 2 of JP6 connects the bias directly to the mic signal. Refer to [“MIC Select Jumper \(JP6\)” on page 2-23](#) for more information.

J7 and J8 are 3.5 mm connectors for the audio portion of the board. J7 connects the mic on the top portion and line-in on the bottom. J8 connects the headphone on the top portion and line-out on the bottom. If there is no 3.5 mm cable plugged into the bottom of J7 or J8, the `LINEIN` to `LINOUT` signals are looped back inside the connector, as long as SW23 positions 3 and 4 are ON.

For testing purposes, SW8 positions 1 and 2 allow the `MICIN` signal to be connected to either the left or right headphone. Do not connect both left

and right to the `MICIN` signal at the same time—only position 1 or 2 of `SW8` should be `ON` at the same time. Refer to “[Mic/HP LPBK Audio Mode Switch \(SW8\)](#)” on page 2-14 for more information.

For more information, see “[Dual Audio Connectors \(J7–8\)](#)” on page 2-30.

The EZ-KIT Lite is shipped with a headphone and multiple 3.5 mm cables, which allow you to run the example programs provided in the EZ-KIT Lite installation directory and learn about the audio interface.

## USB OTG Interface

The ADSP-BF527 processor has a built-in, high-speed USB on-the-go (OTG) interface and integrated PHY. The interface is connected to a 24 MHz clock (`U12`), has a surge protector, and can be configured as a host or a device. When in device mode, the USB 5V regulator (`VR3`) and FET switch (`U28`) are turned `OFF`. When in host mode, the USB 5V regulator and FET are turned `ON` and can supply 5V at 500 mA.

The control mechanism to turn the two devices on and off are via the `PG13` flag pin of the processor and must be connected on the board to signal `USB_VRSEL` through switch `SW13`. By default, `USB_VRSEL` is held low or a logic 0 via a pull-down resistor, and both devices are turned off. To use host mode and provide 5V to a device, turn `SW13` position 2 `OFF` and position 3 `ON`. This disables push button 2. Note that signal `USB_VRSEL` is shared with `HOSTADDR`. By default, positions 2 and 3 of `SW13` are `ON` and `OFF`, which shut off the `VR3` regulator and `U28` FET. For more information, see “[GPIO Enable Switch \(SW13\)](#)” on page 2-17.

The USB OTG interface has a mini-AB connector (`P1`); cables that plug into `P1` are shipped with the EZ-KIT Lite.

Use example programs in the EZ-KIT Lite installation directory to learn about the ADSP-BF527 processor’s device and host modes. For more

## UART Interface

information about the USB interface, refer to the *ADSP-BF52x Blackfin Processor Hardware Reference*.

## UART Interface

The ADSP-BF527 processor has two built-in universal asynchronous receiver transmitters (UARTs). UART1–0 share the processor pins with other peripherals on the EZ-KIT Lite.

UART1 has full RS-232 functionality via the Analog Devices 3.3V ADM3202 line driver and receiver (U25). The UART can be disconnected from the ADM3202 device by turning all positions of SW10 OFF. When using UART1, SW10 position 8 should be OFF. Turning this switch provides UART data loopback and should be ON only when running the POST program. If signals RTS and CTS are needed for flow control, the UART1CTS\_LCDSPICS\_Z port pin PF10 can be configured as a GPIO for CTS. The HWAIT port pin PG0 can be used for RTS by setting up the pin accordingly. See [“UART Enable Switch \(SW10\)” on page 2-15](#) for more information.

UART1 signals are connected to the ADM3202 device through the CPLD 14–15/DCE enable switch (SW30). To connect TX and RX signals, turn SW30 positions 3 and 4 ON. Additionally, a flow control can be added by connecting SW30 positions 5 and 6 ON. Refer to [“CPLD 14–15/DCE ENB Switch \(SW30\)” on page 2-22](#) for more information.

UART0 and UART1 are connected to the expansion interface. UART0 of the processor also is available via a STAMP connector (P5). See [“UART0 Connector \(P5\)” on page 2-31](#).

Example programs are included in the EZ-KIT Lite installation directory to demonstrate UART and RS-232 operations.

For more information about the UART interface, refer to the *ADSP-BF52x Blackfin Processor Hardware Reference*.



## RTC Interface

The ADSP-BF527 processor has a real-time clock (RTC) and a watchdog timer. Typically the RTC interface is used to implement a real-time watchlog or life counter of the time elapsed since the last system reset. The EZ-KIT Lite is equipped with a Sanyo (CR2430) lithium coin 3V battery supplying 280 mAh. The 3V battery and 3.3V supply of the board are connected to the RTC power pin of the processor. When the EZ-KIT Lite is powered, the RTC circuit uses the board power to supply voltage to the RTC pin. When the EZ-KIT Lite is not powered, the RTC circuit uses the lithium battery to maintain the power to the RTC pin. After removing the mylar, the battery will last for about one year with the EZ-KIT Lite unpowered.

Example programs are included in the EZ-KIT Lite installation directory to demonstrate the RTC features.



The EZ-KIT Lite is shipped with a protective Mylar sheet placed between the coin battery and positive pin of the battery holder. Please remember to remove the Mylar sheet before trying to use RTC functionality of the processor.

For more information on the RTC and watchdog timer, refer to the *ADSP-BF52x Blackfin Processor Hardware Reference*.

## LEDs and Push Buttons

The EZ-KIT Lite provides two push buttons and three LEDs for general-purpose I/O.

The three LEDs, labeled LED1 through LED3, are accessed via the PF8, PG11, and PG12 pins of the processor, respectively. For information on how to program the pins, refer to the *ADSP-BF52x Blackfin Processor Hardware Reference*.

## JTAG Interface

LED0 is shared with a touchscreen controller interrupt and PPI data pin 8. LED1 is shared with the HOSTWR# signal, keypad controller interrupt, touchscreen controller interrupt, and LCD reset. LED2 is shared with the HOSTACK signal. The LED1 signal can be used for the LCD reset by turning SW5 positions 1 ON and 2 OFF. LED2 is shared with HOSTACK and PPI\_SEL functionality. Refer to [“LCD Reset Switch \(SW5\)”](#) on page 2-13, [“Touchpad INT Switch \(SW24\)”](#) on page 2-20, [“LCD/KPAD CTL Switch \(SW25\)”](#) on page 2-20, and [“GPIO Enable Switch \(SW13\)”](#) on page 2-17 for configuration options.

The two general-purpose push buttons are labeled PB1 and PB2. The status of each individual button can be read through programmable flag inputs, PG0 and PG13. The flag reads 1 when a corresponding switch is being pressed. When the switch is released, the flag reads 0. A connection between the push button and processor input is established through the SW13 DIP switch.

Push button 1 is shared with HWAIT. Push button 2 is shared with HOSTADDR and also can be connected to USB\_VRSEL by setting SW13 position 2 OFF and position 3 ON. USB\_VRSEL allows the USB OTG to power an external USB device with 5V. See [“USB OTG Interface”](#) on page 1-25 and [“GPIO Enable Switch \(SW13\)”](#) on page 2-17 for more information.

An example program is included in the EZ-KIT Lite installation directory to demonstrate functionality of the LEDs and push buttons.

## JTAG Interface

The JTAG emulation port allows an emulator to access the processor’s internal and external memory through a six-pin interface. The JTAG emulator port of the processor can be accessed via the on-board USB debug agent or with an external emulator via the JTAG connector (ZP4). When an external emulator connects to the board, the on-board USB debug agent is disabled. See [“JTAG Connector \(ZP4\)”](#) on page 2-35 for more information.


For more information about emulators, contact Analog Devices or go to:  
<http://www.analog.com/processors/tools/blackfin>.

## Expansion Interface

The expansion interface consists of three 90-pin connectors (J1–3). These connectors contain a majority of the ADSP-BF527 processor's signals. For the pinout of the connectors, go to “[ADSP-BF527 EZ-KIT Lite Schematic](#)” on page B-1. The expansion interface allows an EZ-Extender<sup>®</sup> or a custom-design daughter board to be tested across various hardware platforms. The mechanical dimensions of the expansion connectors can be obtained by contacting [Technical Support](#).

Analog Devices offers many EZ-Extender products. For more information about EZ-Extenders, visit the Analog Devices Web site at:  
<http://www.analog.com/processors/tools/blackfin>.

Limits to current and interface speed must be taken into consideration when using the expansion interface. Current for the expansion interface is sourced from the EZ-KIT Lite; therefore, the current should be limited to 1A for both the 5V and 3.3V planes. If more current is required, then a separate power connector and a regulator must be designed on a daughter card. Additional circuitry can add extra loading to signals, decreasing their maximum effective speed.

 Analog Devices does not support and is not responsible for the effects of additional circuitry.

## Power Measurements

Several locations are provided for measuring the current draw from various power planes. Precision 0.05 ohm shunt resistors are available on the VDDINT, VDDEXT, and VDDMEM pins. For current draw measurements, the associated jumper (P14, P15, or P16) should be removed. Once the jumper is

## Power-On-Self Test

removed, voltage across the resistor can be measured using an oscilloscope. Once voltage is measured, current can be calculated by dividing the voltage by 0.05. For the highest accuracy, a differential probe should be used for measuring the voltage across the resistor.

For more information, see [“VDDINT Power Jumper \(P14\)”](#), [“VDDEXT Power Jumper \(P15\)”](#), and [“VDDMEM Power Jumper \(P16\)”](#) on page 2-25.

## Power-On-Self Test

The power-on-self program (POST) tests all EZ-KIT Lite peripherals and validates functionality as well as connectivity to the processor. Once assembled, each EZ-KIT Lite is fully tested for an extended period of time with a POST. All EZ-KIT Lites are shipped with the POST preloaded into parallel flash (U5) and SPI flash (U8) memories. The POST is executed by resetting the board and pressing the proper push button(s). The POST also can be used for reference for a custom software design or hardware troubleshooting.

When running the POST, you may need to place switches and jumpers in specific test modes. In some instances, such as Ethernet, you may need to plug in an Ethernet loopback connector (provided with the EZ-KIT Lite) to run the POST. The user LEDs (LED1–3) convey whether the specific tests have passed or failed.

Note that the source code for the POST program is included in the EZ-KIT Lite installation directory along with the readme file, which describes how the board is configured to run POST.



The POST program is only available when using VisualDSP++.

## Example Programs

Example programs are provided with the ADSP-BF527 EZ-KIT Lite to demonstrate various capabilities of the product. The programs are included in the product installation kit and can be found in the `Examples` folder of the installation. Refer to a readme file provided with each example for more information.

CCES users are encouraged to use the example browser to find examples included with the EZ-KIT Lite Board Support Package.

## Board Design Database

A `.zip` file containing all of the electronic information required for the design, layout, fabrication and assembly of the product is available for download from the Analog Devices board design database at:  
<http://www.analog.com/board-design-database>.



# 2 ADSP-BF527 EZ-KIT LITE HARDWARE REFERENCE

This chapter describes the hardware design of the ADSP-BF527 EZ-KIT Lite board.

The following topics are covered.

- [“System Architecture” on page 2-2](#)  
Describes the ADSP-BF527 EZ-KIT Lite board configuration and explains how the board components interface with the processor.
- [“Programmable Flags” on page 2-3](#)  
Shows the locations and describes the programming flags (PFs).
- [“Push Buttons and Switches” on page 2-10](#)  
Shows the locations and describes the on-board push buttons and switches.
- [“Jumpers” on page 2-23](#)  
Shows the locations and describes the on-board configuration jumpers.
- [“LEDs” on page 2-26](#)  
Shows the locations and describes the on-board LEDs.
- [“Connectors” on page 2-28](#)  
Shows the locations and provides part numbers for the on-board connectors. In addition, the manufacturer and part number information is provided for the mating parts.

## System Architecture

This section describes the processor's configuration on the EZ-KIT Lite board (Figure 2-1).




Figure 2-1. System Architecture

The EZ-KIT Lite is designed to demonstrate the ADSP-BF527 processor capabilities. The processor has an I/O voltage of 3.3V. The core voltage of the processor is controlled by the internal voltage regulator.



The core voltage and clock rate can be set on the fly by the processor. The input clock is 25 MHz. A 32.768 kHz crystal supplies the real-time clock (RTC) inputs of the processor. The default boot mode for the processor is external parallel flash boot. See [“Boot Mode Select Switch \(SW2\)”](#) on [page 2-11](#) for information on how to change the default boot mode.

## Programmable Flags

The processor has 50 general-purpose input/output (GPIO) signals spread across four ports (PF, PG, PH, and PJ). The pins are multi-functional and depend on the ADSP-BF527 processor setup. The following tables show how the programmable flag pins are used on the EZ-KIT Lite.

- PF programmable flag pins in [Table 2-1](#)
- PG programmable flag pins in [Table 2-2](#)
- PH programmable flag pins in [Table 2-3](#)
- PJ programmable flag pins in [Table 2-4](#)

Table 2-1. PF Port Programmable Flag Connections

| Processor Pin | Other Processor Function | EZ-KIT Lite Function   |
|---------------|--------------------------|--|
| PF0           | PPID0/DROPRI/ND_D0A      | Default: LCD via CPLD.<br>Expansion interface via J1.72.<br>PPI connector via P8.8.  |
| PF1           | PPID1/RFS0/ND_D1A        | Default: LCD via CPLD.<br>Expansion interface via J1.73.<br>PPI connector via P8.9.  |
| PF2           | PPID2/RSCLK0/ND_D2       | Default: LCD via CPLD.<br>Expansion interface via J1.74.<br>PPI connector via P8.10. |
| PF3           | PPID3/DTOPRI/ND_D3A      | Default: LCD via CPLD.<br>Expansion interface via J1.75.<br>PPI connector via P8.11. |

## Programmable Flags

Table 2-1. PF Port Programmable Flag Connections (Cont'd)

| Processor Pin | Other Processor Function       | EZ-KIT Lite Function   |
|---------------|--------------------------------|--|
| PF4           | PPID4/TFS0/ND_D4A/<br>TACLK0   | Default: LCD via CPLD.<br>Expansion interface via J2.43.<br>PPI connector via P8.12.   |
| PF5           | PPID5/TSCLK0/ND_D5A/<br>TACLK1 | Default: LCD via CPLD.<br>Expansion interface via J2.44.<br>PPI connector via P8.13.   |
| PF6           | PPID6/DT0SEC/ND_D6A/<br>TACIO  | Default: LCD via CPLD.<br>Expansion interface via J2.45.<br>PPI connector via P8.14.   |
| PF7           | PPID7/DROSEC/ND_D7A/<br>TACI1  | Default: LCD via CPLD.<br>Expansion interface via J2.46.<br>PPI connector via P8.15.   |
| PF8           | PPID8/DR1PRI                   | Default: LED1.<br>LCD via CPLD, SW29, and JP15.<br>Touchscreen interrupt via SW24.1 and JP15.<br>Expansion interface via J1.79, J2.29, and J2.47.<br>Via a quick switch U30 and JP15 to the following connectors: SPORT0 P6.25, SPORT1 P7.8, SPI P9.14, TWI P10.10, and PPI P8.24. |
| PF9           | PPID9/RSCLK1/SPISEL6#          | Default: KEYIRQ# (U35) via SW25.4.<br>LCD via CPLD and SW29.<br>Expansion interface via J2.48 and J2.33.<br>Via a quick switch U38 to SPORT1 connector P7.16 and PPI connector P8.17.  |
| PF10          | PPID10/PRFS1/SPISEL7#          | Default: $\overline{\text{LCD\_SPIC\#}}$ via SW25.1.<br>LCD via CPLD and SW29.<br>CTS UART1 U25 via SW10.3 and SW30.<br>Expansion interface via J2.31 and J2.49.<br>Via a quick switch U38 to SPORT1 connector P7.7 and PPI connector P8.18.                                       |
| PF11          | PPID11/TFS1/CZM                | Default: CZM rotary (SW3) via SW11.3.<br>LCD via CPLD and SW29.<br>Expansion interface via J2.32 and J2.50.<br>Via a quick switch U30 to PPI connector P8.19 and SPORT1 connector P7.11.   |

## ADSP-BF527 EZ-KIT Lite Hardware Reference

Table 2-1. PF Port Programmable Flag Connections (Cont'd)

| Processor Pin | Other Processor Function        | EZ-KIT Lite Function  |
|---------------|---------------------------------|---|
| PF12          | PPID12/DT1PRI/<br>SPISEL2#/CDG  | Default: CDG rotary (SW3) via SW11.2.<br>LCD via CPLD and SW29.<br>Expansion interface via J2.30 and J2.51.<br>Via a quick switch U31 to the following connectors: SPI P9.9, SPORT1 P7.14 and P7.19, PPI P8.20 and P8.26, SPORT0 P6.19. |
| PF13          | PPID13/TSCLK1/<br>SPISEL3#/CUD  | Default: CUD rotary (SW3) via SW11.1.<br>LCD via CPLD and SW29.<br>Expansion interface via J2.34 and J2.52.<br>Via a quick switch U30 to the following connectors: SPORT1 P7.6 and P7.21, SPORT0 P6.21, PPI P8.21 and P8.25, SPI P9.12. |
| PF14          | PPID14/DT1SEC/UART1TX           | Default: UART1 (U25) TX via SW30.<br>LCD via CPLD and SW30.<br>Expansion interface via J2.28, J2.53, J2.55, J3.8.<br>Via a quick switch U38 to SPORT1 connector P7.12, and PPI connector P8.22.   |
| PF15          | PPID15/DR1SEC/UART1RX/T<br>ACI3 | Default: UART1 (U25) RX via SW10.2 and SW30.<br>LCD via CPLD and SW30.<br>Expansion interface via J2.27, J2.54, J2.56, J3.7, SPORT1 connector P7.10, and PPI connector P8.23  |

Table 2-2. PG Port Programmable Flag Connections

| Processor Pin | Other Processor Function | EZ-KIT Lite Function   |
|---------------|--------------------------|--|
| PG0           | HWAIT                    | Default: PB1 via SW13.1.<br>UART1 RTS (HWAIT) via SW10.1 and SW30, host connector P13.12, and expansion interface J1.84.   |
| PG1           | SPISS#/SPISEL1#          | Default: SPI flash (U8) CS via SW9.4.<br>LCD CS via SW25.2, expansion interface J2.11, via quick switch U31 to the following connectors: SPI P9.10, PPI P8.27, SPORT0 P6.17, and SPORT1 P7.17. |

## Programmable Flags

Table 2-2. PG Port Programmable Flag Connections (Cont'd)

| Processor Pin | Other Processor Function     | EZ-KIT Lite Function  |
|---------------|------------------------------|---|
| PG2           | SPISCK                       | Default: SPI flash (U8), codec (U2) via SW19, and LCD. Expansion interface J2.9, via quick switch U31 to the following connectors: SPI P9.8, SPORT0 P6.22, SPORT1 P7.22, and PPI P8.34.                       |
| PG3           | SPIMISO/DROSECA              | Default: SPI flash (U8) and LCD. Via a quick switch (U31) to the following connectors: SPI P9.6, SPORT0 P6.10 and P6.20, SPORT1 P7.20, and PPI P8.32, and expansion interface J2.12, J2.35.                   |
| PG4           | SPIMOSI/DTOSECA              | Default: SPI flash (U8), codec (U2) via SW19, and LCD. Via a quick switch (U31) to the following connectors: SPORT0 P6.12 and P6.18, SPORT1 P7.18, SPI P9.5, PPI P8.30, and expansion interface J2.10, J2.36. |
| PG5           | TMR1/PPIFS2/TFS0A            | Default: LCD via CPLD. PPI connector P8.33, expansion interface J2.24.  |
| PG6           | DTOPRIA/TMR2/PPIFS3          | Default: SPORT0 audio codec (U2) via SW20.2. Via JP14 to PPI connector P8.29 and SPORT0 connector P6.14. Expansion interface via J2.38, J2.23.  |
| PG7           | TMR3/DROPRIA/UART0TX         | Default: SPORT0 audio codec (U2) via SW20.3. Via a quick switch (U34) to the following connectors: UART0 P5.6, SPORT0 P6.8 and P6.28, SPORT1 P7.28, timers P11.6, and expansion interface J2.37, J3.6.        |
| PG8           | TMR4/RFS0A/UART0RX/<br>TACI4 | Default: SPORT0 audio codec (U2) via SW20.4. Via a quick switch (U34) to the following connectors: SPORT0 P6.7 and P6.30, SPORT1 P7.30, timers P11.8, UART0 P5.10, and expansion interface J2.39, J3.5.       |
| PG9           | TMR5/RSCLK0A/TACI5           | Default: SPORT0 audio codec (U2) via SW23.2. Via a quick switch (U34) to the following connectors: SPORT0 P6.32 and P6.16, SPORT1 P7.32, timers P11.10, and expansion interface J2.41.                        |
| PG10          | TMR6/TSCLK0A/TACI6           | Default: SPORT0 audio codec (U2) via SW23.1. SPORT0 connector P6.6, expansion interface J2.42.  |

## ADSP-BF527 EZ-KIT Lite Hardware Reference

Table 2-2. PG Port Programmable Flag Connections (Cont'd)

| Processor Pin | Other Processor Function                 | EZ-KIT Lite Function   |
|---------------|--|--|
| PG11          | TMR7/HOST_WR#                            | Default: LED2.<br>Keypad interrupt via SW25.5, touchscreen interrupt via SW24.2, LCD reset via SW5.1. Host connector P13.4, via a quick switch to the following connectors: SPORT0 P6.27, UART0 P5.3, SPORT1 P7.29, TWI P10.9, timers P11.3, SPI P9.15, and expansion interface J1.80. |
| PG12          | DMAR1/UART1TXA/<br>HOST_ACK              | Default: LED3.<br>PPI_SEL via SW13.4, host connector P13.10, via a quick switch (U30) to the following connectors: UART0 P5.5, timers P11.5, TWI P10.12, SPORT0 P6.29, SPORT1 P7.31, SPI P9.16, and expansion interface J1.81.   |
| PG13          | DMAR0/UART1RXA/<br>HOST_ADDR/TACI2       | Default: PB2 via SW13.2.<br>OTG USB_VRSEL via SW13.3 ON and SW13.2 OFF, host connector P13.8, and expansion interface J1.85.   |
| PG14          | TSCCLK0A/MDC/HOST_RD#                    | Default: host connector P13.6.<br>MDIO PHY (U14) via SW1.2, expansion interface J3.41.   |
| PG15          | TFS0A/MIIPHYINT#/<br>RMIIMDINT#/HOST_CE# | Default: SPORT0 audio codec (U2) via SW20.1.<br>RMIIMDINT# PHY (U14), host connector P13.6, SPORT0 connector P6.11, and expansion interface J2.40, J3.31.  |

Table 2-3. PH Port Programmable Flag Connections

| Processor Pin | Other Processor Function            | EZ-KIT Lite Function  |
|---------------|-------------------------------------|---|
| PH0           | ND_D0/MIICRS/<br>RMIICRS/DV/HOST_D0 | Default: NAND Data 0 (U4).<br>RMI carrier sense/receive data valid (U14.36), host connector data 0 (P13.31), and expansion interface (J3.40). |
| PH1           | ND_D1/ERXER/HOST_D1                 | Default: NAND Data 1 (U4).<br>PHY receive error (U14.21), host connector data 1 (P13.29), expansion interface (J3.39).                        |

## Programmable Flags

Table 2-3. PH Port Programmable Flag Connections (Cont'd)

| Processor Pin | Other Processor Function                   | EZ-KIT Lite Function   |
|---------------|--|--|
| PH2           | ND_D2/MDIO/HOST_D2                         | Default: NAND Data 2 (U4).<br>PHY management bus MDIO via SW1.1, host connector data 2 (P13.27), and expansion interface (J3.42).  |
| PH3           | ND_D3/ETXEN/HOST_D3                        | Default: NAND Data 3 (U4).<br>PHY transmit enable (U14.6), host connector data 3 (P13.25), and expansion interface (J3.15).  |
| PH4           | ND_D4/MIITXCLK/<br>RMIIREF_CLK/<br>HOST_D4 | Default: NAND Data 4 (U4).<br>PHY RMI ref clock (U14.14) via SW1.3 OFF, oscillator output U24, host connector data 4 (P13.23), and expansion interface (J3.16).              |
| PH5           | ND_D5/ETXD0/HOST_D5                        | Default: NAND Data 5 (U4).<br>PHY RMI transmit data 0 (U14.23), host connector data 5 (P13.21), and expansion interface (J3.11).   |
| PH6           | ND_D6/ERXD0/HOST_D6                        | Default: NAND Data 6 (U4).<br>PHY RMI receive data 0 (U14.18), PHY mode via SW9.3, host connector data 6 (P13.19), and expansion interface (J3.33).                          |
| PH7           | ND_D7/ETXD1/HOST_D7                        | Default: NAND Data 7 (U4).<br>PHY RMI transmit data 1 (U14.24), host connector data 7 (P13.17), and expansion interface (J3.12).   |
| PH8           | SPISEL4#/ERXD1/<br>HOST_D8/TACLK2          | Default: NAND Data 7 (U4).<br>PHY RMI transmit data 1 (U14.24), keypad/touch-screen chip select via SW18.2, host connector data 8 (P13.17), and expansion interface (J3.12). |
| PH9           | SPISEL5#/ETXD2/<br>HOST_D9/TACLK3          | Default: SPI SEL5 audio codec U2.<br>Host connector data 9 (P13.13), expansion interface (J3.13).  |
| PH10          | ND_CE#_ERXD2/HOST_D10                      | Default: NAND chip enable via SW11.4 ON.<br>Host connector data 10 (P13.17), expansion interface (J3.35).  |
| PH11          | ND_WE/ETXD3/HOST_D11                       | Default: NAND write enable (U4).<br>Host connector data 11 (P13.9), expansion interface (J3.14).   |

## ADSP-BF527 EZ-KIT Lite Hardware Reference

Table 2-3. PH Port Programmable Flag Connections (Cont'd)

| Processor Pin | Other Processor Function    | EZ-KIT Lite Function   |
|---------------|-----------------------------|--|
| PH12          | ND_RE/ERXD3/HOST_D12        | Default: NAND output enable (U4).<br>Host connector data 12 (P13.7), expansion interface (J3.36).        |
| PH13          | ND_BUSY/ERXCLK/<br>HOST_D13 | Default: NAND busy (U4).<br>Host connector data 13 (P13.5), expansion interface (J3.38).                 |
| PH14          | ND_CLE/ERXDV/HOST_D14       | Default: NAND command latch enable (U4).<br>Host connector data 14 (P13.3), expansion interface (J3.37). |
| PH15          | ND_ALE/COL/HOST_D15         | Default: NAND address latch enable (U4).<br>Host connector data 15 (P13.1), expansion interface (J3.32). |

Table 2-4. PJ Port Programmable Flag Connections

| Processor Pin | Other Processor Function | EZ-KIT Lite Function   |
|---------------|--------------------------|--|
| PJ0           | PPIFS1/TMRO              | Default: LCD via CPLD.<br>PPI connector (P8.31), expansion interface (J2.25).  |
| PJ1           | PPICLK/TMRCLK            | Default: LCD via CPLD.<br>Output of switch (U20), PPI connector (P8.6), and expansion interface (J1.71).   |
| PJ2           | SCL                      | Default: touchscreen (U37).<br>Codec via SW19.4, expansion interface (J2.57), the following connectors via a quick switch (U31): TWI (P10.5), PPI (P8.38), SPORT0 (P6.26), and SPORT1 (P7.26). |
| PJ3           | SDA                      | Default: touchscreen (U37).<br>Codec via SW19.4, expansion interface (J2.58), the following connectors via a quick switch (U31): TWI (P10.6), PPI (P8.36), SPORT0 (P6.24), and SPORT1 (P7.24). |

## Push Buttons and Switches

This section describes operation of the push buttons and switches. The push button and switch locations are shown in [Figure 2-2](#).




Figure 2-2. Push Button and Switch Locations

### ETH Enable Switch (SW1)

The Ethernet enable switch (SW1) allows the Ethernet to operate. Ethernet and NAND flash share the same lines and cannot operate at the same time. By default, SW1 is OFF, OFF, ON, OFF (see [Table 2-5](#)). Ethernet is enabled by setting the switch to ON, ON, OFF, ON. SW1 positions 1 and 2 connect the management bus (MDIO and MDC). SW1 position 3 enables the 50 MHz RMII clock. SW1 position 4 holds the PHY in reset (set to OFF) or connects the PHY reset to the EZ-KIT Lite reset (set to ON).



Table 2-5. ETH Enable Switch (SW1)

| SW1 Switch Setting | Ethernet Mode |
|--------------------|---------------|
| OFF, OFF, ON, OFF  | OFF (default) |
| ON, ON, OFF, ON    | ON            |

## Boot Mode Select Switch (SW2)

The rotary switch (SW2) determines the boot mode of the processor. [Table 2-6](#) shows the available boot mode settings. By default, the ADSP-BF527 processor boots from the on-board parallel flash memory.



The selected position of SW2 is marked by the notch down the entire rotating portion of the switch, not the small arrow.

Table 2-6. Boot Mode Select Switch (SW2)

| SW2 Position | Processor Boot Mode                                    |
|--------------|--|
| 0            | Reserved   |
| 1            | <b>Boot from 8-bit external flash memory (default)</b> |
| 2            | Boot from 16-bit asynchronous FIFO                     |
| 3            | Boot from serial SPI memory                            |
| 4            | Boot from SPI host device                              |
| 5            | Boot from serial TWI memory                            |
| 6            | Boot from TWI host                                     |
| 7            | Boot from UART0 host                                   |
| 8            | Boot from UART1 host                                   |
| 9            | Reserved   |
| A            | Boot from SDRAM  |
| B            | Reserved   |
| C            | Boot from 8-bit NAND flash PORTF                       |
| D            | Boot from 8-bit NAND flash PORTH                       |

## Push Buttons and Switches

Table 2-6. Boot Mode Select Switch (SW2) (Cont'd)

| SW2 Position | Processor Boot Mode       |
|--------------|---------------------------|
| E            | Boot from 16-bit host DMA |
| F            | Boot from 8-bit host DMA  |

## Rotary Encoder With Momentary Switch (SW3)

The rotary encoder (SW3) can be turned clockwise for an up count or counter-clockwise for a down count. The encoder also features a momentary switch, activated by pushing down the switch and setting the counter to zero. The rotary encoder is a two-bit quadrature (Gray code) encoder. Refer to the “Rotary Counter” section in the *ADSP-BF52x Hardware Reference Manual* for additional information about interfacing with the rotary encoder.

The rotary encoder can be disconnected from the processor by setting the rotary enable switch SW11 positions 1, 2 and 3 to OFF. See “[Rotary NAND Enable Switch \(SW11\)](#)” on page 2-16 for more information.

## MIC Gain Switch (SW4)

The microphone gain switch (SW4) sets the gain of the MIC signal, which is connected to the top 3.5 mm jack (J7). The gain can be set to 14 dB, 0 dB, or –6 dB by turning position 1, 2 or 3 of the switch ON (see [Table 2-7](#)). When the corresponding position for the desired gain is ON, the remaining positions should be OFF. Refer to “[Audio Interface](#)” on [page 1-23](#) for more information about the audio codec.

Table 2-7. MIC Gain Switch (SW4)

| Gain      | SW4 Switch Settings |
|-----------|---------------------|
| 5 (14 dB) | ON, OFF, OFF, OFF   |
| 1 (0 dB)  | OFF, ON, OFF, OFF   |

Table 2-7. MIC Gain Switch (SW4) (Cont'd)

| Gain        | SW4 Switch Settings         |
|-------------|-----------------------------|
| 0.5 (–6 dB) | OFF, OFF, ON, OFF (default) |
| Unused      | OFF, OFF, OFF, OFF          |

## LCD Reset Switch (SW5)

The LCD reset switch (SW5) in default mode connects the general  $\overline{\text{RESET}}$  line to the  $\overline{\text{LCD\_RESET}}$  line. By default, SW5.2 is ON. When SW5.1 is set to ON,  $\overline{\text{LCD\_RESET}}$  comes from HOSTWR#\_LED1 (see [Table 2-8](#)).

Table 2-8. LCD Reset Switch (SW5)

| SW5 Position (Default) | From                 | To        | Function  |
|------------------------|----------------------|-----------|---|
| 1 (OFF)                | Processor (U2, PG11) | LCD RESET | Resets the LCD through the processor's PG11 pin |
| 2 (ON)                 | Main reset (U27)     | LCD RESET | Reset the LCD through the main reset            |

## Flash Enable Switch (SW7)

The flash enable switch (SW7) disconnects  $\overline{\text{AMS}}$  signals from flash memory, allowing other devices to utilize the signals via the expansion interface. For each switch listed in [Table 2-9](#) that is turned OFF, the size of available flash memory is reduced by 1 MB.

Table 2-9. Flash Enable Switch (SW7)

| SW7 Switch Position (Default) | Processor Signal         |
|-------------------------------|--------------------------|
| 1 (ON)                        | $\overline{\text{AMS0}}$ |
| 2 (ON)                        | $\overline{\text{AMS1}}$ |

## Push Buttons and Switches

Table 2-9. Flash Enable Switch (SW7) (Cont'd)

| SW7 Switch Position (Default) | Processor Signal         |
|-------------------------------|--------------------------|
| 3 (ON)                        | $\overline{\text{AMS2}}$ |
| 4 (ON)                        | $\overline{\text{AMS3}}$ |

### Mic/HP LPBK Audio Mode Switch (SW8)

The audio mode select switch SW8 places the EZ-KIT Lite in loopback mode to test signal/circuit continuity and functionality (see [“Power-On-Self Test” on page 1-30](#)).

SW8 positions 1 and 2 connect the MICIN signal to the headphone left and right outputs for audio loopback. Do not turn SW8 positions 1 and 2 ON at the same time.

SW8 positions 3 and 4 select the control interface for the audio codec. SW8 position 3 ON and 4 OFF select SPI interface, while position 3 OFF and position 4 ON select TWI mode. The SW8 default settings are OFF, OFF, ON, OFF. See [“SPI/TWI Switch \(SW19\)” on page 2-19](#) for more information.

### ETH Mode Flash CS Switch (SW9)

The Ethernet mode flash CS switch (SW9) sets the bootstrapping options for the LAN8700 RMII PHY chip (U14). [Table 2-10](#) shows the SW9 default as well as the alternate switch settings.

SW9 position 4 disconnects SPISEL1 from the SPI flash chip (U8). Setting SW9 position 4 OFF is useful when using SPISEL1 on the expansion interface at connector J2 pin 11. By default, SW9 position 4 is ON.

Table 2-10. ETH Mode Flash CS Switch (SW9)

| SW9 Switch Setting | MODE[2:0] Setting | Mode Definitions                                    |
|--------------------|-------------------|---|
| OFF, OFF, OFF      | 111               | All capable, auto negotiation (default)             |
| OFF, OFF, ON       | 110               | Power down mode                                     |
| OFF, ON, OFF       | 101               | Repeater mode, auto negotiation                     |
| OFF, ON, ON        | 100               | 100Base-TX half duplex advertised, auto negotiation |
| ON, OFF, OFF       | 011               | 100Base-TX full duplex                              |
| ON, OFF, ON        | 010               | 100Base-TX half duplex                              |
| ON, ON, OFF        | 001               | 10Base-T full duplex                                |
| ON, ON, ON         | 000               | 10Base-T half duplex                                |

## UART Enable Switch (SW10)

The UART enable switch (SW10) disconnects UART1 signals from the GPIO pins of the processor (see [Table 2-11](#)). When SW10 is OFF, its associated GPIO signals can be used for other functions. By default, SW10 is OFF, ON, OFF, OFF, OFF, OFF, OFF, OFF, OFF. Flow control is not implemented in POST programs, so SW10 positions 1 and 3 are OFF. Refer to the ADM3202 data sheet for more information about the UART interface.

Table 2-11. UART Enable Switch (SW10)

| POS    | From                          | To           | Default | Alternate Function      |
|--------|-------------------------------|--------------|---------|-------------------------|
| SW10.1 | HWAIT_PUSHBUTTON1 (PG0) (U2)  | T2IN in U25  | OFF     | Ties URT1RTS to T2IN    |
| SW10.2 | UART1RX (PF15) (U2)           | U25          | ON      | Disconnects UART1RX     |
| SW10.3 | UART1CTS_LCDSPICS (PF10) (U2) | R2OUT in U25 | OFF     | CTS flow control signal |
| SW10.4 | R2OUT                         | T2IN in U25  | OFF     | Loopback of CTS to RTS  |

## Push Buttons and Switches

Table 2-11. UART Enable Switch (SW10) (Cont'd)

| POS    | From               | To          | Default | Alternate Function                     |
|--------|--------------------|-------------|---------|--|
| SW10.5 | R2OUT              | SOFT_RESET  | OFF     | Soft resets the processor through UART |
| SW10.6 | Pin 7 in J4        | R2IN in U25 | OFF     | Ties pin 7 in J4 to R2IN               |
| SW10.7 | Pins 1, 4, 6 in J4 | R2IN in U25 | OFF     | Ties pins 1, 4, 6 in J4 to R2IN        |
| SW10.8 | UART1TX            | UART1RX     | OFF     | Loopback of TX to RX                   |

## Rotary NAND Enable Switch (SW11)

The rotary NAND enable switch (SW11) disconnects the rotary encoder signals from the GPIO pins of the processor. When SW11 is OFF, its associated GPIO signals can be used on the host interface (see [Table 2-12](#)). Position 4 of SW11 disconnects the chip enable for NAND flash memory (U4).

Table 2-12. Rotary NAND Enable Switch (SW11)

| SW11 Position (Default) | From                 | To                   | Alternate Function/OFF Mode   |
|-------------------------|----------------------|----------------------|---|
| 1 (ON)                  | Encoder (SW3)        | Processor (U2, PF13) | Expansion interface (J2.34, J2.52) STAMP buffer (U34)   |
| 2 (ON)                  | Encoder (SW3)        | Processor (U2, PF12) | CS audio codec (U2), CS keypad/touch controller (U16), expansion interface (J2.30, J2.51), STAMP buffer (U30) |
| 3 (ON)                  | Encoder (SW3)        | Processor (U2, PF11) | Expansion interface (J2.32, J2.50), STAMP buffer (U34)  |
| 4 (ON)                  | Processor (U2, PH10) | NAND (U4)            | Host connector (P13.11), expansion interface (J3.35)  |

## GPIO Enable Switch (SW13)

The general-purpose input/output (GPIO) switch (SW13) disconnects the associated push buttons and LED circuits from the GPIO pins of the processor and allows the signals to be used for other functions. Depending on the switch configuration, the signals can be used as PPI clock select, keypad\_busy, or OTG host mode 5V select (see [Table 2-13](#)).

Table 2-13. GPIO Enable Switch (SW13)

| SW13 Position (Default) | From                 | To                   | Function  |
|-------------------------|----------------------|----------------------|---|
| 1 (ON)                  | Push button 1        | Processor (U2, PG0)  | ON (PB1), OFF (UART1 CTS U25, host connector P13.12, keypad busy SW13.8, expansion interface J1.84) |
| 2 (ON)                  | Push button 2        | Processor (U2, PG13) | ON (PB2), OFF (host connector P13.8, OTG voltage select SW13.7, expansion interface J1.85)          |
| 3 (OFF)                 | OTG PWR (VR3, U28)   | Processor (U2, PG13) | OFF (host connector P13.8, expansion interface J1.85), ON (PB2 SW13.11, OTG power VR3, U28)         |
| 4 (OFF)                 | Processor (U2, PG12) | PPI CLK (U20)        | OFF (LED2, host connector P13.10, expansion interface J1.81, STAMP buffer U34), ON (PPI CLK U20)    |

To select an on-board or external PPI clock through software, set SW13 position 4 ON. Drive the PG12 programmable flag to low (0) to connect an external expansion interface clock. Drive PG12 high to select the on-board PPI oscillator. By default, SW13 position 4 is OFF, and the PPI clock source is on-board.

The USB\_VRSEL signal is used to provide 5V to a device connected over the USB OTG interface when running in host mode. Signal USB\_VRSEL is connected by setting SW13 position 2 OFF and position 3 ON. Then the PG13 programmable flag pin of the processor can be used to control the 5V regulator (VR3). Refer to [“USB OTG Interface” on page 1-25](#) for more information.

### Programmable Flag Push Buttons (SW14–15)

Two momentary push buttons (SW14–15) are provided for general-purpose user input. The push buttons are connected to the PG0 and PG13 GPIO pins of the processor. The push buttons are active high and, when pressed, send a high (1) to the processor. The GPIO enable switch (SW13) disconnects the push buttons from the corresponding PB signal. Refer to [“GPIO Enable Switch \(SW13\)” on page 2-17](#) for more information.

### Reset Push Button (SW16)

The reset push button (SW16) resets the following ICs.

- Processor (U2), parallel flash (U5), PHY (U14) if SW1 position 4 is ON
- LCD (P12) if SW5 position 1 is OFF and 2 is ON
- CPLD (U34)

The reset push button does not reset the following ICs.

- SDRAM (U7), NAND flash (U4), SPI flash (U8)
- Audio codec (U2), keypad controller (U35), touchscreen controller (U37)
- UART1 (U25)

The reset push button does not reset the debug agent once it has been connected to a PC. The USB chip is not reset when the push button is pressed after the USB cable has been plugged in and communication with the PC has been initialized correctly. After USB communication has been initialized, the only way to reset the USB chip is by powering down the board.



## SPI/TWI Switch (SW19)

The SPI/TWI switch (SW19) selects the control interface for the audio codec. By default, SW19 is ON, OFF, ON, OFF (SPI interface is selected). TWI is selected by setting SW19 to OFF, ON, OFF, ON. See “[Mic/HP LPBK Audio Mode Switch \(SW8\)](#)” on page 2-14 for more information on how to set up the audio mode.

## SPORT0A ENBL Switches (SW20 and SW27)

The SPORT0A enable switches (SW20 and SW27) connect the SPORT0A interface of the processor to the audio codec. When SPORT0A is needed at the expansion interface, turn SW20, SW27.1, and SW27.2 all OFF. By default, the switches are all ON.

## TFS0A/HOSTCE Enable Switch (SW21)

The TFS0A/HOSTCE enable switch (SW21) disconnects the PG15 programmable flag signal TFS0A\_RMIIMDINT#\_HOSTCE# from SPORT0 (position 1) connector P6 pin 11 and host connector (position 2) P13 pin 6. By default, SW21 is OFF, OFF.

## Touch ADD Switch (SW22)

The touchscreen address switch (SW22) sets the I<sup>2</sup>C address of the AD7879-1 controller (U37) as shown in [Table 2-14](#).

Table 2-14. AD7879-1 (U37) I<sup>2</sup>C Address Options

| SW22.1 Setting | SW22.2 Setting | I <sup>2</sup> C Address |
|----------------|----------------|--------------------------|
| ON             | ON             | 0101 100                 |
| ON             | OFF            | 0101 101                 |

## Push Buttons and Switches

Table 2-14. AD7879-1 (U37) I<sup>2</sup>C Address Options (Cont'd)

| SW22.1 Setting | SW22.2 Setting | I <sup>2</sup> C Address |
|----------------|----------------|--------------------------|
| OFF            | ON             | 0101 110                 |
| OFF            | OFF            | 0101 111 (default)       |

### Touchpad INT Switch (SW24)

The touchpad interrupt switch (SW24) selects a GPIO signal as the AD7879-1 controller's (U37) interrupt signal. The signal options are:

- LED0 (PF8) on position 1
- HOSTWR#\_LED1 (PG11) on position 2
- SPISEL5#\_HOSTD9 (PH9) on position 3

Position 4 is not connected to any signals. By default, SW24 is ON, OFF, OFF, OFF.

### LCD/KPAD CTL Switch (SW25)

The LCD/keypad control switch (SW25) selects the LCD SPI chip select and interrupt line signals for the ADP5520 keypad controller (U35).

The signal options for the LCD SPI chip select are:

- UART1CTS\_LCDSPICS (PF10) on position 1
- $\overline{\text{SPISEL1}}$  (PG1) on position 2
- SPISEL5#\_HOSTD9 (PH9) on position 3.

The signal options for the keypad interrupt are:

- KEYIRQ# (PF9) on position 4
- HOSTWR#\_LED1 (PG11) on position 5
- SPISEL5#\_HOSTD9 (PH9) on position 6.

By default, SW25 is ON, OFF, OFF, ON, OFF, OFF.



Check other board settings before making a selection for this switch. Many signals are multiplexed with other functions and may cause a conflict if not handled appropriately.

## Mode Switch (SW26)

The mode switch (SW26) selects the mode between the LCD and CPLD interfaces. See [Table 2-15](#).

Table 2-15. LCD Mode Interface Select Switch (SW26)

| SW26 Positions 2, 1 | Mode Definition                   |
|---------------------|-----------------------------------|
| ON, ON              | 16-bit PPI pass through           |
| ON, OFF             | 16-bit PPI pass through           |
| OFF, ON             | RGB565 input mMode 16BPP          |
| OFF, OFF            | RGB888 input mode 24BPP (default) |

SW26 positions 3, 4, and 5 are not used and available for future use. SW26 position 6 enables a PPI data buffer between the processor and LCD (active low). By default, SW26 is OFF, OFF, ON, ON, ON, ON.

## Push Buttons and Switches

### Line In-Out LPBK Switch (SW28)

The line in/out loopback switch (SW28) disconnects `LINEIN` audio signals from `LINEOUT` (the signals are no longer looped back). The loopback also can be broken by plugging a cable into the bottom of the J7 or J8 connector. SW28 is ON when a POST example is running.

### CPLD D8–13 Switch (SW29)

The CPLD D8–13 switch (SW29) connects PPI data lines 8–13 to the CPLD. By default, SW29 is all OFF.

### CPLD 14–15/DCE ENB Switch (SW30)

The CPLD 14–15/DCE enable switch (SW30) disconnects the processor's signals from the EZ-KIT Lite's peripherals:

- Positions 1 and 2 disconnect PPI data lines 14-15 from the CPLD.
- Positions 3 and 4 disconnect `UART1TX` and `UART1RX` signals from the DCE (UART) interface.
- Positions 5 and 6 disconnect flow control signals from the DCE (UART) interface.

By default, SW30 is OFF, OFF, ON, ON, OFF, OFF.

## Jumpers

This section describes functionality of the configuration jumpers. [Figure 2-3](#) shows the jumper locations.




Figure 2-3. Configuration Jumper Locations

### MIC Select Jumper (JP6)

The MIC select jumper (JP6) connects the MICBIAS signal to the MICIN (JP6 on 1 and 2) or the 3.5 mm connector J7 pin 3 (JP6 on 2 and 3). By default, JP6 is installed on 2 and 3.

### STAMP Enable Jumper (JP7)

STAMP connectors have a number of nets connected by enabling quick switches at locations U30, U31, and U38. When installed, the STAMP enable jumper (JP7) enables the quick switches. [Table 2-16](#) lists the

## Jumpers

signals that are connected when JP7 is installed. By default, JP7 is uninstalled.

Table 2-16. STAMP Enable Jumper (JP7)

| STAMP Signals Connected through Quick Switches U30–31, U38 |                                     |
|--|-------------------------------------|
| SCL  | DROPRIA                             |
| SDA  | RFSOA                               |
| SPISCK   | CZM                                 |
| SPISEL1  | CUD                                 |
| SPISEL2#_CDG   | LED0                                |
| SPIMISO  | HOSTWR#_LED1                        |
| SPIMOSI  | HOSTACK_LED2                        |
| RSCLK0A  | KEYIRQ#, UART1CTS_LCDSPICS, UART1TX |

### Flash WP Jumper (JP10)

The flash WP jumper (JP10) is used to write-protect block 70 of the parallel flash chip. Block 70 contains 64 KB of configuration data at address range 0x203 F0000–0x203 FFFFF. When the jumper is installed on JP10, and the parallel flash driver from Analog Devices is used, block 70 is read-only. By default, JP10 is not installed.

### STP ENB Enable Jumper (JP14)

The stamp enable jumper (JP14) connects the DTOPRIA\_PPIFS3 signal to the STAMP interface connectors. By default, JP14 is uninstalled.

### LED0 OFF Jumper (JP15)

The LED0 OFF jumper (JP15) disconnects the LED0 signal from the following switches: SW24, SW29, and a quick switch U38.

## VDDINT Power Jumper (P14)

The VDDINT power jumper (P14) is used to measure the core voltage and current supplied to the processor core. By default, P14 is ON, and the power flows through the two-pin IDC header. To measure power, remove the jumper and measure voltage across the 0.05 ohm resistor. Once voltage is measured, the power can be calculated. For more information, refer to [“Power Measurements” on page 1-29](#).

## VDDEXT Power Jumper (P15)

The VDDEXT power jumper (P15) is used to measure the processor's I/O voltage and current. By default, JP15 is ON, and the power flows through the two-pin IDC header. To measure power, remove the jumper and measure voltage across the 0.05 ohm resistor. Once voltage is measured, the power can be calculated.

## VDDMEM Power Jumper (P16)

The VDDMEM power jumper (P16) is used to measure the voltage and current supplied to the memory interface of the processor. By default, P16 is ON, and the power flows through the two-pin IDC header. To measure power, remove the jumper and measure voltage across the 0.05 ohm resistor. Once voltage is measured, the power can be calculated.

## LEDs

## LEDs

This section describes the on-board LEDs. [Figure 2-4](#) shows the LED locations.




Figure 2-4. LED Locations

### User LEDs (LED1–3)

Three LEDs are connected to the three general-purpose I/O pins of the processor (see [Table 2-17](#)). The LEDs are active high and are lit by writing a 1 to the correct PF signal.

Table 2-17. User LEDs

| LED Reference Designator | Processor Programmable Flag Pin |
|--------------------------|---------------------------------|
| LED1                     | PF8                             |
| LED2                     | PG11                            |
| LED3                     | PG12                            |



### Power LED (LED4)

When LED4 is lit (green), it indicates that power is being properly supplied to the board.

### Reset LED (LED5)

When LED5 is lit, it indicates that the master reset of all major ICs is active. The reset LED is controlled by the Analog Devices ADM708 supervisory reset circuit. You can assert the reset push button (SW16) to assert a master reset and to activate LED5. [For more information, see “Reset Push Button \(SW16\)” on page 2-18.](#)

### Ethernet LEDs (LED6–7)

When LED6 is lit solid, it indicates that the SMSC LAN8700 chip (U14) detects a valid link. When transmit or receive activity is sensed, LED7 flashes as an activity indicator. For more information about LEDs, refer to the LAN8700 chip data sheet provided by the product manufacturer.

### Keypad Current Sink LED (LED8)

LED8 can be used as a keypad current sink LED. It is programmable up to 14 mA and can be turned on and off. The sink current can be set up using LED1\_CURRENT in register 0 x 14. The LED sink can be enabled with the LED1\_EN register 0 x 11 in the ADP5520 keypad controller (U35). For details, refer to the ADP5520 data sheet.

# Connectors

This section describes connector functionality and provides information about mating connectors. The connector locations are shown in [Figure 2-5](#).




Figure 2-5. Connector Locations

## Expansion Interface Connectors (J1–3)

Three board-to-board connector footprints provide signals for most of the processor’s peripheral interfaces. The connectors are located at the bottom of the board. For more information, see [“Expansion Interface” on page 1-29](#). For availability and pricing of the J1–3 connectors, contact Samtec.

## ADSP-BF527 EZ-KIT Lite Hardware Reference

| Part Description                             | Manufacturer | Part Number       |
|--|--------------|-------------------|
| 90-position 0.05" spacing,<br>SMT            | SAMTEC       | SFC-145-T2-F-D-A  |
| <b>Mating Connector</b>                      |              |                   |
| 90-position 0.05" spacing<br>(through hole)  | SAMTEC       | TFM-145-x1 series |
| 90-position 0.05" spacing<br>(surface mount) | SAMTEC       | TFM-145-x2 series |
| 90-position 0.05" spacing<br>(low cost)      | SAMTEC       | TFC-145 series    |

### DCE (RS-232) Connector (J4)

| Part Description            | Manufacturer | Part Number       |
|-----------------------------|--------------|-------------------|
| DB9, female, vertical mount | NORCOMP      | 191-009-213-L-571 |
| <b>Mating Cable</b>         |              |                   |
| 2m female-to-female cable   | DIGI-KEY     | AE1020-ND         |

### Battery Holder (J5)

| Part Description                                 | Manufacturer | Part Number |
|--|--------------|-------------|
| 24 mm battery holder                             | KEYSTONE     | 105         |
| <b>Mating Battery (shipped with EZ-KIT Lite)</b> |              |             |
| 3V 280MAH 24 mm LI-COIN                          | SANYO        | CR2430      |

## Connectors

### Power Connector (J6)

The power connector (J6) provides all of the power necessary to operate the EZ-KIT Lite board.

| Part Description                                      | Manufacturer | Part Number      |
|---|--------------|------------------|
| 2.5 mm power jack                                     | SWITCHCRAFT  | RAPC712X         |
| <b>Mating Power Supply (shipped with EZ-KIT Lite)</b> |              |                  |
| 7.0VDC@2.14A power supply                             | CUI INC      | DMS070214-P6P-SZ |

### Dual Audio Connectors (J7–8)

| Part Description                                   | Manufacturer | Part Number |
|--|--------------|-------------|
| 3.5 mm dual stereo jack                            | SWITCHCRAFT  | 35RAPC7JS   |
| <b>Mating Cable (shipped with EZ-KIT Lite)</b>     |              |             |
| 3.5 mm male/male 6' cable                          | RANDOM       | 10A3-01106  |
| <b>Mating Headphone (shipped with EZ-KIT Lite)</b> |              |             |
| 3.5 mm stereo headphones                           | KOSS         | 151225 UR5  |

### Ethernet Connector (J9)

| Part Description                               | Manufacturer | Part Number   |
|--|--------------|---------------|
| RJ-45 Ethernet jack                            | STEWART      | SS-6488-NF    |
| <b>Mating Cable (shipped with EZ-KIT Lite)</b> |              |               |
| Cat 5E patch cable                             | RANDOM       | PC10/100T-007 |

## USB OTG Connector (P1)

The pinout of the P1 connector can be found in [“ADSP-BF527 EZ-KIT Lite Schematic” on page B-1](#).

| Part Description                                | Manufacturer    | Part Number |
|---|-----------------|-------------|
| USB 5-pin mini AB                               | MOLEX           | 56579-0576  |
| <b>Mating Keypad (shipped with EZ-KIT Lite)</b> |                 |             |
| 5-in-1 USB 2.0 cable                            | JO-DAN INTERNAT | GXQU-06     |

## Keypad Connector (P2)

| Part Description                                | Manufacturer   | Part Number        |
|---|----------------|--------------------|
| IDC header female                               | SAMTEC         | SSW-109-01-TM-S    |
| <b>Mating Keypad (shipped with EZ-KIT Lite)</b> |                |                    |
| 4 x 4 keypad                                    | ACT COMPONENTS | ACT-07-30008-000-R |

## UART0 Connector (P5)

The pinout of the P5 connector can be found in [“ADSP-BF527 EZ-KIT Lite Schematic” on page B-1](#).

| Part Description        | Manufacturer | Part Number  |
|-------------------------|--------------|--------------|
| IDC header              | FCI          | 68737-410HLF |
| <b>Mating Connector</b> |              |              |
| IDC socket              | DIGI-KEY     | S4205-ND     |

## Connectors

### SPORT0 Connector (P6)

The pinout of the P6 connector can be found in [“ADSP-BF527 EZ-KIT Lite Schematic”](#) on page B-1.

| Part Description | Manufacturer | Part Number  |
|------------------|--------------|--------------|
| IDC header       | FCI          | 68737-434HLF |
| Mating Connector |              |              |
| IDC socket       | DIGI-KEY     | S4217-ND     |

### SPORT1 Connector (P7)

The pinout of the P7 connector can be found in [“ADSP-BF527 EZ-KIT Lite Schematic”](#) on page B-1.

| Part Description | Manufacturer | Part Number  |
|------------------|--------------|--------------|
| IDC header       | FCI          | 68737-434HLF |
| Mating Connector |              |              |
| IDC socket       | DIGI-KEY     | S4217-ND     |

### PPI Connector (P8)

The pinout of the P8 connector can be found in [“ADSP-BF527 EZ-KIT Lite Schematic”](#) on page B-1.

| Part Description | Manufacturer | Part Number  |
|------------------|--------------|--------------|
| IDC header       | FCI          | 68737-440HLF |
| Mating Connector |              |              |
| IDC socket       | DIGI-KEY     | S4220-ND     |

## SPI Connector (P9)

The pinout of the P9 connector can be found in [“ADSP-BF527 EZ-KIT Lite Schematic” on page B-1](#).

| Part Description        | Manufacturer | Part Number  |
|-------------------------|--------------|--------------|
| IDC header              | FCI          | 68737-420HLF |
| <b>Mating Connector</b> |              |              |
| IDC socket              | DIGI-KEY     | S4210-ND     |

## TWI Connector (P10)

The pinout of the P10 connector can be found in [“ADSP-BF527 EZ-KIT Lite Schematic” on page B-1](#).

| Part Description        | Manufacturer | Part Number  |
|-------------------------|--------------|--------------|
| IDC header              | FCI          | 68737-420HLF |
| <b>Mating Connector</b> |              |              |
| IDC socket              | DIGI-KEY     | S4210-ND     |

## TIMERS Connector (P11)

The pinout of the P11 connector can be found in [“ADSP-BF527 EZ-KIT Lite Schematic” on page B-1](#).

| Part Description        | Manufacturer | Part Number  |
|-------------------------|--------------|--------------|
| IDC header              | FCI          | 68737-410HLF |
| <b>Mating Connector</b> |              |              |
| IDC socket              | DIGI-KEY     | S4205-ND     |

## Connectors

### Host Interface Connector (P13)

The pinout of the P13 connector can be found in [“ADSP-BF527 EZ-KIT Lite Schematic” on page B-1.](#)

| Part Description        | Manufacturer | Part Number    |
|-------------------------|--------------|----------------|
| IDC header              | SAMTEC       | TSW-116-26-T-D |
| <b>Mating Connector</b> |              |                |
| IDC socket              | SAMTEC       | TSW-116-01-T-D |

### CPLD JTAG Connector (P17)

The CPLD JTAG connector (P17) is not populated; CPLD code should not be altered for LCD operations.

| Part Description        | Manufacturer | Part Number  |
|-------------------------|--------------|--------------|
| IDC header              | FCI          | 68737-410HLF |
| <b>Mating Connector</b> |              |              |
| IDC socket              | DIGI-KEY     | S4205-ND     |

### LCD Data Connector (P18)

| Part Description  | Manufacturer | Part Number      |
|---|--------------|------------------|
| FPC 67PIN CON063  | KYOCERA ELCO | 046281267212846+ |
| <b>Mating LCD Display Module (shipped with EZ-KIT Lite)</b> |              |                  |
| 3.5" TFT LCD with touchscreen                               | Sharp        | LQ035Q1DH02      |



### USB Debug Agent Connector (ZJ1)

The USB debug agent connector (ZJ1) is the connecting point for the JTAG USB debug agent interface. The JTAG header (ZP4) should not be used whenever ZJ1 and its mating cable are used to communicate to the processor via CCES or VisualDSP++.

### JTAG Connector (ZP4)

The JTAG header (ZP4) is the connecting point for a JTAG in-circuit emulator pod. When an emulator connects to the JTAG header, the USB debug interface is disabled.

Pin 3 is missing to provide keying. Pin 3 in the mating connector should have a plug.

When using an emulator with the EZ-KIT Lite board, follow the connection instructions provided with the emulator.

## Connectors

# A ADSP-BF527 EZ-KIT LITE BILL OF MATERIALS

The bill of materials corresponds to “[ADSP-BF527 EZ-KIT Lite Schematic](#)” on page B-1.

| Ref. | Qty. | Description                      | Reference Designator | Manufacturer | Part Number                  |
|------|------|----------------------------------|----------------------|--------------|------------------------------|
| 1    | 1    | 74LVC14A<br>SOIC14               | U17                  | TI           | 74LVC14AD                    |
| 2    | 1    | IDT74FCT324<br>4APY SSOP20       | U22                  | IDT          | IDT74FCT3244APYG             |
| 3    | 1    | SN74AHC1G0<br>0 SOT23-5          | U6                   | TI           | SN74AHC1G00DBVR              |
| 4    | 1    | 32.768KHZ<br>OSC008              | U1                   | EPSON        | MC-156-32.7680KA-<br>A0:ROHS |
| 5    | 1    | 25MHZ<br>OSC003                  | U3                   | EPSON        | SG-8002CA MP                 |
| 6    | 5    | SN74LVC1G08<br>SOT23-5           | U9-11,U29,U36        | TI           | SN74LVC1G08DBVR              |
| 7    | 1    | FDS9431A<br>SOIC8                | U21                  | FAIRCHILD    | FDS9431A                     |
| 8    | 1    | MT48LC32M1<br>6A2TG-75<br>TSOP54 | U7                   | MICRON       | MT48LC32M16A2P-75            |
| 9    | 2    | SI4411DY SO-8                    | U18,U23              | VISHAY       | Si4411DY-T1-E3               |
| 10   | 1    | HX1188<br>ICS007                 | U26                  | DIGI-KEY     | 553-1340-ND                  |
| 11   | 1    | 24MHZ<br>OSC003                  | U12                  | EPSON        | SG-8002CA-MP                 |

| Ref. | Qty. | Description                      | Reference Designator | Manufacturer      | Part Number                   |
|------|------|----------------------------------|----------------------|-------------------|-------------------------------|
| 12   | 1    | LAN8700<br>QFN36                 | U14                  | SMSC              | LAN8700C-AEZG                 |
| 13   | 1    | BF527 M25P16<br>"U8"             | U8                   | NUMONYX           | M25P16-VMW6G                  |
| 14   | 1    | BF527<br>M29W320EB<br>"U5"       | U5                   | NUMONYX           | M29W320EB70ZE6E               |
| 15   | 1    | NAND04<br>TSOP48                 | U4                   | NUMONYX           | NAND04GW3B2BN6E               |
| 16   | 1    | MIC2025-1<br>SOIC8               | U28                  | DIGI-KEY          | 576-1057-ND                   |
| 17   | 1    | 12MHZ<br>OSC003                  | U13                  | EPSON             | SG-8002CA-MP                  |
| 18   | 3    | 74CBTLV3244<br>TSSOP20           | U30-31,U38           | IDT               | IDT74CBTLV3244PGG             |
| 19   | 1    | 15MHZ<br>OSC003                  | U19                  | EPSON             | SG-8002CA-MPT                 |
| 20   | 1    | BF527<br>XC95144XL<br>U34        | U34                  | XILINX            | XC95144XL-10TQ100C            |
| 21   | 1    | 50MHZ<br>OSC003                  | U24                  | DIGI-KEY          | SG-8002CA-PCB-ND(5<br>0.000M) |
| 22   | 1    | ADM708SARZ<br>SOIC8              | U27                  | ANALOG<br>DEVICES | ADM708SARZ                    |
| 23   | 2    | ADP3336ARM<br>Z MSOP8            | VR3-4                | ANALOG<br>DEVICES | ADP3336ARMZ-REEL7             |
| 24   | 1    | ADG752BRTZ<br>SOT23-6            | U20                  | ANALOG<br>DEVICES | ADG752BRTZ-REEL               |
| 25   | 1    | ADM3202ARN<br>Z SOIC16           | U25                  | ANALOG<br>DEVICES | ADM3202ARNZ                   |
| 26   | 1    | ADSPBF527KB<br>CZENGC1<br>MBGA28 | U2                   | ANALOG<br>DEVICES | ADSP-BF527KBCZ-<br>6C2        |

## ADSP-BF527 EZ-KIT Lite Bill Of Materials

| Ref. | Qty. | Description                 | Reference Designator                         | Manufacturer      | Part Number       |
|------|------|-----------------------------|--|-------------------|-------------------|
| 27   | 2    | ADP1864AUJZ<br>SOT23-6      | VR1-2  | ANALOG<br>DEVICES | ADP1864AUJZ-R7    |
| 28   | 1    | ADP5520<br>LFCSP_VQ24       | U35  | ANALOG<br>DEVICES | ADP5520ACPZ-RL    |
| 29   | 1    | AD7879-1<br>LFCSP16         | U37  | ANALOG<br>DEVICES | AD7879-1ACPZ-RL   |
| 30   | 1    | ADP1613<br>MSOP8            | VR5  | ANALOG<br>DEVICES | ADP1613ARMZ-R7    |
| 31   | 1    | PWR<br>2.5MM_JACK<br>CON005 | J6   | SWITCH-<br>CRAFT  | RAPC712X          |
| 32   | 3    | .05 45X2<br>CON019          | J1-3   | SAMTEC            | SFC-145-T2-F-D-A  |
| 33   | 1    | DIP8 SWT016                 | SW10   | C&K               | TDA08H0SB1        |
| 34   | 4    | DIP6 SWT017                 | SW25-26,SW29-30                              | CTS               | 218-6LPST         |
| 35   | 10   | DIP4 SWT018                 | SW1,SW4,SW7-9,<br>SW11,SW13,SW19-20,<br>SW24 | ITT               | TDA04HOSB1        |
| 36   | 1    | DB9 9PIN<br>CON038          | J4   | NORCOMP           | 191-009-213-L-571 |
| 37   | 5    | DIP2 SWT020                 | SW5,SW21-22,SW27-<br>28                      | C&K               | CKN9064-ND        |
| 38   | 2    | IDC 2X1<br>IDC2X1           | JP7,JP10                                     | FCI               | 90726-402HLF      |
| 39   | 3    | IDC 2X1<br>IDC2X1           | P14-16                                       | FCI               | 90726-402HLF      |
| 40   | 1    | IDC 3X1<br>IDC3X1           | JP6  | FCI               | 90726-403HLF      |
| 41   | 2    | IDC 5X2<br>IDC5X2           | P5,P11                                       | FCI               | 68737-410HLF      |
| 42   | 2    | IDC 10X2<br>IDC10X2         | P9-10  | BURG-FCI          | 54102-T08-10LF    |

| Ref. | Qty. | Description                     | Reference Designator | Manufacturer     | Part Number      |
|------|------|---------------------------------|----------------------|------------------|------------------|
| 43   | 2    | IDC 17X2<br>IDC17X2             | P6-7                 | BURG-FCI         | 54102-T08-17LF   |
| 44   | 1    | IDC 20X2<br>IDC20X2             | P8                   | BURG-FCI         | 54102-T08-20LF   |
| 45   | 4    | IDC<br>2PIN_JUMPER<br>_SHORT    | SJ7-10               | DIGI-KEY         | S9001-ND         |
| 46   | 1    | 5A RESE-<br>TABLE FUS005        | F2                   | MOUSER           | 650-RGEF500      |
| 47   | 1    | ROTARY<br>SWT023                | SW2                  | DIGI-KEY         | 563-1047-ND      |
| 48   | 1    | ROTARY_ENC<br>ODER<br>SWT022    | SW3                  | CTS              | 290UAB0R201B2    |
| 49   | 1    | IDC 16x2<br>IDC16x2             | P13                  | SAMTEC           | TSW-116-26-T-D   |
| 50   | 1    | USB_MINI-AB<br>5PIN CON052      | P1                   | MOLEX            | 56579-0576       |
| 51   | 1    | RJ45 8PIN<br>CON_RJ45_12<br>P   | J9                   | DIGI-KEY         | 380-1022-ND      |
| 52   | 3    | MOMEN-<br>TARY SWT024           | SW14-16              | PANASONIC        | EVQ-Q2K03W       |
| 53   | 1    | IDC 9X1<br>IDC9X1               | P2                   | SAMTEC           | SSW-109-01-TM-S  |
| 54   | 1    | BATT_HOLDE<br>R 24MM<br>CON054  | J5                   | KEYSTONE<br>ELEC | 105              |
| 55   | 1    | FPC 67PIN<br>CON063             | P18                  | KYOCERA<br>ELCO  | 046281267212846+ |
| 56   | 2    | 3.5MM<br>DUAL_STERE<br>O CON066 | J7-8                 | SWITCH-<br>CRAFT | 35RAPC7JS        |

## ADSP-BF527 EZ-KIT Lite Bill Of Materials

| Ref. | Qty. | Description                  | Reference Designator        | Manufacturer | Part Number       |
|------|------|------------------------------|-----------------------------|--------------|-------------------|
| 57   | 1    | IDC<br>2PIN_JUMPER<br>_SHORT | SJ13                        | DIGI-KEY     | 3M9414-ND         |
| 58   | 2    | IDC 2X1<br>IDC2X1_2MM        | JP14-15                     | SAMTEC       | TMM-101-01-T-D    |
| 59   | 4    | YELLOW<br>LED001             | LED1-3,LED6                 | DIGI-KEY     | P512TR-ND         |
| 60   | 1    | 22PF 50V 5%<br>0805          | C307                        | AVX          | 08055A220JAT      |
| 61   | 6    | 0.22UF 25V<br>10% 0805       | C112,C283-287               | AVX          | 08053C224KAT2A    |
| 62   | 1    | 0.1UF 50V 10%<br>0805        | C277                        | AVX          | 08055C104KAT      |
| 63   | 4    | 10K 1/10W 5%<br>0805         | R319-322                    | VISHAY       | CRCW080510K0JNEA  |
| 64   | 2    | 100 1/10W 5%<br>0805         | R122,R124                   | VISHAY       | CRCW0805100RJNEA  |
| 65   | 15   | 600 100MHZ<br>200MA 0603     | FER2-16                     | DIGI-KEY     | 490-1014-2-ND     |
| 66   | 3    | 600 100MHZ<br>500MA 1206     | FER1,FER19-20               | STEWARD      | HZ1206B601R-10    |
| 67   | 5    | 1UF 16V 10%<br>0805          | C92,C144,C148,C159,<br>C178 | KEMET        | C0805C105K4RAC TU |
| 68   | 1    | 10 1/10W 5%<br>0805          | R64                         | VISHAY       | CRCW080510R0FKEA  |
| 69   | 2    | 10UF 16V 20%<br>CAP002       | CT5,CT8                     | PANASONIC    | EEE1CA100SR       |
| 70   | 1    | 10UH 20%<br>IND001           | L1                          | TDK          | 445-2014-1-ND     |
| 71   | 2    | 0 1/10W 5%<br>0805           | R58,R188                    | VISHAY       | CRCW08050000Z0EA  |

| Ref. | Qty. | Description              | Reference Designator   | Manufacturer | Part Number    |
|------|------|--------------------------|--|--------------|----------------|
| 72   | 1    | 190 100MHZ<br>5A FER002  | FER17  | MURATA       | DLW5BSN191SQ2  |
| 73   | 2    | 1A ZHCS1000<br>SOT23-312 | D7,D9  | ZETEX        | ZHCS1000TA     |
| 74   | 4    | 1UF 10V 10%<br>0805      | C164-165,C302-303  | AVX          | 0805ZC105KAT2A |
| 75   | 11   | 10UF 6.3V 10%<br>0805    | C7,C22,C33,C43,C52,<br>C59,C68,C99,C101-<br>102,C186   | AVX          | 08056D106KAT2A |
| 76   | 2    | 4.7UF 6.3V<br>10% 0805   | C143,C171  | AVX          | 08056D475KAT2A |
| 77   | 48   | 0.1UF 10V 10%<br>0402    | C12-19,C27-30,C38-<br>41,C47-50,C56-57,<br>C64-66,C78,C81,C83,<br>C88,C98,C100,C103,<br>C105,C111,C132,<br>C135-136,C146,C157-<br>158,C160-161,C249,<br>C280,C300-301,C305,<br>C308  | AVX          | 0402ZD104KAT2A |
| 78   | 76   | 0.01UF 16V<br>10% 0402   | C2,C4-6,C8-11,C20-<br>21,C23-26,C31-32,<br>C34-37,C42,C44-46,<br>C51,C53-55,C58,C60-<br>63,C67,C69-77,C79-<br>80,C82,C84-87,C90-<br>91,C93,C97,C116-117,<br>C121-127,C137-138,<br>C155-156,C163,C166-<br>168,C187-188,C248,<br>C250,C306 | AVX          | 0402YC103KAT2A |



## ADSP-BF527 EZ-KIT Lite Bill Of Materials

| Ref. | Qty. | Description            | Reference Designator  | Manufacturer | Part Number      |
|------|------|------------------------|---|--------------|------------------|
| 79   | 69   | 10K 1/16W 5%<br>0402   | R2-3,R11-14,R16-22,<br>R24-27,R34,R53-55,<br>R59,R65,R69-70,R73-<br>76,R89,R91,R104-105,<br>R107,R118-121,R125-<br>126,R129-131,R140,<br>R144,R157-158,R160,<br>R164,R166,R169,R176-<br>178,R196,R198,R213,<br>R305,R318,R324-325,<br>R329,R332-333,R335,<br>R342-343,R345,R351 | VISHAY       | CRCW040210K0FKED |
| 80   | 2    | 4.7K 1/16W 5%<br>0402  | R23,R212  | VISHAY       | CRCW04024K70JNED |
| 81   | 12   | 0 1/16W 5%<br>0402     | R6-7,R110,R116,R149,<br>R172,R192,R215,R302,<br>R310,R336-337   | PANASONIC    | ERJ-2GE0R00X     |
| 82   | 2    | 1.2K 1/16W 5%<br>0402  | R87-88  | PANASONIC    | ERJ-2GEJ122X     |
| 83   | 3    | 22 1/16W 5%<br>0402    | R193-195  | PANASONIC    | ERJ-2GEJ220X     |
| 84   | 17   | 33 1/16W 5%<br>0402    | R1,R8-10,R31,R46,<br>R139,R167,R311,R344,<br>R346-347,R350,R352-<br>353,R356-357  | VISHAY       | CRCW040233R0JNEA |
| 85   | 2    | 18PF 50V 5%<br>0805    | C1,C3   | AVX          | 08055A180JAT2A   |
| 86   | 3    | 100UF 10V<br>10% C     | CT6,CT9-10  | AVX          | TPSC107K010R0075 |
| 87   | 1    | 150UF 10V<br>10% D     | CT16  | AVX          | TPSD157K010R0050 |
| 88   | 10   | 2.2UF 10V 10%<br>0805  | C288-290,C293-299   | AVX          | 0805ZD225KAT2A   |
| 89   | 1    | 64.9K 1/10W<br>1% 0805 | R145  | VISHAY       | CRCW080564K9FKEA |

| Ref. | Qty. | Description            | Reference Designator                  | Manufacturer | Part Number      |
|------|------|------------------------|---------------------------------------|--------------|------------------|
| 90   | 1    | 210.0K 1/4W<br>1% 0805 | R146                                  | VISHAY       | CRCW0805210KFKEA |
| 91   | 2    | 1.5K 1/10W 5%<br>0603  | R71-72                                | PANASONIC    | ERJ-3GEYJ152V    |
| 92   | 3    | 0.1UF 16V 10%<br>0603  | C169,C273-274                         | AVX          | 0603YC104KAT2A   |
| 93   | 3    | 1UF 16V 10%<br>0603    | C96,C104,C109                         | KEMET        | C0603C105K4PACTU |
| 94   | 2    | 68PF 50V 5%<br>0603    | C141,C183                             | AVX          | 06035A680JAT2A   |
| 95   | 1    | 4.7UF 6.3V<br>20% 0603 | C131                                  | PANASONIC    | ECJ-1VB0J475M    |
| 96   | 2    | 470PF 50V 5%<br>0603   | C140,C182                             | AVX          | 06033A471JAT2A   |
| 97   | 3    | 220UF 6.3V<br>20% D2E  | CT1,CT7,CT11                          | SANYO        | 10TPE220ML       |
| 98   | 2    | 10K 1/10W 5%<br>0603   | R314-315                              | VISHAY       | CRCW060310K0JNEA |
| 99   | 1    | 10M 1/10W 5%<br>0603   | R15                                   | VISHAY       | CRCW060310M0FNEA |
| 100  | 1    | 100K 1/10W<br>5% 0603  | R317                                  | VISHAY       | CRCW0603100KJNEA |
| 101  | 5    | 330 1/10W 5%<br>0603   | R111-113,R115,R123                    | VISHAY       | CRCW0603330RJNEA |
| 102  | 1    | 1M 1/10W 5%<br>0603    | R33                                   | VISHAY       | CRCW06031M00FNEA |
| 103  | 7    | 0 1/10W 5%<br>0603     | R102,R109,R133,R168,<br>R308-309,R334 | PHYCOMP      | 232270296001L    |
| 104  | 10   | 49.9 1/16W 1%<br>0603  | R60-63,R78-80,R83-85                  | VISHAY       | CRCW060349R9FNEA |
| 105  | 2    | 10 1/10W 5%<br>0603    | R127-128                              | VISHAY       | CRCW060310R0JNEA |

## ADSP-BF527 EZ-KIT Lite Bill Of Materials

| Ref. | Qty. | Description             | Reference Designator       | Manufacturer | Part Number      |
|------|------|-------------------------|----------------------------|--------------|------------------|
| 106  | 8    | 100PF 50V 5%<br>0603    | C260-267                   | PANASONIC    | ECJ-1VC1H101J    |
| 107  | 1    | 12.4K 1/10W<br>1% 0603  | R67                        | DIGI-KEY     | 311-12.4KHRTR-ND |
| 108  | 2    | 75.0 1/10W 1%<br>0603   | R81-82                     | DALE         | CRCW060375R0FKEA |
| 109  | 2    | 100 1/16W 5%<br>0402    | R44-45                     | DIGI-KEY     | 311-100JRTR-ND   |
| 110  | 1    | 390PF 25V 5%<br>0603    | C270                       | AVX          | 06033A391FAT2A   |
| 111  | 2    | 24.9K 1/10W<br>1% 0603  | R98,R150                   | DIGI-KEY     | 311-24.9KHTR-ND  |
| 112  | 5    | 10UF 10V 10%<br>0805    | C89,C94,C128,C170,<br>C279 | PANASONIC    | ECJ-2FB1A106K    |
| 113  | 1    | 105.0K 1/16W<br>1% 0603 | R137                       | PANASONIC    | ERJ-3EKF1053V    |
| 114  | 4    | 0.05 1/2W 1%<br>1206    | R134,R141-143              | SEI          | CSF 1/2 0.05 1%R |
| 115  | 2    | 10UF 16V 10%<br>1210    | C147,C184                  | AVX          | 1210YD106KAT2A   |
| 116  | 2    | GREEN<br>LED001         | LED4,LED7                  | PANASONIC    | LN1361CTR        |
| 117  | 2    | RED LED001              | LED5,LED8                  | PANASONIC    | LN1261CTR        |
| 118  | 2    | 1000PF 50V<br>5% 1206   | C179-180                   | AVX          | 12065A102JAT2A   |
| 119  | 1    | 255.0K 1/10W<br>1% 0603 | R152                       | VISHAY       | CRCW06032553FK   |
| 120  | 2    | 80.6K 1/10W<br>1% 0603  | R99,R151                   | DIGI-KEY     | 311-80.6KHRCT-ND |
| 121  | 4    | 5A<br>MBRS540T3G<br>SMC | D5,D10-12                  | ON SEMI      | MBRS540T3G       |

| Ref. | Qty. | Description                     | Reference Designator | Manufacturer       | Part Number      |
|------|------|---------------------------------|----------------------|--------------------|------------------|
| 122  | 3    | 15KV<br>PGB1010603<br>0603      | D2-4                 | LITTLEFUSE         | PGB1010603MR     |
| 123  | 1    | VARISTOR<br>V5.5MLA 30A<br>0603 | R37                  | LITTLEFUSE         | V5.5MLA0603      |
| 124  | 1    | THERM 0.5A<br>0.4 1206          | R36                  | LITTLEFUSE         | 1206L050-C       |
| 125  | 1    | 20MA<br>MA3X717E<br>DIO005      | D1                   | PANASONIC          | MA3X717E         |
| 126  | 2    | 2.5UH 30%<br>IND013             | L2,L4                | COILCRAFT          | MSS1038-252NLB   |
| 127  | 2    | 330.0 1/16W<br>1% 0402          | R68,R77              | DIGI-KEY           | 541-330LCT-ND    |
| 128  | 5    | 47.0K 1/16W<br>1% 0402          | R38-39,R50-52        | ROHM               | MCR01MZPF4702    |
| 129  | 3    | 1.0K 1/16W 1%<br>0402           | R197,R199-200        | PANASONIC          | ERJ-2RKF1001X    |
| 130  | 2    | 1000PF 2000V<br>10% 1206        | C133-134             | AVX                | 1206GC102KAT1A   |
| 131  | 1    | 1UF 50V 10%<br>0603             | C304                 | DIGI-KEY           | 587-1257-2-ND    |
| 132  | 1    | 10.0K 1/16W<br>1% 0402          | R312                 | DIGI-KEY           | 541-10.0KLCT-ND  |
| 133  | 2    | 0.027 1/2W 1%<br>1206           | R101,R103            | SUSUMU             | RL1632T-R027-F-N |
| 134  | 4    | 5.6K 1/16W<br>0.5% 0402         | R40-43               | SUSUMU             | RR0510P-562-D    |
| 135  | 1    | 680 1/16W 1%<br>0402            | R47                  | BC COMPO-<br>NENTS | 2312 275 16801   |
| 136  | 1    | 90.9K 1/16W<br>5% 0402          | R90                  | DIGI-KEY           | 541-90.9KLCT-ND  |

## ADSP-BF527 EZ-KIT Lite Bill Of Materials



| Ref. | Qty. | Description                 | Reference Designator       | Manufacturer  | Part Number      |
|------|------|-----------------------------|----------------------------|---------------|------------------|
| 137  | 1    | 40.2K 1/16W<br>5% 0402      | R57                        | DIGI-KEY      | 541-40.2KLCT-ND  |
| 138  | 4    | 3.3UF 16V 10%<br>0805       | C113,C118,C120,C129        | DIGI-KEY      | 490-3337-2-ND    |
| 139  | 3    | 22UF 10V 10%<br>1210        | C139,C142,C145             | DIGI-KEY      | 490-1876-2-ND    |
| 140  | 1    | 95K 1/10W 1%<br>0603        | R136                       | DIGI-KEY      | 311-95.3KHRTR-ND |
| 141  | 5    | 15PF 50V 5%<br>0402         | C119,C130,C197-199         | DIGI-KEY      | 399-1014-2-ND    |
| 142  | 1    | 422K 1/10W<br>1% 0603       | R100                       | PANASONIC     | ERJ-3EKF4223V    |
| 143  | 1    | 15uH 20%<br>IND015          | L5                         | COILCRAFT     | MSS4020-153ML    |
| 144  | 3    | .5A B0540W<br>SOD-123       | D17-19                     | DIODES<br>INC | B0540W-7-F       |
| 145  | 1    | .5A<br>BZT52C33S<br>SOD-323 | D20                        | DIODES<br>INC | BZT52C33S-7-F    |
| 146  | 5    | 2.2UF 25V 10%<br>0805       | C275-276,C278,C291-<br>292 | DIGI-KEY      | 490-3331-1-ND    |
| 147  | 11   | 33 1/16W 5%<br>RNS003       | RN2-12                     | PANASONIC     | EXB-2HV330JV     |
| 148  | 2    | 33 1/32W 5%<br>RNS005       | RN13-14                    | PANASONIC     | EXB-28V330JX     |
| 149  | 2    | 51.1 1/16W 1%<br>0402       | R316,R348                  | DIGI-KEY      | 541-51.1LCT-ND   |
| 150  | 1    | 30A GSOT05<br>SOT23-3       | D15                        | VISHAY        | GSOT05-GS08      |
| 151  | 1    | 30A GSOT03<br>SOT23-3       | D14                        | VISHAY        | GSOT03-GS08      |

| Ref. | Qty. | Description                  | Reference Designator | Manufacturer | Part Number |
|------|------|------------------------------|----------------------|--------------|-------------|
| 152  | 1    | 40A<br>ESD5Z2.5T1<br>SOD-523 | D13                  | ON SEMI      | ESD5Z2.5T1G |
| 153  | 1    | 30A GSOT08<br>SOT23-3        | D16                  | VISHAY       | GSOT08-GS08 |



3

4

A



3




4




RTC

A







TFS0A\_R  
HOSTA



3

4


# "RTC BATTERY"



3

4

A




SN74LVC1G08  
SOT23-5

RESET


ARE

AWE

3




4



4

A




U12


3

4


A




3



"SPORT"  
"0A"  
"ENBL"



"SPI"




4

SW20 and SWXX disconnect DSP from AUDIO CODEC

AUDIO CODEC  
SPI MODE:  
TWI MODE:

3




**SW9: Ethernet Mode Select (SW9.1, SW9.2, SW9.3)**


| MODE[2:0] | MODE DEFINITIONS                                   |
|-----------|--|
| 111       | All Capable, Auto Negotiation      DEFAULT         |
| 110       | Power Down Mode                                    |
| 101       | Repeater Mode, Auto Negotiation                    |
| 100       | 100Base-TX Half duplex Advertised, Auto Negotiaion |
| 011       | 100Base-TX Full Duplex                             |
| 010       | 100Base-TX Half Duplex                             |
| 001       | 10Base-T Full Duplex                               |
| 000       | 10Base-T Half Duplex                               |

Internal LAN8700 pullups are used for mode pins

SW9.4 disconnects SPISEL1, for use on expansion interface (J2.11)



4




A


I2C address is

3

4




A





3




4

A


|        |                   |                |     |  |
|--------|-------------------|----------------|-----|--|
| SW13.2 | push button 2     | DSP (U2, PG13) | ON  | ON ( PB2), OFF (HOST connector P13.8, Expansio |
| SW13.3 | OTG PWR(VR3, U28) | DSP (U2, PG13) | OFF | OFF (HOST connector P13.8, Expansio            |
| SW13.4 | DSP(U2, PG12)     | PPI CLK (U20)  | OFF | OFF (LED2, Host connector P13.10, Ex           |

3




DA\_SOFT\_RESET  
CTS

4



A




|     |    |   |   |    |     |
|-----|----|---|---|----|-----|
| D5  | 44 | + | + | 43 | D4  |
| D7  | 46 | + | + | 45 | D6  |
| D9  | 48 | + | + | 47 | D8  |
| D11 | 50 | + | + | 49 | D10 |
| D13 | 52 | + | + | 51 | D12 |
| D15 | 54 | + | + | 53 | D14 |




- TSCLK0A
- PPID5
- PPID7
- KEYIRQ#
- CZM
- CUD
- UART1RX
- UART1RX
- SCL
- ABE1#/SDQM1
- ABE0#/SDQM0
- AOE
- AWE
- SMS
- ABE0#/SDQM0
- SRAS
- SA10
- SWE


3

4


A







3



4

A

# I INDEX

## A

AD7879\_1\_PENIRQ interrupt signal, [1-21](#)  
ADM3202 (U25) line driver/receiver, [1-26](#)  
AMS0-3 select lines, [1-17](#)  
analog audio interface, *See* audio interface  
architecture, of this EZ-KIT Lite, [2-2](#)  
ASYNC (asynchronous memory control)  
    external memory banks 0-3, [1-14](#)  
audio  
    interface, [xiii](#), [1-23](#)  
    dual connectors (J7-8), [1-24](#), [2-30](#)  
    SPORT connect switch (SW20), [1-23](#), [2-19](#)  
    SPORT connect switch (SW27), [1-23](#), [2-19](#)

## B

battery holder (J5), [2-29](#)  
bill of materials, [A-1](#)  
board design database, [1-31](#)  
board schematic (ADSP-BF527), [B-1](#)  
boot  
    modes, [2-11](#)  
    mode select switch (SW2), [1-17](#), [1-18](#), [2-11](#)

## C

CCLK register, [1-16](#)  
clock in (CLK IN) signal, [2-3](#)  
audio codec, *See* audio interface  
code security, [1-11](#)  
configuration, of this EZ-KIT Lite, [1-3](#)

## connectors

    diagram of locations, [2-28](#)  
    J1-3 (expansion), [1-29](#), [2-28](#)  
    J4 (RS-232), [2-29](#)  
    J5 (battery), [2-29](#)  
    J6 (power), [2-30](#)  
    J7-8 (dual audio), [1-24](#), [2-30](#)  
    J9 (Ethernet), [1-23](#), [2-30](#)  
    P10 (TWI) interface, [2-33](#)  
    P11 (timers), [2-33](#)  
    P13 (host interface), [1-17](#), [2-34](#)  
    P17 (JTAG CPLD), [2-34](#)  
    P18 (LCD data), [2-34](#)  
    P1 (USB OTG), [1-8](#), [1-25](#), [2-31](#), [2-35](#)  
    P2 (keypad), [2-31](#)  
    P5 (UART0), [1-26](#), [2-31](#)  
    P6 (SPORT0), [2-32](#)  
    P7 (SPORT1), [2-32](#)  
    P8 (PPI), [2-32](#)  
    P8 (PPI interface), [1-19](#)  
    P9 (SPI), [2-33](#)  
    ZJ1 (USB), [2-35](#)  
    ZP4 (JTAG), [1-28](#), [2-35](#)  
contents, of this EZ-KIT Lite package, [1-3](#)  
core voltage, [2-2](#)  
CPLD 14-15/DCE enable switch (SW30),  
    [1-24](#), [2-22](#)  
CPLD D8-13 switch (SW29), [2-22](#)  
CTS signal, [1-26](#)

# Index

## D

DCE (RS-232) connector (J4), [2-29](#)  
debugger interface (ZJ1), [1-8](#)  
default configuration, of this EZ-KIT Lite, [1-3](#)  
DIP switch (SW13), [1-19](#), [1-25](#), [1-28](#), [2-17](#),  
[2-18](#)  
down signal (CDG), [1-22](#)  
DT0PRIA\_PPIFS3 signal, [2-24](#)

## E

EBIU\_DDRCTL0-2 registers, [1-15](#)  
Ethernet  
  interface, [xiv](#), [1-22](#)  
  connector (J9), [1-23](#), [2-30](#)  
  enable switch (SW1), [1-22](#), [2-10](#)  
  LEDs (LED6-7), [2-27](#)  
  mode switch (SW9), [1-23](#), [2-14](#)  
  PHY IC (U14), [1-17](#)  
evaluation license  
  CCES, [1-10](#)  
example programs, [1-31](#)  
expansion interface, [1-17](#), [1-18](#), [1-22](#), [1-29](#),  
[2-13](#), [2-14](#), [2-28](#)  
external memory, [1-12](#), [1-14](#)

## F

features, of this EZ-KIT Lite, [xiii](#)  
FET switch (U28), [1-25](#)  
flag pins, *See* programmable flags by name (PFx,  
  PGs, PHx, PJx)  
flash memory  
  *See also* parallel flash memory  
  enable switch (SW7), [2-13](#)  
flash WP jumper (JP10), [2-24](#)

## G

general-purpose IO pins, [1-27](#), [2-10](#), [2-15](#),  
[2-16](#), [2-17](#), [2-18](#), [2-26](#)

## H

HOSTACK\_LED2 signal, [1-19](#)  
HOSTACK signal, [1-28](#)  
HOSTADDR signal, [1-25](#), [1-28](#)  
HOSTCE# signal, [1-23](#)  
HOSTD9 signal, [1-18](#)  
host interface connector (P13), [1-17](#), [2-34](#)  
HOSTWR#\_LED1 signal, [1-20](#), [2-13](#)  
HOSTWR signal, [1-28](#)  
HWAIT port, [1-26](#), [1-28](#)

## I

I2C address, [1-21](#)  
ILED pin, [1-21](#)  
installation, of this EZ-KIT Lite, [1-4](#), [1-8](#)  
  CCES, [1-4](#)  
IO voltage, [2-2](#)

## J

JTAG  
  interface, [1-28](#)  
  connector (ZP4), [1-28](#), [2-35](#)  
  CPLD connector (P17), [2-34](#)  
jumpers  
  diagram of locations, [2-23](#)  
  JP10 (flash WP), [2-24](#)  
  JP14 (stamp enable), [2-24](#)  
  JP15 (LED0 off), [2-24](#)  
  JP5 (UART1 loopback), [2-24](#)  
  JP6 (mic select), [1-24](#), [2-23](#)  
  JP7 (STAMP enable), [2-23](#)  
  P14 (VDDINT power), [1-29](#), [2-25](#)  
  P15 (VDDEXT power), [1-29](#), [2-25](#)  
  P16 (VDDMEM power), [1-29](#), [2-25](#)

## K

- KEYIRQ signal, 1-21
- keypad interface
  - connections, 1-21
  - components, xiv
  - connector (P2), 2-31
  - current sink LED (LED8), 2-27
  - LCD reset switch (SW5), 1-28, 2-13
  - LCD SPI/IRQ select switch (SW25), 1-18, 1-21, 2-20

## L

- LCD module
  - See also* touchscreen interface, xiv, 1-19
  - data connector (P18), 2-34
  - mode switch (SW26), 1-20, 2-21
  - SPI/keypad control switch (SW25), 1-18, 1-21, 2-20
- LCD\_RESET line, 2-13
- LED0 off jumper (JP15), 2-24
- LED1\_CURRENT signal, 2-27
- LED1\_EN register, 2-27
- LEDs
  - diagram of locations, 2-26
  - LED0 (SW24 switch), 1-21
  - LED1-3 (PF8, PG11-12), 1-27, 1-30, 2-26
  - LED4 (power), 2-27
  - LED5 (reset), 2-27
  - LED6-7 (Ethernet), 2-27
  - LED8 (keypad current sink), 1-21, 2-27
  - ZLED3 (USB monitor), 1-8
- license restrictions, 1-11
- line in-out loopback switch (SW28), 2-22
- LINEIN signal, 1-24
- LINOUT signal, 1-24
- Lockbox secure technology, 1-11
- loopback switch (SW28), 2-22

## M

- MAC address, 1-23
- media independent interface (MII), 1-22
- Media Instruction Set Computing (MISC), xi
- memory map, of this EZ-KIT Lite, 1-12
- MICBIAS signal, 1-24, 2-23
- MICIN signal, 1-24, 2-23
- microphone
  - gain switch (SW4), 2-12
  - loopback switch (SW8), 1-24, 2-14
  - select jumper (JP6), 1-24, 2-23
- Micro Signal Architecture (MSA), xi
- momentary switch (SW3), 1-22, 2-12

## N

- NAND flash memory
  - interface, xiii, 1-17
  - enable switch (SW11), 1-17, 2-16
- NDCE#\_HOSTD10 signal, 1-17
- NINT keypad interrupt signal, 1-21
- notation conventions, xxi

## O

- oscilloscope, 1-30

## P

- package contents, 1-3
- parallel flash memory, xiii, 1-17
- parallel peripheral interface (PPI), *See* PPI interface
- PF0-7 signals, 2-3
- PF8 signal, 2-3
- PF9-15 signals, 2-3
- PG0-10 signals, 2-5
- PG11-12 (IO) signals, 1-19, 1-20, 2-5, 2-26
- PG13 (IO) signal, 1-25, 2-5
- PG14-15 (IO) signals, 2-5
- PG8 (IO) signal, 2-26



# Index

PH0-9 signals, 2-7  
PH10 signal, 2-7  
PH11-15 signals, 2-7  
PJ0-3 signals, 2-9  
PLL\_CTL register, 1-16  
PLL\_DIV register, 1-16  
POST (power-on-self test) program, 1-17, 1-18, 1-30, 2-23  
power  
  connector (J6), 2-30  
  LED (LED4), 2-27  
  measurements, 1-29  
  supply, 1-3  
PPI interface  
  connections, 1-19  
  connector (P8), 1-19, 2-32  
PPI\_SEL signal, 1-19  
product information, xviii  
push buttons (PB1-2), 1-28  
push buttons (SW14-15), 2-18

## R

real-time clock (RTC) interface, 1-27, 2-3  
Reduced Instruction Set Computing (RISC), xi  
reduced media independent interface (RMII), 1-22  
reset  
  LED (LED5), 2-27  
  push button (SW16), 2-18  
RESET line, 2-13  
RMIIMDINT signal, 1-23  
rotary encoder  
  interface, 1-22  
  enable switch (SW11), 1-22, 2-16  
  switch (SW3), 1-22, 2-12  
RS-232 connector (J4), 2-29  
RTC power pin, 1-27  
RTS signal, 1-26

## S

schematic, of ADSP-BF527 EZ-KIT Lite, B-1  
SDRAM interface, 1-14, 1-15  
serial peripheral interconnect (SPI) ports, *See* SPI  
SPI interface  
  codec control, 1-24  
  config switch (SW19), 1-24  
  connector (P9), 2-33  
SPISEL1 signal, 1-18  
SPISEL5 signal, 1-18  
SPISEL7 signal, 1-18  
SPORT0A  
  enable switch (SW20), 1-23, 2-19  
  enable switch (SW27), 1-23, 2-19  
SPORT0 connector (P6), 2-32  
SPORT1 connector (P7), 2-32  
SRAM memory, 1-12  
STAMP connectors  
  enable jumper (JP7), 2-23  
  UART0 (P5), 1-26  
stamp enable jumper (JP14), 2-24  
startup, of this EZ-KIT Lite, 1-8  
  CCES, 1-4  
SW10 (UART1 enable) switch, 1-26, 2-15  
SW11 (NAND enable) switch, 1-22, 2-16  
SW13 (push button enable) DIP switch, 1-19, 1-25, 1-28, 2-17, 2-18  
SW14-15 (PF) push buttons, 2-18  
SW16 (reset) push button, 2-18  
SW19 (SPI/TWI config) switch, 1-24  
SW1 (Ethernet enable) switch, 1-22, 2-10  
SW20 (audio and SPORT enable) switch, 1-23, 2-19  
SW21 (TFS0A/HOSTCE enable) switch, 1-23, 2-19  
SW22 (touch address) switch, 1-21, 2-19  
SW24 (touchpad interrupt) switch, 1-21, 2-20  
SW25 (LCD/keypad control) switch, 1-18, 1-21, 2-20

- SW26 (LCD mode) switch, [1-20](#), [2-21](#)  
 SW27 (audio and SPORT enable) switch, [1-23](#), [2-19](#)  
 SW28 (line in-out loopback) switch, [2-22](#)  
 SW29 (CPLD D8-13) switch, [2-22](#)  
 SW2 (boot mode select) switch, [1-17](#), [1-18](#), [2-11](#)  
 SW30 (CPLD 14-15/DCE enable) switch, [1-24](#), [2-22](#)  
 SW3 (rotary) switch, [1-22](#), [2-12](#)  
 SW4 (mic gain) switch, [1-24](#), [2-12](#)  
 SW5 (LCD reset) switch, [1-28](#), [2-13](#)  
 SW7 (flash enable) switch, [2-13](#)  
 SW8 (mic loopback) switch, [1-24](#), [2-14](#)  
 SW9 (Ethernet mode) switch, [1-23](#), [2-14](#)  
 switches  
   *See also* switches by name (SW<sub>x</sub>)  
   diagram of locations, [2-10](#)  
 synchronous dynamic random access memory,  
   *See* SDRAM  
 system architecture, of this EZ-KIT Lite, [2-2](#)
- T**  
 technical support, [xvii](#)  
 TFS0A/HOSTCE enable switch (SW21), [1-23](#), [2-19](#)  
 TFS0A signal, [1-23](#)  
 TFS0A\_RMIIMDINT#\_HOSTCE# signal, [1-24](#)  
 thumbwheel control, [xiv](#)  
 timers connector (P11), [2-33](#)  
 touchpad interrupt switch (SW24), [1-21](#), [2-20](#)  
 touchscreen address switch (SW22), [1-21](#), [2-19](#)  
 two-wire interface (TWI)  
   config switch (SW19), [1-24](#)  
   connector (P10), [2-33](#)  
   selecting for codec, [1-24](#)
- U**  
 UART0 interface connector (P5), [1-26](#), [2-31](#)  
 UART1 interface  
   enable switch (SW10), [1-26](#), [2-15](#)  
   loopback jumper (JP5), [2-24](#)  
   UART1\_RX signal, [2-23](#)  
   UART1\_TX signal, [2-23](#), [2-24](#)  
 universal asynchronous receiver transmitter, *See*  
   UART0, UART1  
 up signal (CUD), [1-22](#)  
 USB  
   debug agent connector (ZJ1), [2-35](#)  
   OTG interface connector (P1), [1-8](#), [1-25](#), [2-31](#), [2-35](#)  
   voltage regulators, [1-25](#)  
 USB\_VRSEL signal, [1-25](#), [1-28](#)
- V**  
 VDDEXT  
   pin, [1-29](#)  
   power jumper (P15), [1-29](#), [2-25](#)  
 VDDINT  
   pin, [1-29](#)  
   power jumper (P14), [1-29](#), [2-25](#)  
 VDDMEM  
   pin, [1-29](#)  
   power jumper (P16), [1-29](#), [2-25](#)  
 very-long instruction word (VLIW), [xi](#)  
 VisualDSP++ environment, [1-8](#)  
 voltage planes, [1-27](#), [1-29](#), [2-17](#)  
 VR3 (USB voltage) regulator, [1-25](#)
- W**  
 watchdog timer, [1-27](#)

## X-ON Electronics

Largest Supplier of Electrical and Electronic Components

*Click to view similar products for [Development Boards & Kits - Other Processors](#) category:*

*Click to view products by [Analog Devices](#) manufacturer:*

Other Similar products are found below :

[EVB-MEC1418MECC](#) [20-101-1252](#) [C29XPCIE-RDB](#) [CC-ACC-18M433](#) [MAX1464EVKIT](#) [RTE510Y470TGB00000R](#)  
[RTK0EN0001D01001BZ](#) [MAXQ622-KIT#](#) [YR0K505231S000BE](#) [YR0K50571MS000BE](#) [YQB-R5F1057A-TB](#) [YQB-R5F104PJ-TB](#) [CC-](#)  
[ACC-ETHMX](#) [OV-7604-C7-EVALUATION-BOARD](#) [SK-AD02-D62Q1747TB](#) [SK-BS01-D62Q1577TB](#) [ST7MDT1-EMU2](#) [GROVE BASE](#)  
[KIT FOR RASPBERRY PI](#) [CAB M-M\(40-17-RAINBOW\)](#) [CY8CKIT-143A](#) [EK-MPC5744P](#) [KITAURIXTC234TFTTOBO1](#) [ESP32-C3-](#)  
[DEVKITC-02](#) [ENW89854AXKF](#) [ENWF9201AVEF](#) [QB-R5F104LE-TB](#) [LV18F V6 64-80-PIN TQFP MCU CARD EMPTY](#) [LV-24-33 V6](#)  
[44-PIN TQFP MCU CARD EMPTY](#) [LV-24-33 V6 64-PIN TQFP MCU CARD EMPTY](#) [LV-24-33 V6 80-PIN TQFP 1 MCU CARD EMPTY](#)  
[32X32 RGB LED MATRIX PANEL - 6MM PITCH](#) [3.3 - 5 VTRANSLATOR](#) [READY FOR XMEGA CASING \(WHITE\)](#) [RELAY4 BOARD](#)  
[ETHERNET CONNECTOR](#) [RFID CARD 125KHZ - TAG](#) [RFID READER](#) [RFM12B-DEMO](#) [MAROON](#) [3G CLICK \(FOR EUROPE AND](#)  
[AUSTRALIA\)](#) [MAX232](#) [MAX3232 BOARD](#) [ARTY S7-50](#) [THREE-AXIS ACCELEROMETER BOARD](#) [TINKERKIT HALL SENSOR](#)  
[TOUCHPANEL](#) [TOUCHPANEL CONTROLLER](#) [MIKROBOARD FOR AVR WITH ATMEGA128](#) [MIKROBOARD FOR PSOC WITH](#)  
[CY8C27643](#) [MIKROBUS CAPE](#)