Body Voltage Monitor Installation, Operation and Maintenance





United States of America



Figure 1. Desco 19241 Body Voltage Monitor

Description

The Desco Body Voltage Monitor is a single station continuous monitor for one operator, one ESD worksurface and one tool ground. A second monitored jack is featured for use by a supervisor or second operator.

The Body Voltage Monitor uses *Dual-Channel Voltage Monitoring Technology* for true continuous monitoring (versus pulsed or intermittent). The *Dual-Channel Voltage Monitoring Technology* uses one lead of the dual-wire wrist strap to provide a path-to-ground for the operator while the other lead continuously monitors for voltage induced onto the operator greater than ±3 VDC. Voltage on the operator can be caused by strong AC fields in the work area or by other charge generators such as rolling a non-ESD safe chair.

The Body Voltage Monitor has a second monitored jack for a supervisor or a second operator if needed at the workstation. An optional tool ground can be used to monitor the ground integrity of a conductive tool or fixture less than 3 Ohms.

Each Body Voltage Monitor is calibrated with accepted procedures and standards traceable to the National Institute of Standards and Technology (NIST) and includes a NIST certificate.

ANSI/ESD S20.20 section 7.3 states "Compliance verification records shall be established and maintained to provide evidence of conformity to the technical requirements." Per ANSI/ESD S1.1 Annex A.3 Daily (wrist strap system) testing may be omitted if constant monitoring used." Per ESD Handbook ESD TR 20.20 section 5.3.2.4.4 "Typical Test programs recommend that wrist straps that are used daily should be tested daily. However, if the products that are being produced are of such value that knowledge of a continuous, reliable ground is needed, and then continuous monitoring should be considered or even required."

Packaging

- 1 Body Voltage Monitor
- 1 Power Adapter, 5VDC, North America
- 1 Mat Monitor Cord (White)
- 1 Tool Monitor Cord (White)
- 1 Monitor Ground Cord (Green and Yellow)
- 1 Washer
- 1 Flat Head Screw, 6-32 thread
- 1 Alligator Clip
- 1 Ring Terminal
- 1 Mounting Bracket
- 2 Pan Head Screws, #8 x 3/4"
- 1 Certificate of Calibration

DESCO WEST - 3651 Walnut Avenue, Chino, CA 91710 • (909) 627-8178

DESCO EAST - One Colgate Way, Canton, MA 02021-1407 • (781) 821-8370 • Website: Desco.com

Features and Components




Figure 2. Body Voltage Monitor features and components

- **A. Monitored Operator Jack:** The operator connects to the monitor here.
- **B. Monitored Supervisor Jack:** The supervisor or second operator connects to the monitor here.
- **C. Operator LED:** When the LED is illuminated green, the operator is properly grounded. When the LED is illuminated red and the alarm sounds, the operator is not properly grounded.
- **D. Mat LED:** When the LED is illuminated green, the worksurface mat is properly grounded. When the LED is illuminated red and the alarm sounds, the worksurface mat is not properly grounded.
- **E. Tool LED:** When the LED is illuminated green, the tool is properly grounded. When the LED is illuminated red and the alarm sounds, the tool is not properly grounded.
- **F. Supervisor LED:** When the LED is illuminated green, the supervisor is properly grounded. When the LED is illuminated red and the alarm sounds, the supervisor is not properly grounded.
- **G. Monitored Mat Terminal:** Monitors a worksurface mat for proper dissipative resistance and static charges. Connect the white mat monitor cord here.

- **H. Monitored Tool Terminal:** Monitors a grounded metal tool fixture. Connect the white tool monitor cord here.
- **I. Ground Terminal:** Common ground point for the monitor. Connect the green and yellow monitor ground cord here.
- **J. Power Jack:** Connect the included 5VDC power adapter here.

Installation




Figure 3. Installing the Body Voltage Monitor

- Remove the monitor from the carton and inspect for damage.
 - **NOTE:** All Body Voltage Monitors are packaged with a wire shorting the tool terminal to the ground terminal. This is to prevent the tool circuit from alarming when not in use.
- Determine the mounting location of the Body Voltage Monitor. The front panel should be visible to the operator. Use the included mounting bracket and #8 pan head screws if desired.

DESCO WEST - 3651 Walnut Avenue, Chino, CA 91710 • (909) 627-8178

DESCO EAST - One Colgate Way, Canton, MA 02021-1407 • (781) 821-8370 • Website: Desco.com



Figure 4. Body Voltage Monitor with included mounting bracket

- Attach the tinned wire end of the mat monitor cord to its appropriate terminal block connection located on the back of the monitor.
- 4. Route the mat monitor cord from the back of the monitor to the worksurface mat. Use the included washer and screw to secure the cord to the mat (see Figure 5). The worksurface mat requires its ground cord to have an embedded 1 megohm resistor such as the Desco <u>09813</u>.




Figure 5. Screw allows ground cord to be bolted to mat to keep cord from disconnecting

- 5. Attach the tinned wire end of the included ground cord to the appropriate terminal block connection on the back of the monitor. Attach the ring terminal end to a ground point. It is important that this ground cord is attached to a different ground point than that of the worksurface mat. The face plate screw of a grounded AC wall outlet may provide a convenient connection point.
- 6. If applicable, attach the tinned wire end of the tool monitor cord to the appropriate terminal block connection on the back of the monitor. The included alligator clip or ring terminal may be applied to the banana plug for a secure connection to the grounded metal tool fixture that you choose to monitor.
- Connect the DC power supply to the power jack located on the back of the monitor. Route the wire from the supply to a nearby AC outlet and plug it into the outlet. Make sure the voltage and frequency match those listed on the power supply. The monitor is now powered.

NOTE: Worksurface must have a conductive layer such as Dual Layer Rubber or Dissipative 3-Layer Vinyl or Micastat® Dissipative Laminate with conductive buried layers. Desco continuous monitors are not recommended for use with homogeneous matting.

Operation USING THE MONITOR

- 1. Fit the wristband snugly onto your wrist.
- 2. Snap the wrist cord to the wristband.
- Plug the wrist cord into the monitored jack labeled "OPR". The corresponding operator LED will illuminate solid green. This indicates that the operator is properly grounded.
- If this does not happen, examine the wrist cord for continuity or damage and your wristband to ensure that it fits securely. If you have dry skin, apply an approved dissipative hand lotion such as <u>Menda Reztore® ESD</u> <u>Hand Lotion</u>.



Figure 6. Using the Body Voltage Monitor

DESCO WEST - 3651 Walnut Avenue, Chino, CA 91710 • (909) 627-8178

DESCO EAST - One Colgate Way, Canton, MA 02021-1407 • (781) 821-8370 • Website: Desco.com

Specifications

Operating Voltage 5 VDC

Operating Temperature 32°F - 104°F (0 - 40°C)

Monitor Dimensions 2.4" x 2.7" x 1.2"

(6.1cm x 6.9cm x 3.0cm)

Monitor Weight 0.4 lbs (0.2 kg)

DEFAULT TEST VOLTAGES

Operator (Open Circuit) < 0.5 V Worksurface (Open Circuit) < 1.5 V Tool (Open Circuit) < 0.5 V

DEFAULT TEST LIMITS

Operator Fail: > ±3 VDC

Alarm Accuracy ±1 VDC

Worksurface Low Fail: < 450 kilohms

Pass: 500k - 5M

High Fail: > 5.5 megohms

Tool Pass: 0 - 2 ohms

Fail: > 3 ohms

Limited Warranty, Warranty Exclusions, Limit of Liability and RMA Request Instructions

See the Desco Warranty -

Desco.com/Limited-Warranty.aspx

DESCO WEST - 3651 Walnut Avenue, Chino, CA 91710 • (909) 627-8178

DESCO EAST - One Colgate Way, Canton, MA 02021-1407 • (781) 821-8370 • Website: Desco.com

TB-3061 Page 4 of 4 © 2019 DESCO INDUSTRIES INC

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Antistatic Control Products category:

Click to view products by Desco manufacturer:

Other Similar products are found below:

13020 13490 13870 13879 13881 13883 13882 14404 2202SP 3039 37061 42470 09060 09857 42516 37059 04563 17252 19691 19695 09037 09826 09813 66070 100816 68101 68103 98132 73741 13868 13485 13457 13245 13468 13420 13332 13205 13135 91070 8031 8523 66085 40931 37081 13080 13215 13806 73749 010-0225 17260