

PRODUCT DESCRIPTION

The PTS Pair Tracing System comprises the PTS 200 Tone Generator and the PTS 100 Probe in a woven polyester carrying pouch. The System is designed to provide an easy to use and cost effective means of tracing wire pairs.

PTS 200 Tone Generator

The PTS 200 may be connected via the modular plug or the crocodile clips to the pair under test. Depending on the switch position the Tone Generator will test Polarity continuity or short circuits. The PTS 200 can be used on twisted pair wiring (Telecom, Datacom, security / alarm, audio and electrical), single conductors, coaxial cables, de-energized AC wiring and just about any other wiring you can think of.

PTS 100 Probe

The PTS 100 Probe has a built-in loudspeaker to make it easy to hear the tracing signals and a near/far sensitivity adjustment to allow both broad searches and pinpoint identification of wires. To operate just press the button on the top and adjust the sensitivity control to hear the tone generated by the PTS 200.



FEATURES

- Fast, Accurate Wire Identification
- · Sends Tone to Identify Wires
- Polarity Indication
- Continuity Test
- Adjustable Volume Control
- Easy to Operate
- · 2-Line Modular Test Lead
- · Rugged Industrial design
- Water Resistant

PTS 100 Output

No Tone

Tone on one wire

Quiet on one wire, loud on the other

Power hum on pair with tone

Power hum only

Noise with tone

Can't kill tone by shorting the pair

Continuous tone

Hiss from adjacent pair

Probable Cause

Wrong cable or a complete cable disconnection or

Tone Generator is disconnected

One wire disconnection

High resistance fault on low level (quiet) wire

Earth (ground) fault on one or both wires

Disconnection and earth fault

Crosstalk (severe cable fault) or earth fault

One wire disconnected or split pair or high resistance fault on one wire

Dying battery on the oscillator

ISDN or other digital service or base-band modem transmission

PTS Pair Tracing System

SPECIFICATIONS

PTS 200

Electrical:

Output Power (into 600Ω): -3dBm+3dB Output Frequency (nominal): 1004Hz±100Hz Sweep Rate: 6Hz

Voltage Protection (into a 600Ω Circuit): 60VDC

Power Source:

1 x 9V Battery: Battery Life (nominal): 290 hours

Environment:

0°C to 50°C Operating Temperature: Storage Temperature: -20°C to +60°C Relative Humidity: 0 - 90%

Physical:

Length: 125mm Width: 33mm Depth: 23mm Weight: 0.13kg

Warranty: One Year

PTS 100

Electrical:

Gain Range: 30dB $100 \mathrm{M}\Omega$ Input Impedance: Frequency Range (approx): 500Hz - 1200Hz

Power Source:

1 x 9V Battery: Battery Life (nominal): 15 to 25 hours

Environment:

Operating Temperature: 0°C to 50°C Storage Temperature: -20°c to +60°C Relative Humidity: 0 - 90%

Physical:

Length: 210mm Width: 32mm Depth: 42mm Weight: 0.13kg Warranty: One Year

PAIR TRACING

Connect the Tone Generator to the pair to be traced. Check that the tone is being sent before leaving the oscillator. PTS100 Probe detects the electrostatic field around the wire pair and outputs it to the integral speaker after filtering to reduce mains interference. In most circumstances the low sensitivity setting will work well but if the signal is weak or noisy then choosing the higher sensitivity setting may help.

Placing the probe alongside the pair gives a strong signal except where the wires cross.

Here there should be a noticeable null. Move the probe back and forth along the wire to confirm this.

Placing the tip in the centre of an opened twist of the pair should give a minimum signal. If it does not decrease, suspect a split pair (two wires from different pairs) or a faulty pair one wire broken or high resistance.



Shorting the pair should cause the signal to completely disappear or fall to a very low level. This verifies that you have the right pair.





X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Greenlee manufacturer:

Other Similar products are found below:

00042 06186 0652-22 1116 112AVBB 1161 124AV 127AV 128AV 1302 13544 1434AV 14722 15908 1614AA 1614SS 1760AV 1761AV 1895 1903 1916-SS 1917-SS 1924AA 1925AA 1935 200EP-G 20243 2034 2039 249AV 249AVBBP 28155 2929AV 29451 304AV 304AVBB 31962 31990 31991 3257AV 34941 3561 35682 435 45000 45504 50763 53997 60001 60115