



MICROCHIP

**UCS1002
Evaluation Board
User's Guide**

Note the following details of the code protection feature on Microchip devices:

- Microchip products meet the specification contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is one of the most secure families of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our knowledge, require using the Microchip products in a manner outside the operating specifications contained in Microchip's Data Sheets. Most likely, the person doing so is engaged in theft of intellectual property.
- Microchip is willing to work with the customer who is concerned about the integrity of their code.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as "unbreakable."

Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our products. Attempts to break Microchip's code protection feature may be a violation of the Digital Millennium Copyright Act. If such acts allow unauthorized access to your software or other copyrighted work, you may have a right to sue for relief under that Act.

Information contained in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION, INCLUDING BUT NOT LIMITED TO ITS CONDITION, QUALITY, PERFORMANCE, MERCHANTABILITY OR FITNESS FOR PURPOSE. Microchip disclaims all liability arising from this information and its use. Use of Microchip devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights unless otherwise stated.

Microchip received ISO/TS-16949:2009 certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona; Gresham, Oregon and design centers in California and India. The Company's quality system processes and procedures are for its PIC[®] MCUs and dsPIC[®] DSCs, KEELoQ[®] code hopping devices, Serial EEPROMs, microperipherals, nonvolatile memory and analog products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001:2000 certified.

**QUALITY MANAGEMENT SYSTEM
CERTIFIED BY DNV
= ISO/TS 16949 =**

Trademarks

The Microchip name and logo, the Microchip logo, AnyRate, dsPIC, FlashFlex, flexPWR, Heldo, JukeBlox, KEELoQ, KEELoQ logo, Klear, LANCheck, LINK MD, MediaLB, MOST, MOST logo, MPLAB, OptoLyzer, PIC, PICSTART, PIC32 logo, RightTouch, SpyNIC, SST, SST Logo, SuperFlash and UNI/O are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

ClockWorks, The Embedded Control Solutions Company, ETHERSYNCH, Hyper Speed Control, HyperLight Load, IntelliMOS, mTouch, Precision Edge, and QUIET-WIRE are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Analog-for-the-Digital Age, Any Capacitor, AnyIn, AnyOut, BodyCom, chipKIT, chipKIT logo, CodeGuard, dsPICDEM, dsPICDEM.net, Dynamic Average Matching, DAM, ECAN, EtherGREEN, In-Circuit Serial Programming, ICSP, Inter-Chip Connectivity, JitterBlocker, KlearNet, KlearNet logo, MiWi, motorBench, MPASM, MPF, MPLAB Certified logo, MPLIB, MPLINK, MultiTRAK, NetDetach, Omniscient Code Generation, PICDEM, PICDEM.net, PICkit, PICtail, PureSilicon, RightTouch logo, REAL ICE, Ripple Blocker, Serial Quad I/O, SQL, SuperSwitcher, SuperSwitcher II, Total Endurance, TSHARC, USBCheck, VariSense, ViewSpan, WiperLock, Wireless DNA, and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

Silicon Storage Technology is a registered trademark of Microchip Technology Inc. in other countries.

GestIC is a registered trademarks of Microchip Technology Germany II GmbH & Co. KG, a subsidiary of Microchip Technology Inc., in other countries.

All other trademarks mentioned herein are property of their respective companies.

© 2016, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.

ISBN: 978-1-5224-0313-5

Object of Declaration: UCS1002 Evaluation Board

EU Declaration of Conformity

Manufacturer: Microchip Technology Inc.
2355 W. Chandler Blvd.
Chandler, Arizona, 85224-6199
USA

This declaration of conformity is issued by the manufacturer.

The development/evaluation tool is designed to be used for research and development in a laboratory environment. This development/evaluation tool is not a Finished Appliance, nor is it intended for incorporation into Finished Appliances that are made commercially available as single functional units to end users under EU EMC Directive 2004/108/EC and as supported by the European Commission's Guide for the EMC Directive 2004/108/EC (8th February 2010).

This development/evaluation tool complies with EU RoHS2 Directive 2011/65/EU.

This development/evaluation tool, when incorporating wireless and radio-telecom functionality, is in compliance with the essential requirement and other relevant provisions of the R&TTE Directive 1999/5/EC and the FCC rules as stated in the declaration of conformity provided in the module datasheet and the module product page available at www.microchip.com.

For information regarding the exclusive, limited warranties applicable to Microchip products, please see Microchip's standard terms and conditions of sale, which are printed on our sales documentation and available at www.microchip.com.

Signed for and on behalf of Microchip Technology Inc. at Chandler, Arizona, USA


Derek Carlson
VP Development Tools

12-Sep-14
Date

NOTES:

Table of Contents

Preface	7
Introduction.....	7
Document Layout	7
Conventions Used in this Guide	8
Recommended Reading.....	9
The Microchip Web Site	9
Customer Support	9
Document Revision History	9
 Chapter 1. Product Overview	
1.1 Introduction	11
1.2 UCS1002 Evaluation System	11
1.3 What the UCS1002 Evaluation Board kit Contains	12
 Chapter 2. Installation and Operation	
2.1 Introduction	13
2.2 Connectors on the Evaluation Board	13
2.3 LEDs on the Evaluation Board	14
2.4 Jumpers on the Evaluation Board	15
2.5 Data Test Points on the Evaluation Board	16
2.6 Ground Test Points on the Evaluation Board	17
2.7 Software Installation	18
2.8 USB Bridge Installation	20
 Chapter 3. Hardware Description	
3.1 UCS1002 Device	23
3.2 Evaluation Board Power Source	23
3.3 V _S 5V Power Source	23
3.4 USB-to-SMBus Bridge	23
3.5 Direct SMBus Connect Option	24
3.6 LED Indicators	24
3.7 Jumper Settings	25
3.8 Test Points	25
 Chapter 4. Software Description	
4.1 Overview	27
4.1.1 Tips for Using the EVB GUI	28
4.1.2 GUI Abbreviations	28
4.1.3 Keyboard Shortcuts	28

UCS1002 Evaluation Board User's Guide

4.2 Interface Description and Operation	29
4.2.1 Panel Controls	29
4.2.2 Pin State and Attach Status Panel	30
4.2.3 Pin State & Attach Status Panel	31
4.2.4 Active Mode Selection	31
4.3 Tabs Description	32
4.3.1 Main Tab	32
4.3.2 Configuration and General Status Tab	36
4.3.3 Custom Charging Tab	38
4.3.4 Register Set Tab	40
4.3.5 Demo Tab	42
4.4 Troubleshooting	44
Appendix A. Schematic and Layouts	
A.1 Introduction	45
A.2 Board – Schematic	46
A.3 Board – Top Silk	47
A.4 Board – Top Solder Mask	47
A.5 Board – Top Copper	48
A.6 Board – 2 nd Layer Copper	48
A.7 Board – 3 rd Layer Copper	49
A.8 Board – Bottom Copper	49
A.9 Board – Bottom Solder Mask	50
A.10 Board – Bottom Silk	50
Appendix B. Bill of Materials	51
Worldwide Sales and Service	54

Preface

NOTICE TO CUSTOMERS

All documentation becomes dated, and this manual is no exception. Microchip tools and documentation are constantly evolving to meet customer needs, so some actual dialogs and/or tool descriptions may differ from those in this document. Please refer to our website (www.microchip.com) to obtain the latest documentation available.

Documents are identified with a “DS” number. This number is located on the bottom of each page, in front of the page number. The numbering convention for the DS number is “DSXXXXXXXXA”, where “XXXXXXXX” is the document number and “A” is the revision level of the document.

For the most up-to-date information on development tools, see the MPLAB® IDE online help. Select the Help menu, and then Topics to open a list of available online help files.

INTRODUCTION

This chapter contains general information that will be useful to know before using the UCS1002 Evaluation Board. Items discussed in this chapter include:

- [Document Layout](#)
- [Conventions Used in this Guide](#)
- [Recommended Reading](#)
- [The Microchip Web Site](#)
- [Customer Support](#)
- [Document Revision History](#)

DOCUMENT LAYOUT

This document describes how to use the UCS1002 Evaluation Board. The manual layout is as follows:

- **Chapter 1. “Product Overview”** – Important information about the UCS1002 Evaluation Board.
- **Chapter 2. “Installation and Operation”** – Includes instructions on how to get started with this user’s guide and the board.
- **Chapter 3. “Hardware Description”** – Describes the UCS1002 Evaluation Board features and functionalities.
- **Chapter 4. “Software Description”** – Describes the interface that operates the UCS1002 Evaluation Board.
- **Appendix A. “Schematic and Layouts”** – Shows the schematic and layout diagrams for the UCS1002 Evaluation Board.
- **Appendix B. “Bill of Materials”** – Lists the parts used to build the UCS1002 Evaluation Board.

UCS1002 Evaluation Board User's Guide

CONVENTIONS USED IN THIS GUIDE

This manual uses the following documentation conventions:

DOCUMENTATION CONVENTIONS

Description	Represents	Examples
Arial font:		
Italic characters	Referenced books	<i>MPLAB[®] IDE User's Guide</i>
	Emphasized text	...is the <i>only</i> compiler...
Initial caps	A window	the Output window
	A dialog	the Settings dialog
	A menu selection	select Enable Programmer
Quotes	A field name in a window or dialog	"Save project before build"
Underlined, italic text with right angle bracket	A menu path	<u><i>File>Save</i></u>
Bold characters	A dialog button	Click OK
	A tab	Click the Power tab
N'Rnnnn	A number in verilog format, where N is the total number of digits, R is the radix and n is a digit.	4'b0010, 2'hF1
Text in angle brackets < >	A key on the keyboard	Press <Enter>, <F1>
Courier New font:		
Plain Courier New	Sample source code	#define START
	Filenames	autoexec.bat
	File paths	c:\mcc18\h
	Keywords	_asm, _endasm, static
	Command-line options	-Opa+, -Opa-
	Bit values	0, 1
	Constants	0xFF, 'A'
Italic Courier New	A variable argument	<i>file.o</i> , where <i>file</i> can be any valid filename
Square brackets []	Optional arguments	mcc18 [options] <i>file</i> [options]
Curly brackets and pipe character: { }	Choice of mutually exclusive arguments; an OR selection	errorlevel {0 1}
Ellipses...	Replaces repeated text	var_name [, var_name...]
	Represents code supplied by user	void main (void) { ... }

RECOMMENDED READING

This user's guide describes how to use the UCS1002 Evaluation Board. Other useful documents are listed below. The following Microchip documents are available and recommended as supplemental reference resources.

- **UCS1002 Data Sheet - “Programmable USB Port Power Controller with Charger Emulation” (Revision 1.4 - 07-16-2013)**
- **AN 24.14 - “UCS1002 Fundamentals of Custom Charger Emulation” (DS20005234)**

THE MICROCHIP WEB SITE

Microchip provides online support via our web site at www.microchip.com. This web site is used as a means to make files and information easily available to customers. Accessible by using your favorite Internet browser, the web site contains the following information:

- **Product Support** – Data sheets and errata, application notes and sample programs, design resources, user's guides and hardware support documents, latest software releases and archived software
- **General Technical Support** – Frequently Asked Questions (FAQs), technical support requests, online discussion groups, Microchip consultant program member listing
- **Business of Microchip** – Product selector and ordering guides, latest Microchip press releases, listing of seminars and events, listings of Microchip sales offices, distributors and factory representatives

CUSTOMER SUPPORT

Users of Microchip products can receive assistance through several channels:

- Distributor or Representative
- Local Sales Office
- Field Application Engineer (FAE)
- Technical Support

Customers should contact their distributor, representative or field application engineer (FAE) for support. Local sales offices are also available to help customers. A listing of sales offices and locations is included in the back of this document.

Technical support is available through the web site at:
<http://www.microchip.com/support>.

DOCUMENT REVISION HISTORY

Revision A (February 2016)

- Initial release of this document.

UCS1002 Evaluation Board User's Guide

NOTES:

Chapter 1. Product Overview

1.1 INTRODUCTION

This document provides a description of the software and hardware used to evaluate the features of the UCS1002.

1.2 UCS1002 EVALUATION SYSTEM

The evaluation system has several components, as shown in [Figure 1-1](#):

- Customer-provided Windows® PC
- UCS1002 Graphical User Interface program (GUI) and USB Bridge Driver
- UCS1002 Evaluation Board
- USB Cable for GUI communications (Standard-A plug to mini-B plug)
- 5V power source (V_s)
- Customer-provided portable device and OEM USB charging cable (with Standard-A plug at board's end)




FIGURE 1-1: UCS1002 Evaluation System.

UCS1002 Evaluation Board User's Guide

A block diagram of the UCS1002 Evaluation Board is shown in [Figure 1-2](#) below:




FIGURE 1-2: UCS1002 Evaluation Board Block Diagram.

1.3 WHAT THE UCS1002 EVALUATION BOARD KIT CONTAINS

This UCS1002 Evaluation Board kit includes:

- UCS1002 Evaluation Board (ADM00497)
- Important Information Sheet
- 5V AC-DC Wall Adapter
- Standard-A plug to mini-B plug USB Cable

Chapter 2. Installation and Operation

2.1 INTRODUCTION

This chapter identifies the main connectors, LEDs, jumpers and test points that can be found on the UCS1002 Evaluation Board. It also explains the steps to install the board's graphical user interface and drivers.

2.2 CONNECTORS ON THE EVALUATION BOARD

Figure 2-1 shows the top of the evaluation board and highlights some components.




FIGURE 2-1: UCS1002 Evaluation Board Top View - Connectors.

TABLE 2-1: CONNECTORS DESCRIPTION

Designator	Connector Type	Description
U1		Populated with the UCS1002 device (pin 1 upper left)
J2	Right-Angle USB Standard-B Receptacle	This connects the evaluation board to the USB host (and also provides 5V power to the UCS1002 device V_S pins if J11 is installed).
J3	Right-Angle Power Supply	This connects directly to the UCS1002 V_S input pins.
P1	Right-Angle USB Standard-A Receptacle	This connects the board to the portable device.

UCS1002 Evaluation Board User's Guide

TABLE 2-1: CONNECTORS DESCRIPTION (CONTINUED)

Designator	Connector Type	Description
P2	Right-Angle Receptacle for Factory Use Only	This is a programming port for the 8051 microcontroller.
P3	Right-Angle USB Mini-B Receptacle.	This connects the board to the PC with the GUI software. It also provides 5V power to the evaluation board and to the V _{DD} pin on the UCS1002 device.
P4	Right-Angle USB Standard-A Receptacle	This connects directly to the UCS1002 V _{BUS} output pins. No data connection present. This is the power thief port.

2.3 LEDs ON THE EVALUATION BOARD

Figure 2-2 shows the top of an EVB and highlights the LEDs.




FIGURE 2-2: Evaluation Board Top View - LEDs.

TABLE 2-2: LEDs DESCRIPTION

Designator	Function	Description
LED2	USB Activity	When lit, this yellow LED means 5V power is applied to the USB bridge IC.
LED3	SMBus Activity	When flashing, this yellow LED indicates SMBus communication activity.
LED4	ALERT#	When lit, this red LED indicates an alert signal is active.
LED5	A_DET#/CHRG#	When lit, this green LED indicates a device is attached for the UCS1002.

2.4 JUMPERS ON THE EVALUATION BOARD

Figure 2-3 shows the top of an EVB and highlights the jumpers.




FIGURE 2-3: Evaluation Board Top View - Jumpers.

TABLE 2-3: JUMPERS DESCRIPTION

Designator	Assigned Pin	Description
J4	PWR_EN	When installed, this jumper will force a low at the PWR_EN pin.
J5	Not Used	The jumper is not used.
J6	EM_EN	When installed, this jumper will force a low at the EM_EN pin.
J7	M1	When installed, this jumper will force a low at the M1 pin.
J8	M2	When installed, this jumper will force a low at the M2 pin.
J9	SMCLK/S0	This jumper must be left off for SMBus communications to be enabled. If the UCS1002 is in Stand-Alone mode (as selected by using J13 instead of J12), Detect Power state will be enabled without the jumper installed.
J10	SMDATA/LATCH	If UCS1002 is configured in SMBus communication mode, this jumper must be left out. In Stand-Alone mode (as selected by using J13 instead of J12), this jumper will enable the "auto-retry" fault handler if installed, and the "Latch" fault handler if left out.

UCS1002 Evaluation Board User's Guide

TABLE 2-3: JUMPERS DESCRIPTION (CONTINUED)

Designator	Assigned Pin	Description
J11	VS Input Selection	This jumper connects the 5V pin of connector J2 to the UCS1002 V _S power input pins. It MUST be left out if external power supply is connected to J3.
J12	Current Limit	When UCS1002 in SMBus mode, this jumper selects the current limit.
J13	Current Limit Stand-Alone	This jumper selects the current limit. This is used when the device is in Stand-Alone mode.
J14	Active Low Address	Active Low Address Selection. See device data Sheet for details. Only one jumper between J14 and J17 can be selected at a time.
J15	V _{BUS} Output	This jumper connects the 5V pin of connector P1 to the UCS1002 V _{BUS} power output pins. It should be left off if power is to be drawn only from auxiliary power output connector P4.
J16	SMBus SDA	If the UCS1002 is in SMBus mode (as selected by using J12 instead of J13), then this jumper must be populated to connect the data line to the USB bridge IC. Otherwise, the jumper must be left out.
J17	Active High Address	Active High Address Selection. See device data sheet for details. Only one jumper between J14 and J17 can be selected at a time.
J18	SMBus SCL	If the UCS1002 is in SMBus mode (as selected by using J12 instead of J13), then this jumper must be populated to connect the data line to the USB bridge IC. Otherwise, the jumper must be left out.

2.5 DATA TEST POINTS ON THE EVALUATION BOARD

Figure 2-4 shows the top of the board and highlights the USB data line test points.




FIGURE 2-4: Evaluation Board Top View - Data Test Points.

Installation and Operation

TABLE 2-4:

Designator	Assigned Pin	Description
TP10	DMin	This test point connects to the DMin data line through a 1 MΩ series resistor.
TP11	DPin	This test point connects to the DPin data line through a 1 MΩ series resistor.
TP14	DP_out	This test point connects to the DP_out data line through a 1 MΩ series resistor.
TP16	DM_out	This test point connects to the DM_out data line through a 1 MΩ series resistor.

2.6 GROUND TEST POINTS ON THE EVALUATION BOARD

Figure 2-5 shows the top of the board and highlights the ground test points.




FIGURE 2-5: Evaluation Board Top View - Ground Test Points.

TABLE 2-5:

Designator	Test Point Type	Description
SGND1, SGND2	Signal Ground	These test points connect to the signal ground of the board. These are the ground reference for the UCS1002.
EGND1, EGND2, EGND3	Earth Ground	These test points connect to the earth ground of the board (the shield of the USB connectors).

UCS1002 Evaluation Board User's Guide

2.7 SOFTWARE INSTALLATION

To begin using the UCS1002 Evaluation Board, software must be installed on a Windows®-based computer with a USB port.

1. Download the software archive from the board's web page, unzip it and double-click the `Setup.exe`, to start the installation. Figure 2-6 shows the initial installation screen, which displays briefly as the setup program loads.




FIGURE 2-6: Software Installation – Initialize Window.

2. Click **Next** in the Destination Directory window, as shown in Figure 2-7. For proper operation, the files must be installed in the default locations. The default location for the software files is `C:\Program Files\SMSC\UCS1002\`, while the default for the LabVIEW software is `C:\Program Files\National Instruments\`.




FIGURE 2-7: Software Installation – Setting the Destination Directory.

3. Read and accept the license agreement, then click **Next**.




FIGURE 2-8: Software Installation – Software License Agreement.

4. To use the LabVIEW software, read and accept the license agreement, then click **Next**.




FIGURE 2-9: Software Installation – LabVIEW License Agreement.

On the next screens, hit **Next** and follow the on-screen instructions to complete the installation. When installation is complete, press **Finish**; the program will automatically run. If a screen appears requiring a restart for the changes to take effect, reboot your computer.

The UCS1002 interface will start with the SMBus communications.

UCS1002 Evaluation Board User's Guide

2.8 USB BRIDGE INSTALLATION

Connect the USB mini connector to the evaluation board and the standard USB connector to any available USB port on the PC. If the USB Bridge driver has not previously been installed on the selected USB port, the "Find New Hardware" wizard will pop up on the PC's screen. Follow the on-screen instructions to complete the installation process. The files will automatically be retrieved from the installation package. See Figures 2-10 through 2-14 for a step-by-step view of the installation.

Note: If the installation of the driver is done on a Windows 7 PC, look for the WIN7 Installation Note.pdf that can be found in the Documentation folder included in the software installation package.



FIGURE 2-10: USB Bridge Driver Installation – Step 1.




FIGURE 2-11: USB Bridge Driver Installation – Step 2.




FIGURE 2-12: USB Bridge Driver Installation – Step 3.

UCS1002 Evaluation Board User's Guide




FIGURE 2-13: USB Bridge Driver Installation – Step 4.




FIGURE 2-14: USB Bridge Driver Installation – Step 5.

Chapter 3. Hardware Description

3.1 UCS1002 DEVICE

The UCS1002 device provides a single USB port power switch for precise control of up to 2.5A continuous current with overcurrent limiting, dynamic thermal management, latch/auto-recovery upon fault, selectable active low or high enable, undervoltage and overvoltage lockout, and back-drive protection.

USB Charging Port profiles are integrated into the UCS1002 to ensure compliance to multiple standards. In addition to power switching and USB Charging Port profiling, the UCS1002 provides automatic and configurable USB data line handshaking to enable charging of USB-IF Battery Charging 1.2 (CDP or DCP modes), Chinese Telecommunications Industry Standard YD/T 1591-2009, Apple[®] Inc., RIM[®] and many other mobile devices.

The UCS1002 provides a device attachment detection output, as well as a dedicated alert output, with current monitoring and charge rationing for controlled delivery of current regardless of a host's power state. When the limit is reached, the UCS1002 will perform the user programmed behavior (report and disconnect is the default).

3.2 EVALUATION BOARD POWER SOURCE

The UCS1002 Evaluation Board requires a single USB cable to operate. USB bus voltage is provided to the on-board indicator LEDs and the USB Bridge. This bridge regulates the +5V USB power to +3.3V used by the board's circuitry.

3.3 V_S 5V POWER SOURCE

A 5V power source is needed for V_S to charge the portable device. This can come from a PC USB port (limited to 500 mA) through a USB cable with a Standard-B plug end into the evaluation board, or from the 5V wall adapter provided (up to 2.5A).

3.4 USB-TO-SMBUS BRIDGE

The USB-to-SMBus bridge is based on an 8051 microcontroller with integrated USB-to-SMBus interfaces, as well as internal flash and RAM. During board manufacture, firmware is loaded into the bridge that provides the interface between the USB and the SMBus. Power is sourced to the microcontroller from the USB interface. To evaluate the UCS1002, the USB bridge is used to buffer the ALERT# and A_DET# outputs from the device.

UCS1002 Evaluation Board User's Guide

3.5 DIRECT SMBUS CONNECT OPTION

It is also possible to connect an external SMBus master to the UCS1002 Evaluation Board. Remove the jumpers on J16 and J18 and connect the SMBus master to Pin 1 of the appropriate header. The USB connection on P3 must remain attached to provide +3.3V for the chip and indicator LEDs. Note that ground must be connected to one of the test point grounds on the EVB. See [Figure 3-1](#) for connector pins.




FIGURE 3-1: UCS1002-to-SMBus Bridge Jumpers.

3.6 LED INDICATORS

The UCS1002 Evaluation Board has LED status indicators, as listed in [Table 3-1](#).

TABLE 3-1: LED STATUS INDICATORS

LED No.	Signal	OFF	GREEN	RED	YELLOW
2	USB Activity	No activity on USB port	N/A	N/A	Activity on USB port
3	SMBus Activity	No Activity within USB-SMBus bridge	N/A	N/A	Activity within USB-SMBus bridge
4	ALERT#	$\overline{\text{ALERT}}$ pin is not asserted	N/A	$\overline{\text{ALERT}}$ pin is asserted	N/A
5	A_DET#/CHRG#	No device attached	A device is detached	N/A	N/A

3.7 JUMPER SETTINGS

The UCS1002 Evaluation Board has pin headers and jumper configurations to evaluate the features of the UCS1002, as listed in [Table 3-2](#).

TABLE 3-2: JUMPER SETTINGS

Pin Header	Label	Default Position	Alternate position
J4	PWR_EN	No jumper = signal high	Jumpered = signal low
J5	N/A	N/A	N/A
J6	EM_EN	No jumper = signal high	Jumpered = signal low
J7	M1	Jumpered = signal low	No jumper = signal high
J8	M2	Jumpered = signal low	No jumper = signal high
J9	SMCLK/S0	Open for SMBus communications	See data sheet for standalone operation
J10	SMDATA/LATCH	Open for SMBus communications	See data sheet for standalone operation
J11	J11	No jumper = voltage input to power switch coming from auxiliary power input (J3)	Jumper = voltage input to power switch coming from host (J2)
J12	SMBus	Jumpered pins select the corresponding resistor which selects the I_{LIM} setting.	
J13	STAND ALONE	Applicable only in Stand-Alone mode. Jumpered pins select the corresponding resistor which selects the I_{LIM} setting.	
J14	ACTIVE LOW	No jumper selected, see J17	Install 1 jumper (J14 or J17) to select an SMBus address
J15	J15	Jumper = voltage output from power switch going to the portable device (P1)	No jumper = voltage output from power switch going to auxiliary power output (J16)
J16	SDA_8051	Jumpered = SMBus via 8051	No jumper = external SMBus host
J17	ACTIVE HIGH	Jumper = 15-16 installed = address 57h	Install 1 jumper (J14 or J17) to select an SMBus address.
J18	SCL_8051	Jumpered = SMBus via 8051	No jumper = external SMBus host

3.8 TEST POINTS

The UCS1002 Evaluation Board provides test points for ground reference and signal access, as listed in [Table 3-3](#).

TABLE 3-3: TEST POINTS

Test Point	Signal Function Monitored
1	PWR_EN
2	N/A
3	EM_EN
4	M1
5	M2
6	SMCLK/S0
7	SMDATA/LATCH
8	ALERT#
9	A_DET#/CHRG#
10	DMin
11	DPin
14	DP_out

UCS1002 Evaluation Board User's Guide

TABLE 3-3: TEST POINTS (CONTINUED)

Test Point	Signal Function Monitored
16	DM_out
SGND1	Signal Ground
SGND2	Signal Ground
EGND1	Earth Ground
EGND2	Earth Ground
EGND3	Earth Ground

Chapter 4. Software Description

4.1 OVERVIEW

To get the graphical interface and the evaluation board running, follow these instructions:

1. Start the UCS1002 GUI software: from the Windows Start menu, select *Programs > SMSC > UCS1002*.
2. Connect the USB mini connector end of the cable to the board and the standard USB connector of the cable to any available USB port on the PC. The USB Activity LED should light, indicating that the board is getting power.

The UCS1002 Evaluation Board interface (Figure 4-1), consists of Five tabs (**Main**, **Configuration & General Status**, **Custom Charging**, **Register Set** and **Demo**) as well as the right side sections that are always visible (**Panel Controls**, **Pin State & Attach Status** and **Active Mode Selection**).




FIGURE 4-1: UCS1002 Evaluation Board Initial Window.

UCS1002 Evaluation Board User's Guide

4.1.1 Tips for Using the EVB GUI

- For many controls on the GUI panel, placing the mouse cursor over a control will pop up context help that indicates the register address or gives a description. In addition, a context help window can be displayed by clicking the Help menu and then selecting Show Context Help. Display speed varies by system.
- After a power up of the evaluation board, the default settings are loaded. Users can save setting configurations to user-named files which can be reloaded at any time for quick reconfiguration (see [Section 4.3.4.4 “Configuration Save and Load”](#)).
- The GUI cannot be used to demonstrate UCS1002 behavior in Stand-Alone mode since SMBus communication is required.

4.1.2 GUI Abbreviations

Abbreviation	Description
BC	Battery Charging
CDP	Charging Downstream Port
DBP	Dead Battery Provision
DC	Dedicated Charger
DCE	Dedicated Charger Emulation
DCP	Dedicated Charging Port
EM	Emulation
EM_EN	Emulation Enable
M1	Mode Control Pin Number One
M2	Mode Control Pin Number Two

4.1.3 Keyboard Shortcuts

Some GUI controls have keyboard shortcuts, as shown in [Table 4-1](#).

TABLE 4-1: UCS1002 EVALUATION BOARD GUI KEYBOARD SHORTCUTS

GUI Control	Shortcut	Control Description
Run	CTRL + R	Section 4.2.1.1 “Stop and Run Buttons”
Stop	F12	Section 4.2.1.1 “Stop and Run Buttons”

4.2 INTERFACE DESCRIPTION AND OPERATION

4.2.1 Panel Controls

The Panel Controls section on the right side of the GUI, shown in [Figure 4-2](#), affects GUI operation. This section is always displayed.




FIGURE 4-2: Panel Controls.

4.2.1.1 STOP AND RUN BUTTONS

Pressing the **Stop** button, shown in [Figure 4-2](#), interrupts GUI software communication with the evaluation board. When this button is clicked, the **Run** button appears under an extended menu bar, as shown in [Figure 4-3](#).




FIGURE 4-3: Stop and Run Button.

4.2.1.2 RUN BUTTON

To restart communications between the software and the evaluation board, click the **Run** button. This button disappears when communication resumes.

Note: Stopping and restarting the GUI do not affect register settings. To restore default register settings, disconnect power from the board, then reconnect power.

To close the program, press the **Close (X)** button on the upper right corner of the window.

UCS1002 Evaluation Board User's Guide

4.2.1.3 COM STATUS INDICATOR

The **COM Status** indicator shows the status of communications over the SMBus. During normal operation, COM Status is green. If SMBus communications fail, COM Status turns red (or alternates red and green).

4.2.1.4 REGISTER READ DELAY

The **Register Read Delay** sets the GUI control panel update speed. It affects the speed that the software reads the registers, but will not affect the device's sampling time. The default is 50 ms. This number can range from 0 to 5000 ms in increments of 25 ms.

4.2.1.5 SINGLE/CONTINUOUS READ

The panel defaults to continuous register reads (toggle switch in down position, as shown in [Figure 4-2](#)). To stop continuous register reads, check the "Single Read Enable" box. In order to capture the register values at a given time, click the switch, which will briefly flip to Single Read.

4.2.1.6 DEFAULT

When this button is pressed, it loads the defaults to all registers of the UCS1002.

4.2.1.7 STEP

When selected, **Step** will go through the Emulation Profiles in sequence, from Legacy 1 through 6, then BC1.2 DCP, and finally Custom. The actual DCE cycle is slightly different. For more information, see product's data sheet.

4.2.1.8 DEMO

The **Demo** button enables an automated routine to cycle through a user-defined set of profiles and selects the highest current profile. This feature emulates an external controller and is not part of the UCS1002 device.

4.2.2 Pin State and Attach Status Panel

The Pin State & Attach Status section on the right side of the GUI, shown in [Figure 4-4](#), provides a quick graphical status reference and allows physical control pin override. This section is always displayed.




FIGURE 4-4: Pin State and Attach Status.

4.2.3 Pin State & Attach Status Panel

4.2.3.1 ALERT# AND A_DET# INDICATORS

When the ALERT# and A_DET# indicators are green, the signals at the device's respective pin are low and the corresponding condition has occurred (alert or device attached, respectively). When the indicators are dark, the pin states are high.

4.2.3.2 PIN INDICATORS

The pin indicators (SEL, PWR_EN, M1, M2 and EM_EN) shown in [Figure 4-4](#) are green if the signal on the corresponding pin on the UCS1002 device is high, and dark if the signal is low. If the "Pin Ignore" box is checked (see [Section 4.2.3.3 "Pin Override"](#)), these indicators will reflect the GUI overrides for these pins.

4.2.3.3 PIN OVERRIDE

For evaluation convenience, the GUI can override the setting of the following pins on the UCS1002 device: PWR_EN, M1, M2 and EM_EN. Check the "Pin Ignore" box (see [Figure 4-4](#)) to enable pin override. Then, check in the corresponding pin box to set the value high.

Note 1: Pin override does not affect the actual signal on the pin. It only affects the register values.

2: The SEL pin is only read once by the UCS1002 at power up, so there is no pin override for it. To close the port power switch, the PWR_EN state must match the SEL state (e.g., SEL = high and PWR_EN = high).

4.2.4 Active Mode Selection

The Active Mode Selection section on the right side of the GUI, shown in [Figure 4-5](#), provides a quick reference regarding operating state based on the values of M1, M2 and EM_EN. This section is always displayed.

Active Mode Selection			
M1	M2	EM EN	OP State
0	0	1	DCE CYCLE
0	1	0	DATA PASS-THRU
0	1	1	BC1.2 DCP
1	0	0	BC1.2 SDP
1	0	1	DCE CYCLE
1	1	0	DATA PASS-THRU
1	1	1	BC1.2 CDP

FIGURE 4-5: *Charger Emulation Selection.*

UCS1002 Evaluation Board User's Guide

4.3 TABS DESCRIPTION

4.3.1 Main Tab

The **Main** tab (Figure 4-6) shows key parameters related to the port power switch, including the maximum current limit, the present current limit (always equal to or less than maximum current limit), and power state (e.g. detect, active, error, etc.). When a portable device has been successfully attached, the screen shows the power state change from Detect to Active and shows the various handshakes applied. Once it is determined that the device is charging, the screen shows which emulation profile was successful, and the graph shows the charging current. Optionally, the user may monitor the charge delivered or ration the charge delivered to the attached device.




FIGURE 4-6: Main Tab Window Overview.

4.3.1.1 DEDICATED CHARGER EMULATION (DCE) CYCLE

As shipped, the UCS1002 is ready to function as a dedicated charger, which will be applied when there is an attach detection. To view this behavior, perform the following:

1. Connect V_S to the evaluation board (see Section 3.7 “Jumper Settings”). The VS_LOW indicator on the bottom of the **Main** Tab must be dark. If the color is red, the voltage is not high enough to charge a portable device.
2. Connect a portable device to the board. Use the OEM USB charging cable that comes with the portable device.
3. The UCS1002 should detect an attachment, switch to the Active Power state, apply an emulation profile and deliver a charge. Figure 4-7 shows the interface after charging has started.

Software Description




FIGURE 4-7: Main Tab - Charging Started.

4. Disconnect the portable device from the board.

The UCS1002 should detect a removal, switch to the Detect power state and stop delivering a charge. Figure 4-8 shows the interface after a removal was detected.




FIGURE 4-8: Main Tab - Removal Detected.

UCS1002 Evaluation Board User's Guide

4.3.1.2 CHARGING DOWNSTREAM PORT (CDP)

The CDP charging profile is based on the “*USB Battery Charging Specification v1.x*”. When a BC1.x-compliant portable device attachment is detected, the UCS1002 and the portable device do handshaking based on the standard. If handshaking is successful, charging occurs up to the set current limit.

To select the CDP port power profile, M1, M2 and EM_EN must all be high. This can be done by removing the jumpers for these pins (J7, J8 and J6 respectively) or by using the pin override in the GUI (see [Section 4.2.3.3 “Pin Override”](#)).

4.3.1.3 PASS-THROUGH

Data Pass-Through does not apply any type of charger emulation. When selected, it closes the USB high-speed data switch and supplies current up to the current limit.

To select Data Pass-Through, M1, M2 and EM_EN can be set to any one of the two DATA PASS-THRU combinations (010 and 110), as shown in [Figure 4-9](#). This can be done by setting the jumpers for these pins (J7, J8, and J6 respectively - see [Section 3.7 “Jumper Settings”](#)) or by using the pin override in the GUI (see [Section 4.2.3.3 “Pin Override”](#)).

Active Mode Selection				
M1	M2	EM	EN	OP State
0	0	1		DCE CYCLE
0	1	0		DATA PASS-THRU
0	1	1		BC1.2 DCP
1	0	0		BC1.2 SDP
1	0	1		DCE CYCLE
1	1	0		DATA PASS-THRU
1	1	1		BC1.2 CDP

FIGURE 4-9: Data Pass-Through Selection Options.

4.3.1.4 CURRENT MONITORING AND CHARGE RATIONING

To view current monitoring and current rationing, perform the following on the **Main** tab:

1. Set a Ration Limit. The ration limit is expressed in mAh (electric charge).
2. Set rationing behavior. The Ration Completion Behavior defaults to “Report & Disconnect”. Once the ration limit is reached, portable device charging will cease, the ALERT# pin will assert and the `Ration Complete` bit will be set. If you do not want the system to behave in this fashion, select one of the other three options from the Ration Completion Behavior drop-down list: Report, Report & Sleep or Take No Action.
3. Connect V_S to the evaluation board (see [Section 3.7 “Jumper Settings”](#)). The VS_LOW indicator on the bottom of the **Main** tab must be dark. If the VS_LOW indicator is red, the voltage is not high enough to charge a portable device.
4. Connect a portable device to the evaluation board. Use the OEM USB charging cable that comes with the portable device.
5. Enable rationing by checking the Ration Enable check box on the **Main** tab.
6. Watch the GUI as the device starts charging. [Figure 4-10](#) shows the interface after the ration limit was reached (for “Report & Disconnect” behavior setting).

Note: As shown in [Figure 4-10](#), the green trace is the instantaneous current, while the red diagonal line is the charge being delivered in mAh. Both are also presented in numeric format in the bottom left boxes. Trace color and characteristics can be changed by clicking on the waveform boxes to the left of these numerical values.




FIGURE 4-10: Main Tab - Ration Limit Reached.

UCS1002 Evaluation Board User's Guide

4.3.2 Configuration and General Status Tab

The **Configuration & General Status** tab (Figure 4-11) includes various status indicators and configuration controls. Items are grouped by function, detailed in the following sections.




FIGURE 4-11: Configuration & General Status Tab.

4.3.2.1 INTERRUPT STATUS

The indicators in the Interrupt Status section turn green when the corresponding bit is high and are dark when the bit is low.

4.3.2.2 GENERAL STATUS

Indicators in the General Status section turn green when the corresponding bit is high and are dark when the bit is low.

4.3.2.3 EMULATION BEHAVIOR

Check the necessary check box to enable the corresponding emulation behavior.

4.3.2.4 COMMUNICATIONS

Controls related to SMBus and USB communications.

4.3.2.5 EMULATION PROFILE DISABLE

Check the Profiles boxes to disable them. They will not be used during emulation. Selecting “Disable ALL” will toggle all profile check boxes.

4.3.2.6 ATTACH/REMOVE ENABLE

Click the S0_SET box to remove the check mark and disable the function.

4.3.2.7 FAULT HANDLER

These are controls related to fault handling.

4.3.2.8 GENERAL CONTROL

Controls for general parameters.

4.3.2.9 THERMAL REGULATION

Controls for thermal and detection delay parameters.

4.3.2.10 PORT POWER KEEP-OUT

Displays values for the port power parameters.

4.3.2.11 GENERAL EMULATION/CHARGING SETTINGS

Controls for emulation and charging.

4.3.2.12 EMULATION TIMEOUTS

Sets the emulation timeout period for each profile. These timeout periods are not used if the EM_TIMEOUT_DIS control in the Emulation Behavior section is checked.

4.3.2.13 CHARGING THRESHOLD CURRENT

Controls charging threshold current setting.

4.3.2.14 HIGH SPEED SWITCH CONFIGURATION

Controls the high-speed switch parameters.

UCS1002 Evaluation Board User's Guide

4.3.3 Custom Charging Tab

The **Custom Charging** tab (Figure 4-12) provides the means for users to create custom charger emulator configurations. These configurations include signaling on the USB data lines, as well as what method of current limiting to employ (Constant Current or Trip). For more information, refer to the UCS1002 Data Sheet and AN24.14 - "UCS1002 Fundamentals of Custom Charger Emulation" (DS20005234).




FIGURE 4-12: Custom Charging Tab.

4.3.3.1 CUSTOM EMULATION CONFIGURATION

Creating a custom emulation profile is a two-part process of entering the appropriate stimulus-response pairs in the provided fields, as well as the desired current limiting behavior (after emulation is applied and the portable device starts to draw current).

4.3.3.1.1 Example

Settings shown in Figure 4-12 will apply the Legacy 1 stimulus pair. This includes a voltage divider on DP and on DM with the values shown in the STEP 5 column.

If the portable device draws bus current greater than the charging threshold being used, it will always operate in Current Limiting Trip mode (with trip point based on the current limit setting).

4.3.3.2 CUSTOM CURRENT LIMITING BEHAVIOR

The second part of creating custom profiles is to specify the behavior of current limiting and minimum voltage output. This is accomplished using the Ibus_r2min and Vbus_Min drop-down lists, as shown in [Figure 4-13](#).




FIGURE 4-13: Current-Voltage Behavior Selection.

4.3.3.3 CUSTOM EMULATION QUICK LOAD

The Custom Emulation Quick Load drop-down menu allows single-click loading of the Custom Emulation Configuration registers. Simply select the profile to load from the menu and registers 41h – 4Ch will be loaded with that profile. Emulation Timeout will also be loaded based on the settings of the corresponding Emulation Timeout on the **Configuration & General Status** tab.

4.3.3.4 SAVE CUSTOM EMULATION CONFIGURATION

Customs Emulation Configuration allows for a quick way to save to a file the necessary registers to configure the UCS1002 for a custom profile. Enter the path and press the **SAVE** button. Files will be overwritten if duplicate file names are used.

Registers 40h – 4Ch (Custom Emulation Configuration - **Custom Charging** tab), 16h (Emulation Behavior - **Configuration** tab), 19h (ILIM - **Main** tab), 25h (High Speed Switch Configuration - **Configuration** tab) and 51h (Custom Current Limiting Behavior - **Custom Charging** tab) will be saved in a two-column format. Comments can be added at the end of the file for documentation.

UCS1002 Evaluation Board User's Guide

4.3.4 Register Set Tab

The **Register Set** tab (Figure 4-14) allows viewing and updating of the UCS1002 registers, identifies the device on the evaluation board and manages configuration files.




FIGURE 4-14: Register Set Tab.

4.3.4.1 REGISTER CONTENT

Register Content shown in Figure 4-14 is a scrollable list of the UCS1002 registers and the current value. It is important to note that not all addresses are physical memory locations on the device; these registers will read '0'. Likewise, some registers shown that are undocumented in the data sheet may contain data. Editing these registers can cause unexpected results.

To update a register value, locate the register address in the left column, type the new value in the corresponding cell in the right column and press **Enter** on the keyboard or click outside the editable field to complete the action.

4.3.4.1.1 Numbering Systems Views

The Register Content section allows values to be displayed using different numbering systems: Decimal, Hex, Octal, Binary or SI Notation. To view a value using a different numbering system, click the indicator (x) to the left of the value in the cell (Figure 4-15).




FIGURE 4-15: Numbering System Indicators.

4.3.4.2 PRODUCT INFORMATION

Product Information panel shows the values of three registers (FDh, FEh and FFh) which identify the device on the evaluation board.

4.3.4.3 GUI INFORMATION

Check for GUI Update requires an Internet connection. When this button is pressed, it will check if the current version is up to date and will automatically download a .zip file if out of date.

The **Documentation** button will launch a Windows file viewer, opening the local folder containing the current evaluation board documentation.

4.3.4.4 CONFIGURATION SAVE AND LOAD

The **Register Set** tab contains controls (Figure 4-16) which save the settings currently configured in the UCS1002 to allow quick reconfiguration at any time.




FIGURE 4-16: Save/Load Section.

To save configuration settings, configure the UCS1002 as desired, then display the **Register Set** tab. Type a path in the “File Stored Path” field or press the **Browse** button to select the folder where the configuration file will be saved. The file should be named with the .txt extension or with a similar text file format. Once a file name and location has been chosen, click the **Save All Register Values** switch and the file is saved.

Note: If a file with the same name already exists, it will be overwritten and the old data will be lost.

The data is saved in two columns separated by tabs. The first column is the register address and the second column is the register data.

Once a file is saved, it can be recalled at any time by selecting the file in the “File Load Path” field and by clicking the **Load All Register Values** switch.

UCS1002 Evaluation Board User's Guide

4.3.5 Demo Tab

The **Demo** tab (Figure 4-17) demonstrates external controller logic to apply custom emulation profiles and optimize charging current. This feature uses the LabView engine to step through the selected files and store the current drawn by the device. Several options are available to customize the operation of the demo and explore the potential of the UCS1002.




FIGURE 4-17: Demo Tab.

4.3.5.1 STEP 1: CONFIGURE DEVICE FOR DEMO ROUTINE

The first step in preparing to run the Demo feature is to configure the device to the desired starting configuration. A file has been preloaded at installation and is ready to be used, or a new configuration can be created. Each time the **Demo** button (in the **Panel Control** section) is toggled, the `Setup.txt` file will be loaded.

4.3.5.2 STEP 2: DEFINE CUSTOM EMULATION CONFIGURATIONS

At installation, a set of files are preloaded on the user's system (`profile1.txt` – `profile6.txt`) with the default profiles of the UCS1002. These files can be changed easily by using the **Custom Charging** tab.

4.3.5.2.1 Active Files

Check the corresponding check box to activate the desired profile in the demo routine.

4.3.5.2.2 Custom Emulation Files

This column contains the full path to the profile file to be loaded. This file should contain registers 40h – 4Ch, 16h and 25h. This file can be created with the GUI on the **Custom Charging** tab.

4.3.5.2.3 Current Reading

This column displays the current being drawn from the attached device. If End Value is selected (from the Demo Options section, Current Reading features), this will update continuously. If MAX Value is selected, this will store the highest value of current during the dwell time.

4.3.5.2.4 Dwell Time

Dwell Time column defines the amount of time from PWR_EN set to PWR_EN unset. The default is 8 seconds, which has been found to work with most devices and profiles. Each profile can have a different Dwell Time.

4.3.5.3 DEMO OPTIONS

TABLE 4-2: DEMO OPTIONS DESCRIPTION

Options	Description
Repeat if 0 mA	When this option is set, it will repeat if all of the profiles read 0 mA, i.e. no device connected.
Repeat Forever	When set, it will repeat the set of files until unchecked.
Dead Batt. Repeat	When set, it will start the demo after the initial cycle after the specified Dead Batt. Delay time. This is useful when the battery is completely discharged and the device OS is unable to handshake with UCS1002.
Dead Batt. Delay	This option is defined in minutes. Minimum is 0 minutes, maximum is 10 minutes.
Current Reading	Select either the End Value (last value before PWR_EN set low) or MAX Value (highest value during Dwell Time).

4.3.5.4 CUSTOM FILE PATH QUICK LOAD

When starting the UCS1002 interface, the file paths are reset to a default path. If desired, the user may save the files in an alternate location. This quick load feature saves the paths of the `Setup.txt` and all six profile locations to quickly return or change files with one click.

4.3.5.5 RUNNING THE DEMO

Once the files and settings are configured as desired, enable the Demo routine by pressing the **Demo** switch within the Panel Controls area. The routine begins and the results are displayed in Profile MAX and Current MAX. By default, the Demo routine will enable the profile that is indicated by Profile MAX.

- **Profile MAX:** Stores the profile of the highest value of current draw.
- **Current MAX:** Stores the highest current associated with the Profile MAX #.

Note: The **Demo** tab does not need to be visible to activate the Demo routine.

UCS1002 Evaluation Board User's Guide

4.4 TROUBLESHOOTING

Table 4-3 identifies possible problems and their solutions to troubleshoot the UCS1002 software.

TABLE 4-3: TROUBLESHOOTING THE INTERFACE - COMMON PROBLEMS

Problem	Solution
GUI Controls Unresponsive After Installation	Restart the computer. In some cases, a restart is required after installation.
GUI Freezes	If the GUI freezes for unknown reasons, communications cannot be stopped and the program cannot be closed, disconnect the USB cable from the evaluation board, then close the program. Reconnect the board, then restart the GUI.
Random Panel Display	When a board is not connected to the PC running the GUI, the panel will be in an all-zero register-displayed state. This also occurs when SMBus communications are disconnected. The panel display is not meaningful. Connect the board and establish SMBus communications. If this still does not work, there is a problem with the connection. The cable or the USB port may be defective.
Device Is Not Charging or Not Charging Optimally	<ul style="list-style-type: none">• Check if the current limit jumper is set appropriately.• The current source may not have high enough capacity from V_S.• Run the Demo routine to determine highest current profile.



UCS1002 EVALUATION BOARD USER'S GUIDE


Appendix A. Schematic and Layouts

A.1 INTRODUCTION


This appendix contains the following schematics and layouts for the UCS1002 Evaluation Board:

- Board – Schematic
- Board – Top Silk
- Board – Top Solder Mask
- Board – Top Copper
- Board – 2nd Layer Copper
- Board – 3rd Layer Copper
- Board – Bottom Copper
- Board – Bottom Solder Mask
- Board – Bottom Silk


A.2 BOARD - SCHEMATIC



A.3 BOARD – TOP SILK




A.4 BOARD – TOP SOLDER MASK




UCS1002 Evaluation Board User's Guide


A.5 BOARD – TOP COPPER




A.6 BOARD – 2ND LAYER COPPER



A.7 BOARD – 3RD LAYER COPPER




A.8 BOARD – BOTTOM COPPER




UCS1002 Evaluation Board User's Guide

A.9 BOARD – BOTTOM SOLDER MASK



A.10 BOARD – BOTTOM SILK



Appendix B. Bill of Materials

TABLE B-1: BILL OF MATERIALS (BOM)

Qty.	Reference	Description	Manufacturer	Part Number
4	B1 – B4	Bumper Black 3705.19" cylinder	Richco [®] , Inc.	RBS-35BK
5	C1, C2, C5, C8, C13	Capacitor ceramic 0.1 µF 50V 10% X7R 0603	Murata Electronics [®]	GRM188R71H104KA93D
1	C3	Capacitor ceramic 0.01 µF 16V 10% X7R 060	Panasonic [®] - ECG	ECJ-1VB1C103K
2	C4, C14	Capacitor tantalum low ESR 10 µF 10V 10% S	AVX Corporation	TPSA106K010R0900
2	C6, C9	Capacitor ceramic 1.0 µF 50V Y5V 0805	TDK Corporation	C2012Y5V1H105Z
2	C11, C12	Capacitor ceramic 470 pF 50V 10% X7R 0603	Murata Electronics	GRM188R71H471KA01D
1	C15	Capacitor tantalum low ESR 150 µF 10V 10% SMD	AVX Corporation	TPSD157K010R0100
1	C26	Capacitor ceramic 1.0 µF 16V DC 10% X5R 06	Panasonic - ECG	ECJ-1VB1C105K
3	D1, D2, D6	TVS 260W 5.0V Unidirect. SOD-523	Diodes [®] Incorporated	T5V0S5-7
2	D4, D5	TVS Zener Bidirectional 5V SOD-882	NXP Semiconductors	PESD5V0X1BL
5	EGND1 – EGND3, SGND1, SGND2	Test Point	Keystone Electronics Corp.	5015
1	J2	Receptacle, USB, Style B, right angle	TE Connectivity, Ltd.	292304-1
1	J3	Connector power jack 5.5 MM X, 2.5A, RA	Switchcraft [®]	RAPC722X
10	J4, J6, J11, J15, J16, J18	Header, 1 X 2, 0.1 inch, vertical	Molex [®]	22-28-4020
1	J5	Header, 1 X 2, 0.1 inch, vertical - DO NOT POPULATE	Molex	22-28-4020
4	J12 – J14, J17	Header, 2 X 8, 0.1 inch, vertical	Samtec, Inc.	TSW-108-07-L-D
1	L1	Choke Common mode 330MA 900 HM	Murata Electronics	DLW21HN900SQ2L
2	LED2, LED3	LED Yellow 0603	Stanley Electric Co., Ltd.	AY1111C-TR
1	LED4	LED Red Clear 0603 SMT	Lite-On [®] , Inc.	LTST-C190CKT
1	LED5	LED Green SMT	Stanley Electric Co., Ltd.	BG1111C-TR
2	P1, P4	Receptacle, USB, Style B, right angle	FCI	87520-0010BLF
1	P2	Connector header 8 POS 2MM RT ang. Gold	Molex	87833-0820
1	P3	Connector Recept. USB Mini B R/A 5 POS SMD	Molex	54819-0572
1	PCB	UCS1002 Evaluation Board - Printed Circuit Board	Microchip Technology Inc.	PCB-8106-B0

Note 1: The components listed in this Bill of Materials are representative of the PCB assembly. The released BOM used in manufacturing uses all RoHS-compliant components.

UCS1002 Evaluation Board User's Guide

TABLE B-1: BILL OF MATERIALS (BOM) (CONTINUED)

Qty.	Reference	Description	Manufacturer	Part Number
8	R1 – R3, R6 – R7, R12, R44	Resistor 10.0 K Ohm 1/10W 1% 0603	Yageo Corporation	RC0603FR-0710KL
1	R4	Resistor 10.0 K Ohm 1/10W 1% 0603 - DO NOT POPULATE	Yageo Corporation	RC0603FR-0710KL
2	R8, R9	Resistor 2.2 K Ohm 1/10W 5% 0603 SMD	Panasonic - ECG	ERJ-3GEYJ222V
12	R10, R33, R38 – R41, R58 – R62, R70 – R71	Resistor Zero Ohm 1/10W 5% 0603 - DO NOT POPULATE	Yageo Corporation	RC0603JR-070RL
7	R11, R26, R27, R32, R36 – R37, R42	Resistor Zero Ohm 1/10W 5% 0603	Yageo Corporation	RC0603JR-070RL
2	R13, R45	Resistor 12.0 K Ohm 1/10W 1% 0603	Yageo Corporation	RC0603FR-0712KL
2	R14, R46	Resistor 15.0 K Ohm 1/10W 1% 0603 SMD	Yageo Corporation	RC0603FR-0715KL
2	R15, R47	Resistor 18.0 K Ohm 1/10W 1% 0603	Yageo Corporation	RC0603FR-0718KL
2	R16, R48	Resistor 22.0 K Ohm 1/16W 1% 0603 SMD	Yageo Corporation	RC0603FR-0722KL
2	R17, R50	Resistor 27.0 K Ohm 1/16W 1% 0603 SMD	Vishay Intertechnology, Inc.	CRCW060327K0FKEA
2	R18, R49	Resistor 33 K Ohm 1/10W 1% 0603	Yageo Corporation	RC0603FR-0733KL
2	R19, R51	Resistor 47.0 K Ohm 1/10W 1% 0603 SMD	Yageo Corporation	RC0603FR-0747KL
2	R20, R52	Resistor 56 K Ohm 1/10W 5% 0603 SMD	Yageo Corporation	RC0603JR-0756KL
2	R21, R53	Resistor 68.0 K Ohm 1/10W 1% 0603 SMD	Yageo Corporation	RC0603FR-0768KL
2	R22, R54	Resistor 82.0 K Ohm 1/10W 1% 0603 SMD	Yageo Corporation	RC0603FR-0782KL
2	R23, R55	Resistor 100 K Ohm 1/10W 1% 0603	Yageo Corporation	RC0603JR-07100KL
2	R24, R56	Resistor 120 K Ohm 1/10W 1% 0603 SMD	Yageo Corporation	RC0603FR-07120KL
2	R25, R57	Resistor 150 K Ohm 1/10W 1% 0603 SMD	Yageo Corporation	RC0603FR-07150KL
3	R28, R29 R31	Resistor 330 Ohm 1/16W 3300PPM 5% 0603	Panasonic - ECG	ERA-V33J331V
1	R30	Resistor 2.00 K Ohm 1/10W 1% 0603 SMD	Yageo Corporation	RC0603FR-072KL
2	R34, R35	Resistor 33 Ohm 1/10W 5% 0603	Yageo Corporation	RC0603JR-0733RL
3	R63 – R65	Resistor 1.00 K Ohm 1/10W 1% 0603 SMD	Yageo Corporation	RC0603FR-071KL
4	R66 – R69	Resistor 1.00 M Ohm 1/16W 1% 0402 SMD	Yageo Corporation	RC0402FR-071ML
13	S1 – S13	Connector shunt 0.1" w/ handle	TE Connectivity, Ltd.	881545-2

Note 1: The components listed in this Bill of Materials are representative of the PCB assembly. The released BOM used in manufacturing uses all RoHS-compliant components.

TABLE B-1: BILL OF MATERIALS (BOM) (CONTINUED)

Qty.	Reference	Description	Manufacturer	Part Number
2	TP10, TP16	Test Point loop compact Yellow	Keystone Electronics Corp.	5009
2	TP11, TP14	Test Point loop compact Green	Keystone Electronics Corp.	5121
1	U1	UCS1002 – Programmable USB Port Power Controller with Charger Emulation	Microchip Technology Inc.	UCS1002
1	U3	IC 8051 MCU Flash 64K 48 TQFP	Silicon Laboratories® Inc.	C8051F340-GQ
1	—	5V AC-DC > 500 mA wall adapter with positive center 2.1mm I.D. x 5.5mm O.D. x 10mm Female cord plug	Phihong USA Corporation	PSAA20R-050

Note 1: The components listed in this Bill of Materials are representative of the PCB assembly. The released BOM used in manufacturing uses all RoHS-compliant components.



MICROCHIP

Worldwide Sales and Service

AMERICAS

Corporate Office

2355 West Chandler Blvd.
Chandler, AZ 85224-6199
Tel: 480-792-7200
Fax: 480-792-7277
Technical Support:
<http://www.microchip.com/support>

Web Address:

www.microchip.com

Atlanta

Duluth, GA
Tel: 678-957-9614
Fax: 678-957-1455

Austin, TX

Tel: 512-257-3370

Boston

Westborough, MA
Tel: 774-760-0087
Fax: 774-760-0088

Chicago

Itasca, IL
Tel: 630-285-0071
Fax: 630-285-0075

Cleveland

Independence, OH
Tel: 216-447-0464
Fax: 216-447-0643

Dallas

Addison, TX
Tel: 972-818-7423
Fax: 972-818-2924

Detroit

Novi, MI
Tel: 248-848-4000

Houston, TX

Tel: 281-894-5983

Indianapolis

Noblesville, IN
Tel: 317-773-8323
Fax: 317-773-5453

Los Angeles

Mission Viejo, CA
Tel: 949-462-9523
Fax: 949-462-9608

New York, NY

Tel: 631-435-6000

San Jose, CA

Tel: 408-735-9110

Canada - Toronto

Tel: 905-673-0699
Fax: 905-673-6509

ASIA/PACIFIC

Asia Pacific Office

Suites 3707-14, 37th Floor
Tower 6, The Gateway
Harbour City, Kowloon

Hong Kong

Tel: 852-2943-5100
Fax: 852-2401-3431

Australia - Sydney

Tel: 61-2-9868-6733
Fax: 61-2-9868-6755

China - Beijing

Tel: 86-10-8569-7000
Fax: 86-10-8528-2104

China - Chengdu

Tel: 86-28-8665-5511
Fax: 86-28-8665-7889

China - Chongqing

Tel: 86-23-8980-9588
Fax: 86-23-8980-9500

China - Dongguan

Tel: 86-769-8702-9880

China - Hangzhou

Tel: 86-571-8792-8115
Fax: 86-571-8792-8116

China - Hong Kong SAR

Tel: 852-2943-5100
Fax: 852-2401-3431

China - Nanjing

Tel: 86-25-8473-2460
Fax: 86-25-8473-2470

China - Qingdao

Tel: 86-532-8502-7355
Fax: 86-532-8502-7205

China - Shanghai

Tel: 86-21-5407-5533
Fax: 86-21-5407-5066

China - Shenyang

Tel: 86-24-2334-2829
Fax: 86-24-2334-2393

China - Shenzhen

Tel: 86-755-8864-2200
Fax: 86-755-8203-1760

China - Wuhan

Tel: 86-27-5980-5300
Fax: 86-27-5980-5118

China - Xian

Tel: 86-29-8833-7252
Fax: 86-29-8833-7256

ASIA/PACIFIC

China - Xiamen

Tel: 86-592-2388138
Fax: 86-592-2388130

China - Zhuhai

Tel: 86-756-3210040
Fax: 86-756-3210049

India - Bangalore

Tel: 91-80-3090-4444
Fax: 91-80-3090-4123

India - New Delhi

Tel: 91-11-4160-8631
Fax: 91-11-4160-8632

India - Pune

Tel: 91-20-3019-1500

Japan - Osaka

Tel: 81-6-6152-7160
Fax: 81-6-6152-9310

Japan - Tokyo

Tel: 81-3-6880-3770
Fax: 81-3-6880-3771

Korea - Daegu

Tel: 82-53-744-4301
Fax: 82-53-744-4302

Korea - Seoul

Tel: 82-2-554-7200
Fax: 82-2-558-5932 or
82-2-558-5934

Malaysia - Kuala Lumpur

Tel: 60-3-6201-9857
Fax: 60-3-6201-9859

Malaysia - Penang

Tel: 60-4-227-8870
Fax: 60-4-227-4068

Philippines - Manila

Tel: 63-2-634-9065
Fax: 63-2-634-9069

Singapore

Tel: 65-6334-8870
Fax: 65-6334-8850

Taiwan - Hsin Chu

Tel: 886-3-5778-366
Fax: 886-3-5770-955

Taiwan - Kaohsiung

Tel: 886-7-213-7828

Taiwan - Taipei

Tel: 886-2-2508-8600
Fax: 886-2-2508-0102

Thailand - Bangkok

Tel: 66-2-694-1351
Fax: 66-2-694-1350

EUROPE

Austria - Wels

Tel: 43-7242-2244-39
Fax: 43-7242-2244-393

Denmark - Copenhagen

Tel: 45-4450-2828
Fax: 45-4485-2829

France - Paris

Tel: 33-1-69-53-63-20
Fax: 33-1-69-30-90-79

Germany - Dusseldorf

Tel: 49-2129-3766400

Germany - Karlsruhe

Tel: 49-721-625370

Germany - Munich

Tel: 49-89-627-144-0
Fax: 49-89-627-144-44

Italy - Milan

Tel: 39-0331-742611
Fax: 39-0331-466781

Italy - Venice

Tel: 39-049-7625286

Netherlands - Drunen

Tel: 31-416-690399
Fax: 31-416-690340

Poland - Warsaw

Tel: 48-22-3325737

Spain - Madrid

Tel: 34-91-708-08-90
Fax: 34-91-708-08-91

Sweden - Stockholm

Tel: 46-8-5090-4654

UK - Wokingham

Tel: 44-118-921-5800
Fax: 44-118-921-5820

07/14/15

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for [Power Management IC Development Tools](#) category:

Click to view products by [Microchip](#) manufacturer:

Other Similar products are found below :

[EVB-EP5348UI](#) [MIC23451-AAAYFL EV](#) [MIC5281YMME EV](#) [124352-HMC860LP3E](#) [DA9063-EVAL](#) [ADP122-3.3-EVALZ](#) [ADP130-0.8-EVALZ](#) [ADP130-1.8-EVALZ](#) [ADP1740-1.5-EVALZ](#) [ADP1870-0.3-EVALZ](#) [ADP1874-0.3-EVALZ](#) [ADP199CB-EVALZ](#) [ADP2102-1.25-EVALZ](#) [ADP2102-1.875EVALZ](#) [ADP2102-1.8-EVALZ](#) [ADP2102-2-EVALZ](#) [ADP2102-3-EVALZ](#) [ADP2102-4-EVALZ](#) [AS3606-DB](#) [BQ25010EVM](#) [BQ3055EVM](#) [ISLUSBI2CKIT1Z](#) [LP38512TS-1.8EV](#) [EVAL-ADM1186-1MBZ](#) [EVAL-ADM1186-2MBZ](#) [ADP122UJZ-REDYKIT](#) [ADP166Z-REDYKIT](#) [ADP170-1.8-EVALZ](#) [ADP171-EVALZ](#) [ADP1853-EVALZ](#) [ADP1873-0.3-EVALZ](#) [ADP198CP-EVALZ](#) [ADP2102-1.0-EVALZ](#) [ADP2102-1-EVALZ](#) [ADP2107-1.8-EVALZ](#) [ADP5020CP-EVALZ](#) [CC-ACC-DBMX-51](#) [ATPL230A-EK](#) [MIC23250-S4YMT EV](#) [MIC26603YJL EV](#) [MIC33050-SYHL EV](#) [TPS60100EVM-131](#) [TPS65010EVM-230](#) [TPS71933-28EVM-213](#) [TPS72728YFFEVM-407](#) [TPS79318YEQEVM](#) [UCC28810EVM-002](#) [XILINXPWR-083](#) [LMR22007YMINI-EVM](#) [LP38501ATJ-EV](#)