



Quick Start Guide

i.MX RT1010 Evaluation Kit




## GET TO KNOW THE i.MX RT1010 EVK

**TABLE 1: BOOT OPTIONS**

BOOT_MODE[1:0](SW8-3 SW8-4)		BOOT Type		
00		Boot From Fuses (The boot ROM code uses the boot eFUSE settings only)		
01		Serial Downloader(Download a Program Image to the chip over USB or UART)		
10		Internal Boot (Execute the boot code from the internal boot ROM)		
11		Reserved		

SW8-1	SW8-2	SW8-3	SW8-4	Boot Device
OFF	OFF	ON	OFF	QSPI FLASH



**Figure 1: Front side of MIMXRT1010-EVK**

## HOW TO GET STARTED

- 1** The evaluation kit is shipped with a MIMXRT1010-EVK and a USB cable (Micro B).
- 2** Connect the MIMXRT1010-EVK board to a PC using the included micro USB cable to USB connector J41.  
  
The MIMXRT1010 EVK comes preprogrammed with a demo which flashes the LED on the board.
- 3** Explore more out-of-box demos and download software and tools on [www.nxp.com/MIMXRT1010-EVK/startnow](http://www.nxp.com/MIMXRT1010-EVK/startnow).
- 4** Enjoy your design freedom with the MIMXRT1010-EVK.

## SUPPORT

Visit [www.nxp.com/support](http://www.nxp.com/support) for a list of phone numbers within your region.

## WARRANTY

Visit [www.nxp.com/warranty](http://www.nxp.com/warranty) for complete warranty information.



## Get Started

Download installation software and documentation at [www.nxp.com/MIMXRT1010-EVK](http://www.nxp.com/MIMXRT1010-EVK).

---

[www.nxp.com](http://www.nxp.com)

NXP and the NXP logo are trademarks of NXP B.V. All other product or service names are the property of their respective owners. © 2019 NXP B.V.

Document Number: IMXRT1010EVKQSG REV 0  
Agile Number: 926-45852 Rev A

## X-ON Electronics

Largest Supplier of Electrical and Electronic Components

*Click to view similar products for [Development Boards & Kits - ARM category](#):*

*Click to view products by [NXP manufacturer](#):*

Other Similar products are found below :

[SAFETI-HSK-RM48](#) [PICOHOBBITFL](#) [CC-ACC-MMK-2443](#) [TWR-MC-FRDMKE02Z](#) [EVALSPEAR320CPU](#) [MAX32600-KIT#](#)  
[TMDX570LS04HDK](#) [TXSD-SV70](#) [OM13080UL](#) [EVAL-ADUC7120QSPZ](#) [OM13082UL](#) [TXSD-SV71](#) [YGRPEACHNORMAL](#)  
[OM13076UL](#) [PICODWARFFL](#) [YR8A77450HA02BG](#) [3580](#) [32F3348DISCOVERY](#) [ATTINY1607](#) [CURIOSITY NANO](#) [PIC16F15376](#)  
[CURIOSITY NANO BOARD](#) [PIC18F47Q10](#) [CURIOSITY NANO](#) [VISIONSTK-6ULL V.2.0](#) [80-001428](#) [DEV-17717](#) [EAK00360](#)  
[YR0K77210B000BE](#) [RTK7EKA2L1S00001BE](#) [SLN-VIZN-IOT](#) [LV18F V6 DEVELOPMENT SYSTEM](#) [READY FOR AVR BOARD](#)  
[READY FOR PIC BOARD](#) [READY FOR PIC \(DIP28\)](#) [AVRPLC16 V6 PLC SYSTEM](#) [MIKROLAB FOR AVR XL](#) [MIKROLAB FOR PIC L](#)  
[MINI-AT BOARD - 5V](#) [MINI-M4 FOR STELLARIS](#) [MOD-09.Z](#) [BUGGY + CLICKER 2 FOR PIC32MX + BLUETOOT](#) [1410](#) [LETS](#)  
[MAKE PROJECT PROGRAM. RELAY PIC](#) [LETS MAKE - VOICE CONTROLLED LIGHTS](#) [LPC-H2294](#) [DSPIC-READY2 BOARD](#)  
[DSPIC-READY3 BOARD](#) [MIKROBOARD FOR ARM 64-PIN](#) [MIKROLAB FOR AVR](#) [MIKROLAB FOR AVR L](#) [MIKROLAB FOR](#)  
[DSPIC](#) [MIKROLAB FOR DSPIC XL](#)