



# Quick Start Guide

## EK-F3x-CAP

# Quick Start Guide EK-F3-CAP

- 1 **Install FTDI USB driver** for the sensor cable:

[www.ftdichip.com/Drivers/VCP.htm](http://www.ftdichip.com/Drivers/VCP.htm)


- 2 **Install sensiviewer software** after download from:

[www.sensirion.com/USB-viewer](http://www.sensirion.com/USB-viewer)


- 3 **Connect the USB sensor cable** to the sensor PCB and the PC.

- 4 **Start up the USB RS485 Sensor Viewer.**

- 5 **Select Sensirion Flow Meters (SF05 Chip)** from Sensor Product.




- 6 **Select RS485 / USB Sensor Cable** from COM Hardware.



## 7 Choose COM Port Settings

Select **COM Port** and press „**OK**“. Highest COM port is most often correct (your COM port may have a different number it should be the one corresponding to the USB serial port. The viewer window should open.




The image shows a 'Product Selection' dialog box with the following settings:

- Sensor Product: Sensirion Flow Meters (SF05 Chip)
- COM Hardware: RS485/USB Sensor Cable
- COM Port Settings: Port: COM4
- Echo On (Halfduplex):
- RS485 Device Settings: Baudrate: 115200
- Fixed Address:  0
- Scan until first Device found:
- Scan all (0...254):

Buttons: Cancel, OK

- 8 Select the desired **heater power** for the additional heater (see sensor datasheet for details of this option). If option is not needed or you don't know what it is use 0 %.



The image shows the 'Flow Meter (SF05 Chip) Viewer' window with the following settings:

- Measurement Control: Run, Stop, Sampling Time (ms): 0
- Type of Measurement: Flow [Lin]
- Timing Information:  Relative  Absolute
- Product Settings: Scale Factor Flow: 120, Serial Number: 0016290174, Resolution (bit): 14, Interface: RS485 (Adr: 0), Scale Factor Temp: 100, FW Version: 1.8, Offset Flow: 32768, Offset Temp: 20000, I2C Address: 64, Ext. Heater: 0 %
- Data Logging: Select File, C:\Temp\DataLog.csv
- Measure Graph:  Display OFF,  Show X-Axis, Autoscale, Flow lin: -, Effective Sampling Time: -

The 'Ext. Heater' dropdown menu is open, showing options: 0 %, 25 %, 50 %, 75 %, 100 %.

9 Press „Run“ to start the program.





## X-ON Electronics

Largest Supplier of Electrical and Electronic Components

*Click to view similar products for [Multiple Function Sensor Development Tools](#) category:*

*Click to view products by [Sensirion](#) manufacturer:*

Other Similar products are found below :

[MAXWSNENV#](#) [STEVAL-MKIT01V1](#) [KT-O2-25%-TB200A-E](#) [KT-TVOC-200-TB200A](#) [KT-NmHc-200-TB200A](#) [SEN0344](#) [PIM520](#)  
[PIM518](#) [PIM519](#) [PIM502](#) [AS7022-EVALKIT](#) [ALTEHTG2SMIP](#) [MAX30101WING#](#) [OB1203SD-U-EVK](#) [MIKROE-4265](#) [A000070](#)  
[EV\\_ICG-20660L](#) [GX-F12A-P](#) [GX-F15A](#) [GX-F8AI-P](#) [GX-H15AI-P](#) [GX-H6A-P](#) [GX-HL15B-P](#) [1093](#) [MIKROE-2455](#) [MIKROE-2458](#)  
[MIKROE-2507](#) [MIKROE-2508](#) [MIKROE-2516](#) [MIKROE-2529](#) [1458](#) [MIKROE-1628](#) [176](#) [189](#) [1893](#) [2106](#) [ATQT4-XPRO](#) [GP30-DEMO](#)  
[MODULE](#) [GX-F12AI-P](#) [GX-F15A-P](#) [GX-FL15B-P](#) [GX-H12AI-P](#) [GX-H15A-P](#) [GX-H6AI-P](#) [GX-H8A-P](#) [GX-F15AI-P](#) [GX-FL15A-P](#) [AAS-](#)  
[AQS-UNO](#) [DFR0018](#) [DFR0131](#)