

iJA Evaluation Kit Operators Guide



This Guide shows you how to Get Started and use your IJA Evaluation System.

Please contact to TDK-Lambda if you have any questions or need further product details.


Note: The GUI software is provided on a CD-ROM and is also available at <http://www.us.tdk-lambda.com/lp/contacts/gui-download-page/>. If downloading from the web, registration is required.

TDK - Lambda Americas Inc.

401 Mile of Cars Way, Suite 325
National City, California 91950

Phone 1-800-526-2324
www.us.tdk-lambda.com/lp

iJA Evaluation Kit Contents




Install Smart Power GUI Interface Tool



The Interface tool allows the user to configure and operate the iJA device via the PMBus. Install as shown.



1.Put attached CD-ROM into your PC



2. Run "Power_Smart_xxxxx.exe" Application

*Require Windows XP or later



A icon will appear on your desktop after install.

Please check latest version on our website

<http://www.us.tdk-lambda.com/lp/contacts/gui-download-page/>

iJA Eval Board Installation



- **System requirements**

- Windows XP, Windows 7 (32bit or 64bit)
- Java
- Free USB port

- **GUI installation**

- Do not connect USB cable !
- Install “SmartPower_1.1_20130926_win32-setup.exe”
- Follow the instruction by the installer
- Close GUI

- **Evaluation board set-up**

- Apply 12V source to the Vin terminal (see picture 1)
- Connect USB cable to board and PC
- Driver will be installed

About the iJA



TDK-Lambda

iJA Series

100W, 35A Non-isolated SMT Point of Load with PMBus

Features

- ◆ Only 0.45 in² Board Space
- ◆ PMBus Compliant (Read & Write)
- ◆ Surface Mountable
- ◆ Digital Adaptive Control
- ◆ Parallel Operation with Current Sharing
- ◆ Configurable Sequence & Fault Management



Key Market Segments & Applications




Vo: 0.6 to 3.3 Volts

100 Watts

35 Amps

About the EVAL Board




Connect It Up



Connect
Dongle to
Eval Board

Switch in
“OPEN”
Position




8.0 to 14 VDC
**Observe
Polarity!**

Connect
Resistive Load


Power It Up / Run the GUI - Basic



- Energize the Eval Board
- Open the GUI
- Cycle Power Switch to “Short” Position



GUI Features



Status and Fault Indicators

green except during NVM storage operation

shows if the module is ON or OFF

indicates if V_{out} is within the limits

green when V_{in} is lower than set limit in the fault section

green when V_{in} is higher than set limit in the fault section

green when V_{out} is lower than set limit in the fault section

loss of sense, when V_{sense} is lost module will be set OFF

green when V_{out} is higher than set limit in the fault section

green when I_{out} is lower than set limit in the fault section

green when short circuit protection has not been active

green when Temp. is lower than set limit in the fault section

green when Temp. is lower than set limit in the fault section

green when Temp. is higher than set limit in the fault section

green when Temp. is higher than set limit in the fault section

indicates invalid or unsupported data


indicates communication / memory / logic status

Clear Faults can be used to clear any previous fault flags that were raised

GUI Features (cont.)



The General Tab



GUI Features (cont.)



The Configure Tab - Basic

Configuration

Controls Output voltage Trim values, allowable maximum output voltages and scaling selection (internal or external).

Controls Ratiometric output voltages for non-parallel multiple device operation.


Controls Output voltage timing on power up and power down.

Sets incremental voltage margin control in percent.

On/Off Configuration

Establishes on/off hardware control features.

GUI Features (cont.)



- The Power Modules feature an internal voltage divider which can be disabled to enhance voltage setpoint accuracy when no attenuation is required. (output voltage 1.500 volts or lower). During startup the module will turn the divider on or off depending on the VOUT_OV_FAULT_LIMIT that was determined based on Rset value. With voltage attenuation off, VOUT_MAX = 1.6 V. With voltage attenuation on, VOUT_MAX = 3.5 V.
- If you want to change to higher voltage then you must turn voltage divider on (select 0.2857). This will happen automatically if resistor on Vset pin is changed so generally a user does not need to worry about this item, but in case of EV-kit they may need to turn on or off.

GUI Features (cont.)



The Configure Tab - Fault

The screenshot shows the 'Configure' tab selected in the top navigation bar. The 'Fault' sub-tab is active. On the left, there's a sidebar with 'Single Mode' and 'System Mode' buttons, and a 'PV3012 [0000:27]' device selection. Below that are 'Live parameter update' and 'Status' sections with indicators for 'BUSY', 'OFF', and 'Power Good'. A 'Faults' section lists various fault types with green status indicators. At the bottom is a 'Clear Faults' button.

Fault Limits	
Input OVLO Limit:	15.00 V
Input UVLO Turn-On Threshold:	7.60 V
Input UVLO Turn-Off Threshold:	7.00 V
Output OVP Limit:	3.500 V
Output OVP Response Delay:	40.00 µs
Output OVP Retry/Latch:	Retry
Output OCP Limit:	40 A
Output OCP Response Delay:	1500.0 µs
Output OCP Retry/Latch:	Retry
Output OCP Retry Delay:	500 ms
OTP Limit:	120 °C
UTP Limit:	-50 °C

Warning Limits	
Output UV Limit:	0.801 V
OT Limit:	110 °C
UT Limit:	-30 °C

Fault Limits

- Sets Values for Input Over Voltage Lock Out (OVLO), Output Over Voltage Protection, Output Overcurrent Protection (OCP) and Over/Under Temperature Protection (OTP and UTP).
- Once Fault limits are exceeded, device shuts down.

Warning Limits

- Sets Warning Limits for Output Under Voltage (UV), device Overtemperature (OT) and Undertemperature (UT).
- Warning thresholds do not cause shutdown of supply.

The Store Tab



General Configure Store

Default Settings

Storage Space Usage: 21% **Store** Restore Erase

Customer info

Customer Name: TDK (21)
Product ID: Digital POL Module (4)

⚠ Customer name and product ID fields can not be empty

Vout ~ Margins

Vout Setting: 1.500 V
Vout Trim: 0.000 V
Vout Max: 1.600 V
Vout Scale Loop: 1.0000
Vout Tracking: Off
Slew Rate: 1.042 mV/µs
ON Rise Time: 2.9 ms
ON Time Delay: 2.0 ms
OFF Time Delay: 0.0 ms
Upper Voltage Margin: 10.0 %
Lower Voltage Margin: -10.0 %

Current Sense ~ Power ~ Margining

Calibrated Current Sense Element (@ 25°C): 0.277 mΩ
Operation On/Off: On
 ⓘ CONTROL Pin Asserted required to turn unit on
Margining: None

On/Off Configuration

Requires OPERATION ON: Yes
Requires CTRL Pin Asserted: Yes
CTRL Pin Polarity: Active Low
CTRL Pin Off Action: Turn Off Delay

Control loop

Optimization Factor (Dynamic): 9 Lowest Transient

Digital Stress Share

Digital Stress Share: Off
DSS Auto-Zero: Disable
DSS Vout Correction Range: 100 mV
DSS Bandwidth: 10
Nominal Current Sense Element (@ 25°C): 0.28 mΩ

Fault Limits

Input OVLO Limit: 15.00 V
Input UVLO Turn-On Threshold: 7.60 V
Input UVLO Turn-Off Threshold: 6.80 V
Output OVP Limit: 1.600 V
Output OVP Delay: 40 µs
Output OVP Retry/Latch: Retry
Output OCP Limit: 118 A
Output OCP Delay: 300.0 µs
Output OCP Retry/Latch: Retry
Output OCP Retry Period: 500 ms
OTP Fault Limit: 135 °C
UTP Fault Limit: -40 °C

Warning Limits

Output UV Warning Limit: 0.801 V
OTP Warning Limit: 135 °C
UTP Warning Limit: -40 °C

ⓘ Dynamic phase dropping only applies to dual phase mode

Programmable Power Good

Programmable Power Good: 12 %

PMBus Address

PMBus Address: 0x 27

The NVM capacity on the iJX devices is limited; using the Store function is not advised.

Values can be changed in working memory without using the “store” command.

Exercise the Module



Exercise:

Change output voltage to 3.3 volts, Change Margin to 10%, Adjust On/Off Configuration.

Vout max: 3.400

Click Internal Rdiv On/Off

Set Margins to +10% and -10%.

Requires Operation ON: YES

Output OVP Limit: 3.600

Exercise the Module (cont.)



Single Mode
System Mode
PV3012 [0000:27]

Live parameter update

Status
BUSY (green)
OFF (red)
Power Good (orange)

Faults
Input OVLO (green)
Input UVLO (green)
Output OVP (green)
Output LOS (green)
Output UV (Warning) (green)
Output OCP (green)
SCP (green)
Phase Loss (green)
OTP (green)
OT (Warning) (green)
UTP (green)
UT (Warning) (green)
Invalid Data (green)
CML Fault (green)

General Configure Store

Monitoring

V _{IN} :	13.50 V
V _{OUT} :	0.009 V
I _{OUT} :	0.00 A
Internal Temp:	33.8 °C

Basic Settings

V _{OUT} Setting:	3.300 V	3.300 V
---------------------------	---------	---------

Calibrated Current Sense Element (@ 25°C): 0.732 mΩ 0.732 mΩ

Operation On/Off: **OPERATION** OFF

CONTROL Pin Asserted required to turn unison


Power Good:

Voltage Margining

Margining:	None	Low	High	OFF
Upper Voltage Margin:	3.630 V			
Lower Voltage Margin:	2.970 V			

Set output to 3.300 Volts

Press Operation Button



Exercise the Module (cont.)



From the General Tab:
Adjust the Margin from 1.00 Volt +10% and -10%

Voltage Margining

Margining:	<input checked="" type="radio"/> None	<input type="radio"/> Low	<input type="radio"/> High	OFF
Upper Voltage Margin:	1.100 V			
Lower Voltage Margin:	0.900 V			

Monitoring

V _{IN} :	13.49 V
V _{out} :	1.005 V
I _{out} :	3.32 A
Internal Temp:	32.0 °C

Voltage Margining

Margining:	<input type="radio"/> None	<input checked="" type="radio"/> Low	<input type="radio"/> High	LOW
Upper Voltage Margin:	1.100 V			
Lower Voltage Margin:	0.900 V			

Monitoring

V _{IN} :	13.50 V
V _{out} :	0.905 V
I _{out} :	2.99 A
Internal Temp:	31.7 °C

Voltage Margining

Margining:	<input type="radio"/> None	<input type="radio"/> Low	<input checked="" type="radio"/> High	HIGH
Upper Voltage Margin:	1.100 V			
Lower Voltage Margin:	0.900 V			

Monitoring


V _{IN} :	13.49 V
V _{out} :	1.103 V
I _{out} :	3.67 A
Internal Temp:	31.6 °C

Appendix




- iJA Eval Board Schematic
- iJA Eval Board Silkscreen
- iJA Eval Board BOM

Eval Board Schematic (iJA series)



Board Layout (iJA Series)



BOM (iJA Series)



BOM Ref Des	Description	Manufacturers, Mfr. Part Number	Manufacturer
C101	Capacitor	C3225X7R1C226MT	TDK
C102	Capacitor	C3225X7R1C226MT	TDK
C103	Capacitor	C3225X7R1C226MT	TDK
C104	Capacitor	C3225X7R1C226MT	TDK
C105	Capacitor	C3225X7R1C226MT	TDK
C106	Capacitor	C3225X7R1C226MT	TDK
C107	Capacitor	C3225X7R1C226MT	TDK
C108	Capacitor	C3225X7R1C226MT	TDK
C109	Capacitor	C3225X7R1C226MT	TDK
C110	Capacitor	C3225X7R1C226MT	TDK
C111	Capacitor	C3225X5R01107MT	TDK
C112	Capacitor	C3225X5R0J107MT	TDK
C113	Capacitor	C3225X5R0J107MT	TDK
C114	Capacitor	C3225X5R0J107MT	TDK
C115	Capacitor	C3225X5R0J107MT	TDK
C116	Capacitor	C3225X5R0J107MT	TDK
C117	Capacitor	C3225X5R0J107MT	TDK
C118	Capacitor	C3225X5R0J107MT	TDK
C119	Capacitor	C3225X5R0J107MT	TDK
C120	Capacitor	C3225X5R0J107MT	TDK
C32	Capacitor	C1608X7R1H104KT	TDK
CONN1	Connector	8196	Keystone
CONN2	Connector	8196	Keystone
CONN5	Connector	8196	Keystone
CONN6	Connector	8196	Keystone
CR31	Zener diode SOD323	BZX384-B5V1	NXP Semiconductor
J1	12 pin header	MC34771	Multi comp
PS1	Digital POL Module		TDK Lambda Americas Inc
PWB1	PWB		TDK Lambda Americas Inc
Q31	Transistor SOT323	MUN5135T1G	On semiconductor
Q32	Mosfet SOT323	RHU002N06	Rohm
R101	Resistor 0805	RK73H2ATTE1003F	KOA
R102	Resistor 0805	RK73H2ATTE1103F	KOA
R105	Resistor 0805	RK73Z2ATTE	KOA
R106	Resistor 0805	RK73Z2ATTE	KOA
R7	Resistor 0805	RK73Z2ATTE	KOA
R31	Resistor 0805	RK73H2ATTE1002F	KOA
R32	Resistor 0805	RK73H2ATTE1002F	KOA
R33	Resistor 0805	RK73H2ATTE1002F	KOA
R34	Resistor 0805	RK73H2ATTE1002F	KOA
SW31	Toggle switch	2AS3T2A1M2RE	Multi comp
TP1	Test pin	5014	Keystone
TP2	Test pin	5014	Keystone
TP3	Test pin	5014	Keystone
TP4	Test pin	5014	Keystone
TP5	Test pin	5011	Keystone
TP6	Test pin	5014	Keystone
TP7	Test pin	5014	Keystone
TP10	Test pin	5010	Keystone
TP11	Test pin	5011	Keystone
TP12	Test pin	5010	Keystone
TP13	Test pin	5011	Keystone

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Power Management IC Development Tools category:

Click to view products by TDK-Lambda manufacturer:

Other Similar products are found below :

[EVAL-ADM1168LQEBCZ](#) [EVB-EP5348UI](#) [MIC23451-AAAYFL EV](#) [MIC5281YMME EV](#) [DA9063-EVAL](#) [ADP122-3.3-EVALZ](#) [ADP130-0.8-EVALZ](#) [ADP130-1.2-EVALZ](#) [ADP130-1.5-EVALZ](#) [ADP130-1.8-EVALZ](#) [ADP1712-3.3-EVALZ](#) [ADP1714-3.3-EVALZ](#) [ADP1715-3.3-EVALZ](#) [ADP1716-2.5-EVALZ](#) [ADP1740-1.5-EVALZ](#) [ADP1752-1.5-EVALZ](#) [ADP1828LC-EVALZ](#) [ADP1870-0.3-EVALZ](#) [ADP1871-0.6-EVALZ](#) [ADP1873-0.6-EVALZ](#) [ADP1874-0.3-EVALZ](#) [ADP1882-1.0-EVALZ](#) [ADP199CB-EVALZ](#) [ADP2102-1.25-EVALZ](#) [ADP2102-1.875EVALZ](#) [ADP2102-1.8-EVALZ](#) [ADP2102-2-EVALZ](#) [ADP2102-3-EVALZ](#) [ADP2102-4-EVALZ](#) [ADP2106-1.8-EVALZ](#) [ADP2147CB-110EVALZ](#) [AS3606-DB](#) [BQ24010EVM](#) [BQ24075TEVM](#) [BQ24155EVM](#) [BQ24157EVM-697](#) [BQ24160EVM-742](#) [BQ24296MEVM-655](#) [BQ25010EVM](#) [BQ3055EVM](#) [NCV891330PD50GEVB](#) [ISLUSBI2CKIT1Z](#) [LM2744EVAL](#) [LM2854EVAL](#) [LM3658SD-AEV/NOPB](#) [LM3658SDEV/NOPB](#) [LM3691TL-1.8EV/NOPB](#) [LM4510SDEV/NOPB](#) [LM5033SD-EVAL](#) [LP38512TS-1.8EV](#)