


The PT5232, delivers position feedback via RS232 serial communication to your data acquisition or controller system. The PT5232 sends a raw 16-bit position count from 0000 to FFFF (hex). Additionally this device can be set to continuously send data or send data only when polled.

As the internal position sensing element is a precision potentiometer, this transducer maintains current accurate position even during power loss and does not need to be reset to a "home" position.

Output Signal



PT5232

Cable Actuated Sensor Industrial Grade • RS232

Absolute Linear Position to 250 inches (6350 mm)

Hard Anodized Aluminum Enclosure

High Cycle Applications

IP67 • NEMA 6 Protection

General

Full Stroke Range 0-2 to 0-50 inches

Format RS232

Accuracy ± 0.75 to 0.18% full stroke (see ordering information)

 $\begin{array}{ll} \textbf{Repeatability} & \text{see ordering information} \\ \textbf{Resolution} & \pm \ 0.003\% \ \text{full stroke} \\ \end{array}$

Measuring Cablethermoplastic or stainless steelEnclosurehard-anodized aluminum

Sensor plastic-hybrid precision potentiometer

Potentiometer Cycle see ordering information

Life

Maximum Cable see ordering information

Velocity • Acceleration

Weight 5 lbs., max

Electrical

Input Voltage 9...22 VDC Input Current 40 mA

Baud Rate 9600 (selectable to 38.4K)

Update Rate 32msec

Environmental

Environmental NEMA 6, IP 67

Suitability


Operating -40° to 200°F (-40° to 90°C)

Temperature

Vibration up to 10 g to 2000 Hz maximum

SENSOR SOLUTIONS /// PT5232 12//2015 Page 1

I/O Format



Data Frame

6 byte Hex string:

STX	CMD	B ₀	B ₁	B ₂	ETX	
STX = 0x02	CMD = Co	mmand Code	* B ₀ - B ₂ =	Data Field*	ETX = 0x03	ţ

* –see below

Important! All communications to/from the transducer are in HEX!

User Commands:

		User Com	mand		Sensor Response						
Description	<cmd></cmd>	<b<sub>0></b<sub>	<b<sub>1></b<sub>	<b<sub>2></b<sub>	<cmd></cmd>	<b<sub>0></b<sub>	<b<sub>1></b<sub>	<b<sub>2></b<sub>			
Get Sensor Info	0x05	0x00	0x00	0x00	0x05	version ⁽⁴⁾	date ⁽⁵⁾	date ⁽⁵⁾			
Get Serial Number	0x15	0x00	0x00	0x00	0x15	serial number ⁽³⁾					
Start Continuous Data	0x25	0x00	0x00	0x00	0x25	0x00	0x00	0x00			
Stop Continuous Data	0x35	0x00	0x00	0x00	0x35	0x00	0x00	0x00			
Get Position Data	0x45	0x00	0x00	0x00	0x45	$CMC^{(1)}$	$CMC^{(1)}$	status ⁽²⁾			

(1)CMC - Current Measurement Count (Position)

The Current Measurement Count (CMC) is the output data that indicates the present position of the measuring cable.

The CMC is a 16-bit value that occupies the first two bytes (B_0 and B_1) of the data field. B_0 is the MSB (most significant byte) and B_1 is the LSB (least significant byte).

The CMC starts at 0000H with the measuring cable fully retracted and continues upward to the end of the stroke range stopping at FFFFH. This holds true for all ranges.

⁽²⁾Status

The status byte is used as a flag to indicate the validity of the position signal that the internal electronics receives from the potentiometer.

Flags are as follows:

0x00 = GREEN, 0x55 = YELLOW, 0xAA = RED

A "green" flag shows everything OK. A "yellow" or "red" flag indicates that the sensor has either been extended beyond its range or that there is a problem with the potentiometer. (3)Serial Number

Each sensor has it's own unique serial number. This information can be retrieved by sending the sensor the "Get Serial Number" command.

The serial number is a 3 byte value from which ranges from 0 to 9999999 (decimal).

⁽⁴⁾Version

This is a single byte value (0-255 decimal) which indicates the currently installed firmware version of the sensor.

(5)Date

This is a 2 byte value showing the date of currently installed firmware. This value ranges from 01011 - 12319 (decimal). Format is MMDDY. While the month and day are expressed as two digit numbers the year is expressed in a single digit only.

Example: 08054 = August 5, 2004

Baud Rate

The baud rate can be set using switches 7 & 8 on the 8-pole DIP switch found on the rs232 controller board located inside the transducer.


DIP-7	DIP-8	baud rate
0	0	9600
1	0	19200
0	1	38400
1	1	9600



RS232 Controller Board and DIP Switch Location

baud rate switches






internal dip switches & controller board to gain access to the controller board,

cover bracket.

remove four Allen-Head Screws and remove end

Outline Drawing



Ordering Information

Model Number:



Sample Model Number:

PT5232 - 50 - N34 - UP - M6

R range: 50 inches

measuring cable: .034 nylon-coated stainless


B measuring cable exit: up (top exit)

electrical connection: 6-pin plastic connector


Full Stroke Range:

order code:	10	15	20	25	30	40	50	60	80	100	125	150	200	250	
full stroke range, min:	10 in.	15 in.	20 in.	25 in.	30 in.	40 in.	50 in.	60 in.	80 in.	100 in.	125 in.	150 in.	200 in.	250 in.	
accuracy (±% of f.s.):	.75%	.6%	.5%	.5%	.5%	.3%	.3%	.25%	.25%	.25%	.25%	.18%	.18%	.18%	
repeatability (±% of f.s.):	.1%	.1%	.05%	.05%	.05%	.05%	.05%	.02%	.02%	.02%	.02%	.02%	.02%	.02%	
potentiometer cycle life:	2,500,000 cycles						500,000 cycles					250,000 cycles			
cable tension (20%):	41 ounces									21 ounces					
max. cable velocity/acceleration:	300 in./sec ● 5 g										120 in./sec ● 2 g				


Measuring Cable:



Cable Exit:



Electrical Connection:



NORTH AMERICA

Measurement Specialties, Inc., a TE Connectivity company 20630 Plummer Street Chatsworth, CA 91311 Tel +1 800 423 5483 Tel +1 818 701 2750 Fax +1 818 701 2799

TE.com/sensorsolutions

info@celesco.com

Measurement Specialties, Inc., a TE Connectivity company.

Measurement Specialties, TE Connectivity, TE Connectivity (logo) and EVERY CONNECTION COUNTS are trademarks. All other logos, products and/or company names referred to herein might be trademarks of their respective owners.

The information given herein, including drawings, illustrations and schematics which are intended for illustration purposes only, is believed to be reliable. However, TE Connectivity makes no warranties as to its accuracy or completeness and disclaims any liability in connection with its use. TE Connectivity's obligations shall only be as set forth in TE Connectivity's Standard Terms and Conditions of Sale for this product and in no case will TE Connectivity be liable for any incidental, indirect or consequential damages arising out of the sale, resale, use or misuse of the product. Users of TE Connectivity products should make their own evaluation to determine the suitability of each such product for the specific application.

© 2015 TE Connectivity Ltd. family of companies All Rights Reserved.

PT5232 12/01/2015

X-ON Electronics

Largest Supplier of Electrical and Electronic Components

Click to view similar products for Industrial Pressure Sensors category:

Click to view products by TE Connectivity manufacturer:

Other Similar products are found below:

75380-05 76053-00000300-01 76053-00000300-05 76061-00000015-01 76062-B00000350-01 76063-00000350-05 76083-05000500-01 76311-05 76577-00000070-01 76584-M00000100-24 77343-24.0H2-01 77343-25.0H2-01 78291-B00000060-01 78303-B00000400-01 78303-B00000400-01 78303-B000000400-05 78316-B00000030-01 78353-B00000020-05 78665-00000014-05 78677-B00000070-05 78678-00000040-01 79279-0000060-01 79296-B00000350-01 79322-00250035-01 79614-30.0H2-14 79670-00000090-15 79700-00002750-01 79917-B00000280-01 80569-00700100-01 81509081 81739-B00000900-01 81807-B00000020-01 MLH010BST01A MLH010BST14A MLH025BGC13B MLH025BSCDJ1292 MLH025BSCDJ1303 MLH750PSCDJ1245 82903-B00000020-01 83250-02500600-05 83271-00000040-04 83278-B00000200-21 83286-00000150-01 83299-00000150-05 83303-00000600-01 83305-00001350-01 83330-00000100-01 83349-00001470-24 83350-04.0HG-05 83350-15.0H2-05 83357-00000030-21