


# 4ZeroBox User Manual

Part Number: IND-4ZB-09-F016



For more details, visit: [www.zerynth.com](http://www.zerynth.com)

This Document is the property of Zerynth (Zerynth S.r.l.). Duplication and reproduction are forbidden if not authorized.

Contents of the present documentation refers to products and technologies described within. All technical data contained in this document may be modified without prior notice The content of this documentation is subject to periodic revision.

# Table of contents

General Specification	2
General Characteristics	4
Screw Description	5
Technical Specifications	8
Dip-Switches	14
Switch SW1	15
Switch SW2	16
Typical setups of Switches	17
Pinmap	19
Warnings and Safety Use	22





# General Specification

4ZeroBox is a modular hardware electronic unit that simplifies the development of Industrial IoT applications allowing rapid integration with sensors, actuators, and Cloud services.

4ZeroBox mounts a powerful ESP32 Microcontroller by Espressif Systems (240MHz, 16Mb Flash, 512KB SRAM) and provides many onboard features like: a DIN-rail mountable case with industrial grade sensor channels, support for Wi-fi, Bluetooth, Ethernet, LoRa, CAN, RS485, RS232, SD Card, JTAG, I2C, SPI; the crypto element ATECC608A from Microchip has been integrated to handle secure connections in an easy manner, exchanging certificates and keys, encrypting messages over TLS protocol and using secure authentication procedures.

4ZeroBox lets the user choose the best installation strategy, adapting it to the specific industrial environment. While allowing to acquire data from the PLC via digital ports - filtering the data onboard to avoid bandwidth overload and waste of cloud resources - it also enables the installation and management of external sensors, for a full Industrial IoT experience.

4ZeroBox is programmable in Python (or hybrid C/Python) thanks to the Zerynth software.



## General Characteristics

DIN-rail mountable (9 slots)	Connectivity: • WiFi (Client and AP mode supported)
4 selectable analog input channels: 4-20mA single-ended 4-20mA differential 0-10V standard	Bluetooth® Low-Energy
3 current transformers (non-invasive)	Ethernet
4 resistive sensor channels (NTC, RTD, contact, proximity, etc.)	Crypto Chip - Secure Hardware Encryption
2 opto-isolated digital inputs	RS-485 and RS232 peripherals
2 sink digital output (60A @ 30V)	2 onboard mikroBUS sockets
MicroSD card slot	LiPo battery support • LiPo battery onboard charging unit
1 Digital I/O + 2 Digital Input (3.3V)	JTAG support
2 NO/NC Relay (10A @ 250V AC)	RGB status led
CAN peripheral	Espressif ESP32 - 32bit Microcontroller 240MHz clock, 16Mb of Flash, 312Kb SRAM Python-Programmable thanks to Zerynth technology

# Screw Description

Connector J1 (Upper-Left Corner)	Symbol	Description
<b>Screw Number 1</b>	24V	External Power Supply 24Vdc pin
<b>Screw Number 2</b>	GND	Ground pin
<b>Screw Number 3</b>	H	High Channel for CAN Bus (Term Resistor can be enabled through SW1 - see Dip-Switches Settings)
<b>Screw Number 4</b>	L	Low Channel for CAN Bus (Term Resistor can be enabled through SW1 - see Dip-Switches Settings)

Connector J4 (Upper-Center)	Symbol	Description
<b>Screw Number 5</b>	D0	Digital Input directly connected to the microcontroller with integrated ADC functionalities (Max 3.3V input)
<b>Screw Number 6</b>	D1	Digital Input directly connected to the microcontroller with integrated ADC functionalities (Max 3.3V input)
<b>Screw Number 7</b>	D2	Digital Input/Output directly connected to the microcontroller (Max 3.3V input)
<b>Screw Number 8</b>	Out2 Sink2	Sink2 Output to enable external circuits (60A @ 30V)
<b>Screw Number 9</b>	Out1 Sink1	Sink1 Output to enable external circuits (60A @ 30V)
<b>Screw Number 10</b>	B RS485	B Channel of RS485 Bus (Pull-Down and/or Term Resistor can be enabled through SW1 - see Dip-Switches Settings)
<b>Screw Number 11</b>	A	A Channel of RS485 Bus (Pull-Up and/or Term

	RS485	Resistor can be enabled through SW1 - see Dip-Switches Settings)
<b>Screw Number 12</b>	RX RS232	RX Channel of RS232 Bus
<b>Screw Number 13</b>	TX RS232	TX Channel of RS232 Bus

<b>Connector J2 (Upper-Right Corner)</b>	<b>Symbol</b>	<b>Description</b>
<b>Screw Number 14</b>	GND	Ground pin
<b>Screw Number 15</b>	P1-	Negative terminal of Probe1 for 0-10V or 4-20mA Sensor (according to SW2 position - see Dip-Switches Settings)
<b>Screw Number 16</b>	P1+	Positive terminal of Probe1 for 0-10V or 4-20mA Sensor (according to SW2 position - see Dip-Switches Settings)
<b>Screw Number 17</b>	P2-	Negative terminal of Probe2 for 0-10V or 4-20mA Sensor (according to SW2 position - see Dip-Switches Settings)
<b>Screw Number 18</b>	P2+	Positive terminal of Probe2 for 0-10V or 4-20mA Sensor (according to SW2 position - see Dip-Switches Settings)
<b>Screw Number 19</b>	P3-	Negative terminal of Probe3 for 0-10V or 4-20mA Sensor (according to SW2 position - see Dip-Switches Settings)
<b>Screw Number 20</b>	P3+	Positive terminal of Probe3 for 0-10V or 4-20mA Sensor (according to SW2 position - see Dip-Switches Settings)
<b>Screw Number 21</b>	P4-	Negative terminal of Probe4 for 0-10V or 4-20mA Sensor (according to SW2 position - see Dip-Switches Settings)
<b>Screw Number 22</b>	P4+	Positive terminal of Probe4 for 0-10V or 4-20mA Sensor (according to SW2 position - see Dip-Switches Settings)

Connector J3 (Lower-Left Corner)	Symbol	Description
<b>Screw Number 23</b>	GND	Ground pin
<b>Screw Number 24</b>	NC2	Normal Closed Terminal of Relay 2
<b>Screw Number 25</b>	COM2	Common Terminal of Relay 2
<b>Screw Number 26</b>	NO2	Normal Open Terminal of Relay 2
<b>Screw Number 27</b>	NC1	Normal Closed Terminal of Relay 1
<b>Screw Number 28</b>	COM1	Common Terminal of Relay 1
<b>Screw Number 29</b>	NO1	Normal Open Terminal of Relay 1
<b>Screw Number 30</b>	Opto-In 2	Opto-Isolator Input 2 - input terminal with isolated positive terminal - from 5Vdc to 24Vdc (according to SW2 position - see Dip-Switches Settings)
<b>Screw Number 31</b>	Opto-In 1	Opto-Isolator Input 1 - input terminal with isolated positive terminal - from 5Vdc to 24Vdc (according to SW2 position - see Dip-Switches Settings)

Connector J5 (Lower-Right Corner)	Symbol	Description
<b>Screw Number 32</b>	GND	Ground pin
<b>Screw Number 33</b>	S4	Input for Resistive Sensor 4
<b>Screw Number 34</b>	S3	Input for Resistive Sensor 3
<b>Screw Number 35</b>	S2	Input for Resistive Sensor 2
<b>Screw Number 36</b>	S1	Input for Resistive Sensor 1
<b>Screw Number 37</b>	COM	COM pin for Current Transformers (to close current loop)



<b>Screw Number 38</b>	C3	Input pin for Current Transformer 3 (Max $\pm 50$ mA)
<b>Screw Number 39</b>	C2	Input pin for Current Transformer 2 (Max $\pm 50$ mA)
<b>Screw Number 40</b>	C1	Input pin for Current Transformer 2 (Max $\pm 50$ mA)

**IMPORTANT :** Current Transformers (CTs) are sensors that measure alternating current (AC). They are particularly useful for measuring whole building electricity consumption or generation.

## Technical Specifications

Power Supply	
<b>Voltage</b>	8 to 36 Vdc
<b>Power Consumption</b>	Typical: 1 W; Maximum: 5 W.

Inputs / Outputs	
<b>ADC Inputs Resolution</b>	11 bit + sign.
<b>4-20mA Channels - x4 (according to switches position - see Dip-Switches Settings)</b>	Min supported input current 4 mA Max supported input current 20 mA
<b>0-10V Channels - x4 (according to switches position - see Dip-Switches Settings)</b>	Min supported input voltage 0 V Max supported input voltage 10 V
<b>Resistive Channels (x4)</b>	Min supported Resistor value 0 Ohm Max supported Resistor value 70 KOhm
<b>Current Channels (x3)</b>	Min supported input current -50 mA Max supported input current 50 mA
<b>Opto-Isolator Inputs</b>	Input Voltage 5 to 24V
<b>Relays</b>	10 A - 250 VAC (general use) at 40°C 8 A - 30 VDC (resistive load) at 40°C

<b>Sinks</b>	60A - 30V (general use) at 40°C
<b>Digital I/O</b>	Max supported voltage 3.3 V

**IMPORTANT :** Values in table are referred to related standards; 4-20mA channels are compatible also with 0-20mA industrial standard (software settings)

<b>Environmental Conditions</b>	
<b>Temperature</b>	-40 to +85 °C
<b>Humidity</b>	Max 80% (not condensing)
<b>Storage Temperature</b>	-40 to +85 °C
<b>Degree Protection</b>	< IP40


<b>Connectors</b>	
<b>Ethernet</b>	RJ45 Connector
<b>Programming</b>	Micro USB Connector
<b>Micro SD</b>	Micro SD Slot
<b>Power Supply, Sensors, RS485, RS232, CAN, Relays, Opto-Isolators, Sinks</b>	Pluggable Screw Connectors 5.08 pitch
<b>Li-Po Battery</b>	JST Connector
<b>MikroBus Click Add-on</b>	MikroBus Slots

<b>Enclosure</b>	
<b>Dimensions</b>	L: 160 mm; H: 90 mm; W: 58 mm
<b>Material</b>	PC (UL 94 V-0), Light Grey
<b>Standards</b>	RoHS compliant DIN EN 60715 TH35 REACH compliant


- **4-20mA Channels**

The 4ZeroBox has 4 analog channels for 4-20mA probes. These channels can be used for reading 2, 3 and 4 wires 4-20mA sensors; through switches positions, standard mode or differential mode can be chosen.


The following diagrams report various wiring configuration



**2 wire 4-20mA Sensor Reading Circuit**




**3 wires 4-20mA Sensor Reading Circuit**




**4 wires 4-20mA Sensor Reading Circuit**

The 4-20mA channels can be also used for reading current signals with other reader or PLC (Differential mode) . The following diagrams report various wiring configuration for the serial reading of 4-20mA signals.



### 0-10V Channels

Same screws used for 4-20mA sensor reading of The 4ZeroBox can be set by dip-switches to read industrial standard 0-10V sensors. Through switches positions, standard mode or differential mode can be chosen; the following diagram reports 0-10V Sensor reading circuit.




### Resistive Channels

S1, S2, S3, S4 represent 4 inputs for resistive channels; resistive probes are sensors that change their resistive value in function of their related measured physical quantity.


Examples of these probes are RDT Sensors (Resistance Temperature Detector), NTC Sensors (Negative Temperature Coefficient), Contact Sensors, Proximity Sensors etc.

The following diagram reports Resistive Sensor reading wiring configuration.




### Current Transformers Channels



C1, C2, C3, in combination with COM to close the current measurement loop, are the input screws for connecting 3 different current transformers; these sensors measure alternating current (AC) and they are particularly useful for measuring whole building electricity consumption or generation.



### Opto-Isolators, Relay, Sinks




Opto-Isolator Reading Circuit



Sink Circuit

## MikroBus Slots

The MikroBus slot comprises a pair of 1x8 female headers with a specific proprietary pin configuration. The pinout (always laid out in the same order) consists of three groups of communications pins (SPI, UART and I2C).



To complete the MicroBus standard there are six additional pins (PWM, Interrupt, Analog input, Reset and Chip select), and two power groups (+3.3V and GND on the left, and 5V and GND on the right 1x8 header).

The spacing of pins is compatible with standard (2.54 mm pitch) breadboards.

With these 2 slots, the user can extend the 4ZeroBox with hundreds of MikroElektronika click boards (available on [www.mikroe.com/click](http://www.mikroe.com/click) ) to add extra-features to the 4ZeroBox (for example GPS module, LoRa module, GPRS Module, etc.).

**IMPORTANT :** Each hardware component and major feature can be handled via software through high-level functions in dedicated library (more info in “4ZeroBox Library”); each expansion click mountable on the MikroBus slot, instead, need a specific extra library.

**IMPORTANT :** 4ZeroBox Library and other several click libraries, as specified in section “Software Recommendations”, are available in Python language for Zerynth; to get more info about specific pin function or connections between each component (AD converter, relay, MikroBus slot pins, etc.), please refer to the “Pinmap” section.

### Jumper JP1

Jumper JP1 selects the power supply source for the board; possible choices are:

- E5V: External 5V provided by onboard DC-DC converter powered through screw connector with external power supply;
- U5V: USB 5V provided by VBUS connected to the micro-USB interface.

**IMPORTANT :** During the programming phase, jumper JP1 must be in U5V position and the external power supply must be detached; once programmed and installed on DIN rail, jumper JP1 of the 4ZeroBox must be placed in E5V position.

## Dip-Switches

Switch SW1 (the lower one) handles functionalities related to MikroBus Slots, RS485 peripheral, and CAN peripheral; more details in the following table.

## Switch SW1

OFF Position	Pin Number	ON Position
CS pin on MikroBus Slot 1 disabled	<b>1</b>	CS pin on MikroBus Slot 1 enabled
CS pin on MikroBus Slot 2 disabled	<b>2</b>	CS pin on MikroBus Slot 2 enabled
RX pin on MikroBus Slot 1 disabled	<b>3</b>	RX pin on MikroBus Slot 1 enabled
RX pin on MikroBus Slot 2 disabled	<b>4</b>	RX pin on MikroBus Slot 2 enabled
TX pin on MikroBus Slot 1 disabled	<b>5</b>	TX pin on MikroBus Slot 1 enabled
TX pin on MikroBus Slot 2 disabled	<b>6</b>	TX pin on MikroBus Slot 2 enabled
Pull-up on RS485 Ch A disabled	<b>7</b>	Pull-up on RS485 Ch A enabled
Pull-down on RS485 Ch B disabled	<b>8</b>	Pull-down on RS485 Ch B enabled
Term resistor on RS485 Bus disabled	<b>9</b>	Term resistor on RS485 Bus enabled
Term resistor on CAN Bus disabled	<b>10</b>	Term resistor on CAN Bus enabled
RST pin on MikroBus Slot 1 disabled	<b>11</b>	RST pin on MikroBus Slot 1 enabled
RST pin on MikroBus Slot 2 disabled	<b>12</b>	RST pin on MikroBus Slot 2 enabled

Switch SW2 (the upper one) handles functionalities related to 4-20mA and 0-10V Sensors, RS232 and USB peripheral, and Opto-Isolator Inputs; more details in the following table




## Switch SW2

OFF Position	Pin Number	ON Position
0-10V range reading sensor enabled for Probe1	<b>1</b>	4-20mA range reading sensor enabled for Probe1
Probe1 differential measurement enabled	<b>2</b>	Probe1 measurement referred to onboard GND
0-10V range reading sensor enabled for Probe2	<b>3</b>	4-20mA range reading sensor enabled for Probe2
Probe2 differential measurement enabled	<b>4</b>	Probe2 measurement referred to onboard GND
0-10V range reading sensor enabled for Probe3	<b>5</b>	4-20mA range reading sensor enabled for Probe3
Probe3 differential measurement enabled	<b>6</b>	Probe3 measurement referred to onboard GND
0-10V range reading sensor enabled for Probe4	<b>7</b>	4-20mA range reading sensor enabled for Probe4
Probe4 differential measurement enabled	<b>8</b>	Probe4 measurement referred to onboard GND
Opto-Isolator input Ch 1 enabled to 24 V	<b>9</b>	Opto-Isolator input Ch 1 enabled to 5 V
Opto-Isolator input Ch 2 enabled to 24 V	<b>10</b>	Opto-Isolator input Ch 2 enabled to 5 V
USB RX channel disabled	<b>11</b>	USB RX channel enabled
RS232 RX channel disabled	<b>12</b>	RS232 RX channel enabled


## Typical setups of Switches

Here below 3 examples of typical dip-switch configurations.



Configuration 1:


- 4ZeroBox in Programming/Debug mode:  
SW2 pin11 enabled and SW2 pin12 disabled;
- Analog Interface set to read 4 channels 4-20mA referred to 4ZeroBox GND:  
SW2 pin1 to pin8 enabled;
- Opto-Isolators 1 and 2 optimized to read input voltage up to 24V:  
SW2 pin9 and pin10 disabled;
- MikroBus Slot 1 full connected:  
SW1 pin1, pin3, pin5, pin11 enabled;
- MikroBus Slot 2 disconnected:  
SW1 pin2, pin4, pin6, pin 12 disabled;
- Pull-Up on channel A, Pull-Down on channel B and Term Resistor of RS485 disabled:  
SW1 pin7, pin8, pin9 disabled;
- Term Resistor of CAN Bus disabled:  
SW1 pin10 disabled.



Configuration 2:

- 4ZeroBox in Programming/Debug mode:  
SW2 pin11 enabled and SW2 pin12 disabled;
- Analog Interface set to read 4 channels 0-10V referred to 4ZeroBox GND:

- SW2 pin1, pin3, pin5, pin7 disabled;
- SW2 pin2, pin4, pin6, pin8 enabled;
- Opto-Isolators 1 and 2 optimized to read input voltage up to 5V:  
SW2 pin9 and pin10 enabled;
- MikroBus Slot 1 disconnected:  
SW1 pin1, pin3, pin5, pin11 disabled;
- MikroBus Slot 2 fully connected:  
SW1 pin2, pin4, pin6, pin12 enabled;
- Pull-Up on channel A, Pull-Down on channel B and Term Resistor of RS485 enabled:  
SW1 pin7, pin8, pin9 enabled;
- Term Resistor of CAN Bus disabled:  
SW1 pin10 disabled.



### Configuration 3:

- 4ZeroBox with RS232 enabled:  
SW2 pin11 disabled and SW2 pin12 enabled;
- Analog Interface set to read:  
SW2 pin1 enabled, pin2 disabled (channel 4-20mA differential);  
SW2 pin3, pin4 enabled (channel 4-20mA referred to 4ZeroBox GND);  
SW2 pin5 disabled, pin6 enabled (channel 0-10V referred to 4ZeroBox GND);  
SW2 pin7, pin8 disabled (channel 0-10V differential);
- Opto-Isolators 1 optimized to read input voltage up to 24V:  
SW2 pin9 disabled;
- Opto-Isolators 2 optimized to read input voltage up to 5V:  
SW2 pin10 enabled;
- MikroBus Slot 1 and 2 disconnected:  
SW1 pin1, pin2, pin3, pin4, pin5, pin6, pin11, pin12 disabled;
- Pull-Up on channel A, Pull-Down on channel B and Term Resistor of RS485 disabled:  
SW1 pin7, pin8, pin9 disabled;
- Term Resistor of CAN Bus enabled:  
SW1 pin10 enabled.

# Pinmap

According to the Zerynth standards and terminology, below you'll find the map of the 4ZeroBox pins with related connections and functionalities.

Pin Name	Direction	Functions	Connected to
<b>D0</b>	IN	Reserved	Auto-Programming Circuit Ethernet Oscillator (XTAL1)
<b>D1</b>	OUT	SERIAL0 - TX pin	USB Serial Port RS232 Peripheral
<b>D2</b>	IN	SPI0 - MISO pin	SD Card Slot CAN Peripheral (MCP2515) MISO pin on MikroBus Slot 1 MISO pin on MikroBus Slot 2
<b>D3</b>	IN	SERIAL0 - RX pin	USB Serial Port RS232 Peripheral
<b>D4</b>	IN	Digital Pin to Power On/Off all components except ESP32 and Ethernet block	Controlled Power Supply block
<b>D5</b>	OUT	SERIAL2 - TX pin	RS485 Periphera
<b>D10</b>	OUT	SERIAL1 - TX pin	TX pin on MikroBus Slot 1 TX pin on MikroBus Slot 2
<b>D12</b>	OUT	SPI0 - CS1 pin (Chip Select)	CAN Peripheral (MCP2515)
<b>D13</b>	IN/OUT	Digital I/O or PWM	PWM pin on MikroBus Slot 1
<b>D14</b>	OUT	SPI0 - SCLK pin	SD Card Slot CAN Peripheral (MCP2515) SCK pin on MikroBus Slot 1 SCK pin on MikroBus Slot 2
<b>D15</b>	OUT	SPI0 - MOSI pin	SD Card Slot CAN Peripheral (MCP2515) MOSI pin on MikroBus Slot 1 MOSI pin on MikroBus Slot 2
<b>D16</b>		I2C0 - SDA pin	Crypto Chip (ATECC608A) Port Expander (SX1503) A/D Converters (ADS1015)

			SDA pin on MikroBus Slot 1 SDA pin on MikroBus Slot 2
<b>D17</b>	OUT	I2C0 - SCL pin	Crypto Chip (ATECC608A) Port Expander (SX1503) A/D Converters (ADS1015) SCL pin on MikroBus Slot 1 SCL pin on MikroBus Slot 2
<b>D18</b>	IN/OUT	Reserved	MDIO pin on Ethernet
<b>D19</b>	OUT	Reserved	EMAC_TXD0 pin on Ethernet
<b>D21</b>	OUT	Reserved	EMAC_TX_EN pin on Ethernet
<b>D22</b>	OUT	Reserved	EMAC_TXD1 pin on Ethernet
<b>D23</b>	OUT	Reserved	MDC pin on Ethernet
<b>D25</b>	IN	Reserved	EMAC_RXD0 pin on Ethernet
<b>D26</b>	IN	Reserved	EMAC_RXD1 pin on Ethernet
<b>D27</b>	IN	Reserved	EMAC_RX_CRSDV pin on Ethernet
<b>D32</b>	OUT	SPI0 - CS0 pin (Chip Select)	SD Card Slot
<b>D33</b>	OUT	SPI0 - CS2 pin (Chip Select)	CS pin on MikroBus Slot 1 CS pin on MikroBus Slot 2
<b>D34</b>	IN	Digital Input or ADC input	AN pin on MikroBus Slot 1 Pin 1 on Digital I/O Screw
<b>D35</b>	IN	SERIAL1 - RX pin	RX pin on MikroBus Slot 1 RX pin on MikroBus Slot 2
<b>D36</b>	IN	SERIAL2 - RX pin	RS485 Peripheral
<b>D39</b>	IN	Digital Input	INT pin on MikroBus Slot 1 Pin 0 on Digital I/O Screw

<b>D40</b>	OUT	Receive/Transmit enable pin	RS485 Peripheral
<b>D41</b>	IN/OUT	Digital I/O	AN pin on MikroBus Slot 2
<b>D42</b>	IN/OUT	Digital I/O	RST pin on MikroBus Slot 1 or Slot 2 Pin 2 on Digital I/O Screw
<b>D43</b>	IN/OUT	Digital I/O	PWM pin on MikroBus Slot 2
<b>D44</b>	IN/OUT	Digital I/O	INT pin on MikroBus Slot 2
<b>D45</b>	OUT	Digital Output	Relay 1
<b>D46</b>	OUT	Digital Output	Relay 2
<b>D47</b>	OUT	Digital Output	Led Red
<b>D48</b>	IN	Digital Input	Opto-Isolator Input 2
<b>D49</b>	OUT	Digital Output	Sink 1
<b>D50</b>	OUT	Digital Output	Sink 2
<b>D51</b>	OUT	Digital Output	Ethernet Reset pin
<b>D52</b>	IN	Digital Input	External Voltage Detect pin
<b>D53</b>	IN	Digital Input	Opto-Isolator Input 1
<b>D54</b>	OUT	Digital Output	Led Green
<b>D55</b>	OUT	Digital Output	Led Blue



**IMPORTANT** : SERIAL0 is mapped on the USB programming/debugging port and on the RS232 peripheral can be used only one (selected by SW2 - see Dip-Switches and Jumper Settings)

**IMPORTANT** : SERIAL1 is mapped on the MikroBus Slot 1 and MikroBus Slot 2; can be used only one at a time (selected by SW1 - see Dip-Switches and Jumper Settings).

**IMPORTANT** : CS and RST pins of MikroBus Slot 1 and 2 are connected on microcontroller side respectively to D33 and D42 so they cannot be enabled to both MikroBus Slots.

**IMPORTANT** : I2C0 clock frequency must be the same respectively for all I2C Components.

**IMPORTANT** : SPI0 clock frequency must be the same respectively for all SPI Components.

**IMPORTANT** : I2C address already used by internal components of the 4ZeroBox are:

- 0x35 (hex) Crypto Chip
- 0x20 (hex) Port Expander;
- 0x48 (hex) A/D Converter for Resistive sensors;
- 0x49 (hex) A/D Converter for 4-20mA and/or 0-10V Sensors;
- 0x4B (hex) A/D Converter for current sensors.

**More Info and Graphic Pinmap are available on:**

<https://www.zerynth.com/4zerobox/>

## Warnings and Safety Use

Important: Keep these information for future reference. for full set up and installation instructions please

visit [docs.zerynth.com/](https://docs.zerynth.com/)

### Getting Started

- Download the Zerynth SDK from our website: <https://www.zerynth.com/zsdk/>
- Install the Zerynth SDK and open the VSCode application;
- Register a Zerynth account and log-in;
- Connect the Development Board to the PC using the USB Type-C Cable;
- Clone the "Hello Zerynth" example;
- Uplink the project;
- For more details about the installation and demos, please visit:

<https://docs.zerynth.com>

### Warnings



- All external power supplies used with Zerynth boards must comply with the relevant regulations and standards applicable in the country of use and must provide a voltage between 9 and 36 VDC.
- The relays on-board can switch loads up to 250VAC 10A through its screw contacts (C, NO, NC). Those lines must be protected with 10 amps fuses or similar devices to limit the current.
- Hereby, Zerynth srl declares that the radio equipment mounted on 4ZeroBox is in compliance with Directive 2014/53/EU (RED). The full text of the EU declaration of conformity is available at the following internet address:  
<https://www.zerynth.com/download/20248/>
- The manufacturer cannot guarantee compliance with the RED directive if the end user uses custom circuits other than those supplied by Zerynth (used in conformity tests).
- The 4ZeroBox that requires CE marking has been tested and meets the essential requirements set by the Directives: 2014/30/EU (EMC), 2014/35/EU (LVD), 2011/65/EU (RoHS). The declaration of conformity (DoC) can be downloaded from the website <https://www.zerynth.com/download/20248/>
- All Zerynth boards have undergone compliance testing for conducted and radiated emissions meeting the requirements of the following standards: FCC Part 15 B and IC ICES-003.
- Any device or component connected to one of the screw connectors must comply with the electrical characteristics defined in the specifications described in the complete manual to ensure that the performance and safety requirements are met.
- Each cable used to connect other devices or components to the Zerynth boards must be less than 300 cm long and must offer adequate insulation and operation so that the appropriate performance and safety requirements are met.

### **Instructions for safe use**

- Do not expose this product to water or moisture and do not place it on a conductive surface while it is operating.
- Do not expose this product to excessive heat sources which could cause it to operate outside the permitted temperature range defined in the specifications (-40, +85 °C).
- Be careful when handling the product to avoid mechanical or electrical damage to the printed circuit board and connectors.
- If a board looks damaged, do not use it.
- Do not touch the printed circuit board when it is powered and never operate on live electrical parts.
- The printed circuit board must not come into contact with conductive objects when it is powered.



- Discharge static electricity from your body and touch only the edges of the board to minimize the risk of damage from electrostatic discharge.

### **Waste Electrical and Electronic Equipment (WEEE) Symbol**



The use of the WEEE symbol indicates that this product/board may not be treated as household waste. By ensuring this product/board is disposed of correctly, you will help protect the environment. For more detailed information about recycling of this product/board, please contact your local authority, your household waste disposal service provider or the shop where you purchased it.

## X-ON Electronics

Largest Supplier of Electrical and Electronic Components

*Click to view similar products for [Development Boards & Kits - Other Processors](#) category:*

*Click to view products by [Zerynth](#) manufacturer:*

Other Similar products are found below :

[EVB-MEC1418MECC](#) [20-101-1252](#) [C29XPCIE-RDB](#) [CC-ACC-18M433](#) [STM8S/32-D/RAIS](#) [MAX1464EVKIT](#) [RTE510Y470TGB00000R](#)  
[RTK0EN0001D01001BZ](#) [MAXQ622-KIT#](#) [YR0K505231S000BE](#) [YR0K50571MS000BE](#) [YQB-R5F1057A-TB](#) [QB-R5F104PJ-TB](#) [CC-](#)  
[ACC-ETHMX](#) [OV-7604-C7-EVALUATION-BOARD](#) [SK-AD02-D62Q1747TB](#) [SK-BS01-D62Q1577TB](#) [ST7MDT1-EMU2](#)  
[KITA2GTC3975VTRBSTOBO1](#) [RASPBERRY PI PICO KIT](#) [EK-MPC5744P](#) [KITAURIXTC234TFTTOBO1](#) [ESP32-C3-DEVKITC-02](#) [QB-](#)  
[R5F104LE-TB](#) [LV18F V6 64-80-PIN TQFP MCU CARD EMPTY](#) [LV-24-33 V6 44-PIN TQFP MCU CARD EMPTY](#) [LV-24-33 V6 64-PIN](#)  
[TQFP MCU CARD EMPTY](#) [LV-24-33 V6 80-PIN TQFP 1 MCU CARD EMPTY](#) [32X32 RGB LED MATRIX PANEL - 6MM PITCH](#) [3.3 - 5](#)  
[VTRANSLATOR](#) [READY FOR XMEGA CASING \(WHITE\)](#) [RELAY4 BOARD](#) [ETHERNET CONNECTOR](#) [RFID CARD 125KHZ - TAG](#)  
[RFID READER](#) [RFM12B-DEMO](#) [MAROON](#) [3G CLICK \(FOR EUROPE AND AUSTRALIA\)](#) [MAX232](#) [MAX3232 BOARD](#) [THREE-AXIS](#)  
[ACCELEROMETER BOARD](#) [TINKERKIT HALL SENSOR](#) [TOUCHPANEL](#) [TOUCHPANEL CONTROLLER](#) [MIKROBOARD FOR AVR](#)  
[WITH ATMEGA128](#) [MIKROBOARD FOR PSOC WITH CY8C27643](#) [MIKROBUS CAPE](#) [MIKRODRIVE](#) [MIKROETH 100 BOARD](#)  
[MIKROLAB FOR 8051 L](#)